

SPARE PARTS MERCEDES S-320 L SALOON							
CODE	PART NO.	DESCRIPTION	QTY				
01-02-49645	A 112 010 81 05	CRANK CASE	8	2			
01-02-49646	A 112 997 02 46	SEAL RING	80	20			
01-02-49647	A 023 997 84 47	SEAL RING	80	20			
01-02-49648	A 112 997 08 45	SEAL RING	160	40			
01-02-49649	A 111 997 03 30	SCREW PLUG	80	20			
01-02-49650	N007603014106	SEAL RING,V LRUB	320	80			
01-02-49651	A 112 010 62 02	ENGINE	16	4			
01-02-49652	A 112 180 01 43	OIL NOZZLE	40	10			
01-02-49653	A 112 016 03 20	CYLINDER HEAD GASKET	40	10			
01-02-49654	A 112 016 04 20	CYLINDER HEAD GASKET	40	10			
01-02-49655	A 006 997 26 45	SEAL RING,VLRUB	20	5			
01-02-49656	A 112 015 06 30	EXPANSION PLUG	20	5			
01-02-49657	A 112 184 00 80	GASKET	20	5			
01-02-49658	A 111 992 02 25	SLEEVE	12	3			
01-02-49659	A 112 990 04 78	CONNECTOR	8	2			
01-02-49660	N000443 028001	EXPANSION PLUG	20	5			
01-02-49661	A 112 055 00 45	FLANGE	8	2			
01-02-49662	A 112 016 02 21	GASKET	40	10			
01-02-49663	A 112 016 03 21	GASKET	40	10			
01-02-49664	A 112 030 16 01	CRANKSHAFT	8	2			
01-02-49665	A 112 035 09 00	VIBRATION ABSORBER	4	1			
01-02-49666	A 112 030 06 12	RING GEAR	8	2			
01-02-49667	A 112 030 00 40 54	CRANKSHAFT BEARING	160	40			
01-02-49668	A 112 030 01 40	CRANKSHAFT BEARING	160	40			
01-02-49669	A 112 030 14 72	DRIVE SHAFT	4	1			
01-02-49670	A 112 990 00 14	SCREW	8	2			
01-02-49671	A 112 034 07 22	COUNTER WEIGHT	4	1			
01-02-49672	A 112 034 01 73	LOCK	8	2			
01-02-49673	A 112 030 06 17	PISTON	48	12			
01-02-49674	A 112 030 13 17	PISTON	96	24			
01-02-49675	A 112 030 03 24	PISTON RING	144	36			
01-02-49676	A 112 030 08 24	PISTON RING	48	12			
01-02-49677	A113 030 00 20	CONNECTING ROD	24	6			
01-02-49678	A 112 038 01 50	PISTON PIN BUSHING	144	36			
01-02-49679	A 112 030 00 60	CONNECTING ROD BEARING	240	60			
01-02-49680	A 112 030 01 60	CONNECTING ROD BEARING	240	60			
01-02-49681	A 003 997 68 94	ROLLER CHAIN	16	4			
01-02-49682	A 000 997 22 98	CHAIN LOCK LINK	16	4			
01-02-49683	A 112 052 01 16	SLIDING RAIL	40	10			
01-02-49684	A112 052 00 16	SLIDING RAIL	20	5			
01-02-49685	A112 052 02 16	SLIDING RAIL	20	5			
01-02-49686	A 112 050 05 11	CHAIN TIGHTENER	16	4			
01-02-49687	A 112 038 00 71	SCREW	24	6			
01-02-49688	A 112 050 40 01	CAMSHAFT	16	4			
01-02-49689	A 112 050 41 01	CAMSHAFT	16	4			
01-02-49690	A 112 050 07 31	ROCKER ARM SPINDLE	8	2			
01-02-49691	A 112 050 09 31	ROCKER ARM SPINDLE	8	2			
01-02-49692	A 113 050 05 34	ROCKER ARM	144	36			
01-02-49693	A 113 050 00 33	ROCKER ARM	144	36			
01-02-49694	A 113 050 01 33	ROCKER ARM	144	36			
01-02-49695	A 113 055 00 76	WASHER	96	24			
01-02-49696	A 113 050 00 80	HYDRAULIC ELEMENT	240	60			
01-02-49697	A 113 050 03 80	HYDRAULIC ELEMENT	120	30			
01-02-49698	A 112 050 02 04	CAMSHAFT GEAR	4	1			
01-02-49699	A 113 053 01 01	INTAKE VALVE	480	120			
01-02-49700	A 113 050 02 27	EXHAUST VALVE	240	60			
01-02-49701	A 612 050 00 58	SEAL	120	30			
01-02-49702	A 112 078 01 49	VALVE	192	48			
01-02-49703	A 019 997 13 48	SEAL RING,VLRUB	400	100			

01-02-49704	A 119 078 06 41	BRACKET,INJECT VALVE	24	6		
01-02-49705	A 000 078 04 29	VALVE	16	4		
01-02-49706	A 112 090 11 01	AIR CLEANER	4	1		
01-02-49707	A 112 094 00 04	FILTER ELEMENT	2800	700		
01-02-49708	A 112 094 00 41	BRACKET	24	6		
01-02-49709	A 112 094 11 82	HOSE	8	2		
01-02-49710	A 112 094 10 82	HOSE	8	2		
01-02-49711	A 002 466 86 01	HYDRAULIC PUMP	8	2		
01-02-49712	A 000 460 01 83	OIL TANK	4	1		
01-02-49713	A 000 230 85 11	COMPRESSOR	16	4		
01-02-49714	A 112 230 17 56	PIPE	12	3		
01-02-49715	A 112 230 08 56	PIPE	12	3		
01-02-49716	A 210 997 03 45	SEAL RING	120	30		
01-02-49717	A 220 997 04 45	SEAL RING	120	30		
01-02-49718	A 140 997 07 45	SEAL RING	120	30		
01-02-49719	A 220 997 02 45	SEAL RING	120	30		
01-02-49720	A 011 997 97 92	V-BELT	600	150		
01-02-49721	A 112 141 10 80	GASKET	80	20		
01-02-49722	A 111 997 05 45	SEAL RING	40	10		
01-02-49723	A 111 141 02 42	CLAMPING STRIP	8	2		
01-02-49724	A 117 997 09 82	HOSE,INJECTION,VLRUB	12	3		
01-02-49725	A 112 140 00 09	EXHAUST MANIFOLD	8	2		
01-02-49726	A 112 140 01 09	EXHAUST MANIFOLD	8	2		
01-02-49727	A000 990 25 52	NUT	64	16		
01-02-49728	A 112 142 00 72	NUT	144	36		
01-02-49729	A 112 142 01 80	GASKET	120	30		
01-02-49730	A 112 140 00 60	VALVE	4	1		
01-02-49731	A 112 140 01 08	EXHAUST LINE	4	1		
01-02-49732	A 112 141 03 80	GASKET	12	3		
01-02-49733	A 000 990 73 67	RING	16	4		
01-02-49734	A 117 078 02 81	HOSE,VACUUM CONNECT,VLRUB	16	4		
01-02-49735	A 117 078 05 81	HOSE, THERMO, ,VALALVE VLRUB	16	4		
01-02-49736	A 112 142 02 80	GASKET	12	3		
01-02-49737	A 004 153 32 28	SENDER UNIT	8	2		
01-02-49738	A 027 997 27 48	SEAL RING	24	6		
01-02-49739	A 112 094 01 48	AIR MASS SENSOR	16	4		
01-02-49740	A 112 141 01 80(1121411880)	GASKET	40	10		
01-02-49741	A 112 141 02 80	GASKET	40	10		
01-02-49742	A 112 141 00 40(1121410340)	BRACKET	8	2		
01-02-49743	A 112 141 01 40	BRACKET	8	2		
01-02-49744	A 112 141 01 25	SLIDE	16	4		
01-02-49745	A 001 546 00 43	BRACKET	8	2		
01-02-49746	A 112 018 03 82	HOSE	8	2		
01-02-49747	A 112 018 00 09(1120180209)	CONNECTOR	8	2		
01-02-49748	A 117 990 15 78	CONNECTOR,CYLINDER HEAD	16	4		
01-02-49749	A 112 018 02 82	HOSE	8	2		
01-02-49750	A 112 018 04 82	HOSE	8	2		
01-02-49751	A 112 018 01 82	HOSE	8	2		
01-02-49752	A 112 151 00 01	STARTING MOTOR	16	4		
01-02-49753	A 000 152 04 10	SOLENOID SWITCH	48	12		
01-02-49754	A 000 151 64 15	ARMATURE	8	2		
01-02-49755	A 001 151 21 13	PINION	80	20		
01-02-49756	A 001 151 08 14	CARBON BRUSH SET	24	6		
01-02-49757	A 000 151 53 50	BUSHING	48	12		
01-02-49758	A 019 981 19 10	NEEDLE BEARING	32	8		
01-02-49759	A 000 151 68 50	BUSHING ,STARTER	24	6		
01-02-49760	A 112 140 00 18	HOUSING	4	1		
01-02-49761	A 000 140 37 85	PUMP	4	1		
01-02-49762	A 002 540 14 97	VALVE	8	2		
01-02-49763	A 117 078 09 81	HOSE,CHANGOVER VALVE,VLRUB	4	1		
01-02-49764	N040621012200	INSULATING HOSE,PLASTIC	8	2		

01-02-49765	N040621018200	INSULATING HOSE,PLASTIC	8	2		
01-02-49766	A 001 140 66 60	CHECK VALVE	4	1		
01-02-49767	A 112 237 02 40	BRACKET	4	1		
01-02-49768	A 601 078 02 45	HOSE,VACUUM CONTROL,VLRUB	8	2		
01-02-49769	A 011 154 32 02	ALTERNATOR	40	10		
01-02-49770	A 002 154 92 06	REGULATOR	80	20		
01-02-49771	A 007 981 89 25	BALL BEARING	80	20		
01-02-49772	A 007 981 73 25	BALL BEARING	80	20		
01-02-49773	A 119 155 01 15	PULLEY	4	1		
01-02-49774	A000 990 22 50	NUT	8	2		
01-02-49775	A 000 158 78 03	IGNITION COIL	120	30		
01-02-49776	A 112 150 01 18	IGNITION CABLE	400	100		
01-02-49777	A 112 150 02 18	IGNITION CABLE	200	50		
01-02-49778	A 003 159 66 03 26	SPARK PLUG	36000	9000		
01-02-49779	A 004 153 69 28	SENDER UNIT	12	3		
01-02-49780	A 003 153 86 28	KNOCK SENSOR	24	6		
01-02-49781	A 003 153 28 28	SENDER UNIT	16	4		
01-02-49782	A 022 997 25 48	SEAL RING,VLRUB	120	30		
01-02-49783	A 000 542 51 18	SENDER UNIT	48	12		
01-02-49784	A 022 997 98 48	SEAL RING	200	50		
01-02-49785	A 004 153 53 28	SENDER UNIT	12	3		
01-02-49786	A 023 997 43 48	SEAL RING	120	30		
01-02-49787	A 112 180 10 01	OIL PUMP	24	6		
01-02-49788	A 003 997 74 94	ROLLER CHAIN	24	6		
01-02-49789	A 000 997 32 98	CHAIN LOCK LINK	24	6		
01-02-49790	A 112 181 00 59	CLAMPING BRACKET	8	2		
01-02-49791	A 112 993 03 20(1129930220)	SPRING	8	2		
01-02-49792	A 112 181 00 74	PIN	8	2		
01-02-49793	A611 180 01 15	PRESSURE RELIEF VALVE	8	2		
01-02-49794	A 112 180 00 09(0001802209)	FILTER ELEMENT	20000	5000		
01-02-49795	A 112 180 01 10(1121800510)	OIL FILTER	4	1		
01-02-49796	A 112 184 01 02	HOUSING	4	1		
01-02-49797	A 112 184 00 61	SEAL RING	48	12		
01-02-49798	A 112 184 00 17	FITTING	8	2		
01-02-49799	A 112 188 04 01	OIL COOLER	12	3		
01-02-49800	A 112 184 02 61	SEAL RING	160	40		
01-02-49801	A 112 184 03 61	SEAL RING	160	40		
01-02-49802	A 112 200 14 01	WATER PUMP	160	40		
01-02-49803	A 112 201 01 80	GASKET	80	20		
01-02-49804	A 112 203 03 82	HOSE	40	10		
01-02-49805	N0000000000667	CLAMP	24	6		
01-02-49806	A 112 200 00 15	THERMOSTAT	120	30		
01-02-49807	A 112 203 00 76	GASKET	240	60		
01-02-49808	A 111 992 02 25	SLEEVE	8	2		
01-02-49809	A 112 202 01 10	PULLEY	24	6		
01-02-49810	A 000 202 00 19	TIGHTENER PULLEY	240	60		
01-02-49811	A 112 200 03 70(1122000870)	BELT TIGHTENER	60	15		
01-02-49812	A 112 203 00 61	HOUSING	4	1		
01-02-49813	A 112 223 19 04	ENGINE SUPPORT	4	1		
01-02-49814	A 112 223 18 04	ENGINE SUPPORT	4	1		
01-02-49815	A 220 540 70 06	CABLE HARNESS	8	2		
01-02-49816	A 220 545 46 28	PLUG	8	2		
01-02-49817	A 004 545 20 26	PLUG SOCKET	4	1		
01-02-49818	N072581 000 305	FUSE ELEMENT	400	100		
01-02-49819	A 220 240 02 18	ENGINE MOUNTING	80	20		
01-02-49820	A 220 267 11 24	FLOOR ,SHIFT MECHANISM	4	1		
01-02-49821	A 220 267 01 64	WIRE CABLE	4	1		
01-02-49822	A 220 267 16 88	COVERING	4	1		
01-02-49823	A 220 267 01 10 9C05	HANDLE	4	1		
01-02-49824	A 000 994 43 60	LOCK	16	4		
01-02-49825	A 000 994 51 48	LOCK WASHER	16	4		

01-02-49826	A 210 992 00 10	BUSHING	16	4		
01-02-49827	A 001 545 21 09	SWITCH	8	2		
01-02-49828	A 005 545 22 14	KICK-DOWN SWITCH	8	2		
01-02-49829	A 220 300 00 04	ACCELERATOR PEDAL	12	3		
01-02-49830	A 220 320 51 13	HYDROPNEUMATIC SPRING LEG	48	12		
01-02-49831	A 220 320 15 89	ROD	16	4		
01-02-49832	A 220 320 16 89	ROD	16	4		
01-02-49833	A 220 320 03 89	ROD	48	12		
01-02-49834	A 220 320 00 32	LINK	16	4		
01-02-49835	A 220 320 01 04	COMPRESSOR	12	3		
01-02-49836	A 220 320 00 04	COMPRESSOR	24	6		
01-02-49837	A 220 320 00 69	FILTER	20	5		
01-02-49838	A 220 320 02 58	VALVE	8	2		
01-02-49839	A 220 327 09 30	RUBBER BUFFER	48	12		
01-02-49840	A 220 327 08 30	RUBBER BUFFER	60	15		
01-02-49841	A 000 327 00 69(0003270369)	CONNECTOR	8	2		
01-02-49842	A 220 327 01 45	LINE	12	3		
01-02-49843	A 220 327 08 45	LINE	12	3		
01-02-49844	A 220 542 01 18	SENDER UNIT	8	2		
01-02-49845	A 000 327 01 69	CONNECTOR	16	4		
01-02-49846	A 220 327 10 45	LINE	32	8		
01-02-49847	A 220 320 02 15	AIR CELL	8	2		
01-02-49848	A 220 327 12 30	RUBBER BUFFER	24	6		
01-02-49849	A 220 328 08 39	RUBBER BUFFER	24	6		
01-02-49850	A 220 330 43 07	SPRING CONTROL	24	6		
01-02-49851	A 220 330 44 07	SPRING CONTROL	24	6		
01-02-49852	A 220 333 17 14	BEARING	40	10		
01-02-49853	A 220 333 01 27	JOINT	32	8		
01-02-49854	A 220 333 01 71	SCREW	120	30		
01-02-49855	N910113014000	NUT	120	30		
01-02-49856	A 220 330 14 07	TRANSVERSE CONTROL ARM	40	10		
01-02-49857	A 220 330 15 07	TRANSVERSE CONTROL ARM	40	10		
01-02-49858	A 220 330 33 11(2203304311)	STRUT	32	8		
01-02-49859	A 220 330 34 11(2203304411)	STRUT	32	8		
01-02-49860	A 220 323 03 68	JOINT	64	16		
01-02-49861	A 220 330 07 25	FRONT WHEEL HUB	32	8		
01-02-49862	A 116 334 03 72	CLAMPING NUT	8	2		
01-02-49863	A 220 350 21 14	HOUSING	16	4		
01-02-49864	A 220 350 29 14	REPAIR KIT	8	2		
01-02-49865	A 210 353 05 72	NUT	8	2		
01-02-49866	A 220 350 74 08	REAR SUBFRAME	12	3		
01-02-49867	A 220 350 05 75	RUBBER MOUNTING	120	30		
01-02-49868	A 220 351 11 42	RUBBER MOUNTING	120	30		
01-02-49869	A 220 350 09 15	EXTENSION	12	3		
01-02-49870	A 220 351 09 42	RUBBER MOUNTING	140	35		
01-02-49871	A 220 352 13 65	RUBBER MOUNTING	120	30		
01-02-49872	A 220 350 89 08	REAR SUBFRAME	16	4		
01-02-49873	A 220 350 90 08	REAR SUBFRAME	16	4		
01-02-49874	A 220 352 11 02	TRANSVERSE CONTROL ARM	24	6		
01-02-49875	A 220 352 00 27	JOINT	24	6		
01-02-49876	A 220 350 26 06	CONTROL ARM	48	12		
01-02-49877	A 220 350 04 53	TIE ROD	48	12		
01-02-49878	A 220 350 22 06	CONTROL ARM	48	12		
01-02-49879	A 220 350 24 06	CONTROL ARM	48	12		
01-02-49880	A 220 40 10194	BALANCING WEIGHT	4000	1000		
01-02-49881	A 220 401 02 94	BALANCING WEIGHT	4000	1000		
01-02-49882	A 220 401 03 94	BALANCING WEIGHT	4000	1000		
01-02-49883	A 220 401 04 94	BALANCING WEIGHT	4000	1000		
01-02-49884	A 220 401 05 94	BALANCING WEIGHT	4000	1000		
01-02-49885	A 220 401 06 94	BALANCING WEIGHT	4000	1000		
01-02-49886	A 220 401 07 94	BALANCING WEIGHT	4000	1000		

01-02-49887	A 124 401 07 28	WHEEL WEIGHT CLIP	8000	2000		
01-02-49888	A 124 401 36 94	BALANCING WEIGHT	4000	1000		
01-02-49889	A 124 401 37 94	BALANCING WEIGHT	4000	1000		
01-02-49890	A 124 401 38 94	BALANCING WEIGHT	4000	1000		
01-02-49891	A 124 401 53 94	BALANCING WEIGHT	4000	1000		
01-02-49892	A 124 401 54 94	BALANCING WEIGHT	4000	1000		
01-02-49893	A 124 401 55 94	BALANCING WEIGHT	4000	1000		
01-02-49894	A 124 401 56 94	BALANCING WEIGHT	4000	1000		
01-02-49895	A 000 400 03 13	VALVE ,TIRE	240	60		
01-02-49896	A 000 400 02 13	VALVE,TIRE	40	10		
01-02-49897	A 124 411 05 15	SHAFT PLATE	320	80		
01-02-49898	A 220 410 00 15	FLEXIBLE JOINT DISC	160	40		
01-02-49899	A 220 410 13 06	PROPELLER SHAFT	12	3		
01-02-49900	A 220 410 06 01	PROPELLER SHAFT	8	2		
01-02-49901	A 220 410 11 02	PROPELLER SHAFT	8	2		
01-02-49902	A 008 981 43 25	BALL BEARING	60	15		
01-02-49903	A 202 411 04 97	BOOT	60	15		
01-02-49904	A 003 420 42 20	BRAKE SHOE	4000	1000		
01-02-49905	A 000 421 00 47	VIBRATION ABSORBER	80	20		
01-02-49906	A000 421 80 91	SPRING	16	4		
01-02-49907	A 001 420 82 83	CALIPER	16	4		
01-02-49908	A 001 420 81 83	CALIPER	20	5		
01-02-49909	A 220 421 09 12	BRAKE DISC	1600	400		
01-02-49910	A 003 420 19 20	BRAKE SHOE	2400	600		
01-02-49911	A 001 420 71 83	CALIPER	16	4		
01-02-49912	A 001 420 72 83	CALIPER	16	4		
01-02-49913	A 000 421 92 86	CUP	40	10		
01-02-49914	A 000 421 94 86	REPAIR KIT	64	16		
01-02-49915	A 220 420 05 20	BRAKE SHOE	120	30		
01-02-49916	A 220 423 01 12	BRAKE DISC	480	120		
01-02-49917	A 220 540 07 17	SENDER UNIT	8000	2000		
01-02-49918	A 000 421 75 91	SPRING	16	4		
01-02-49919	A 003 431 88 12 (0044314712)	BRAKE PRESSURE REGULATOR	8	2		
01-02-49920	A 005 430 91 01	BRAKE MASTER CYLINDER	40	10		
01-02-49921	A 005 430 25 30	BRAKE BOOSTER ASSEMBLY	4	1		
01-02-49922	A 220 430 14 29	LINE	12	3		
01-02-49923	A 220 430 00 02	RESERVOR RESERVOIR	8	2		
01-02-49924	A 000 431 15 50	BUSHING	40	10		
01-02-49925	A 220 420 00 48	BRAKE HOSE	16	4		
01-02-49926	A 220 420 01 48	BRAKE HOSE	16	4		
01-02-49927	A 220 420 17 85	BRAKE HOSE	8	2		
01-02-49928	A 220 460 10 00	REPAIR KIT	48	12		
01-02-49929	A 220 338 10 15(2303380115)	TIE ROD	200	50		
01-02-49930	A 220 338 07 15(2303380015)	TIE ROD	200	50		
01-02-49931	A 220 463 00 66	RUBBR MOUNTING	40	10		
01-02-49932	A 220 997 54 82	HOSE	48	12		
01-02-49933	A 220 466 12 81	HOSE	48	12		
01-02-49934	A 220 320 06 72	LINE	8	2		
01-02-49935	A 220 997 42 82	HOSE	48	12		
01-02-49936	A 004 997 74 90	CALMP CLAMP	120	30		
01-02-49937	A 220 466 01 81	HOSE	48	12		
01-02-49938	A 220 997 59 82	HOSE	40	10		
01-02-49939	B66268190	STEERING WHEEL	4	1		
01-02-49940	A 220 470 24 01	FUEL TANK	4	1		
01-02-49941	A 220 470 00 05	FILLER CAP	8	2		
01-02-49942	A 000 470 78 94	AUXILIARY PUMP	600	150		
01-02-49943	A 002 477 31 01(0024773001)	FUEL FILTER	1800	450		
01-02-49944	A 202 492 06 44	SUSPENSION RING,VLRUB	200	50		
01-02-49945	A 220 492 00 44	SUSPENSION RING	200	50		
01-02-49946	A 220 500 14 03	RADIATOR	20	5		
01-02-49947	A 220 500 01 54	CONDENSER	8	2		

01-02-49948	A 220 500 00 93	BLOWER	80	20		
01-02-49949	A 013 997 58 92	V-BELT	400	100		
01-02-49950	A 220 504 02 12	RUBBER MOUNTING	80	20		
01-02-49951	A 220 504 01 12	RUBBER MOUNTING	120	30		
01-02-49952	A 220 504 01 46	CLAMP	120	30		
01-02-49953	A 220 504 00 12	RUBBER MOUNTING	8	2		
01-02-49954	A 210 501 05 15	RADIATOR CAP	100	25		
01-02-49955	A 220 501 00 82	HOSE	8	2		
01-02-49956	A 220 501 03 82	HOSE	16	4		
01-02-49957	A 220 501 18 82	HOSE	16	4		
01-02-49958	A 022 997 26 82	HOSE	8	2		
01-02-49959	A 220 545 05 32	CONTROL UNIT	4	1		
01-02-49960	A 028 545 98 32(0295450432)	CONTROL UNIT SAM	32	8		
01-02-49961	A 027 545 64 32	ESG CONTROL UNIT	8	2		
01-02-49962	A 026 545 53 32	SAM.CONTROL UNIT	8	2		
01-02-49963	A 027 545 04 32(0305452032)	CONTROL UNIT	4	1		
01-02-49964	A 002 542 13 19	RELAY	24	6		
01-02-49965	A 002 542 11 19(0025421119)	RELAY	4	1		
01-02-49966	A 002 542 23 19	RELAY	8	2		
01-02-49967	A 002 542 14 19	RELAY	24	6		
01-02-49968	A 002 545 11 34	CATCH	40	10		
01-02-49969	N910153 000000	FUSE BOX	600	150		
01-02-49970	N072581 000 302	FUSE ELEMENT	600	150		
01-02-49971	A 002 545 08 34	CATCH	400	100		
01-02-49972	N072581 000 304	FUSE ELEMENT	800	200		
01-02-49973	N072581 000305	FUSE ELEMENT	800	200		
01-02-49974	N072581 000 307	FUSE ELEMENT	800	200		
01-02-49975	A 002 542 18 19	RELAY	80	20		
01-02-49976	N000000 000422	FUSE BOX	20	5		
01-02-49977	A 004 542 57 20	HORN	80	20		
01-02-49978	A 004 542 56 20	HORN	80	20		
01-02-49979	A 000 542 84 18	SENDER UNIT	16	4		
01-02-49980	A 220 540 34 11(220540341127)	INSTRUMENT CLUSTER	4	1		
01-02-49981	A 220 542 00 58	DIAL FACING	4	1		
01-02-49982	A 220 584 32 17	GUIDE SIGN	4	1		
01-02-49983	N910141 000000	BULB	80	20		
01-02-49984	A 025 545 44 32	MSA CONTROL UNIT	4	1		
01-02-49985	A 220 545 00 22	SWITCH	4	1		
01-02-49986	A 007 545 76 24	SWITCH,AUTOMATIC	4	1		
01-02-49987	A 220 545 00 10	SWITCH	8	2		
01-02-49988	A 002 542 17 18	SENDER UNIT	4	1		
01-02-49989	A 220 545 06 04 7211(0025452001	SWITCH	4	1		
01-02-49990	A 220 540 01 17	SENDER UNIT	100	25		
01-02-49991	A 220 540 04 17	SENDER UNIT	100	25		
01-02-49992	A 220 540 05 17	SENDER UNIT	100	25		
01-02-49993	A 220 540 56 05	CABLE HARNESS	4	1		
01-02-49994	A 220 583 00 15	JACK	8	2		
01-02-49995	A 140 581 03 01	SOCKET WRENCH	20	5		
01-02-49996	A 140 581 02 01	SOCKET WRENCH	16	4		
01-02-49997	A 220 610 07 10	SIDE MEMBER	4	1		
01-02-49998	A 220 610 08 10	SIDE MEMBER	4	1		
01-02-49999	A 220 620 16 61	WHEEL HOUSE	4	1		
01-02-50000	A 220 620 19 31	CONSOLE	8	2		
01-02-50001	A 220 620 20 31	CONSOLE	8	2		
01-02-50002	A 220 670 17 01	WINDSHIELD	48	12		
01-02-50003	A 220 670 05 22	GARNISH MOULDING	16	4		
01-02-50004	A 220 671 01 12	ANGLE	48	12		
01-02-50005	A 220 671 02 12	ANGLE	64	16		
01-02-50006	A 210 670 02 93	REP KIT	56	14		
01-02-50007	A 220 670 01 22	GARNISH MOULDING	16	4		
01-02-50008	A 220 670 02 22	GARNISH MOULDING	16	4		

01-02-50009	A 220 670 03 22	GARNISH MOULDING	16	4		
01-02-50010	A 202 678 00 79	BRACING,REAR WINDOW	48	12		
01-02-50011	A 220 678 09 37	JOINT COVER	12	3		
01-02-50012	A 210 678 08 37	JOINT COVER	12	3		
01-02-50013	A 202 678 16 37	JOINT COVER	24	6		
01-02-50014	A 220 810 02 30	ASHTRAY	4	1		
01-02-50015	A 220 680 04 39 1400	COVERING	4	1		
01-02-50016	A 220 680 72 39	SLOTTED GATE	4	1		
01-02-50017	A 220 810 00 20	ROLLER BLIND	16	4		
01-02-50018	A 220 694 00 14	BRACKET	8	2		
01-02-50019	A 220 694 01 14	BRACKET	16	4		
01-02-50020	A 220 694 02 14	BRACKET	16	4		
01-02-50021	A 220 860 07 05	HEAD PROTECTION CURTAIN	4	1		
01-02-50022	A 220 860 08 05	HEAD PROTECTION CURTAIN	4	1		
01-02-50023	A 220 690 01 62 9143	LEDGE	16	4		
01-02-50024	A 220 690 02 62 9143	LEDGE	16	4		
01-02-50025	A 220 690 05 62 9143	LEDGE	16	4		
01-02-50026	A 220 690 06 62 9143	LEDGE	16	4		
01-02-50027	A 220 690 13 62 9143	LEDGE	16	4		
01-02-50028	A 220 690 14 62 9143	LEDGE	16	4		
01-02-50029	A 220 690 03 62 9143	LEDGE	32	8		
01-02-50030	A 220 690 04 62 9143	LEDGE	32	8		
01-02-50031	A 220 720 00 16	DOOR CHECK	8	2		
01-02-50032	A 220 720 01 78	WEATHER STRIP	8	2		
01-02-50033	A 220 720 02 78(2207200178)	WEATHER STRIP	8	2		
01-02-50034	A 220 760 01 70 9143	HANDLE	8	2		
01-02-50035	A 220 760 02 70 9143	HANDLE	8	2		
01-02-50036	A 140 760 03 41 9B51	CATCH	24	6		
01-02-50037	A 220 720 11 78	WEATHER STRIP	8	2		
01-02-50038	A 220 720 12 78	WEATHER STRIP	8	2		
01-02-50039	A 220 720 03 18	CRANK OPERATED WINDOW	4	1		
01-02-50040	A 220 720 04 18	CRANK OPERATED WINDOW	4	1		
01-02-50041	A 220 810 01 64 9143	PANELLING	20	5		
01-02-50042	A 220 810 02 64 9143	PANELLING	20	5		
01-02-50043	A 220 810 03 21	MIRROR GLASS	12	3		
01-02-50044	A 220 810 04 21	MIRROR GLASS	12	3		
01-02-50045	20 720 45 89 7211(220720458972)	COVER PLATE	8	2		
01-02-50046	A 220 720 48 89 7211	COVER PLATE	8	2		
01-02-50047	A 220 766 01 24	LEVER	8	2		
01-02-50048	A 220 766 02 24	LEVER	8	2		
01-02-50049	A 220 730 00 16	DOOR CHECK	8	2		
01-02-50050	A 220 760 01 70 9143	HANDLE	8	2		
01-02-50051	A 220 760 01 70 9143	HANDLE	8	2		
01-02-50052	A 220 730 39 35(2207304535)	DOOR LOCK	4	1		
01-02-50053	A 220 730 40 35 730	DOOR LOCK	4	1		
01-02-50054	A 220 730 09 18	CRANK OPERATED WINDOW	8	2		
01-02-50055	A 220 730 10 18	CRANK OPERATED WINDOW	8	2		
01-02-50056	A 220 730 07 20	GLASS PANE	4	1		
01-02-50057	A 220 730 08 20	GLASS PANE	4	1		
01-02-50058	A 220 750 01 98	SEAL	16	4		
01-02-50059	A 220 750 01 93	HANDLE	8	2		
01-02-50060	A 220 750 07 87	HINGE	4	1		
01-02-50061	A 220 750 08 87	HINGE	4	1		
01-02-50062	A 220 757 01 29	SPRING	80	20		
01-02-50063	A 220 758 00 58	MERCEDES STAR	8	2		
01-02-50064	A 220 800 03 48	PUMP	8	2		
01-02-50065	A 220 820 38 42	ELECTRIC MOTOR	8	2		
01-02-50066	A 210 780 00 89	CABLE	4	1		
01-02-50067	A 210 780 01 89	CABLE	4	1		
01-02-50068	A 202 899 01 80	KEY	4	1		
01-02-50069	A 220 780 01 98	SEAL	4	1		

01-02-50070	A 220 780 00 13	RAIL	8	2		
01-02-50071	A 220 821 60 51 7C45	SWITCH	12	3		
01-02-50072	A 220 820 20 10 7C45	SWITCH	12	3		
01-02-50073	A 220 821 87 51 7C45	SWITCH	12	3		
01-02-50074	20 821 92 51 7C45(22082132587C	SWITCH	12	3		
01-02-50075	A 220 820 10 10 7C45	SWITCH	12	3		
01-02-50076	A 220 820 12 10 7C45	SWITCH	20	5		
01-02-50077	20 821 15 58 7C45(22082149587C	KNOB	8	2		
01-02-50078	20 821 16 58 7C45(22082150587C	KNOB	8	2		
01-02-50079	A 220 820 06 45	WIPER BLADE	1200	300		
01-02-50080	A 220 820 01 41	LINKAGE	4	1		
01-02-50081	A 202 820 94 10	SWITCH	4	1		
01-02-50082	A 220 820 01 61	LIGHTING UNIT	24	6		
01-02-50083	A 220 820 02 61	LIGHTING UNIT	24	6		
01-02-50084	A 220 826 01 90	LENS	160	40		
01-02-50085	A 220 826 02 90	LENS	160	40		
01-02-50086	N400809 000007	BULB	400	100		
01-02-50087	N000000 000 375	BULB	200	50		
01-02-50088	A 220 820 01 64	TAIL LAMP	8	2		
01-02-50089	A 220 820 02 64	TAIL LAMP	8	2		
01-02-50090	N072601 012190	BULB	800	200		
01-02-50091	N400809 000000	BULB	800	200		
01-02-50092	N072601 012701	BULB	800	200		
01-02-50093	A 000 825 01 94	BULB	400	100		
01-02-50094	A 220 820 06 86	RADIO SET ASSEMBLY	4	1		
01-02-50095	A 210 830 10 18	PK DUST FILTER	160	40		
01-02-50096	A 210 830 11 18	FILTER	8	2		
01-02-50097	A 220 830 03 84	VALVE	8	2		
01-02-50098	A 003 830 23 15	PIPE LINE	4	1		
01-02-50099	A 220 830 02 72	TEMPERATURE SEN	12	3		
01-02-50100	A 220 830 01 85	OPERATING UNIT	4	1		
01-02-50101	A 220 830 02 85	OPERATING UNIT	4	1		
01-02-50102	A 220 830 03 84	VALVE	16	4		
01-02-50103	A 220 832 03 94	HOSE	8	2		
01-02-50104	A 220 832 05 94	HOSE	12	3		
01-02-50105	A 220 832 00 94	HOSE	12	3		
01-02-50106	A 220 832 01 94	HOSE	12	3		
01-02-50107	A 220 832 07 94	HOSE	12	3		
01-02-50108	A 220 832 44 94	HOSE	12	3		
01-02-50109	A 007 997 20 90	LOOM TIE	40	10		
01-02-50110	A 220 830 03 96	HOSE	12	3		
01-02-50111	A 220 832 00 15	PIPE LINE	4	1		
01-02-50112	A 220 500 00 40	VALVE	4	1		
01-02-50113	A 220 830 08 96	HOSE	8	2		
01-02-50114	A 220 832 01 15	PIPE LINE	4	1		
01-02-50115	A 220 830 04 96	HOSE	8	2		
01-02-50116	A 220 830 00 96	HOSE	8	2		
01-02-50117	A 220 830 02 96	HOSE	8	2		
01-02-50118	A 220 830 02 84	VALVE	12	3		
01-02-50119	A 220 832 18 94	HOSE	8	2		
01-02-50120	A 220 832 40 94	HOSE	8	2		
01-02-50121	A 220 832 41 94	HOSE	8	2		
01-02-50122	A 220 830 00 83	TANK	48	12		
01-02-50123	A 220 830 34 15	PIPE LINE	8	2		
01-02-50124	A 220 830 05 84	VALVE	12	3		
01-02-50125	A 140 830 00 72	TEMPERATURE SENSOR	40	10		
01-02-50126	A 210 830 00 72	TEMPERATURE SENSOR	40	10		
01-02-50127	A 112 230 08 56	PIPE LINE	4	1		
01-02-50128	A 220 830 35 15	PIPE LINE	4	1		
01-02-50129	A 220 830 14 15	PIPE LINE	4	1		
01-02-50130	A 220 830 01 15	PIPE LINE	4	1		

01-02-50131	A 112 230 17 56	PIPE LINE	4	1		
01-02-50132	A 220 830 03 58	EVAPORATOR	4	1		
01-02-50133	A 220 830 00 72	TEMPERATURE SENSOR	16	4		
01-02-50134	A 220 830 26 15	ELECTRIC CABLE	4	1		
01-02-50135	A 220 820 92 10	BLOWER REGULATOR	4	1		
01-02-50136	A 220 869 00 20	RESERVOIR	4	1		
01-02-50137	A 210 869 08 21	PUMP	8	2		
01-02-50138	A 220 540 00 45	SWITCH	4	1		
01-02-50139	A 220 860 01 47(2038600147)	NOZZLE	8	2		
01-02-50140	A 220 860 02 47(2038600147)	NOZZLE	8	2		
01-02-50141	A 203 860 01 47	NOZZLE	8	2		
01-02-50142	A 124 869 01 72	CAP,W/WASHER RESERVE	8	2		
01-02-50143	A 220 830 00 61	HEATER UNIT	4	1		
01-02-50144	A 220 880 03 18	FRONT FENDER	8	2		
01-02-50145	A 220 880 04 18	FRONT FENDER	8	2		
01-02-50146	A 220 880 17 14	BRACKET	4	1		
01-02-50147	A 220 880 18 14	BRACKET	4	1		
01-02-50148	A 220 889 05 25	COVERING	4	1		
01-02-50149	A 220 889 06 25	COVERING	4	1		
01-02-50150	A 009 988 54 78	CLIP	80	20		
01-02-50151	A 220 690 25 30	COVERING	8	2		
01-02-50152	A 220 690 26 30	COVERING	8	2		
01-02-50153	A 220 690 15 30	COVERING	8	2		
01-02-50154	A 220 690 16 30	COVERING	8	2		
01-02-50155	A 220 889 01 95	INTERMEDIATE LAYER	8	2		
01-02-50156	A 220 889 01 95	INTERMEDIATE LAYER	8	2		
01-02-50157	A 220 889 03 95	INTERMEDIATE LAYER	8	2		
01-02-50158	A 220 889 04 95	INTERMEDIATE LAYER	8	2		
01-02-50159	A 220 880 03 40	PANELLING	8	2		
01-02-50160	A 220 885 01 21 9143	RAIL	16	4		
01-02-50161	A 220 885 02 21 9143	RAIL	16	4		
01-02-50162	A 220 885 02 23	BUMPER JOINT COVER	16	4		
01-02-50163	A 220 885 11 23	BUMPER JOINT COVER	16	4		
01-02-50164	A 220 885 09 23	BUMPER JOINT COVER	16	4		
01-02-50165	A 220 880 04 05 9143	ESCUTCHEON	16	4		
01-02-50166	A 220 880 03 05 9143	ESCUTCHEON	16	4		
01-02-50167	A 220 885 03 23 9143	BUMPER JOINT COVER	16	4		
01-02-50168	A 220 885 11 37	ENERGY-ABSORBING UNIT	8	2		
01-02-50169	A 220 885 01 37	ENERGY-ABSORBING UNIT	8	2		
01-02-50170	A 220 885 02 37	ENERGY-ABSORBING UNIT	8	2		
01-02-50171	A 220 885 01 65	INSIDE PART	8	2		
01-02-50172	A 220 880 01 40	PANELLING	12	3		
01-02-50173	A 220 885 09 21 9143	RAIL	8	2		
01-02-50174	A 220 885 10 21 9143	RAIL-R	8	2		
01-02-50175	A 220 885 11 21 9143	RAIL-CENTER	8	2		
01-02-50176	A 220 880 01 52	INSIDE PART	16	4		
01-02-50177	A 220 885 09 37	ENERGY-ABSORBING UNIT	8	2		
01-02-50178	A 220 885 05 37	ENERGY-ABSORBING UNIT	8	2		
01-02-50179	A 220 885 06 37	ENERGY-ABSORBING UNIT	8	2		
01-02-50180	A 220 885 04 23 9143	BUMPER JOINT COVER	16	4		
01-02-50181	A 220 885 01 63	GUIDE	4	1		
01-02-50182	A 220 885 02 63	GUIDE	4	1		
01-02-50183	A 220 880 01 57	ENGINE HOOD	8	2		
01-02-50184	A 220 880 02 05 9143	VENTILATION SCREEN	16	4		
01-02-50185	A 220 880 01 05	COVERING	8	2		
01-02-50186	A 210 880 01 86	MERCEDES STAR	80	20		
01-02-50187	A 220 889 08 95	INTERMEDIATE LAYER	8	2		
01-02-50188	A 220 880 03 29	SPRING	64	16		
01-02-50189	A 220 880 01 28	HINGE	12	3		
01-02-50190	A 220 880 02 28	HINGE	12	3		
01-02-50191	A 220 880 03 59	ENGINE HOOD RELEASE CABLE	4	1		

01-02-50192	A 220 880 02 59	ENGINE HOOD RELEASE CABLE	4	1		
01-02-50193	A 220 880 02 64	SAFETY HOOK	4	1		
01-02-50194	A 220 887 01 23	END PIECE	24	6		
01-02-50195	A 220 880 03 83 9040	RADIATOR GRILLE SHELL	40	10		
01-02-50196	A 220 270 05 00	AUTOMATIC TRANSMISSION	12	3		
01-02-50197	A 140 270 65 00	GASKET KIT	20	5		
01-02-50198	N007603010100	SEAL RING,VLRUB	20	5		
01-02-50199	A 140 270 01 97	OIL PUMP	16	4		
01-02-50200	A 010 997 47 47	SEAL RING	20	5		
01-02-50201	A 016 997 14 48	SEAL RING.TRANSMISN.VLRUB	40	10		
01-02-50202	A 140 277 42 14	INTERMEDIATE PLATE	12	3		
01-02-50203	A 210 270 23 28	DISC SUPPORT	4	1		
01-02-50204	A 140 993 20 26	DISC SPRING	4	1		
01-02-50205	A 140 993 18 26	DISC SPRING	4	1		
01-02-50206	A 140 272 02 26	OUTER DISC	16	4		
01-02-50207	A 140 272 04 26	OUTER DISC	16	4		
01-02-50208	A 140 272 28 26	OUTER DISC	24	6		
01-02-50209	A 140 272 00 25	INNER DISC	80	20		
01-02-50210	A 210 270 41 28	DISC SUPPORT	4	1		
01-02-50211	A 210 270 00 31	FRE WHEEL UNIT	12	3		
01-02-50212	A 140 272 02 26	OUTER DISC	8	2		
01-02-50213	A 140 272 28 26	OUTER DISC	12	3		
01-02-50214	A 140 272 04 26	OUTER DISC	8	2		
01-02-50215	A 140 272 00 25	INNER DISC	80	20		
01-02-50216	A 210 270 13 43	PLANETARY CARRIER	4	1		
01-02-50217	A 210 270 11 25	DRIVE SHAFT	4	1		
01-02-50218	A 140 272 20 62	GUARD PLATE	16	4		
01-02-50219	A 140 272 06 26	OUTER DISC	12	3		
01-02-50220	A 140 272 29 26	OUTER DISC	20	5		
01-02-50221	A 140 272 08 26	OUTER DISC	12	3		
01-02-50222	A 210 270 03 45	ANNULUS	4	1		
01-02-50223	A 210 272 00 25	INNER DISC	80	20		
01-02-50224	A 210 270 07 26	SHAFT	4	1		
01-02-50225	A 210 272 01 62	GUARD PLATE	20	5		
01-02-50226	A 210 272 02 08	ANNULUS	4	1		
01-02-50227	A 210 270 15 43	PLANETARY CARRIER	8	2		
01-02-50228	A 210 272 08 07	SUN GEAR	4	1		
01-02-50229	A 140 270 05 31	FREEWHEEL UNIT	12	3		
01-02-50230	A 140 272 23 62	GUARD PLATE	16	4		
01-02-50231	A 140 272 12 26	OUTER DISC	12	3		
01-02-50232	A 140 272 27 26	OUTER DISC	20	5		
01-02-50233	A 140 272 10 26	OUTER DISC	16	4		
01-02-50234	A 140 272 16 62	GUARD PLATE	20	5		
01-02-50235	A 140 272 15 62	GUARD PLATE	12	3		
01-02-50236	A 140 272 19 62	GUARD PLATE	12	3		
01-02-50237	A 140 272 22 62	GUARD PLATE	12	3		
01-02-50238	A 140 272 00 26	OUTER DISC	120	30		
01-02-50239	A 140 272 04 25	INNER DISC	160	40		
01-02-50240	A 140 272 14 26	OUTER DISC	24	6		
01-02-50241	A 140 272 23 26	OUTER DISC	16	4		
01-02-50242	A 140 272 06 25	INNER DISC	64	16		
01-02-50243	A 140 272 18 26	OUTER DISC	120	30		
01-02-50244	A 140 272 24 26	OUTER DISC	16	4		
01-02-50245	A 140 271 26 01	HOUSING	4	1		
01-02-50246	A 026 997 41 48	SEAL RING	40	10		
01-02-50247	A 026 997 40 48	SEAL RING	40	10		
01-02-50248	A 140 997 08 46	SEAL RING	20	5		
01-02-50249	A 140 990 11 50	NUT	16	4		
01-02-50250	A 140 997 21 45	SEAL RING	8	2		
01-02-50251	A 140 997 23 45	SEAL RING	8	2		
01-02-50252	A 022 997 87 48	SEAL RING	8	2		

01-02-50253	A 140 277 04 35	VALVE	8	2		
01-02-50254	A 140 277 05 35	VALVE	12	3		
01-02-50255	A 140 277 03 98	LIFTING MAGNET	12	3		
01-02-50256	A 140 271 00 80	GASKET	40	10		
01-02-50257	A 140 277 00 95	OIL FILTER	40	10		
01-02-50258	A 022 997 22 48	SEAL RING	4	1		
01-02-50259	A 022 997 55 82	HOSE	100	25		
01-02-50260	A 020 997 39 82	HOSE	100	25		
01-02-50261	A 000 828 03 88	BATTERY SET	120	30		
01-02-50262	A 001 989 21 03 10	TRANSMISSION OIL	8000	2000		
01-02-50263	A 000 989 08 07 10	BRAKE FLUID	2400	600		
01-02-50264	A 000 989 08 25	ANTIFREEZE	400	100		
01-02-50265	A 001 989 37 51 10	PROTECTIO GREASE	200	50		
01-02-50266	W 220 589 00 99 00	ELECTRICAL CONNECT SET	4	1		
01-02-50267	W 001 589 76 09 00	TORX-SET 9 PIECES	24	6		
01-02-50268	W 000 589 01 10 00	TORX-SET 10 PIECES	32	8		
01-02-50269	A001 989 24 03 10	OIL	1200	300		
01-02-50270	A 002 989 73 20 10	RADIATOR SEAL KIT	32	8		
01-02-50271	124 589 24 21 00	TESTER	8	2		
01-02-50272	124 589 24 21 02	PRESS -HOSE	8	2		
01-02-50273	210 589 00 91 00	TEST CAP	8	2		
01-02-50274	000 833 03 61 (0008330561)	EXTROCTION -RADIO	8	2		
01-02-50275	609 -E10 X E12	DOUBLE TOREX BOX WRENCH E10	24	6		
01-02-50276	E4 UNIT E24	DOUBLE TOREX BOX WRENCH SET	16	4		
01-02-50277	220 830 03 72	SENSOR	40	10		
01-02-50278	220 830 00 84	VALVE	32	8		
01-02-50279	R134 A	A.C GAS KG	1000	250		
01-02-50280	00 1 989 08 03	A.C COMP OIL LITER	20	5		
01-02-50281	A220 240 07 17	ENGINE MOUNT L&R	40	10		
01-02-50282	A220 320 50 13	HYDRO SPRING LEG REAR	48	12		
01-02-50283	A140 320 08 89	ROD TORSION BAR	8	2		
01-02-50284	B66 47 05 43	7HOLE DISCWHEEL	160	40		
01-02-50285	A201 400 04 25	HUB CUP	200	50		
01-02-50286	A140 400 05 70	CLAMPING SCREW	1200	300		
01-02-50287	A210 410 21 81	RUBBER BEARING	40	10		
01-02-50288	A220 460 08 00	STEERING BOX ASSY	20	5		
01-02-50289	A220 500 00 49	EXPANSTON TAUKE	8	2		
01-02-50290	A220 620 03 72	STIFFENING F.CEWTTER	8	2		
01-02-50291	A220 620 10 86	CENTRAL SUPPORT	8	2		
01-02-50292	A220 620 01 72	STIFFENING LIGHT L	8	2		
01-02-50293	A220 620 02 72	STIFFENING LIGHT R	8	2		
01-02-50294	A220 670 02 80	REAR GLASS	24	6		
01-02-50295	A220 730 03 46	WINDOW REGULATOR	16	4		
01-02-50296	A220 730 04 46	WINDOW REGULATOR	16	4		
01-02-50297	A220 750 01 75	REAR LID	12	3		
01-02-50298	A220 330 00 20	KNUCKLE - L	16	4		
01-02-50299	A220 330 01 20	KNUCKLE - R	16	4		
01-02-50300	A220 350 12 10	ROOD AXLE SHAFT	16	4		
01-02-50301	A004 541 46 01	BATTERY	80	20		

SPARE PARTS FOR MERCEDES TYPE S320

CODE	PART NO.	DESCRIPTION	QTY	QTY		
01-02-50302	A 112 010 81 05	CRANK CASE	20	5		
01-02-50303	A 112 997 02 46	SEAL RING	80	20		
01-02-50304	A 112 011 01 08	COVER	8	2		
01-02-50305	A 023 997 84 47	SEAL RING	80	20		
01-02-50306	A 112 010 06 33	TIMING CASE	12	3		
01-02-50307	A 112 997 08 45	SEAL RING	240	60		
01-02-50308	A 112 014 07 02	OIL PAN	12	3		
01-02-50309	A 111 997 03 30	SCREW PLUG	400	100		
01-02-50310	N007603014106	SEAL RING,V LRUB	1600	400		

01-02-50311	A 112 010 03 72	OIL DIPSTICK	12	3		
01-02-50312	A 112 010 02 66	GUIDE TUBE	16	4		
01-02-50313	A 112 018 00 80	GASKET	32	8		
01-02-50314	A 112 010 62 02	ENGINE	48	12		
01-02-50315	A 112 180 01 43	OIL NOZZLE	60	15		
01-02-50316	A 112 010 14 20	CYLINDER HEAD	48	12		
01-02-50317	A 112 010 15 20	CYLINDER HEAD	48	12		
01-02-50318	A 112 016 03 20	CYLINDER HEAD GASKET	80	20		
01-02-50319	A 112 016 04 20	CYLINDER HEAD GASKET	80	20		
01-02-50320	A 006 997 26 45	SEAL RING,VLRUB	80	20		
01-02-50321	A 117 997 02 30	SCREW PLUG	20	5		
01-02-50322	A 023 997 70 48	SEAL RING	40	10		
01-02-50323	A 112 015 06 30	EXPANSION PLUG	20	5		
01-02-50324	A 112 184 00 80	GASKET	40	10		
01-02-50325	A 111 992 02 25	SLEEVE	20	5		
01-02-50326	A 112 990 04 05	STUD	480	120		
01-02-50327	A 112 990 04 78	CONNECTOR	60	15		
01-02-50328	N000443 028001	EXPANSION PLUG	40	10		
01-02-50329	A 112 055 00 45	FLANGE	16	4		
01-02-50330	A 112 010 00 64	OIL FILLER NECK	12	3		
01-02-50331	A111 018 00 80	GASKET,OIL FILTER,VLRUB	80	20		
01-02-50332	A 112 010 03 30	CYLINDER HEAD COVER	12	3		
01-02-50333	A 112 010 02 30	CYLINDER HEAD COVER	12	3		
01-02-50334	N000912 005010	SCREW	60	15		
01-02-50335	A 001 990 83 22	SCREW	120	30		
01-02-50336	A 001 990 84 22	SCREW PLUG	64	16		
01-02-50337	A 112 090 00 89	BEARING	80	20		
01-02-50338	A 112 990 10 22	SCREW	96	24		
01-02-50339	A002 990 97 22	SCREW	40	10		
01-02-50340	A 112 990 02 12	SCREW	240	60		
01-02-50341	N910105008019	SCREW	360	90		
01-02-50342	N910143008003	SCREW	80	20		
01-02-50343	A 113 053 03 29	VALVE GUIDE	480	120		
01-02-50344	A 113 053 04 29	VALVE GUIDE	144	36		
01-02-50345	A 112 016 02 21	GASKET	80	20		
01-02-50346	A 112 016 03 21	GASKET	80	20		
01-02-50347	A 112 010 04 67	COVER PLATE	20	5		
01-02-50348	A 112 030 16 01	CRANKSHAFT	32	8		
01-02-50349	N910105 008019	SCREW	12	3		
01-02-50350	A 112 052 02 03	CRANK SHAFT GEAR	8	2		
01-02-50351	A 112 035 09 00	VIBRATION ABSORBER	8	2		
01-02-50352	A 006 990 71 04	SCREW	8	2		
01-02-50353	A 112 030 06 12	RING GEAR	28	7		
01-02-50354	A 112 030 00 40 54	CRANKSHAFT BEARING	384	96		
01-02-50355	A 112 030 01 40	CRANKSHAFT BEARING	256	64		
01-02-50356	A112 030 00 62	GUARD PLATE	192	48		
01-02-50357	A112 030 01 62	GUARD PLATE	80	20		
01-02-50358	A 001 990 57 12	SCREW	64	16		
01-02-50359	A 112 030 14 72	DRIVE SHAFT	20	5		
01-02-50360	A 112 990 00 14	SCREW	20	5		
01-02-50361	A 112 034 07 22	COUNTER WEIGHT	20	5		
01-02-50362	A 112 034 01 73	LOCK	20	5		
01-02-50363	A 112 030 06 17	PISTON	144	36		
01-02-50364	A 112 030 13 17	PISTON	96	24		
01-02-50365	A 112 030 03 24	PISTON RING	144	36		
01-02-50366	A 112 030 08 24	PISTON RING	72	18		
01-02-50367	A113 030 00 20	CONNECTING ROD	120	30		
01-02-50368	A 112 038 01 50	PISTON PIN BUSHING	144	36		
01-02-50369	A 112 030 00 60	CONNECTING ROD BEARING	576	144		
01-02-50370	A 112 030 01 60	CONNECTING ROD BEARING	384	96		
01-02-50371	A 003 997 68 94	ROLLER CHAIN	48	12		

01-02-50372	A 000 997 22 98	CHAIN LOCK LINK	48	12		
01-02-50373	A 112 052 01 16	SLIDING RAIL	120	30		
01-02-50374	A112 052 00 16	SLIDING RAIL	60	15		
01-02-50375	A112 052 02 16	SLIDING RAIL	60	15		
01-02-50376	A112 052 0174	PIN	360	90		
01-02-50377	A 112 050 05 11	CHAIN TIGHTENER	72	18		
01-02-50378	A 112 038 00 71	SCREW	48	12		
01-02-50379	A 112 050 40 01	CAMSHAFT	32	8		
01-02-50380	A 112 050 41 01	CAMSHAFT	32	8		
01-02-50381	A 112 050 07 31	ROCKER ARM SPINDLE	24	6		
01-02-50382	A 112 050 09 31	ROCKER ARM SPINDLE	24	6		
01-02-50383	A 113 050 05 34	ROCKER ARM	240	60		
01-02-50384	A 113 050 00 33	ROCKER ARM	240	60		
01-02-50385	A 113 050 01 33	ROCKER ARM	240	60		
01-02-50386	A 113 055 00 76	WASHER	320	80		
01-02-50387	A 113 050 00 80	HYDRAULIC ELEMENT	480	120		
01-02-50388	A 113 050 03 80	HYDRAULIC ELEMENT	240	60		
01-02-50389	A 112 050 02 04	CAMSHAFT GEAR	32	8		
01-02-50390	A 113 053 01 01	INTAKE VALVE	720	180		
01-02-50391	A 113 050 02 27	EXHAUST VALVE	320	80		
01-02-50392	A 612 050 00 58	SEAL	80	20		
01-02-50393	A 102 053 02 26	VALVE COLLET	240	60		
01-02-50394	A 113 053 00 20	VALVE SPRING	120	30		
01-02-50395	A 603 053 03 25	RETAINER WASHER	40	10		
01-02-50396	A 112 070 02 95	FUEL DISTRIBUTOR	12	3		
01-02-50397	A 112 078 01 49	VALVE	480	120		
01-02-50398	A 019 997 13 48	SEAL RING,VLRUB	2000	500		
01-02-50399	A 000 070 01 95	INJECT TEST CONNECT	8	2		
01-02-50400	A 119 078 06 41	BRACKET,INJECT VALVE	48	12		
01-02-50401	A 000 078 04 29	VALVE	48	12		
01-02-50402	A 112 090 11 01	AIR CLEANER	16	4		
01-02-50403	A 112 094 00 04	FILTER ELEMENT	3200	800		
01-02-50404	A 112 094 00 41	BRACKET	160	40		
01-02-50405	A 112 094 11 82	HOSE	40	10		
01-02-50406	A 112 094 10 82	HOSE	40	10		
01-02-50407	A 002 466 86 01	HYDRAULIC PUMP	20	5		
01-02-50408	A 000 460 01 83	OIL TANK	12	3		
01-02-50409	A 000 230 85 11	COMPRESSOR	12	3		
01-02-50410	A 112 230 17 56	PIPE	20	5		
01-02-50411	A 112 230 08 56	PIPE	20	5		
01-02-50412	A 210 997 03 45	SEAL RING	120	30		
01-02-50413	A 220 997 04 45	SEAL RING	120	30		
01-02-50414	A 140 997 07 45	SEAL RING	120	30		
01-02-50415	A 220 997 02 45	SEAL RING	120	30		
01-02-50416	A 011 997 97 92(013 997 87 92)	V-BELT	400	100		
01-02-50417	A 112 140 11 01	INTAKE MAINFOLD	8	2		
01-02-50418	A 112 141 10 80	GASKET	240	60		
01-02-50419	A 111 997 05 45	SEAL RING	40	10		
01-02-50420	A 111 141 02 42	CLAMPING STRIP	20	5		
01-02-50421	A 111 141 00 81	CAP	8	2		
01-02-50422	A 112 141 00 69	VACUU BOX	8	2		
01-02-50423	A 117 997 09 82	HOSE,INJECTION,VLRUB	20	5		
01-02-50424	N912010003003	LOCK PLATE	40	10		
01-02-50425	A 002 540 18 97	VALVE	12	3		
01-02-50426	A 112 140 00 09	EXHAUST MANIFOLD	12	3		
01-02-50427	A 112 140 01 09	EXHAUST MANIFOLD	12	3		
01-02-50428	A000 990 25 52	NUT	160	40		
01-02-50429	A 112 142 00 72	NUT	240	60		
01-02-50430	A 112 142 01 80	GASKET	120	30		
01-02-50431	A 112 140 00 60	VALVE	12	3		
01-02-50432	A 112 140 01 08	EXHAUST LINE	16	4		

01-02-50433	A 112 141 03 80	GASKET	48	12		
01-02-50434	A 000 990 73 67	RING	80	20		
01-02-50435	A 117 078 02 81	HOSE,VACUUM CONNECT,VLRUB	64	16		
01-02-50436	A 117 078 05 81	HOSE, THERMO, , VALALVE VLRUB	40	10		
01-02-50437	A 112 142 02 80	GASKET	48	12		
01-02-50438	A 004 153 32 28	SENDER UNIT	16	4		
01-02-50439	A 000 990 68 54	JUNCTION NUT	16	4		
01-02-50440	N910143008005	SCREW	40	10		
01-02-50441	A 027 997 27 48	SEAL RING	80	20		
01-02-50442	A 112 094 01 48	AIR MASS SENSOR	60	15		
01-02-50443	A 112 141 01 80	GASKET	60	15		
01-02-50444	A 112 141 02 80	GASKET	60	15		
01-02-50445	A 112 141 00 40	BRACKET	40	10		
01-02-50446	A 112 141 01 40	BRACKET	40	10		
01-02-50447	A 112 141 01 25	SLIDE	16	4		
01-02-50448	A 001 546 00 43	BRACKET	16	4		
01-02-50449	A 112 018 03 82	HOSE	20	5		
01-02-50450	A 112 018 00 09	CONNECTOR	20	5		
01-02-50451	A 117 990 15 78	CONNECTOR,CYLINDER HEAD	36	9		
01-02-50452	A 112 018 02 82	HOSE	20	5		
01-02-50453	A 112 018 04 82	HOSE	20	5		
01-02-50454	A 112 018 01 82	HOSE	20	5		
01-02-50455	A 112 151 00 01	STARTING MOTOR	4	1		
01-02-50456	A 000 152 04 10	SOLENOID SWITCH	24	6		
01-02-50457	A 000 151 64 15	ARMATURE	12	3		
01-02-50458	A 001 151 21 13	PINION	20	5		
01-02-50459	A 001 151 08 14	CARBON BRUSH SET	24	6		
01-02-50460	A 000 151 53 50	BUSHING	120	30		
01-02-50461	A 019 981 19 10	NEEDLE BEARING	60	15		
01-02-50462	A 000 151 68 50	BUSHING ,STARTER	40	10		
01-02-50463	A 112 140 00 18	HOUSING	12	3		
01-02-50464	A 000 140 37 85	PUMP	8	2		
01-02-50465	A 002 540 14 97	VALVE	12	3		
01-02-50466	A 117 078 09 81	HOSE,CHANGOVER VALVE,VLRUB	8	2		
01-02-50467	N040621012200	INSULATING HOSE,PLASTIC	32	8		
01-02-50468	N040621018200	INSULATING HOSE,PLASTIC	16	4		
01-02-50469	A 001 140 66 60	CHECK VALVE	16	4		
01-02-50470	A 112 237 02 40	BRACKET	8	2		
01-02-50471	A 601 078 02 45	HOSE,VACUUM CONTROL,VLRUB	16	4		
01-02-50472	A 011 154 32 02	ALTERNATOR	8	2		
01-02-50473	A 002 154 92 06	REGULATOR	100	25		
01-02-50474	A 007 981 89 25	BALL BEARING	100	25		
01-02-50475	A 007 981 73 25	BALL BEARING	100	25		
01-02-50476	A 000 154 06 57	SLIP RING ALTERNATOR	16	4		
01-02-50477	A 119 155 01 15	PULLEY	8	2		
01-02-50478	A000 990 22 50	NUT	16	4		
01-02-50479	A 000 158 78 03	IGNITION COIL	60	15		
01-02-50480	A 112 150 01 18	IGNITION CABLE	200	50		
01-02-50481	A 112 150 02 18	IGNITION CABLE	360	90		
01-02-50482	A 003 159 66 03 26	SPARK PLUG	24000	6000		
01-02-50483	A 004 153 69 28	SENDER UNIT	24	6		
01-02-50484	A 003 153 86 28	KNOCK SENSOR	80	20		
01-02-50485	A 003 153 28 28	SENDER UNIT	24	6		
01-02-50486	A 022 997 25 48	SEAL RING,VLRUB	120	30		
01-02-50487	A 000 542 51 18	SENDER UNIT	48	12		
01-02-50488	A 022 997 98 48	SEAL RING	200	50		
01-02-50489	A 004 153 53 28	SENDER UNIT	40	10		
01-02-50490	A 023 997 43 48	SEAL RING	120	30		

01-02-50491	A 008 988 91 78	CLIP	40	10		
01-02-50492	A 112 203 01 40	BRACKET	8	2		
01-02-50493	A 112 180 10 01	OIL PUMP	40	10		
01-02-50494	A 003 997 74 94	ROLLER CHAIN	32	8		
01-02-50495	A 000 997 32 98	CHAIN LOCK LINK	20	5		
01-02-50496	A 112 181 00 59	CLAMPING BRACKET	20	5		
01-02-50497	A 112 993 03 20	SPRING	20	5		
01-02-50498	A 112 181 00 74	PIN	20	5		
01-02-50499	A611 180 01 15	PRESSURE RELIEF VALVE	24	6		
01-02-50500	A 112 180 00 09	FILTER ELEMENT	9600	2400		
01-02-50501	A 112 180 01 10	OIL FILTER	16	4		
01-02-50502	A 112 184 01 02	HOUSING	12	3		
01-02-50503	A 112 184 00 61	SEAL RING	48	12		
01-02-50504	A 112 184 00 17	FITTING	12	3		
01-02-50505	A 112 188 04 01	OIL COOLER	16	4		
01-02-50506	A 112 184 02 61	SEAL RING	160	40		
01-02-50507	A 112 184 03 61	SEAL RING	160	40		
01-02-50508	A 112 200 14 01	WATER PUMP	160	40		
01-02-50509	A 112 201 01 80	GASKET	160	40		
01-02-50510	A 112 203 03 82	HOSE	120	30		
01-02-50511	N000000000667	CLAMP	120	30		
01-02-50512	A 112 200 00 15	THERMOSTAT	120	30		
01-02-50513	A 112 203 00 76	GASKET	240	60		
01-02-50514	A 111 992 02 25	SLEEVE	20	5		
01-02-50515	A 112 202 01 10	PULLEY	4	1		
01-02-50516	N910105006007	SCREW	120	30		
01-02-50517	A 000 202 00 19	TIGHTENER PULLEY	40	10		
01-02-50518	A 112 200 03 70	BELT TIGHTENER	60	15		
01-02-50519	A 112 203 00 61	HOUSING	24	6		
01-02-50520	A 112 990 01 12	SCREW	40	10		
01-02-50521	A 112 223 19 04	ENGINE SUPPORT	4	1		
01-02-50522	A 112 223 18 04	ENGINE SUPPORT	4	1		
01-02-50523	A 220 540 70 06	CABLE HARNESS	16	4		
01-02-50524	A 203 545 39 28	PLUG	16	4		
01-02-50525	A 203 545 30 28	PLUG	72	18		
01-02-50526	A 203 545 05 28	PLUG	72	18		
01-02-50527	A 203 545 34 28	PLUG	4	1		
01-02-50528	A 220 545 46 28	PLUG	20	5		
01-02-50529	A 210 540 21 81	PIN BUSHING HOUSING	12	3		
01-02-50530	A 210 540 20 81	PIN BUSHING HOUSING	16	4		
01-02-50531	A 004 545 20 26	PLUG SOCKET	12	3		
01-02-50532	A 168 545 08 28	PLUG HOUSING	8	2		
01-02-50533	A 013 545 15 26	CONTACT BUSHING	320	80		
01-02-50534	A 013 545 46 26	PLUG	240	60		
01-02-50535	A 009 545 81 26	CONTACT BUSHING	320	80		
01-02-50536	A 008 545 63 26	PLUG	240	60		
01-02-50537	A 003 545 02 26	PLUG SOCKET	20	5		
01-02-50538	A 003 545 26 26	PIN BUSHING	400	100		
01-02-50539	A 008 545 55 26	CONTACT SPRING	360	90		
01-02-50540	A 013 545 16 26	PLUG SOCKET	200	50		
01-02-50541	A 009 545 26 26	PLUG SOCKET	80	20		
01-02-50542	N072581 000 305	FUSE ELEMENT	400	100		
01-02-50543	N304017010051	SCREW	48	12		
01-02-50544	A 202 990 22 01	SCREW	48	12		
01-02-50545	A 220 242 00 01	ENGINE SUPPORT	8	2		
01-02-50546	A 140 242 13 40	BRACKET	8	2		
01-02-50547	A 220 267 11 24	FLOOR ,SHIFT MECHANISM	8	2		
01-02-50548	A 220 267 01 64	WIRE CABLE	8	2		
01-02-50549	A 220 260 04 33	SHIFTING ROD	8	2		
01-02-50550	A 220 267 16 88	COVERING	12	3		
01-02-50551	A 220 267 01 10 9C05	HANDLE	12	3		

01-02-50552	A 000 994 43 60	LOCK	16	4		
01-02-50553	A 000 994 51 48	LOCK WASHER	24	6		
01-02-50554	A 210 992 00 10	BUSHING	20	5		
01-02-50555	A 001 545 21 09	SWITCH	8	2		
01-02-50556	A 005 545 22 14	KICK-DOWN SWITCH	12	3		
01-02-50557	A 220 300 00 04	ACCELERATOR PEDAL	16	4		
01-02-50558	A 220 320 51 13	HYDROPNEUMATIC SPRING LEG	12	3		
01-02-50559	A 220 320 15 89	ROD	64	16		
01-02-50560	A 220 320 16 89	ROD	64	16		
01-02-50561	A 220 320 03 89	ROD	32	8		
01-02-50562	A 220 320 00 32	LINK	16	4		
01-02-50563	A 220 320 01 04	COMPRESSOR	16	4		
01-02-50564	A 220 320 00 04	COMPRESSOR	16	4		
01-02-50565	A 220 320 00 69	FILTER	40	10		
01-02-50566	A 220 320 02 58	VALVE	16	4		
01-02-50567	A 220 327 09 30	RUBBER BUFFER	48	12		
01-02-50568	A 220 327 08 30	RUBBER BUFFER	60	15		
01-02-50569	A 000 327 00 69(000 327 03 69)	CONNECTOR	48	12		
01-02-50570	A 220 327 01 45	LINE	40	10		
01-02-50571	A 220 327 08 45	LINE	40	10		
01-02-50572	A 220 542 01 18	SENDER UNIT	24	6		
01-02-50573	A 000 327 01 69(000 327 03 69)	CONNECTOR	48	12		
01-02-50574	A 220 327 10 45	LINE	80	20		
01-02-50575	A 220 320 02 15	AIR CELL	16	4		
01-02-50576	A 220 327 12 30	RUBBER BUFFER	32	8		
01-02-50577	A 220 328 08 39	RUBBER BUFFER	32	8		
01-02-50578	A 220 330 43 07	SPRING CONTROL	20	5		
01-02-50579	A 220 330 44 07	SPRING CONTROL	20	5		
01-02-50580	A 220 333 17 14	BEARING	80	20		
01-02-50581	A 220 333 01 27	JOINT	28	7		
01-02-50582	A 220 333 01 71	SCREW	160	40		
01-02-50583	N910113014000	NUT	160	40		
01-02-50584	A 220 330 14 07	TRANSVERSE CONTROL ARM	12	3		
01-02-50585	A 220 330 15 07	TRANSVERSE CONTROL ARM	12	3		
01-02-50586	A 220 330 33 11	STRUT	16	4		
01-02-50587	A 220 330 34 11	STRUT	16	4		
01-02-50588	A 220 323 03 68	JOINT	64	16		
01-02-50589	A 220 330 07 25	FRONT WHEEL HUB	12	3		
01-02-50590	A 116 334 03 72	CLAMPING NUT	16	4		
01-02-50591	A 220 350 21 14	HOUSING	20	5		
01-02-50592	A 210 997 02 46	SEAL RING	40	10		
01-02-50593	A 220 350 29 14	REPAIR KIT	12	3		
01-02-50594	A 210 353 05 72	NUT	12	3		
01-02-50595	A 220 350 74 08	REAR SUBFRAME	12	3		
01-02-50596	A 220 350 05 75	RUBBER MOUNTING	120	30		
01-02-50597	A 220 351 11 42	RUBBER MOUNTING	120	30		
01-02-50598	A 220 350 09 15	EXTENSION	20	5		
01-02-50599	A 220 351 09 42	RUBBER MOUNTING	160	40		
01-02-50600	A 220 352 13 65	RUBBER MOUNTING	120	30		
01-02-50601	A 220 350 89 08	REAR SUBFRAME	12	3		
01-02-50602	A 220 350 90 08	REAR SUBFRAME	12	3		
01-02-50603	A 220 352 11 02	TRANSVERSE CONTROL ARM	16	4		
01-02-50604	A 220 350 26 06	CONTROL ARM	32	8		
01-02-50605	A 220 350 04 53	TIE ROD	48	12		
01-02-50606	A 220 350 22 06	CONTROLARM	32	8		
01-02-50607	A 220 350 24 06	CONTROL ARM	32	8		
01-02-50608	A 220 40 10194	BALANCING WEIGHT	400	100		
01-02-50609	A 220 401 02 94	BALANCING WEIGHT	480	120		
01-02-50610	A 220 401 03 94	BALANCING WEIGHT	480	120		
01-02-50611	A 220 401 04 94	BALANCING WEIGHT	480	120		

01-02-50612	A 220 401 05 94	BALANCING WEIGHT	480	120		
01-02-50613	A 220 401 06 94	BALANCING WEIGHT	360	90		
01-02-50614	A 220 401 07 94	BALANCING WEIGHT	240	60		
01-02-50615	A 124 401 07 28	WHEEL WEIGHT CLIP	800	200		
01-02-50616	A 124 401 36 94	BALANCING WEIGHT	360	90		
01-02-50617	A 124 401 37 94	BALANCING WEIGHT	400	100		
01-02-50618	A 124 401 38 94	BALANCING WEIGHT	400	100		
01-02-50619	A 124 401 53 94	BALANCING WEIGHT	400	100		
01-02-50620	A 124 401 54 94	BALANCING WEIGHT	400	100		
01-02-50621	A 124 401 55 94	BALANCING WEIGHT	240	60		
01-02-50622	A 124 401 56 94	BALANCING WEIGHT	240	60		
01-02-50623	A 000 400 03 13	VALVE ,TIRE	120	30		
01-02-50624	A 000 400 02 13	VALVE,TIRE	16	4		
01-02-50625	A 124 411 05 15	SHAFT PLATE	40	10		
01-02-50626	A 220 410 00 15	FLEXIBLE JOINT DISC	20	5		
01-02-50627	A 220 410 13 06	PROPELLER SHAFT	12	3		
01-02-50628	A 220 410 06 01	PROPELLER SHAFT	8	2		
01-02-50629	A 220 410 11 02	PROPELLER SHAFT	8	2		
01-02-50630	A 008 981 43 25	BALL BEARING	60	15		
01-02-50631	A 202 411 04 97	BOOT	12	3		
01-02-50632	A 003 420 42 20	BRAKE SHOE	1200	300		
01-02-50633	A 000 421 00 47	VIBRATION ABSORBER	200	50		
01-02-50634	A 000 421 80 91	SPRING	40	10		
01-02-50635	A 000 421 27 65	VALVE,BRAKE CYL BLEEDER	40	10		
01-02-50636	A 001 420 82 83(001 420 80 83)	CALIPER	20	5		
01-02-50637	A 001 420 81 83	CALIPER	20	5		
01-02-50638	A 220 421 09 12	BRAKE DISC	640	160		
01-02-50639	A 003 420 19 20	BRAKE SHOE	1160	290		
01-02-50640	A 001 420 71 83	CALIPER	20	5		
01-02-50641	A 001 420 72 83	CALIPER	20	5		
01-02-50642	A 000 421 92 86	CUP	80	20		
01-02-50643	A 000 421 94 86	REPAIR KIT	80	20		
01-02-50644	A 220 420 05 20	BRAKE SHOE	324	81		
01-02-50645	A 220 423 01 12	BRAKE DISC	100	25		
01-02-50646	A 220 540 07 17	SENDER UNIT	6000	1500		
01-02-50647	A 000 421 75 91	SPRING	24	6		
01-02-50648	A 003 431 88 12	BRAKE PRESSURE REGULATOR	8	2		
01-02-50649	A 005 430 91 01	BRAKE MASTER CYLINDER	32	8		
01-02-50650	A 005 430 25 30	BRAKE BOOSTER ASSEMBLY	8	2		
01-02-50651	A 220 430 14 29	LINE	12	3		
01-02-50652	A 220 430 00 02	RESERVOR RESERVOIR	8	2		
01-02-50653	A 000 431 15 50	BUSHING	24	6		
01-02-50654	A 220 420 00 48	BRAKE HOSE	48	12		
01-02-50655	A 220 420 01 48	BRAKE HOSE	40	10		
01-02-50656	A 220 420 17 85	BRAKE HOSE	8	2		
01-02-50657	A 220 420 27 85	BRAKE CABLE	8	2		
01-02-50658	A 220 420 28 85	BRAKE CABLE	8	2		
01-02-50659	A 220 460 10 00	REPAIR KIT	24	6		
01-02-50660	A 220 338 10 15	TIE ROD	160	40		
01-02-50661	A 220 338 07 15	TIE ROD	20	5		
01-02-50662	A 220 460 03 10	STEERING COUPLING	8	2		
01-02-50663	A 220 463 00 66	RUBBR MOUNTING	48	12		
01-02-50664	A 220 997 54 82	HOSE	20	5		
01-02-50665	A 215 460 04 16	STEER.COLUMN JACKET TUBE	8	2		
01-02-50666	A 220 460 02 95 9B51	COVERING	8	2		
01-02-50667	A 220 462 01 23 9B51	COVER	8	2		
01-02-50668	220 462 01 23 9B51(220 997 88 8	COVER	8	2		
01-02-50669	A 220 466 12 81	HOSE	4	1		
01-02-50670	A 220 320 06 72	LINE	8	2		
01-02-50671	A 220 997 42 82	HOSE	48	12		

01-02-50672	A 004 997 74 90	CALMP CLAMP	120	30		
01-02-50673	A 220 997 59 82	HOSE	32	8		
01-02-50674	B66268190	STEERING WHEEL	12	3		
01-02-50675	A 220 460 03 98	AIR BAG	12	3		
01-02-50676	A 220 460 03 09	STEERING SHAFT	8	2		
01-02-50677	A 220 470 24 01	FUEL TANK	16	4		
01-02-50678	A 220 470 00 05	FILLER CAP	40	10		
01-02-50679	A 210 470 01 06	FUEL STRAINER	40	10		
01-02-50680	A 000 470 78 94	AUXILIARY PUMP	200	50		
01-02-50681	N916030000527	HOSE,VLRUB	60	15		
01-02-50682	A 107 476 24 26	HOSE	20	5		
01-02-50683	A 220 478 00 37	PROTECTIVE COVER	12	3		
01-02-50684	A 002 477 31 01	FUEL FILTER	800	200		
01-02-50685	A 202 471 13 41	BRACKET	8	2		
01-02-50686	A 006 997 18 90	LOOM TIE	200	50		
01-02-50687	A 006 997 19 90	LOOM TIE	120	30		
01-02-50688	A 220 476 26 75	FUEL HOSE	12	3		
01-02-50689	A 220 470 12 75	FUEL HOSE	16	4		
01-02-50690	A 000 470 15 93	REGENERATION VA	4	1		
01-02-50691	A 220 490 01 19	EXHAUST PIPE	16	4		
01-02-50692	A 220 490 02 19	EXHAUST PIPE	16	4		
01-02-50693	A 202 492 02 81	SEAL RING	40	10		
01-02-50694	A 126 997 00 41	RING,GENERAL,PLASTIC	40	10		
01-02-50695	A 220 490 02 21	EXHAUST PIPE	40	10		
01-02-50696	A 170 990 00 10	SCREW	200	50		
01-02-50697	A 129 990 04 10	SCREW	80	20		
01-02-50698	A 140 990 07 50	NUT	240	60		
01-02-50699	A 202 492 06 44	SUSPENSION RING,VLRUB	1200	300		
01-02-50700	A 220 492 00 44	SUSPENSION RING	600	150		
01-02-50701	A 220 500 14 03	RADIATOR	20	5		
01-02-50702	A 220 500 01 54	CONDENSER	8	2		
01-02-50703	A 220 500 00 93	BLOWER	40	10		
01-02-50704	A 013 997 58 92	V-BELT	120	30		
01-02-50705	A 220 504 02 12	RUBBER MOUNTING	200	50		
01-02-50706	A 220 504 01 12	RUBBER MOUNTING	320	80		
01-02-50707	A 220 504 01 46	CLAMP	320	80		
01-02-50708	A 220 504 00 12	RUBBER MOUNTING	24	6		
01-02-50709	N910105006002	SCREW	80	20		
01-02-50710	A 220 505 10 88	COVERING	16	4		
01-02-50711	A 220 505 00 88	COVERING	16	4		
01-02-50712	A 220 505 12 88	COVERING	16	4		
01-02-50713	N000000 000734	RUBBER HOSE	160	40		
01-02-50714	N000000 000665	CLAMP	320	80		
01-02-50715	A 220 505 09 88	COVERING	16	4		
01-02-50716	A 123 990 00 92	RIVET	200	50		
01-02-50717	A 000 500 01 85	SCREW	16	4		
01-02-50718	A 210 501 05 15	RADIATOR CAP	300	75		
01-02-50719	A 220 501 00 82	HOSE	48	12		
01-02-50720	A 006 997 06 90	LOOM TIE	80	20		
01-02-50721	A 006 997 42 90	LOOM TIE	48	12		
01-02-50722	A 230 995 01 05	CLAMP	48	12		
01-02-50723	A 220 501 03 82	HOSE	48	12		
01-02-50724	A 220 501 18 82	HOSE	48	12		
01-02-50725	A 220 545 00 24	SWITCH,AUTOMATIC	20	5		
01-02-50726	N000000 000 665	CLAMP	40	10		
01-02-50727	A 202 504 01 35	CLIP	20	5		
01-02-50728	A 022 997 26 82	HOSE	20	5		
01-02-50729	A 220 540 05 30	POS.CABLE	8	2		
01-02-50730	A 220 540 01 30	POS.CABLE	8	2		
01-02-50731	A 220 546 03 41	CABLE CONNECTOR	8	2		
01-02-50732	A 220 545 05 32	CONTROL UNIT	16	4		

01-02-50733	A 028 545 98 32	SWITCH	32	8		
01-02-50734	A 027 545 64 32	ESG CONTROL UNIT	40	10		
01-02-50735	A 031 545 09 32	CONTROL UNIT	16	4		
01-02-50736	A 026 545 53 32	SAM.CONTROL UNIT	32	8		
01-02-50737	A 027 545 04 32	CONTROL UNIT	48	12		
01-02-50738	A 220 540 06 24	APPARATUS CASE	8	2		
01-02-50739	A 220 540 05 24	APPARATUS CASE	8	2		
01-02-50740	A 220 540 01 82	COVERING COVER	12	3		
01-02-50741	A 220 540 00 82	COVERING COVER	12	3		
01-02-50742	A 028 545 81 32	CONTROL UNIT	24	6		
01-02-50743	A 002 545 21 01	FUSE BOX	20	5		
01-02-50744	A 002 542 13 19	RELAY	240	60		
01-02-50745	A 002 542 11 19	RELAY	24	6		
01-02-50746	A 002 542 23 19	RELAY	24	6		
01-02-50747	A 002 542 14 19	RELAY	240	60		
01-02-50748	A 002 542 20 01	FUSE BOX	20	5		
01-02-50749	N000000 000698	FUSE BOX	80	20		
01-02-50750	N000000 000696	FUSE BOX	200	50		
01-02-50751	A 002 545 11 34(002 545 43 34)	CATCH	1200	300		
01-02-50752	N910153 000000	FUSE BOX	600	150		
01-02-50753	N072581 000 302	FUSE ELEMENT	400	100		
01-02-50754	A 002 545 08 34(002 545 68 34)	CATCH	400	100		
01-02-50755	N072581 000 304	FUSE ELEMENT	2000	500		
01-02-50756	N072581 000305	FUSE ELEMENT	800	200		
01-02-50757	N072581 000 307	FUSE ELEMENT	800	200		
01-02-50758	N000007 004113	CYLINDRICAL PIN	800	200		
01-02-50759	N000000 000734	RUBBER HOSE	2000	500		
01-02-50760	N000000 001634	SCREW	400	100		
01-02-50761	A 002 545 22 01	FUSE BOX	16	4		
01-02-50762	A 002 542 18 19	RELAY	200	50		
01-02-50763	A 000 540 19 50	FUSE BOX	20	5		
01-02-50764	N000000 000422	FUSE BOX	80	20		
01-02-50765	A 004 542 57 20	HORN	160	40		
01-02-50766	A 004 542 56 20	HORN	160	40		
01-02-50767	A 000 542 84 18	SENDER UNIT	20	5		
01-02-50768	A 220 540 11 06	CABLE HARNESS	8	2		
01-02-50769	A 220 540 09 06	CABLE HARNESS	8	2		
01-02-50770	A 220 540 67 09	CABLE HARNESS	4	1		
01-02-50771	A 220 820 68 15	ELECTRIC CABLE	4	1		
01-02-50772	A 220 540 56 06	CABLE HARNESS	4	1		
01-02-50773	A 220 540 34 11	INSTRUMENT CLUSTER	8	2		
01-02-50774	A 220 542 00 58	DIAL FACING	8	2		
01-02-50775	A 220 584 32 17	GUIDE SIGN	8	2		
01-02-50776	N910141 000000	BULB	200	50		
01-02-50777	A 001 545 21 09	SWITCH	8	2		
01-02-50778	A 025 545 44 32	MSA CONTROL UNIT	8	2		
01-02-50779	A 220 545 00 22	SWITCH	8	2		
01-02-50780	A 220 545 00 10	SWITCH	40	10		
01-02-50781	A 002 542 17 18	SENDER UNIT	8	2		
01-02-50782	A 000 464 03 18	CONTRACT SPIRAL	8	2		
01-02-50783	A 220 545 06 04 7211	SWITCH	12	3		
01-02-50784	A 220 540 01 17	SENDER UNIT	72	18		
01-02-50785	A 220 540 04 17	SENDER UNIT	72	18		
01-02-50786	A 220 540 05 17	SENDER UNIT	8	2		
01-02-50787	A 220 540 56 05	CABLE HARNESS	8	2		
01-02-50788	A 001 540 45 17	SENSOR	40	10		
01-02-50789	A 010 542 76 17	SENDER UNIT	40	10		
01-02-50790	A 220 583 00 15	JACK	24	6		
01-02-50791	A 140 581 03 01	SOCKET WRENCH	20	5		
01-02-50792	A 140 581 02 01	SOCKET WRENCH	8	2		
01-02-50793	A 220 610 00 14	CROSS MEMBER	4	1		

01-02-50794	A 220 610 07 10	SIDE MEMBER	4	1		
01-02-50795	A 220 610 08 10	SIDE MEMBER	4	1		
01-02-50796	A 220 610 00 75	SPARE WHEEL WELL	4	1		
01-02-50797	A 220 620 13 61	WHEEL HOUSE	8	2		
01-02-50798	A 220 620 14 61	WHEEL HOUSE	12	3		
01-02-50799	A 215 628 00 57	SUPPORT	4	1		
01-02-50800	A 220 620 16 16	WHEEL HOUSE	8	2		
01-02-50801	A 220 620 19 31	CONSOLE	12	3		
01-02-50802	A 220 620 20 31	CONSOLE	16	4		
01-02-50803	A 220 630 03 21	REAR FENDER	4	1		
01-02-50804	A 220 630 10 21	REAR FENDER	4	1		
01-02-50805	A 220 670 17 01	WINDSHIELD	60	15		
01-02-50806	A 220 670 05 22	GARNISH MOULDING	24	6		
01-02-50807	A 220 671 01 12	ANGLE	60	15		
01-02-50808	A 220 671 02 12	ANGLE	80	20		
01-02-50809	A 210 670 02 93	ACCESSORIES	20	5		
01-02-50810	A 220 670 01 22	GARNISH MOULDING	24	6		
01-02-50811	A 220 670 02 22	GARNISH MOULDING	24	6		
01-02-50812	A 220 670 03 22	GARNISH MOULDING	24	6		
01-02-50813	A 202 678 00 79	BRACING,REAR WINDOW	120	30		
01-02-50814	A 220 678 09 37	JOINT COVER	40	10		
01-02-50815	A 210 678 08 37	JOINT COVER	40	10		
01-02-50816	A 202 678 16 37	JOINT COVER	80	20		
01-02-50817	A 220 810 02 30	ASHTRAY	8	2		
01-02-50818	A 220 860 17 05	HOLDING FIXTURE	12	3		
01-02-50819	A 220 680 04 84	FASTENER	8	2		
01-02-50820	A 220 680 02 84	FASTENER	8	2		
01-02-50821	A 000 996 46 72	PULL	12	3		
01-02-50822	A 220 680 01 71 6000	GRANISH MOULDING	16	4		
01-02-50823	A 220 680 05 39	FLAP	16	4		
01-02-50824	A 220 680 22 39	FLAP	12	3		
01-02-50825	A 220 680 04 39 1400	COVERING	16	4		
01-02-50826	A 220 680 72 39	SLOTTED GATE	16	4		
01-02-50827	A 220 810 00 20	ROLLER BLIND	20	5		
01-02-50828	A 220 694 00 14	BRACKET	32	8		
01-02-50829	A 220 694 01 14	BRACKET	64	16		
01-02-50830	A 220 694 02 14	BRACKET	64	16		
01-02-50831	A 220 810 05 17 7D43	INSIDE REAR VIEW MIRROR	16	4		
01-02-50832	A 220 811 01 71 7D43	COVERING	16	4		
01-02-50833	A 220 860 07 05	HEAD PROTECTION CURTAIN	16	4		
01-02-50834	A 220 860 08 05	HEAD PROTECTION CURTAIN	16	4		
01-02-50835	A 220 690 00 41 7C45	PANELLING	16	4		
01-02-50836	A 124 990 07 92 9051	RIVET	200	50		
01-02-50837	A 220 697 05 51 9B56	EDGE GUARD SECTION	64	16		
01-02-50838	A 220 697 06 51 9B56	EDGE GUARD SECTION	56	14		
01-02-50839	A 140 698 03 30 9143	COVERING	240	60		
01-02-50840	A 220 690 01 62 9143	LEDGE	32	8		
01-02-50841	A 220 690 02 62 9143	LEDGE	32	8		
01-02-50842	A 220 690 05 62 9143	LEDGE	20	5		
01-02-50843	A 220 690 06 62 9143	LEDGE	20	5		
01-02-50844	A 220 690 13 62 9143	LEDGE	20	5		
01-02-50845	A 220 690 14 62 9143	LEDGE	20	5		
01-02-50846	A 220 690 03 62 9143	LEDGE	32	8		
01-02-50847	A 220 690 04 62 9143	LEDGE	32	8		
01-02-50848	A 002 988 22 81	FASTENER BUTTON	120	30		
01-02-50849	A 001 988 76 81	FASENER BUTTON	80	20		
01-02-50850	A 007 988 71 78	CLIP	360	90		
01-02-50851	A 008 988 21 78	CLIP	40	10		
01-02-50852	A 009 988 95 78	CLIP	80	20		
01-02-50853	A 002 988 25 81	FASTENER BUTTON	40	10		
01-02-50854	A 002 988 26 81	FASTENER BUTTON	40	10		

01-02-50855	A 007 988 76 78	CLIP	80	20		
01-02-50856	A 000 988 86 25		128	32		
01-02-50857	A 000 988 55 81	PUSH BUTTON	200	50		
01-02-50858	A 220 720 01 05	DOOR SHELL	8	2		
01-02-50859	A 220 720 02 05	DOOR SHELL	8	2		
01-02-50860	A 220 860 03 05	SIDE BAG	24	6		
01-02-50861	A 220 860 04 05	SIDE BAG	24	6		
01-02-50862	A 220 720 00 16	DOOR CHECK	48	12		
01-02-50863	A 220 720 01 78	WEATHER STRIP	24	6		
01-02-50864	A 220 720 02 78	WEATHER STRIP	24	6		
01-02-50865	A 203 766 40 06 9999	KEY	100	25		
01-02-50866	A 220 760 01 70 9143	HANDLE	16	4		
01-02-50867	A 220 760 02 70 9143	HANDLE	16	4		
01-02-50868	A 220 760 03 34	BEARING CLAMP	16	4		
01-02-50869	A 220 760 04 34	BEARING CLAMP	16	4		
01-02-50870	A 220 720 01 35	LOCK	16	4		
01-02-50871	A 220 720 04 35	LOCK	16	4		
01-02-50872	A 140 760 03 41 9B51	CATCH	48	12		
01-02-50873	A 220 720 03 46	WINDOW REGULATOR	12	3		
01-02-50874	A 220 720 04 46	WINDOW REGULATOR	12	3		
01-02-50875	A 220 820 45 42	ELECTRIC MOTOR	8	2		
01-02-50876	A 220 820 46 42	ELECTRIC MOTOR	8	2		
01-02-50877	A 220 720 11 78	WEATHER STRIP	16	4		
01-02-50878	A 220 720 12 78	WEATHER STRIP	16	4		
01-02-50879	A 220 720 03 18	CRANK OPERATED WINDOW	12	3		
01-02-50880	A 220 720 04 18	CRANK OPERATED WINDOW	12	3		
01-02-50881	A 220 810 01 64 9143	PANELLING	80	20		
01-02-50882	A 220 810 02 64 9143	PANELLING	80	20		
01-02-50883	A 220 810 03 21	MIRROR GLASS	24	6		
01-02-50884	A 220 810 04 21	MIRROR GLASS	24	6		
01-02-50885	A 220 720 45 89 7211	COVER PLATE	12	3		
01-02-50886	A 220 720 48 89 7211	COVER PLATE	12	3		
01-02-50887	A 220 766 01 24	LEVER	32	8		
01-02-50888	A 220 766 02 24	LEVER	32	8		
01-02-50889	A 220 766 00 67	SPINDLE	32	8		
01-02-50890	A 124 988 09 78	CLIP	32	8		
01-02-50891	A 220 720 07 70 9B50	PANELLING	12	3		
01-02-50892	A 220 720 08 70 9B50	PANELLING	8	2		
01-02-50893	A 220 730 03 05	DOOR SHELL	4	1		
01-02-50894	A 220 730 04 05	DOOR SHELL	4	1		
01-02-50895	A 220 730 00 16	DOOR CHECK	48	12		
01-02-50896	A 220 730 03 78	WEATHER STRIP	24	6		
01-02-50897	A 220 730 04 78	WEATHER STRIP	24	6		
01-02-50898	A 220 730 23 78	WEATHER STRIP	16	4		
01-02-50899	A 220 730 24 78	WEATHER STRIP	16	4		
01-02-50900	A 220 760 01 70 9143	HANDLE	16	4		
01-02-50901	A 220 760 01 70 9143	HANDLE	16	4		
01-02-50902	A 220 760 17 34	MOUNTING	8	2		
01-02-50903	A 220 760 18 34	MOUNTING	8	2		
01-02-50904	A 220 730 39 35	DOOR LOCK	8	2		
01-02-50905	A 220 730 40 35 730	DOOR LOCK	8	2		
01-02-50906	A 140 766 04 38	BUSHING,PLASTIC	40	10		
01-02-50907	A 220 820 03 42	ELECTRIC MOTOR	8	2		
01-02-50908	A 220 820 04 42	ELECTRIC MOTOR	8	2		
01-02-50909	A 220 820 07 15	ELECTRIC CABLE	16	4		
01-02-50910	A 220 730 09 18	CRANK OPERATED WINDOW	12	3		
01-02-50911	A 220 730 10 18	CRANK OPERATED WINDOW	12	3		
01-02-50912	A 220 730 07 20	GLASS PANE	8	2		
01-02-50913	A 220 730 08 20	GLASS PANE	8	2		
01-02-50914	A 220 730 23 70 9B50	PANELLING	8	2		
01-02-50915	A 220 730 24 70 9B50	PANELLING	8	2		

01-02-50916	A 220 750 01 98	SEAL	32	8		
01-02-50917	A 220 750 01 93	HANDLE	12	3		
01-02-50918	A 220 750 07 87	HINGE	16	4		
01-02-50919	A 220 750 08 87	HINGE	16	4		
01-02-50920	A 220 757 01 29	SPRING	80	20		
01-02-50921	A 201 988 05 11	BUFFER	24	6		
01-02-50922	A 003 994 81 45	LOCK	64	16		
01-02-50923	A 220 750 05 84	FASTENER	28	7		
01-02-50924	A 220 758 00 58	MERCEDES STAR	40	10		
01-02-50925	A 201 997 22 81	GROMMET	120	30		
01-02-50926	A 140 817 32 15	TYPE DESIGNATION	40	10		
01-02-50927	A 220 750 04 91	TUMBLER	24	6		
01-02-50928	A 220 800 03 48	PUMP	48	12		
01-02-50929	A 220 800 00 77	CONNECTOR	40	10		
01-02-50930	A 202 800 04 53	COUPLING	240	60		
01-02-50931	A 202 805 02 44	PLUG	120	30		
01-02-50932	A 202 805 03 44	PLUG	120	30		
01-02-50933	A 202 800 02 53	COUPLING	120	30		
01-02-50934	A 202 800 05 53	COUPLING	200	50		
01-02-50935	A 202 805 01 44	PLUG	120	30		
01-02-50936	A 220 546 00 30	INSUALTING HOSE	8	2		
01-02-50937	A 202 800 07 53	COUPLING	200	50		
01-02-50938	A 000 158 14 35	VACUUM LINE	200	50		
01-02-50939	A 007 997 61 82	HOSE,HEATER ELEMENT,VLRUB	4	1		
01-02-50940	A 210 800 02 22	DISTRIBUTOR	40	10		
01-02-50941	A 170 800 00 22	DISTRIBUTOR	40	10		
01-02-50942	A 210 800 06 22	DISTRIBUTOR	40	10		
01-02-50943	A 000 987 11 45	CAP,INJECTION THROTTLE	80	20		
01-02-50944	A 220 800 00 53	COUPLING	20	5		
01-02-50945	A 004 997 98 90	LOOM TIE	240	60		
01-02-50946	A 005 997 62 90	LOOM TIE	32	8		
01-02-50947	A 220 820 38 42	ELECTRIC MOTOR	12	3		
01-02-50948	A 210 780 00 89	CABLE	16	4		
01-02-50949	A 210 780 01 89	CABLE	16	4		
01-02-50950	A 202 899 01 80	KEY	8	2		
01-02-50951	A 220 780 01 98	SEAL	16	4		
01-02-50952	A 220 780 00 21	SLIDING ROOF PLATE	4	1		
01-02-50953	A 220 780 00 13	RAIL	8	2		
01-02-50954	A 210 782 01 31	GUIDE	8	2		
01-02-50955	A 210 782 02 31	GUIDE	8	2		
01-02-50956	A 140 782 03 35	SPRING	24	6		
01-02-50957	A 220 821 60 51 7C45	SWITCH	32	8		
01-02-50958	A 220 820 20 10 7C45	SWITCH	16	4		
01-02-50959	A 220 821 87 51 7C45	SWITCH	48	12		
01-02-50960	A 220 821 92 51 7C45	SWITCH	48	12		
01-02-50961	A 220 820 10 10 7C45	SWITCH	48	12		
01-02-50962	A 220 820 12 10 7C45	SWITCH	720	180		
01-02-50963	A 220 821 15 58 7C45	KNOB	24	6		
01-02-50964	A 220 821 16 58 7C45	KNOB	24	6		
01-02-50965	A 220 820 06 45	WIPER BLADE	1200	300		
01-02-50966	A 220 820 17 44	WIPER ARM	24	6		
01-02-50967	A 220 820 19 44	WIPER ARM	24	6		
01-02-50968	A 220 820 01 41	LINKAGE	4	1		
01-02-50969	A 220 820 07 42	ELECTRIC MOTOR	16	4		
01-02-50970	A 140 988 01 11	RUBBER BUFFER	24	6		
01-02-50971	A 202 820 94 10	SWITCH	24	6		
01-02-50972	A 220 820 01 61	LIGHTING UNIT	8	2		
01-02-50973	A 220 820 02 61	LIGHTING UNIT	8	2		
01-02-50974	A 220 826 01 90	LENS	80	20		
01-02-50975	A 220 826 02 90	LENS	80	20		

01-02-50976	N400809 000007	BULB	800	200		
01-02-50977	A 220 826 01 91	SEAL RING	80	20		
01-02-50978	A 220 826 01 91	SEAL RING	80	20		
01-02-50979	N000000 000 375	BULB	240	60		
01-02-50980	A 220 820 30 26	CONTROL UNIT	8	2		
01-02-50981	A 220 820 01 64	TAIL LAMP	4	1		
01-02-50982	A 220 820 02 64	TAIL LAMP	4	1		
01-02-50983	A 220 820 03 56	LICENSE PLATE LAMP	40	10		
01-02-50984	N072601 012190	BULB	800	200		
01-02-50985	N400809 000000	BULB	800	200		
01-02-50986	N072601 012701	BULB	800	200		
01-02-50987	A 000 825 01 94	BULB	400	100		
01-02-50988	A 001 820 22 26	CONTROL UNIT	12	3		
01-02-50989	A 220 820 44 26	CONTROL UNIT	24	6		
01-02-50990	A 220 820 06 86	RADIO SET ASSEMBLY	20	5		
01-02-50991	A 220 830 00 62	HEATER CASE	12	3		
01-02-50992	A 220 830 23 15	ELECTRIC CABLE	8	2		
01-02-50993	A 210 830 10 18	PK DUST FILTER	80	20		
01-02-50994	A 001 990 73 91	NUT RETAINER	96	24		
01-02-50995	A 220 826 01 77	ORNAMENTAL COVER	40	10		
01-02-50996	A 210 830 11 18	FILTER	20	5		
01-02-50997	A 000 835 79 98	SEAL RING SET,VLRUB	20	5		
01-02-50998	A 210 830 10 58	EVAPORATOR	4	1		
01-02-50999	A 140 997 07 45	SEAL RING ,VLRUB	48	12		
01-02-51000	A 140 997 09 45	SEAL RING,VLRUB	48	12		
01-02-51001	A 003 830 23 15	PIPE LINE	8	2		
01-02-51002	A 220 830 02 72	TEMPERATURE SEN	40	10		
01-02-51003	A 220 830 01 72	GASEOUS POLLUTAPT SENSOR	8	2		
01-02-51004	A 220 830 01 85	OPERATING UNIT	24	6		
01-02-51005	A 220 830 02 85	OPERATING UNIT	16	4		
01-02-51006	A 230 830 01 84	VALVE	8	2		
01-02-51007	A 220 832 03 94	HOSE	20	5		
01-02-51008	A 220 832 05 94	HOSE	20	5		
01-02-51009	A 220 832 00 94	HOSE	20	5		
01-02-51010	A 220 832 01 94	HOSE	20	5		
01-02-51011	A 220 832 07 94	HOSE	20	5		
01-02-51012	A 220 832 44 94	HOSE	20	5		
01-02-51013	A 007 997 20 90	LOOM TIE	120	30		
01-02-51014	A 210 995 00 05	CLAMP	120	30		
01-02-51015	A 210 995 01 05	CLAMP	120	30		
01-02-51016	A 210 997 11 90	CLAMP	120	30		
01-02-51017	A 210 997 13 90	LOOM TIE	120	30		
01-02-51018	A 210 997 07 90	LOOM TIE	120	30		
01-02-51019	A 230 995 01 05	CLAMP	120	30		
01-02-51020	N916026 020001	CLAMP	120	30		
01-02-51021	A 005 997 01 90	LOOM TIE	120	30		
01-02-51022	N 000000 000668	CLAMP	120	30		
01-02-51023	A 220 830 03 96	HOSE	20	5		
01-02-51024	A 220 832 00 15	PIPE LINE	16	4		
01-02-51025	A 220 500 00 40	VALVE	12	3		
01-02-51026	A 220 830 08 96	HOSE	16	4		
01-02-51027	A 220 832 01 15	PIPE LINE	12	3		
01-02-51028	A 220 830 04 96	HOSE	16	4		
01-02-51029	A 220 830 00 96	HOSE	16	4		
01-02-51030	A 220 830 02 96	HOSE	16	4		
01-02-51031	A 220 830 02 84	VALVE	40	10		
01-02-51032	A 220 832 18 94	HOSE	24	6		
01-02-51033	A 220 832 40 94	HOSE	12	3		
01-02-51034	A 220 832 41 94	HOSE	12	3		
01-02-51035	A 140 832 05 99	RING,HVAC LINES,VLRUB	60	15		
01-02-51036	A 140 832 06 99	RING,HVAC LINES,VLRUB	40	10		

01-02-51037	A 220 830 00 83	TANK	60	15		
01-02-51038	A 220 830 34 15	PIPE LINE	24	6		
01-02-51039	A 220 997 02 45	SEAL RING	120	30		
01-02-51040	A 220 997 03 45	SEAL RING	120	30		
01-02-51041	A 140 997 06 45	SEAL RING,VLRUB	120	30		
01-02-51042	A 220 830 05 84	VALVE	32	8		
01-02-51043	A 140 830 00 72	TEMPERATURE SENSOR	40	10		
01-02-51044	A 210 830 00 72	TEMPERATURE SENSOR	40	10		
01-02-51045	A 033 545 67 28	PLUG	40	10		
01-02-51046	A 032 545 39 28	CONTACT SPRING	40	10		
01-02-51047	A 112 230 08 56	PIPE LINE	20	5		
01-02-51048	A 220 830 35 15	PIPE LINE	20	5		
01-02-51049	A 220 830 14 15	PIPE LINE	20	5		
01-02-51050	A 220 830 01 15	PIPE LINE	20	5		
01-02-51051	A 140 997 11 45	SEAL RING ,VLRUB	80	20		
01-02-51052	A 112 230 17 56	PIPE LINE	20	5		
01-02-51053	A 220 830 02 62	HEATER CASE	12	3		
01-02-51054	A 220 820 36 42	ELECTRIC MOTOR	8	2		
01-02-51055	A 220 830 03 58	EVAPORATOR	8	2		
01-02-51056	A 220 830 00 72	TEMPERATURE SENSOR	32	8		
01-02-51057	A 220 830 26 15	ELECTRIC CABLE	12	3		
01-02-51058	A 220 820 92 10	BLOWER REGULATOR	16	4		
01-02-51059	A 220 869 00 20	RESEVOIR	12	3		
01-02-51060	A 210 869 08 21	PUMP	80	20		
01-02-51061	A 220 860 05 92	HOSE	80	20		
01-02-51062	A220 540 00 45	SWITCH	32	8		
01-02-51063	A 220 997 19 81	GROMMET	60	15		
01-02-51064	A 123 997 36 81	GROMMET	60	15		
01-02-51065	A 220 860 01 47	NOZZLE	16	4		
01-02-51066	A 220 860 02 47	NOZZLE	16	4		
01-02-51067	A 203 860 01 47	NOZZLE	16	4		
01-02-51068	A 220 869 01 08	COVERING	24	6		
01-02-51069	A 124 869 01 72	CAP,W/WASHER RESERVE	40	10		
01-02-51070	A 220 830 00 61	HEATER UNIT	8	2		
01-02-51071	A 009 997 32 81	GROMMET	100	25		
01-02-51072	A 129 997 16 81	GROMMET	100	25		
01-02-51073	A 124 997 50 81	GROMMET	100	25		
01-02-51074	A 000 995 52 44	HASP	80	20		
01-02-51075	A 220 880 03 18	FRONT FENDER	16	4		
01-02-51076	A 220 880 04 18	FRONT FENDER	16	4		
01-02-51077	A 220 690 19 30	COVERING	20	5		
01-02-51078	A 220 690 22 30	COVERING	20	5		
01-02-51079	A 220 880 17 14	BRACKET	16	4		
01-02-51080	A 220 880 18 14	BRACKET	16	4		
01-02-51081	A 220 889 05 25	COVERING	16	4		
01-02-51082	A 220 889 06 25	COVERING	16	4		
01-02-51083	A 009 988 54 78	CLIP	96	24		
01-02-51084	A 220 690 25 30	COVERING	16	4		
01-02-51085	A 220 690 26 30	COVERING	16	4		
01-02-51086	A 220 690 15 30	COVERING	20	5		
01-02-51087	A 220 690 16 30	COVERING	20	5		
01-02-51088	A 001 988 26 78	CLIP	120	30		
01-02-51089	A 220 880 11 14	BRACKET	20	5		
01-02-51090	A 220 880 12 14	BRACKET	20	5		
01-02-51091	A 220 889 01 95	INTERMEDIATE LAYER	16	4		
01-02-51092	A 220 889 01 95	INTERMEDIATE LAYER	16	4		
01-02-51093	A 220 889 03 95	INTERMEDIATE LAYER	16	4		
01-02-51094	A 220 889 04 95	INTERMEDIATE LAYER	16	4		
01-02-51095	A 220 880 03 40	PANELLING	32	8		
01-02-51096	A 220 885 01 21 9143	RAIL	48	12		
01-02-51097	A 220 885 02 21 9143	RAIL	60	15		

01-02-51098	A 220 885 02 23	BUMPER JOINT COVER	56	14		
01-02-51099	A 220 885 11 23	BUMPER JOINT COVER	40	10		
01-02-51100	A 220 885 09 23	BUMPER JOINT COVER	48	12		
01-02-51101	A 220 880 04 05 9143	ESCUTCHEON	40	10		
01-02-51102	A 220 880 03 05 9143	ESCUTCHEON	32	8		
01-02-51103	A 220 885 03 23 9143	BUMPER JOINT COVER	48	12		
01-02-51104	A 220 885 11 37	ENERGY-ABSORBING UNIT	40	10		
01-02-51105	A 220 885 01 37	ENERGY-ABSORBING UNIT	40	10		
01-02-51106	A 220 885 02 37	ENERGY-ABSORBING UNIT	48	12		
01-02-51107	A 220 885 01 65	INSIDE PART	48	12		
01-02-51108	A 220 885 00 36	STAY	20	5		
01-02-51109	A220 885 09 23	MIDDLE GRILL	80	20		
01-02-51110	A220 885 11 23	LEFT GRILL	80	20		
01-02-51111	A220 885 02 23	RIGHT GRILL	120	30		
01-02-51112	112 589 010 900	PLUG WRENCH	20	5		
01-02-51113	A220 885 0174	CROME PLATE LEFT	160	40		
01-02-51114	A220 885 02 74	CROME PLATE RIGHT	200	50		
01-02-51115	A220 885 01 25	RUBBER LEFT	20	5		
01-02-51116	A220 885 02 25	RUBBER RIGHT	20	5		
01-02-51117	A004 994 45 45	CLAMP	240	60		
01-02-51118	A220 889 00 90	SPACER	100	25		
01-02-51119	A220 887 01 27	RELEASE HANDLE	240	60		
01-02-51120	A220 885 03 74	CROME PLATE. L	80	20		
01-02-51121	A220 885 00 74	CROME PLATE. M	80	20		
01-02-51122	A220 885 04 74	CROME PLATE. R	80	20		
01-02-51123	A 220 880 01 40	PANELLING	20	5		
01-02-51124	A 220 885 09 21 9143	RAIL	32	8		
01-02-51125	A 220 885 10 21 9143	RAIL-R	32	8		
01-02-51126	A 220 885 11 21 9143	RAIL-CENTER	32	8		
01-02-51127	A 220 880 01 52	INSIDE PART	24	6		
01-02-51128	A 220 610 05 20	CROSS MEMBER	20	5		
01-02-51129	A 220 885 09 37	ENERGY-ABSORBING UNIT	12	3		
01-02-51130	A 220 885 05 37	ENERGY-ABSORBING UNIT	12	3		
01-02-51131	A 220 885 06 37	ENERGY-ABSORBING UNIT	12	3		
01-02-51132	A 220 885 04 23 9143	BOMBER JOINT COVER	20	5		
01-02-51133	A 220 885 01 63	GUIDE	16	4		
01-02-51134	A 220 885 02 63	GUIDE	16	4		
01-02-51135	A 220 880 01 57	ENGINE HOOD	12	3		
01-02-51136	A 220 880 02 05 9143	VENTILATION SCREEN	20	5		
01-02-51137	A 220 880 01 05	COVERING	12	3		
01-02-51138	A 210 880 01 86	MERCEDES STAR	120	30		
01-02-51139	A 220 889 08 95	INTERMEDIATE LAYER	24	6		
01-02-51140	A 220 880 03 29	SPRING	100	25		
01-02-51141	A 220 880 01 28	HINGE	12	3		
01-02-51142	A 220 880 02 28	HINGE	12	3		
01-02-51143	A 220 880 01 20	HANDLE	20	5		
01-02-51144	A 220 880 03 59	ENGINE HOOD RELEASE CABLE	8	2		
01-02-51145	A 220 880 02 59	ENGINE HOOD RELEASE CABLE	12	3		
01-02-51146	A 220 880 00 29	SPRING	16	4		
01-02-51147	A 220 682 00 26	INSULAtion	24	6		
01-02-51148	A 201 990 02 92 9051	RIVET	800	200		
01-02-51149	A 010 988 28 78	CLIP	40	10		
01-02-51150	A 220 880 03 60	ENGINE HOOD CATCH	24	6		
01-02-51151	A 220 880 01 60	ENGINE HOOD CATCH	24	6		
01-02-51152	A 000 988 16 25	TREENAIL	80	20		
01-02-51153	A 220 880 02 64	SAFETY HOOK	20	5		
01-02-51154	A 220 887 01 23	END PIECE	40	10		
01-02-51155	A 201 988 05 11	BUFFER	60	15		
01-02-51156	A 220 988 01 11	BUFFER	16	4		
01-02-51157	A 220 889 00 90	SPACER	48	12		
01-02-51158	A 220 889 03 98	SEAL	24	6		

01-02-51159	A 220 270 05 00	AUTOMATIC TRANSMISSION	40	10		
01-02-51160	A 210 250 07 02	CONVERTER	16	4		
01-02-51161	N007603010100	SEAL RING,VLRUB	40	10		
01-02-51162	A 124 990 22 01	SCREW	48	12		
01-02-51163	A 010 997 47 47	SEAL RING	80	20		
01-02-51164	A 016 997 14 48	SEAL RING.TRANSMISN.VLRUB	120	30		
01-02-51165	A 140 277 42 14	INTERMEDIATE PLATE	96	24		
01-02-51166	A 210 270 23 28	DISC SUPPORT	16	4		
01-02-51167	A 140 993 20 26	DISC SPRING	8	2		
01-02-51168	A 140 993 18 26	DISC SPRING	12	3		
01-02-51169	A 140 272 02 26	OUTER DISC	32	8		
01-02-51170	A 140 272 04 26	OUTER DISC	32	8		
01-02-51171	A 140 272 28 26	OUTER DISC	64	16		
01-02-51172	A 140 272 00 25	INNER DISC	4	1		
01-02-51173	A 140 994 87 40	SNAP RING	32	8		
01-02-51174	A 140 994 88 40	SNAP RING	40	10		
01-02-51175	A 140 994 89 40	SNAP RING	40	10		
01-02-51176	A 140 994 29 35	SNAP RING	32	8		
01-02-51177	A 210 270 41 28	DISC SUPPORT	12	3		
01-02-51178	A 210 270 00 31	FRE WHEEL UNIT	20	5		
01-02-51179	A 140 994 54 35	SNAP RING	24	6		
01-02-51180	A 140 272 22 55	SEAL RING	32	8		
01-02-51181	A 140 997 39 45	SEAL RING	24	6		
01-02-51182	A 140 272 14 31	PISTON	12	3		
01-02-51183	A 140 993 09 26	DISC SPRING	12	3		
01-02-51184	A 140 993 18 26	DISC SPRING	4	1		
01-02-51185	A 140 272 02 26	OUTER DISC	32	8		
01-02-51186	A 140 272 28 26	OUTER DISC	60	15		
01-02-51187	A 140 272 04 26	OUTER DISC	32	8		
01-02-51188	A 140 272 00 25	INNER DISC	128	32		
01-02-51189	A 140 994 30 35	SNAP RING	12	3		
01-02-51190	A 210 270 13 43	PLANETARY CARRIER	20	5		
01-02-51191	A 140 981 20 10	NEEDLE BEARING	20	5		
01-02-51192	A 140 981 21 10	NEEDLE BEARING	20	5		
01-02-51193	A 210 270 11 25	DRIVE SHAFT	12	3		
01-02-51194	A 140 272 11 55	SEAL RING	72	18		
01-02-51195	A 140 272 27 55	SEAL RING	24	6		
01-02-51196	A 020 981 33 10	NEEDLE BEARING	16	4		
01-02-51197	A 140 272 08 55	SEAL RING	24	6		
01-02-51198	A 140 272 20 62	GUARD PLATE	40	10		
01-02-51199	A 220 993 00 26	DISC SPRING	8	2		
01-02-51200	A 140 272 06 26	OUTER DISC	24	6		
01-02-51201	A 140 272 29 26	OUTER DISC	72	18		
01-02-51202	A 140 272 08 26	OUTER DISC	24	6		
01-02-51203	A 210 270 03 45	ANNULUS	12	3		
01-02-51204	A 210 272 00 25	INNER DISC	60	15		
01-02-51205	A 140 994 92 40	SNAP RING	24	6		
01-02-51206	A 140 994 93 40	SNAP RING	40	10		
01-02-51207	A 140 994 94 40	SNAP RING	40	10		
01-02-51208	A 140 994 32 35	SNAP RING	24	6		
01-02-51209	A 140 993 10 26	DISC SPRING	8	2		
01-02-51210	A 140 994 09 35	SNAP RING	12	3		
01-02-51211	A 210 270 07 26	SHAFT	12	3		
01-02-51212	A 140 272 13 55	SEAL RING	80	20		
01-02-51213	A 140 981 05 10	NEEDLE BEARING	20	5		
01-02-51214	A 140 981 12 10	NEEDLE BEARING	20	5		
01-02-51215	A 210 272 01 62	GUARD PLATE	40	10		
01-02-51216	A 210 981 09 10	NEEDLE BEARING	20	5		
01-02-51217	A 210 981 10 10	NEEDLE BEARING	20	5		
01-02-51218	A 210 272 02 08	ANNULUS	16	4		
01-02-51219	A 210 270 15 43	PLANETARY CARRIER	16	4		

01-02-51220	A 210 272 08 07	SUN GEAR	16	4		
01-02-51221	A 140 997 42 45	SEAL RING	32	8		
01-02-51222	A 140 994 53 35	SNAP RING	12	3		
01-02-51223	A 140 270 05 31	FREEWHEEL UNIT	20	5		
01-02-51224	A 210 270 16 44	SUN GEAR	16	4		
01-02-51225	A 140 272 23 62	GUARD PLATE	16	4		
01-02-51226	A 140 994 57 35	SNAP RING	12	3		
01-02-51227	A 210 272 00 52	SPACER WASHER	24	6		
01-02-51228	A 140 994 99 40	SNAP RING	16	4		
01-02-51229	A140 994 10 35	SNAP RING	16	4		
01-02-51230	A140 994 11 35	SNAP RING	16	4		
01-02-51231	A140 994 35 35	SNAP RING	16	4		
01-02-51232	A 140 272 12 26	OUTER DISC	24	6		
01-02-51233	A 140 272 27 26	OUTER DISC	96	24		
01-02-51234	A 140 272 10 26	OUTER DISC	32	8		
01-02-51235	A 140 993 21 26	DISC SPRING	24	6		
01-02-51236	A 140 994 52 35	SNAP RING	12	3		
01-02-51237	A 140 993 11 26	DISC SPRING	12	3		
01-02-51238	A 140 272 24 55	SEAL RING	16	4		
01-02-51239	A 210 270 13 28	DISC SUPPORT	16	4		
01-02-51240	A 140 272 16 62	GUARD PLATE	40	10		
01-02-51241	A 140 981 11 10	NEEDLE BEARING	20	5		
01-02-51242	A 140 272 15 62	GUARD PLATE	40	10		
01-02-51243	A 140 272 19 62	GUARD PLATE	40	10		
01-02-51244	A 140 272 22 62	GUARD PLATE	40	10		
01-02-51245	N000471 035000	LOCK RING	24	6		
01-02-51246	A 140 272 06 64	SPRING RETAINER	8	2		
01-02-51247	A 140 993 16 26	DISC SPRING	8	2		
01-02-51248	A 140 270 05 68	PISTON GUIDE RING	8	2		
01-02-51249	A 140 272 19 55	SEAL RING	16	4		
01-02-51250	A 140 272 20 55	SNAP RING	16	4		
01-02-51251	A 140 272 20 31	PISTON	8	2		
01-02-51252	A 140 272 26 55	SNAP RING	16	4		
01-02-51253	A 210 272 11 31	PISTON	16	4		
01-02-51254	A 140 997 20 45	SNAP RING	24	6		
01-02-51255	A 140 272 16 55	SNAP RING	16	4		
01-02-51256	A 140 272 17 55	SNAP RING	16	4		
01-02-51257	A 140 270 06 68	PLUNGER GUIDE	8	2		
01-02-51258	A 140 994 63 35	SNAP RING	24	6		
01-02-51259	A 140 994 62 35	SNAP RING	24	6		
01-02-51260	A 140 994 61 35	SNAP RING	24	6		
01-02-51261	A 140 994 60 35	SNAP RING	24	6		
01-02-51262	A 140 994 59 35	SNAP RING	24	6		
01-02-51263	A 140 272 00 26	OUTER DISC	160	40		
01-02-51264	A 140 272 04 25	INNER DISC	160	40		
01-02-51265	A 140 272 14 26	OUTER DISC	32	8		
01-02-51266	A 140 993 19 26	DISC SPRING	24	6		
01-02-51267	A 140 272 23 26	OUTER DISC	24	6		
01-02-51268	A 140 990 55 01	SCREW	24	6		
01-02-51269	A 140 994 15 35	SNAP RING	40	10		
01-02-51270	A 140 994 16 35	SNAP RING	20	5		
01-02-51271	A 140 994 17 35	SNAP RING	20	5		
01-02-51272	A 140 994 41 35	SNAP RING	20	5		
01-02-51273	A 140 994 42 35	SNAP RING	20	5		
01-02-51274	A 140 994 43 35	SNAP RING	20	5		
01-02-51275	A 140 272 06 25	INNER DISC	16	4		
01-02-51276	A 140 272 18 26	OUTER DISC	160	40		
01-02-51277	A 140 272 24 26	OUTER DISC	24	6		
01-02-51278	A 140 993 22 26	DISC SPRING	24	6		
01-02-51279	A 140 271 26 01	HOUSING	8	2		
01-02-51280	A 140 270 02 50	PLUG ADAPTER	32	8		

01-02-51281	A 026 997 41 48	SEAL RING	120	30		
01-02-51282	A 026 997 40 48	SEAL RING	120	30		
01-02-51283	A 140 272 06 52	SPACER WASHER	100	25		
01-02-51284	A 140 272 07 52	SPACER WASHER	80	20		
01-02-51285	A 140 272 08 52	SPACER WASHER	60	15		
01-02-51286	A 140 272 09 52	SPACER WASHER	40	10		
01-02-51287	A 140 981 01 25	BALL BEARING	24	6		
01-02-51288	A 140 997 08 46	SEAL RING	100	25		
01-02-51289	A 140 990 11 50	NUT	160	40		
01-02-51290	A 210 272 04 45	FLANGE	8	2		
01-02-51291	A 126 270 01 82	BREATHER	8	2		
01-02-51292	A 140 997 21 45	SEAL RING	40	10		
01-02-51293	A 140 997 23 45	SEAL RING	40	10		
01-02-51294	A 022 997 87 48	SEAL RING	40	10		
01-02-51295	A 140 270 01 50	GUIDE BUSHING	8	2		
01-02-51296	A 140 994 56 35	SNAP RING	20	5		
01-02-51297	A 140 270 06 06	VALVE GEAR	4	1		
01-02-51298	A 140 270 05 61	ELECTRIC KIT	40	10		
01-02-51299	A 140 270 02 98	FILTER	96	24		
01-02-51300	A 140 277 04 35	VALVE	16	4		
01-02-51301	A 140 277 05 35	VALVE	40	10		
01-02-51302	A 140 277 03 98	LIFTING MAGNET	32	8		
01-02-51303	A 140 270 04 98	FILTER	96	24		
01-02-51304	A 140 270 08 12	OIL PAN	4	1		
01-02-51305	A 140 271 00 80	GASKET	40	10		
01-02-51306	A 140 277 00 95	OIL FILTER	40	10		
01-02-51307	A 140 271 00 68	CLAMPING BODY	40	10		
01-02-51308	A 140 271 01 68	CLAMPING BODY	40	10		
01-02-51309	N000000 000648	SCREW PLUG	160	40		
01-02-51310	A 000 997 65 32	SCREW PLUG	16	4		
01-02-51311	A 126 997 01 32	SCREW PLUG	16	4		
01-02-51312	A 220 271 00 98		16	4		
01-02-51313	A 140 991 00 55	LOCK PIN	20	5		
01-02-51314	A 140 270 00 91	COVER	20	5		
01-02-51315	A 220 270 02 84	OIL FILLER PIPE	8	2		
01-02-51316	A 022 997 22 48	SEAL RING	200	50		
01-02-51317	A 022 997 55 82	HOSE	40	10		
01-02-51318	A 020 997 39 82	HOSE	40	10		
01-02-51319	A 000 828 03 88	BATTERY SET	320	80		
01-02-51320	A 001 989 21 03 10	TRANSMISSION OIL	4800	1200		
01-02-51321	A 000 989 08 07 10	BRAKE FLUID	2000	500		
01-02-51322	A 000 989 08 25	ANTIFREEZE	1200	300		
01-02-51323	A 001 989 37 51 10	PROTECTIO GREASE	200	50		
01-02-51324	W 140 589 34 63 00	SUPPLATE	4	1		
01-02-51325	W 112 589 00 25 00	PULLER	8	2		
01-02-51326	W 112 589 00 32 00	PLATE	8	2		
01-02-51327	W 112 589 01 32 00	PLATE	8	2		
01-02-51328	W 220 589 00 99 00	ELECTRICAL CONNECT SET	12	3		
01-02-51329	W 001 589 76 09 00	TORX-SET 9 PIECES	24	6		
01-02-51330	W 000 589 01 10 00	TORX-SET 10 PIECES	24	6		
01-02-51331	W 000 589 03 10 00	SOCKET	24	6		
01-02-51332	W 000 589 04 10 00	SPANNER	24	6		
01-02-51333	W 112 589 01 03 00	SPANNER	12	3		
01-02-51334	W 112 589 00 01 00	SPANNER	8	2		
01-02-51335	A001 989 24 03 10	OIL	600	150		
01-02-51336	A 002 989 73 20 10	RADIATOR SEAL KIT	600	150		
01-02-51337	W 140 589 15 21 00	MEASURING STICK	16	4		
01-02-51338	00 1 589 72 21 00	TORQUE WRENCH	12	3		
01-02-51339	00 1 589 72 21 02	SOCKET RATCHET	4	1		
01-02-51340	00 1 589 73 21 00	MANUAL VACUUM PUMP	8	2		
01-02-51341	112 589 00 25 00	EXTRACTION GUN	4	1		

01-02-51342	116 589 02 07	T-HANDLE ALAN 5	8	2		
01-02-51343	116 589 03 07	T-HANDLE ALAN 6	12	3		
01-02-51344	00 1 589 77 21	COMPRESSION RECORDER	4	1		
01-02-51345	00 1 589 77 21 13	GRAPH SHEETS	8	2		
01-02-51346	112 589 01 09 00	SPARK PLUG WRENCH	20	5		
01-02-51347	124 589 24 21 00	TESTER	8	2		
01-02-51348	124 589 24 21 02	PRESS -HOSE	8	2		
01-02-51349	210 589 00 91 00	TEST CAP	8	2		
01-02-51350	210 589 03 63 00	ADOPTER	4	1		
01-02-51351	00 1 589 50 33 00	PULLER	4	1		
01-02-51352	140 589 06 34 00	CLAMPING PLIERS	4	1		
01-02-51353	126 589 04 09 00	SOCKET	8	2		
01-02-51354	126 589 12 63 00	FUNNEL	4	1		
01-02-51355	140 589 43 63 00	TEST CABLE 30 PIN	4	1		
01-02-51356	140 589 12 21 00	CURRENT TESTER	4	1		
01-02-51357	140 589 13 21 00	CURRENT TESTER	4	1		
01-02-51358	000 833 03 61	EXTROCTION -RADIO	8	2		
01-02-51359	609 -E10 X E12	DOUBLE TOREX BOX WRENCH E10XE12	12	3		
01-02-51360	E4 UNTIL E24	DOUBLE TOREX BOX WRENCH SET	12	3		
01-02-51361	220 830 03 72	SENSOR	32	8		
01-02-51362	220 830 00 84	VALVE	24	6		
01-02-51363	R134 A	A.C GAS KG	400	100		
01-02-51364	00 1 989 08 03	A.C COMP OIL LITER	32	8		

SPARE PARTS FOR TOYOTA LANDCRUISER

CODE	PART NO.	DESCRIPTION	QTY			
01-02-51365	15102-66020	ROTOR SET	250			
01-02-51366	15163-66021	GEAR OIL	250			
01-02-51367	31111-60300	HOUSING	50			
01-02-51368	31204-36110	FORK	250			
01-02-51369	42431-60220	DISC	50			
01-02-51370	38110-60250	WINCH	50			
01-02-51371	36130-6A120	TRANSFER	50			
01-02-51372	33403-69325	GEAR	250			
01-02-51373	42431-60210	DRAM	150			
01-02-51374	42301-60901	SHAFT	50			
01-02-51375	42302-60901	SHAFT	50			
01-02-51376	44320-60300	PUMP ASSY	100			
01-02-51377	44610-6A060	POSTER	100			
01-02-51378	77001-60510	TANK	50			
01-02-51379	85330-35080	MOTOR	100			
01-02-51380	85330-35070	MOTOR	100			

SPARE PARTS FOR TOYOTA PICK UP

CODE	PART NO.	DESCRIPTION	QTY			
01-02-51381	11301-75021	CASE SUB	100			
01-02-51382	16711-75090	SHROUDFAN	250			
01-02-51383	17141-75080	MAINFOLD	250			
01-02-51384	17111-75040	MAINFOLD	250			
01-02-51385	17700-75260	CLEANER	50			
01-02-51386	25860-75041	VALVE	100			
01-02-51387	19144-75040	LEAD-DISTRBUTOR	100			
01-02-51388	21062-75110	SOLINOID	100			
01-02-51389	31204-20071	FORK	50			
01-02-51390	31111-26032	HOUSING	50			
01-02-51391	33103-30201	HOUSING	50			

01-02-51392	33403-19245	GEAR	100			
01-02-51393	42431-26081	DRUM	50			
01-02-51394	42301-35090	SHAFT	50			
01-02-51395	45100-26250-CO	WHEEL STERING	50			
01-02-51396	45130-26240-CO	BUTTON HORN	50			
01-02-51397	44610-3D770	BOOSTER	100			
01-02-51398	87910-35480	MIRROR	100			
01-02-51399	87940-35450	MIRROR	100			

SPARE PARTS FOR FG WELSON 1000 KVA TYPE OF ENGINE PERKINS 4008 TAG2

CODE	PART NO.	QTY				
01-02-51400	ENGINE OVER HAUL KIT	30				
01-02-51401	CONNECTING ROD & BEARING	30				
01-02-51402	CRANK SHAFT BEARING-s ALL SIZES	30				
01-02-51403	OIL PUMP	10				
01-02-51404	FUEL PUMP	10				
01-02-51405	TURBO CHARGER	10				
01-02-51406	TURBO CHARGER REPAIR KIT	30				
01-02-51407	WATER PUMP	10				
01-02-51408	WATER PUMP REPAIR KIT	30				
01-02-51409	STARTOR MOTOR	10				
01-02-51410	OIL PRESS SENSOR	30				
01-02-51411	HIGH WATER TEME J	30				
01-02-51412	AVR1000 K.V.A F002430 MX321	14				
01-02-51413	AIRFILTERCV 96850	50				
01-02-51414	OILFILTERCV2473	50				
01-02-51415	DIGITAL SPEED CONTROL PROACT MODEL 1- WOOD WORD	18				
01-02-51416	ACTUATOR	18				
01-02-51417	MAGNETIC PICKUP	18				
01-02-51418	FUEL SELOUIED VALUE	18				
01-02-51419	FUEL FILTER 0019596	50				
01-02-51420	PCB FOR 4001 CONTROL PANEL	10				
01-02-51421	WOODWARD HANDHELD PROGRAMER 9905-292	1				
01-02-51422	SERVICE TOOL T 6253/177	1 SET				

Spare parts for 500 k.v.a FG WELSON TYPE OF ENGINE PERKINS 3008 TAG4

01-02-51423	Engine over haul kit GASKETS)	30				
01-02-51424	ConnECTING rod & bearing	30				
01-02-51425	Crank shaft bearing A LL sizes	30				
01-02-51426	Oil pump	10				
01-02-51427	Fuel pump INJECTION	10				
01-02-51428	Turbo charger	10				
01-02-51429	TURBO CHARGER REPAIR KIT	30				
01-02-51430	WATER PUMP	10				
01-02-51431	WATER PUMP REPAIR KIT	30				
01-02-51432	STARTOR MOTOR	10				
01-02-51433	OIL PRESS SENSOR	30				
01-02-51434	HIGH WATER TEME SENSOR	30				
01-02-51435	AVR500KVAF002430 SX440	14				
01-02-51436	AIRFILTER CV 9685	50				
01-02-51437	OILFILTER CV 2473	50				
01-02-51438	FUELFILTER 0019596	50				

01-02-51439	MAGNETIC PICKUP FOR (EIM+)	18				
01-02-51440	FUEL SELOUIED VALVE	18				
SPARE PARTS FOR GENERATORS 750 KVA SDMO TYPE OF ENGINE PERKINS 3012 TAG3A						
01-02-51441	1- oil press sensor	330220219	25			
01-02-51442	2- high water temp sens	330220218	25			
01-02-51443	3- over speed sensor	RV2	25			
01-02-51444	4- oil temp sensor	330220220	25			
01-02-51445	5- turbo charger repairkit	330220169	25			
01-02-51446	6- water pump repairkit	330220159	25			
01-02-51447	7-fanveebelt 3031485	330220004	25			
01-02-51448	8- fuel sTop selenoid	330030575	25			
01-02-51449	9- air filter	330220023	100			
01-02-51450	10-oil filter	330220011	100			
01-02-51451	11-fuel filter	330220012	100			
01-02-51452	12- injector complete	330220022	25			
01-02-51453	13- starter motor	330030560	25			
01-02-51454	automatic voltage					
01-02-51455	14-regulator	330410011	25			
01-02-51456	15- rotating disc	3305262607	25			
01-02-51457	16-frequency metcr	3352556524	25			
01-02-51458	17-voltmeter	3352556852	25			
01-02-51459	18-motorised(MCCB)	3352659545	25			
01-02-51460	For ats					
01-02-51461	19- engine overhaul kit	CVK523+CVK502+CVK504	25			
01-02-51462	20-connecting rod big & BEARING	KRP3007+KRP3007010+KRP300/020	50			
01-02-51463	21- crank shaft bearing	KRP3106/010+KRP3106/020				
01-02-51464	22- oil pump	CV 182927	25			
01-02-51465	23- fuel oil pump	CV11445/118	25			
01-02-51466	24- water pump	CV1457312	50			
01-02-51467	25- starter motor relay	3050687	50			
01-02-51468	26- turbo charger	CV13727/1Z	25			
01-02-51469	27- spare cards & relays	SETA2	25			
01-02-51470	28- pick up sensor	CVK571-1	50			
01-02-51471	29- actuator & electronic MODUL	CVK571-2	50			
01-02-51472	30- over speed thresholdRELAY	RV2-1	50			
01-02-51473	31-ALTERNATOR COMPLETE		5			
SPARE PARTS FOR GENERATORS 500 KVA SDMO type of engine cummins kta19g4						
01-02-51474	1- oil press sensor	3056344	25			
01-02-51475	2- high water temp sens	3056353	25			
01-02-51476	3- over speed sensor	RV2	25			
01-02-51477	4- oil temp sensor	330220220	25			
01-02-51478	5- fan vee belt	330030012	25			
01-02-51479	6- stop selenoid	334286455	25			
01-02-51480	7- air filter	330560046	100			
01-02-51481	8- oil filter	330560510	100			
01-02-51482	9- fuel filter	330560505	100			
01-02-51483	10- nozzle injector	330684125	25			
01-02-51484	11 - starter motor	330030726	25			
01-02-51485	12-regulator	330410089	25			
01-02-51486	13-rotating disc	3305289412	25			
01-02-51487	14-voltmeter	3352556852	25			
01-02-51488	15-moTorised(MCCB)For ats	33526595 12	25			
01-02-51489	16- engine overhaul kit	3028434+AR12313+	25			
		AR 10680+3801005				

01-02-51490	17- connecting rod big& BEARING	205841+205842	50			
01-02-51491	18- CRANK SHAFT BEARING	AR12271+AR12272	50			
01-02-51492	19 OIL PUMP	3047549	25			
01-02-51493	20-FUEL OIL PUMP	3059651	25			
01-02-51494	21- WATER PUMP	3011389	50			
01-02-51495	22- STATER MOTOR RELAY	3050692	50			
01-02-51496	23-TURBO CHARGER	3801697	25			
01-02-51497	24- SPARE CARDS & RELAYS	A2SET	25			
01-02-51498	25- PICK UP SENSOR	213272	50			
01-02-51499	26- ACTUATOR & ELECTRONIC MODUL	3052768+3044196	50			
01-02-51500	27- OVER SPEED THRESHOLD RELAY	RV2-1	50			
01-02-51501	28- FREQUENCY METER	3352556524	25			
01-02-51502	29- WATER PUMP REPAIR KIT	330030729	50			
01-02-51503	30- TURBO CHARGER	3801697	25			
01-02-51504	31-ALTERNATOR COMPLETE		5			
SPARE PARTS FOR GENERATORS 1000KVA SDMO TYPE OF ENGINE CIMMINS KTA38G3A4AS						
01-02-51505	1- oil press sensor	330030588	25			
01-02-51506	2- high water Temp sens	330220218	25			
01-02-51507	3-over speed sensor	RV2	25			
01-02-51508	4- oil temp sensor	330220220	25			
01-02-51509	5- turbo charger repairkit	330525452	25			
01-02-51510	6- water pump repairkit	330030729	25			
01-02-51511	7-fanveebelt 3031485	330030517	25			
01-02-51512	8- fuel stop selenoid	330030586	25			
01-02-51513	9- air filler	330560500	100			
01-02-51514	10-oil filter	330560510	100			
01-02-51515	11- fuel filter	330560505	100			
01-02-51516	12- injector complete	330684253	25			
01-02-51517	13-starter motor	330030284	25			
01-02-51518	automatic voltage					
01-02-51519	14- regulator	330410107	25			
01-02-51520	15- rotating disc	3305262541	25			
01-02-51521	16- frequency meter	3352556524	25			
01-02-51522	17- voltmeter	3352556852	25			
01-02-51523	18-motorised(MCCB)	3352659543	25			
01-02-51524	For ats					
01-02-51525	19- engine overhaul kit	3007585+AR12313+ AR 10680+3801720	25			
01-02-51526	20- connecting rod big & BEARING	3047391+3047392	50			
01-02-51527	21- CRANK SHAFT BEARING	AR12251+AR12252	50			
01-02-51528	22- OIL PUMP	AR12387	25			
01-02-51529	23 - FUEL OIL PUMP	3279629	25			
01-02-51530	24- WATER PUMP	3050443	50			
01-02-51531	25-STARTER MOTOR RELAY	3050692	50			
01-02-51532	26- TURBO CHARGER	3801885	25			
01-02-51533	27- SPARE CARDS& RELAYS	A2SET	25			
01-02-51534	28- PICK UP SENSOR	30399524	50			
01-02-51535	29- ACTUATOR & ELECTRONIC MODUL	3176891+3044196	50			
01-02-51536	30- OVER SPEED THRESHOLD RELAY	RV2	50			
01-02-51537	31-ALTERNATOR COMPLETE		5			
SPARE PARTS FOR TB 340 (6x4)						
NO.	REFERENCE	DESIGNATION E	COEF.	Qte.	GPE	IE

01-02-51538	38166	PLUG	1	5	G1010	8
01-02-51539	72568	UNIONS SCREW	1	20	G0117	5
01-02-51540	127161	PLUG	1	15	G0107	8
01-02-51541	136065	SPRING	1	10	G0416	18
01-02-51542	141306	REAR CASING	1	10	G0120	2
01-02-51543	145613	PIN	1	10	G0120	3
01-02-51544	149310	PLUG	2	20	G1362	10
01-02-51545	150193	PLUG	6	18	G0119	2
01-02-51546	150769	ADJUSTING SCREW	12	25	G0125	17
01-02-51547	153298	FLANGE SET (STD DIMENSIONS)	2	12	G0119	6
01-02-51548	153301	FLANGE (0.75)	2	6	G0119	6
01-02-51549	154527	SCREW	8	40	G0120	5
01-02-51550	157157	CONNECTION PIPE	1	5	G0126	12
01-02-51551	157454	COMPRESSION SPRING	1	5	G0126	7
01-02-51552	170685	NUT	2	10	G0921	20
01-02-51553	171022	STOP PLATE	2	10	G1015	19
01-02-51554	173165	ROLLER	4	20	G0922	17
01-02-51555	174268	RETURN SPRING	2	10	G1015	16
01-02-51556	184086	CLOSING PLATE	2	10	G0922	6
01-02-51557	184091	RUN UP PIN	4	20	G1016	12
01-02-51558	184092	PIN	4	20	G0922	18
01-02-51559	184224	BUSH	2	10	G1015	18
01-02-51560	185159	PLUG	2	20	G0609	3
01-02-51561	185879	THRUST WASHER	2	10	G0909	13
01-02-51562	186464	PLATE	2	20	G0609	7
01-02-51563	188148	SPRING	1	5	G1014	9
01-02-51564	188185	DRAIN PLUG	1	100	G0407	14
01-02-51565	189388	OIL RETAINER PLATE	2	10	G1009	10
01-02-51566	189927	JOINT PROTECTING PLATE	2	10	G1009	9
01-02-51567	190058	PLATE	1	5	G0913	11
01-02-51568	190220	WHEEL BOLT 22X150	20	200	G0609	2
01-02-51569	190293	SCREW (12X22)	4	60	G0909	3
01-02-51570	190306	BUSH	2	20	G0608	8
01-02-51571	190339	DRIVEN GEAR	1	5	G0918	16
01-02-51572	190341	INTERMEDIATE GEAR	1	10	G0917	8
01-02-51573	190346	SUPPORTING WASHER	1	5	G0914	9
01-02-51574	190349	ADJUSTING WASHER (2.7)	1	5	G0914	10
01-02-51575	190350	ADJUSTING WASHER (3.4)	1	5	G0914	10
01-02-51576	190352	INTER CASING PLUG	1	5	G0911	12
01-02-51577	190353	WASHER (18)	1	5	G0911	13
01-02-51578	190356	WASHER (15)	1	5	G0911	13
01-02-51579	190375	BRACKET	1	5	G0911	19
01-02-51580	190424	PLATE	1	10	G0916	13
01-02-51581	190444	DIFFERENTIAL BRACKET	1	5	G0912	1
01-02-51582	190716	DIFFERENTIAL PINION	4	20	G0914	15
01-02-51583	190912	BRAKE LEVER	2	10	G1015	15
01-02-51584	191760	RECUPERATOR THROUGH	1	5	G0916	2
01-02-51585	191913	LEFT DIFFERENTIAL SHAFT	1	5	G1009	11
01-02-51586	192031	BEARING HOUSING	1	5	G0916	4
01-02-51587	192032	JOINT HOLDER HOUSING	1	5	G0916	7
01-02-51588	192033	ADJUSTMENT WASHER	1	5	G0916	6
01-02-51589	192034	SLEEVE	1	5	G0916	12
01-02-51590	192039	INTERMEDIATE SHAFT	1	5	G0917	1
01-02-51591	192040	REAR CASING	1	5	G0911	2
01-02-51592	192041	FRONT CASING	1	5	G0911	1
01-02-51593	192078	RIGHT BRACKET	1	5	G0921	5
01-02-51594	192079	LEFT BRACKET	1	5	G1015	4
01-02-51595	192170	SPACER	1	5	G0917	5
01-02-51596	192172	SPACER	1	5	G0917	5
01-02-51597	192881	LEFT BRACKET	2	10	G1114	44

01-02-51598	193098	SPRING	2	10	G1016	14
01-02-51599	193102	WASHER	32	160	G0922	10
01-02-51600	193497	DIFFERENTIAL PINION THRUST	4	20	G0914	5
01-02-51601	193949	CONTROL PINION	1	5	G0914	11
01-02-51602	193956	FRONT HOUSING	1	5	G0913	1
01-02-51603	193972	DEFLECTOR	1	5	G0913	7
01-02-51604	193990	REAR PLANET GEAR	1	5	G0914	14
01-02-51605	193993	FRONT PLANET GEAR	1	5	G0914	13
01-02-51606	194126	CROSS	1	5	G0914	4
01-02-51607	194276	NUT (39X200)	2	20	G0609	10
01-02-51608	194435	DRUM	2	20	G0609	12
01-02-51609	194513	SHEELS ASSY	1	5	G0914	1
01-02-51610	270526	SPRING	1	100	G1347	39
01-02-51611	323710	REPAIR KIT	1	50	G1716	901
01-02-51612	492878	SPRING	2	50	G1116	11
01-02-51613	504352	PUSH ROD	12	36	G0124	7
01-02-51614	504352	PUSH ROD	12	50	G0124	7
01-02-51615	504363	BUSH	6	100	G0119	8
01-02-51616	504467	OIL PUMP	1	25	G0127	1
01-02-51617	504467	OIL PUMP	1	10	G0127	1
01-02-51618	659306	LOCK RIGHT COVER PLATE	1	10	G1508	7
01-02-51619	659307	LOCK LEFT COVER PLATE	1	10	G1508	7
01-02-51620	662784	LOCK ADJUSTING HANDLE	2	20	G1513	7
01-02-51621	665536	RUBBER	1	20	G1507	7
01-02-51622	665536	RUBBER	1	25	G1507	7
01-02-51623	667509	RIGHT LOCK	1	10	G1513	9
01-02-51624	667510	LEFT LOCK	1	10	G1513	10
01-02-51625	668505	RIGHT OUTER PANEL	1	5	G1512	2
01-02-51626	668506	LEFT OUTER PANEL	1	5	G1512	1
01-02-51627	668551	WINDOW REGULATOR	2	20	G1513	3
01-02-51628	702194	UNION	1	20	G1127	3
01-02-51629	702209	FLEXIBLE	2	20	G1114	36
01-02-51630	702377	FLEXIBLE (488)	2	40	G1127	19
01-02-51631	707526	SUSPENSION CONTACT	2	30	G1336	27
01-02-51632	707650	CABSTOP	2	10	G1336	31
01-02-51633	707811	TORSION BAR	1	5	G1318	6
01-02-51634	708975	FRONT COMPLETE SPRING	2	12	G1316	1
01-02-51635	712557	ELBOW (18X150)	1	50	G1127	5
01-02-51636	712560	JOINT (26.5)	1	25	G1107	2
01-02-51637	716243	HALF BUSHING	4	40	G1318	7
01-02-51638	719357	FLEXIBLE	2	30	G1121	3
01-02-51639	719474	FLEXIBLE	4	50	G1121	5
01-02-51640	719579	UNION	2	40	G1355	2
01-02-51641	719584	UNION	2	40	G1355	4
01-02-51642	719957	RIGHT REAR CYLINDER	2	40	G1122	28
01-02-51643	719958	CYLINDER	1	30	G1708	904
01-02-51644	720128	ROD	2	20	G1318	12
01-02-51645	720542	DRIVING SHAFT	1	15	G1328	9
01-02-51646	721305	WALKING BEAM	1	20	G1116	10
01-02-51647	744438	FITTING PIN	2	40	G1334	15
01-02-51648	745851	EMERGENCY BRACKET	1	10	G1408	19
01-02-51649	748321	GLASS SLIDE	2	5	G1512	8
01-02-51650	758346	PIN (166)	2	30	G1316	8
01-02-51651	768757	TWO DUBOIS DRUM SET	1	40	G1513	18
01-02-51652	768779	OUTER HANDLE	2	40	G1513	17
01-02-51653	771066	FLANGE SET (0.5)	2	6	G0119	6
01-02-51654	771259	EXHAUST VALVE GUIDE SEAT (52)	6	50	G0114	6
01-02-51655	771265	CAMSHAFT	1	6	G0124	1
01-02-51656	771642	VALVE SPRING	1	15	G0126	6
01-02-51657	1063532	BRAKE COVER	1	10	G1408	18

01-02-51658	1089013	SEALING JOINT	2	20	G1107	11
01-02-51659	1089014	CLAMPING PIECE	2	20	G1107	10
01-02-51660	1089177	ELBOW (22X150)	2	20	G1107	9
01-02-51661	1090430	FUEL PRELIMINARY FILTER	1	250	G1355	6
01-02-51662	1093269	AXLE HEAD COUPLING (21X41)	1	5	G1007	1
01-02-51663	1093321	CONICAL COUPLING (12X41)	1	5	G0918	901
01-02-51664	1095284	FRONT AXLE (E6A211)	1	5	G0606	1
01-02-51665	1100691	DOWEL PIN ASSY	0	30	G1808	901
01-02-51666	1100695	SCREW	8	80	G1808	3
01-02-51667	1101782	ASSY COUNTER MOTION END LEG	1	12	G1807	901
01-02-51668	1101797	ASSY CONTROL END LEG PAD	1	12	G1807	902
01-02-51669	1101815	CONTROL BEARING	5	25	G1806	16
01-02-51670	1101824	CRANK BEARING	1	25	G1806	19
01-02-51671	1101834	STOP BUSH	1	25	G1806	14
01-02-51672	1101846	CONTROL PINION	1	25	G1806	15
01-02-51673	1101847	CRANK PINION	1	25	G1806	17
01-02-51674	1102007	CONNECTING TUBE	1	25	G1806	8
01-02-51675	1108522	CRANK BEARING	1	25	G1806	23
01-02-51676	1108613	BRAKE CYLINDER	6	30	G1815	4
01-02-51677	1108906	CONTROL SHAFT	1	15	G1806	9
01-02-51678	1108924	GROOVED PIN	6	30	G1806	7
01-02-51679	1108925	FINGER SPRING	1	5	G1807	25
01-02-51680	1108930	GROOVED GEAR	2	20	G1807	32
01-02-51681	1108953	STOP FINGER	1	5	G1806	24
01-02-51682	1108963	CRANK SHAFT	1	15	G1806	18
01-02-51683	1118851	CAP ASSY	1	30	G1713	901
01-02-51684	1118852	TANK ASSY.	1	50	G1713	902
01-02-51685	1119049	BEARING	1	20	G1413	7
01-02-51686	1120318	RADIATOR	1	20	G1349	1
01-02-51687	1121490	BRUSH	3	250	G1413	10
01-02-51688	1124951	SPARE UNIT FOR 1800	2	40	G1326	901
01-02-51689	1125954	24V KIT	1	30	G1709	902
01-02-51690	1125956	O - RING	1	25	G1709	1
01-02-51691	1125957	FILTER	1	1000	G1709	2
01-02-51692	1125957	FILTER	1	500	G1709	2
01-02-51693	1125959	SET OF MOVABLE PARTS	1	50	G1709	904
01-02-51694	1126983	CLUTCH THRUST BEARING (102)	1	50	G0306	5
01-02-51695	1126983	CLUTCH THRUST BEARING (102)	1	50	G0306	5
01-02-51696	1127807	SLUICE VALVE	1	150	G1118	28
01-02-51697	1131252	RIGHT CAMSHAFT	3	10	G1814	15
01-02-51698	1131253	BEARING	6	50	G1810	6
01-02-51699	1131254	LEFT CAMSHAFT	3	10	G1814	16
01-02-51700	1131255	BEARING	6	50	G1810	7
01-02-51701	1131263	BRAKE SHOE WITH LINING	12	60	G1814	22
01-02-51702	1131264	BRAKE DRUM	6	50	G1810	2
01-02-51703	1131266	STOP BUSH	6	30	G1810	5
01-02-51704	1131268	RETURN SPRING	6	50	G1814	9
01-02-51705	1131269	RETURN SPRING	6	50	G1814	10
01-02-51706	1131275	BRAKE LEVER	6	30	G1814	23
01-02-51707	1131756	HUB	6	50	G1810	1
01-02-51708	1131757	SCREW (20)	36	180	G1810	12
01-02-51709	1131765	CAP	6	30	G1810	19
01-02-51710	1131775	SUSPENSION SPRING	6	30	G1811	1
01-02-51711	1131833	PIN	6	30	G1810	18
01-02-51712	1131849	CORRECTOR	1	20	G1815	5
01-02-51713	1140999	JOINT HOLDER	1	5	G0913	6
01-02-51714	1141566	DRUM	2	25	G0909	2
01-02-51715	1142083	SCREEN WIPPER ENGINE	1	15	G1413	1
01-02-51716	1142531	PROTECTING VALVE	1	15	G1108	21

01-02-51717	1144631	SERVO DECLUTCHING	1	40	G1123	1
01-02-51718	1144656	TANK 200 LITER	2	10	G1353	1
01-02-51719	1145376	SPRING	1	20	G0427	13
01-02-51720	1146347	RESERVOIR	1	30	G1127	8
01-02-51721	1146812	FUEL TRANSMITTER	2	30	G1409	12
01-02-51722	1147457	FIFTH WHEEL COUPLING	1	10	G1360	1
01-02-51723	1148633	BRAKING CORRECTOR	1	30	G1707	902
01-02-51724	1148633	BRAKING CORRECTOR	1	20	G1113	23
01-02-51725	1148803	CLEARANCE LIGHT	2	90	G1407	15
01-02-51726	1148837	TRANSMISSION	1	10	G1329	23
01-02-51727	1148851	TRANSMISSION 1600 INTER AXLE	1	10	G1326	2
01-02-51728	1149122	JACK	1	10	G1127	18
01-02-51729	1150529	VALVE CONTROL	1	20	G1124	1
01-02-51730	1150888	RED ACCOUPPLING HEAD	1	10	G1815	1
01-02-51731	1151195	AIR DRYER	1	200	G1107	12
01-02-51732	1151406	AIR FILTER	1	25	G1711	901
01-02-51733	1151422	MECHANISM + THRUST BEARING	1	80	G0306	1
01-02-51734	1152072	RIGHT MARCHAL HEAD LAMP	1	25	G1406	2
01-02-51735	1152073	LEFT MARCHAL HEAD LAMP	1	25	G1406	1
01-02-51736	1152114	COMPLETE GEAR BOX (B9-150)	1	3	G0406	1
01-02-51737	1152152	RING	2	10	G1106	10
01-02-51738	1152153	UNION	1	15	G1106	8
01-02-51739	1152329	TRANSMISSION 1800	1	10	G1326	1
01-02-51740	1153240	SILENCER OUTLET PIPE	1	30	G1341	26
01-02-51741	1153272	LEFT ARM	1	10	G1515	6
01-02-51742	1153274	RIGHT ARM	1	10	G1515	5
01-02-51743	1153325	FORK	1	15	G0427	6
01-02-51744	1153330	TAPARED KEY	1	15	G0418	29
01-02-51745	1153333	DRIVER SPEEDS LEVER	1	15	G0418	28
01-02-51746	1153354	COMPASSES	2	40	G1519	22
01-02-51747	1153951	HUB (28)	1	120	G1350	48
01-02-51748	1153952	FAN BLADE	1	5	G1351	49
01-02-51749	1153965	RUBBER HOSE	1	15	G1352	1
01-02-51750	1154504	STEEL TUBE (16X18)	1	15	G1107	4
01-02-51751	1154537	BELLOWS	1	50	G1345	31
01-02-51752	1154566	CLUTCH DISK (430)	1	45	G0306	2
01-02-51753	1154670	HOSE (2300)	1	25	G1127	7
01-02-51754	1154671	ELBOW (26X150)	1	25	G1127	6
01-02-51755	1155327	RIGHT REAR VISION MIRROR	1	20	G1515	11
01-02-51756	1155328	LEFT REAR VISION MIRROR	1	20	G1515	20
01-02-51757	1155876	PIN	36	180	G1810	14
01-02-51758	1155877	WASHER	36	180	G1810	13
01-02-51759	1155878	NUT	36	180	G1810	16
01-02-51760	1155879	SPLINT	36	300	G1810	15
01-02-51761	1155884	RIM	6	30	G1810	3
01-02-51762	1155885	RIM BRACKET	6	30	G1810	4
01-02-51763	1159946	SLIDING GLACE	2	30	G1512	9
01-02-51764	1159947	WIND SCREEN GLACE	1	30	G1507	6
01-02-51765	1159947	WINDSCREEN GLASS	1	25	G1507	6
01-02-51766	1160052	HUB	2	20	G0609	1
01-02-51767	1160450	COMPRESSOR	1	10	G1532	4
01-02-51768	1160451	FREON HOSE	1	10	G1532	6
01-02-51769	1160452	FREON HOSE	1	10	G1532	5
01-02-51770	1472355	DUCT FILTER	2	10	G1815	3
01-02-51771	2290062	STEERING D80S-2110	1	5	G1206	1
01-02-51772	3005827	FILTER CARTRIDGE	1	300	G1713	3
01-02-51773	3294863	ARTICULATION	1	20	G1116	4
01-02-51774	3400014	SLIDING JOINT	1	5	G1329	24
01-02-51775	3400015	SPARE UNIT 500	1	15	G1329	901

01-02-51776	3435035	DISTRIBUTOR	1	15	G1712	17
01-02-51777	3435049	JOINT KIT	1	30	G1712	901
01-02-51778	3459204	JOINT KIT	1	20	G1714	901
01-02-51779	3627165	LEFT ROD	1	10	G1413	6
01-02-51780	3627337	BRUSH HOLDER	3	50	G1413	9
01-02-51781	3627362	BEARING	2	20	G1413	4
01-02-51782	3627364	INTER BRUSHES ROD	1	20	G1413	5
01-02-51783	3627366	ENGINE ROD	1	10	G1413	3
01-02-51784	3627425	OPTICAL BLOCK	2	10	G1406	3
01-02-51785	17231027	WINDSHIELD WRENCH		60	G1507	8
01-02-51786	21226314	TOROIDAL RING INTERIOR (68)	2	10	G0909	14
01-02-51787	21323036	JOINT	1	20	G0420	6
01-02-51788	21623312	WHEEL NUT	20	100	G0909	5
01-02-51789	22111054	CLAMP	2	20	G1116	5
01-02-51790	23123264	INTERMEDIATE ROD	1	10	G1330	10
01-02-51791	23123265	ROD	1	15	G1332	901
01-02-51792	23311036	BEARING (55X120X29)	1	10	G0916	5
01-02-51793	23311105	BEARING (85X150X28)	1	5	G0913	4
01-02-51794	23334039	BEARING (50X90X23)	1	15	G0911	16
01-02-51795	23336050	BEARING (100X150X32)	1	15	G0914	7
01-02-51796	23336062	BEARING (85X130X29)	1	15	G0914	8
01-02-51797	23336123	BEARING (100X180X41)	2	10	G0909	6
01-02-51798	23336124	BEARING (110X180X41)	2	10	G1009	6
01-02-51799	23336286	BEARING (55X95X30)	2	10	G0917	4
01-02-51800	23336288	BEARING (45X80X26)	1	5	G0414	2
01-02-51801	23336871	BEARING (60X12X36.51)	1	5	G0918	4
01-02-51802	23336872	BEARING (70X136.52X46)	1	5	G1011	2
01-02-51803	23351022	BEARING (35X45X17)	1	5	G0425	2
01-02-51804	23512094	ABSORBER	2	20	G1318	1
01-02-51805	24145409	FLEXIBLE	1	25	G1113	6
01-02-51806	24145426	FLEXIBLE	1	25	G1107	7
01-02-51807	24248602	UNION NUT	4	20	G1127	17
01-02-51808	24255143	ELBOW	1	25	G1107	8
01-02-51809	24255347	DOUBLE UNION (14/16)	1	15	G1107	18
01-02-51810	24255391	DOUBLE UNION (16/18)	1	15	G1107	13
01-02-51811	24255458	BUSH AND NUT	2	50	G0422	8
01-02-51812	24331118	UNION	4	20	G0142	3
01-02-51813	24427423	O - RING	1	20	G0420	2
01-02-51814	24427461	JOINT (446X2.5)	1	5	G0911	3
01-02-51815	24427575	O - RING	7	48	G0114	11
01-02-51816	24465112	JOINT	2	100	G0407	13
01-02-51817	24472624	SEALING BUSH (85X110X6)	1	20	G0913	9
01-02-51818	24472667	SEALING JOINT (120X160X15)	2	20	G0909	8
01-02-51819	24733003	LOOSENING VALVE	1	20	G1121	22
01-02-51820	24733005	RELAY VALVE	1	15	G1113	15
01-02-51821	24733007	SERVO VALVE	1	25	G1111	23
01-02-51822	24817040	COCK	1	25	G1113	1
01-02-51823	25111065	JACK	1	15	G1128	5
01-02-51824	26325033	HEATING - PLUG	4	25	G0115	15
01-02-51825	26524107	SCREEN WIPPER SPEED SELECTOR	1	20	G1408	6
01-02-51826	26524125	BACK-UP LIGHT SWITCH	1	15	G1408	2
01-02-51827	26524127	GAUGE REVERSER	1	20	G1408	10
01-02-51828	26524130	SCREEN WIPER SWITCH	1	15	G1408	7
01-02-51829	26524131	WINDSHIELD CLEANER	1	10	G1408	5
01-02-51830	26524137	MASTER SWITCH	1	10	G1412	7
01-02-51831	26526112	DUAL-SWITCH	1	20	G1408	14
01-02-51832	26546140	PRESSURE SWITCH	1	5	G1121	21
01-02-51833	27557011	GREEN INDICATOR LIGHT	1	20	G1409	5
01-02-51834	27567009	REAR LIGHT ASSY	4	20	G1817	29
01-02-51835	28628009	GET	2	20	G1531	5

01-02-51836	28781029	VOLTMETER INDICATOR COMPOUND	1	20	G1409	1
01-02-51837	211151122	SCREW (12X16)	4	20	G1016	8
01-02-51838	211501054	SCREW (10X45)	6	30	G0916	11
01-02-51839	221101190	PIN (6X70)	2	110	G0609	11
01-02-51840	222101015	KEY	1	5	G0122	2
01-02-51841	252101060	WASHER W12	6	20	G1308	4
01-02-51842	253101041	CIRCLIP	8	40	G1016	19
01-02-51843	253101057	ADJUSTING SHIM (3.25)	1	5	G0913	17
01-02-51844	253101205	CIRCLIP (150)	1	5	G0913	5
01-02-51845	253109267	TOROIDAL RING EXTERNAL (38)	2	10	G1009	15
01-02-51846	448413901	COVER	1	10	G1408	16
01-02-51847	772591289	BALL (10)	1	10	G0416	17
01-02-51848	870229300	FILTER CARTRIDGE	1	300	G1714	13
01-02-51849	943059510	COCK	1	20	G1722	901
01-02-51850	943180051	HALLOW BOLT	1	25	G1106	9
01-02-51851	943330042	WELLOW ACCOUPPLING HEAD	1	10	G1815	2
01-02-51852	943400046	COMPLETE VALVE	1	15	G1127	12
01-02-51853	944180125	GREASER	2	10	G1016	5
01-02-51854	946650051	BUSH	10	30	G1121	4
01-02-51855	946737059	CLAMPING PARTS	8	40	G1114	40
01-02-51856	948360842	JOINT (46.99X5.3)	2	10	G1016	3
01-02-51857	948380219	JOINT (3X108)	2	10	G0916	3
01-02-51858	948990055	PLUG	1	5	G0913	13
01-02-51859	5000114260	COPPER JOINT	2	50	G0424	5
01-02-51860	5000121853	PRESSURE INDICATOR	1	15	G1121	11
01-02-51861	5000293163	FILTER	1	50	G0224	21
01-02-51862	5000296603	REGULATOR	1	40	G1421	1
01-02-51863	5000296704	BUNDLE	1	20	G0129	3
01-02-51864	5000297589	REGULATOR BLOCK	1	10	G0213	2
01-02-51865	5000462048	REVOLUTION COUNTER	1	20	G1409	9
01-02-51866	5000559101	REPAIR KIT	1	30	G1706	903
01-02-51867	5000653479	HUB	2	10	G1009	1
01-02-51868	5000653564	STRIP	1	10	G0417	1
01-02-51869	5000653565	TORSION BAR	1	10	G0417	3
01-02-51870	5000653866	FRONT FLANGE	1	20	G0425	14
01-02-51871	5000653868	REAR FLANG	1	20	G0425	16
01-02-51872	5000653874	REVERSE GEAR	1	10	G0414	4
01-02-51873	5000653875	SLIDING SLEEVE	1	10	G0414	7
01-02-51874	5000653876	IDLER FIRST GEAR	1	10	G0414	8
01-02-51875	5000653932	PIN	3	9	G0425	7
01-02-51876	5000653989	COVER	1	10	G0417	5
01-02-51877	5000654054	SCREW (12X50)	32	160	G1016	9
01-02-51878	5000654095	OIL PIPE	1	5	G0912	3
01-02-51879	5000655313	INTERMEDIATE SHAFT (43)	1	15	G0414	1
01-02-51880	5000655323	HUB	1	10	G0414	6
01-02-51881	5000655329	CROWN	1	10	G0425	12
01-02-51882	5000655330	CROWN BRACKET	1	10	G0425	10
01-02-51883	5000655381	SLEEVE OF 1800	1	20	G0415	1
01-02-51884	5000655384	TUMBLER SWITCH	1	5	G0421	6
01-02-51885	5000655387	TACHOMETER GEAR (21)	1	10	G0411	1
01-02-51886	5000655403	STRIP	1	10	G0416	7
01-02-51887	5000655418	STRAINER	1	5	G0429	1
01-02-51888	5000655445	STRIP 1ST-2ND	1	5	G0416	10
01-02-51889	5000655446	INTERMEDIATE CASING	1	3	G0407	5
01-02-51890	5000655461	SOCKET SLEEVE	1	5	G0411	2
01-02-51891	5000655465	SELECTION BUSH	1	5	G0417	13
01-02-51892	5000655466	PRINCIPAL DRIVER	1	5	G0417	14
01-02-51893	5000655480	TUBE (60)	1	10	G0410	15
01-02-51894	5000655516	PAD	2	6	G0416	14
01-02-51895	5000655517	PAD	2	6	G0416	16

01-02-51896	5000655532	SHIM (2.8)	1	5	G0409	3
01-02-51897	5000655533	SHIM (3.3)	1	5	G0409	3
01-02-51898	5000655534	SHIM (3.8)	1	5	G0409	3
01-02-51899	5000655536	SHIM (4.8)	1	5	G0409	3
01-02-51900	5000655547	NUT (162X200)	1	10	G0425	19
01-02-51901	5000655573	NEEDLE	1	5	G0416	6
01-02-51902	5000655576	REACTION WASHER	6	24	G0425	6
01-02-51903	5000658281	SPICER	1	5	G0133	14
01-02-51904	5000658553	CYLINDER COVER	6	24	G0114	19
01-02-51905	5000658576	PIN	2	5	G0122	5
01-02-51906	5000658672	SHEATH	1	5	G0118	7
01-02-51907	5000663000	GET	6	5	G0126	16
01-02-51908	5000663118	TURBINE	1	5	G0133	18
01-02-51909	5000663138	UNION SCREW	12	50	G0131	2
01-02-51910	5000663175	UNION SCREW	6	5	G0126	17
01-02-51911	5000663188	PINION	1	5	G0136	2
01-02-51912	5000663324	HALF VALVE SPLIT CON	24	50	G0125	16
01-02-51913	5000663529	INLET VALVE	6	18	G0125	6
01-02-51914	5000663591	WASHER	4	8	G0122	7
01-02-51915	5000664043	LOCK NUT(42X150)	1	5	G1011	20
01-02-51916	5000666314	FILTER HEAD	1	10	G0226	1
01-02-51917	5000666693	WASHER	7	12	G0121	2
01-02-51918	5000666809	STOP	1	5	G0124	4
01-02-51919	5000669599	LOCKING PIN	1	5	G0418	22
01-02-51920	5000669629	PIN	2	6	G0421	8
01-02-51921	5000670031	CASING FLYWHEEL	1	2	G0109	1
01-02-51922	5000670157	TURBINE ASSY	1	10	G0133	1
01-02-51923	5000670168	DELIVERY PIPE	1	4	G0126	5
01-02-51924	5000670211	PINION	1	20	G0122	1
01-02-51925	5000670214	CRANKSHAFT	1	5	G0119	1
01-02-51926	5000670220	SCREW	4	12	G0121	7
01-02-51927	5000670232	NUT	21	24	G0119	10
01-02-51928	5000670258	SCREW	12	24	G0119	9
01-02-51929	5000670321	BANISTERS	1	20	G0227	13
01-02-51930	5000670413	ADJUSTING SHIM (40)	1	50	G0123	2
01-02-51931	5000670414	ADJUSTING SHIM (0.6)	1	50	G0123	2
01-02-51932	5000670505	SEALING BUSH	1	50	G0133	17
01-02-51933	5000670630	SEALING BUSH	1	50	G0133	16
01-02-51934	5000670651	SCREW LG (151)	12	12	G0114	9
01-02-51935	5000670652	SCREW LG (175)	12	12	G0114	9
01-02-51936	5000670688	CYLINDER BLOCK	1	3	G0107	1
01-02-51937	5000670700	CARTRIDGE FILTER	2	5000	G0128	5
01-02-51938	5000670730	EXHAUST VALVE	6	18	G0125	7
01-02-51939	5000670737	ROTOR	1	2000	G0128	16
01-02-51940	5000670743	HUB	1	5	G0121	1
01-02-51941	5000670753	JOINT	6	50	G0116	3
01-02-51942	5000670783	VALVE	1	20	G0128	6
01-02-51943	5000670844	BRACKET	1	15	G0135	1
01-02-51944	5000670845	BEARING	1	30	G0135	5
01-02-51945	5000670846	PINION	1	30	G0135	6
01-02-51946	5000670847	PINION	1	30	G0135	9
01-02-51947	5000670848	PINION	1	30	G0135	7
01-02-51948	5000670849	PIN	1	30	G0135	8
01-02-51949	5000670850	JOINT HOLDER	1	15	G0135	2
01-02-51950	5000670853	BEARING	2	60	G0135	3
01-02-51951	5000670854	INNER BEARING (STD DIMENSION)	7	21	G0119	4
01-02-51952	5000670855	INNER BEARING (0.5)	7	21	G0119	4
01-02-51953	5000670856	INNER BEARING (1)	7	21	G0119	4
01-02-51954	5000673027	HUB	1	10	G0410	7
01-02-51955	5000673029	MAINSHAFT	1	10	G0410	1

01-02-51956	5000673077	GEAR (21)	1	10	G0410	13
01-02-51957	5000673078	DIFFERENTIAL PINION	3	10	G0425	4
01-02-51958	5000673139	OUT SHAFT	1	10	G0425	1
01-02-51959	5000673139	OUT SHAFT	1	10	G0425	1
01-02-51960	5000673307	COVER	1	10	G0412	7
01-02-51961	5000673338	PIPE	1	30	G0419	2
01-02-51962	5000673341	NUT	1	20	G0413	20
01-02-51963	5000673367	PRINCIPAL CASE	1	3	G0407	1
01-02-51964	5000673381	SELECTION ASSY	1	10	G0417	15
01-02-51965	5000673398	SPRING	1	5	G0416	2
01-02-51966	5000673429	SYNCHRONIZER	1	10	G0410	2
01-02-51967	5000673430	3TH - 4TH SYNCHRONIZER	1	10	G0410	8
01-02-51968	5000673524	NUT	1	30	G0410	14
01-02-51969	5000673571	VALVE	1	20	G0422	1
01-02-51970	5000673582	HARD POINT	1	10	G0417	21
01-02-51971	5000673690	FIRST GEAR (61)	1	10	G0410	3
01-02-51972	5000673691	SECOND GEAR (56)	1	10	G0410	11
01-02-51973	5000673692	FOURTH GEAR (43)	1	10	G0410	5
01-02-51974	5000673694	INPUT SHAFT (49)	1	10	G0409	1
01-02-51975	5000673698	GEAR	1	10	G0412	2
01-02-51976	5000675795	RECUPERATOR THROUGH	1	5	G0911	7
01-02-51977	5000677320	BALL PIN	1	5	G0427	8
01-02-51978	5000678832	DAMPER	1	10	G0121	2
01-02-51979	5000681024	OIL CUP	1	5	G0112	1
01-02-51980	5000681076	INLET VALVE SEAT	6	50	G0114	5
01-02-51981	5000681118	MANIFOLD	1	10	G0115	1
01-02-51982	5000681334	STRINER OIL	1	4	G0126	1
01-02-51983	5000681432	CONTROL CYLINDER STOP	1	15	G0228	1
01-02-51984	5000681483	INTERMEDIATE PINION	1	10	G0122	4
01-02-51985	5000681487	PINION	1	5	G0122	3
01-02-51986	5000681499	PINION	1	5	G0124	3
01-02-51987	5000681538	BRACKET	2	5	G0122	6
01-02-51988	5000681541	OIL PUMP	1	20	G0142	5
01-02-51989	5000681554	EXHAUST INNER CUP	6	25	G0125	11
01-02-51990	5000682913	BEVEL WHEEL THRUST	2	10	G0914	3
01-02-51991	5000682923	INTER AXLE SHAFT	1	5	G0916	1
01-02-51992	5000684699	JOINT	1	5	G0134	3
01-02-51993	5000685808	ADJUSTING SHIM (2.5)	1	5	G0913	14
01-02-51994	5000685809	ADJUSTING SHIM (2.75)	1	5	G0913	15
01-02-51995	5000685810	ADJUSTING SHIM (3)	1	5	G0913	16
01-02-51996	5000685811	ADJUSTING SHIM (3.25)	1	5	G0913	17
01-02-51997	5000685812	ADJUSTING SHIM (3.5)	1	5	G0913	18
01-02-51998	5000685813	ADJUSTING SHIM (3.75)	1	5	G0913	19
01-02-51999	5000686112	JOINT	1	20	G0128	4
01-02-52000	5000686132	INJECTOR HOLDER	6	24	G0225	1
01-02-52001	5000686156	EXCHANGER	1	20	G0129	1
01-02-52002	5000686228	SEALING JOINT	1	20	G0140	8
01-02-52003	5000686229	BRACKET FILTER	1	20	G0128	1
01-02-52004	5000686589	FUEL FILTER	2	3000	G0226	3
01-02-52005	5000686610	STEERING WHEEL	1	10	G0120	1
01-02-52006	5000686612	PULLEY	1	10	G0134	2
01-02-52007	5000686661	ADAPTER	1	20	G0128	15
01-02-52008	5000686663	BRACKET	1	20	G0128	10
01-02-52009	5000686677	SPACER	1	5	G0121	5
01-02-52010	5000686746	RETURN TUBE	1	10	G0117	7
01-02-52011	5000686842	PINION	1	5	G0141	9
01-02-52012	5000686867	COMPLETE CONTROL	1	5	G0134	1
01-02-52013	5000686867	COMPLETE CONTROL	1	20	G0134	1
01-02-52014	5000686971	WATER COLLECTOR	1	20	G0132	1
01-02-52015	5000686974	FLEXIBLE	1	40	G0117	2
01-02-52016	5000690011	FORK 1ST-2ND	1	5	G0416	13

01-02-52017	5000690012	FORK 3RD-4TH	1	5	G0416	15
01-02-52018	5000690018	BEARING	1	10	G0410	10
01-02-52019	5000690019	BEARING (55X110X38)	1	10	G0410	12
01-02-52020	5000690026	SYNCHRONIZER	1	20	G0425	15
01-02-52021	5000690034	INTERMEDIATE SHAFT	1	5	G0412	1
01-02-52022	5000690040	BEARING (75X160X37)	1	20	G0425	18
01-02-52023	5000690079	DRIVER FIRST AND REVERSE IDLER	1	10	G0417	10
01-02-52024	5000690126	COVER	1	5	G0420	1
01-02-52025	5000690169	AXLE TUBE	1	10	G0427	1
01-02-52026	5000690181	FORK	1	5	G0416	3
01-02-52027	5000690188	HOIST	1	5	G0419	1
01-02-52028	5000690191	PAD	2	10	G0421	7
01-02-52029	5000694017	WATER FLEXIBLE	1	30	G0142	2
01-02-52030	5000694030	JOINT	2	10	G0112	3
01-02-52031	5000694048	CASING	1	3	G0110	1
01-02-52032	5000694050	TURBO	1	20	G0117	1
01-02-52033	5000694077	FLEXIBLE	1	20	G0140	10
01-02-52034	5000694081	EXHAUST - MANIFOLD	2	10	G0116	2
01-02-52035	5000694082	EXHAUST - MANIFOLD	1	10	G0116	1
01-02-52036	5000694185	JOINT	1	20	G0142	6
01-02-52037	5000694208	GREASING PIPE	1	20	G0138	21
01-02-52038	5000694271	JOINT	6	48	G0114	20
01-02-52039	5000694276	INJECTOR	6	500	G0225	2
01-02-52040	5000694335	WASHER	12	48	G0114	10
01-02-52041	5000694357	SCREW	14	14	G0114	12
01-02-52042	5000694436	BEARING	1	50	G0120	6
01-02-52043	5000694446	AIR COMPRESSOR	1	30	G0141	1
01-02-52044	5000694550	CYLINDER HEAD	6	25	G0114	1
01-02-52045	5000694668	SEALING BUSH (90X110X12)	1	50	G0110	3
01-02-52046	5000694708	BANISTERS	1	10	G0131	1
01-02-52047	5000694785	THERMOSTAT	1	50	G0130	5
01-02-52048	5000694931	AUTOMATIC INJ. ADVANCE	1	10	G0140	1
01-02-52049	5000694985	INJECTION PUMP	1	5	G0207	1
01-02-52050	5000704870	IDLING CONTROL	1	40	G1347	40
01-02-52051	5000716213	PACKING SEGMENT	4	20	G0922	15
01-02-52052	5000716264	LEFT CONNECTION LEVER	1	10	G0608	5
01-02-52053	5000716265	RIGHT CONNECTION LEVER	1	10	G0608	6
01-02-52054	5000737119	LEFT CAM	1	5	G0921	1
01-02-52055	5000737120	RIGHT CAM	1	5	G1015	2
01-02-52056	5000737426	WASHER	2	10	G0609	9
01-02-52057	5000739386	COLLAR	2	20	G1521	11
01-02-52058	5000783941	START SWITCH	1	20	G1408	8
01-02-52059	5000783942	JOINT (85X110X12)	1	5	G0916	9
01-02-52060	5000785273	RESERVOIR	1	5	G1106	3
01-02-52061	5000785328	AIR EXCHANGER	1	5	G1349	22
01-02-52062	5000785342	RIVET (8X18)	72	360	G0922	20
01-02-52063	5000785431	TRANSMITTER	1	30	G1106	1
01-02-52064	5000785488	ELBOW (4/10X100)	2	50	G0422	12
01-02-52065	5000785489	ELBOW (8/10X100)	2	40	G0422	6
01-02-52066	5000785490	T. UNION	1	50	G0422	9
01-02-52067	5000785979	BUSH	2	10	G1015	6
01-02-52068	5000786292	BEARING	1	10	G0409	2
01-02-52069	5000786296	BEARING	1	5	G0413	19
01-02-52070	5000786301	BEARING (32X45.4X150)	3	10	G0425	5
01-02-52071	5000786307	BEARING (30X37X20)	2	20	G0417	9
01-02-52072	5000786373	SEALING BUSH	1	20	G0416	19
01-02-52073	5000786631	AIR SIGNAL LIGHT COMPOUND	1	10	G1409	2
01-02-52074	5000786674	BUSH 33X30X31	8	40	G0922	16
01-02-52075	5000786746	BALL BEARING	2	10	G0133	13
01-02-52076	5000786885	TIMEMETER	1	10	G1409	10

01-02-52077	5000787029	BUSH AND NUT	8	80	G0422	7
01-02-52078	5000787032	BEARING (65X100X18)	1	5	G0425	9
01-02-52079	5000787085	SEALING BUSH (45X55X7)	2	10	G0922	4
01-02-52080	5000787873	LUBRICATING BUSH	1	10	G0427	7
01-02-52081	5000788309	PARKING LIGHT REVERSOR	1	10	G1408	1
01-02-52082	5000788400	SEALING BUSH (85X100X12)	1	5	G0913	8
01-02-52083	5000788838	BELLOWS	1	10	G0417	6
01-02-52084	5000789348	HYDRAULIC PUMP	1	30	G0136	1
01-02-52085	5000789448	OBTURATOR	2	20	G1408	3
01-02-52086	5000789615	DISTRIBUTOR	1	30	G0422	13
01-02-52087	5000789960	TAPPET	12	36	G0124	6
01-02-52088	5000790266	WATER FLEXIBLE	1	20	G0142	1
01-02-52089	5000790702	COCK	1	20	G1526	29
01-02-52090	5000790853	OIL RESERVE OIL	1	20	G0409	5
01-02-52091	5000790990	BALL JOINT	1	20	G1124	12
01-02-52092	5000791145	FILTER	1	1000	G0429	4
01-02-52093	5000793075	DIFFERENTIAL KIT	1	5	G1013	901
01-02-52094	5000793132	SET OF PACKING	1	5	G1016	901
01-02-52095	5000793734	UPPER GASKET SET	1	20	G0146	1
01-02-52096	5000793762	GEAR BOX GASKET SET	1	30	G0430	901
01-02-52097	5000793849	SWIVEL REPAIR KIT	2	20	G0308	4
01-02-52098	5000794009	INNER BEARING (0.25)	7	21	G0119	4
01-02-52099	5000794010	INNER BEARING (0.75)	7	21	G0119	4
01-02-52100	5000802385	JOINT KIT	1	20	G1727	901
01-02-52101	5000802993	REPAIR KIT	1	15	G1707	901
01-02-52102	5000804247	STATOR	1	30	G1421	6
01-02-52103	5000804248	BEARING ASSY	1	20	G1421	5
01-02-52104	5000806166	SPARE UNIT FOR 1600	2	20	G1326	902
01-02-52105	5000806227	SPARE MOUNTING PLATE	1	20	G1408	15
01-02-52106	5000808739	JOINTS SET	1	15	G0137	1
01-02-52107	5000808747	PINIONS SET	1	15	G0137	2
01-02-52108	5000809048	LOW PRESSURE INDICATOR	2	50	G1716	28
01-02-52109	5000813995	STARTER DRIVE	1	20	G1420	13
01-02-52110	5000814000	CONTROL LEVER	1	10	G1420	5
01-02-52111	5000814928	REPAIR KIT	1	20	G1719	901
01-02-52112	5000815107	REPAIR OUTFIT ASSY	1	30	G1710	901
01-02-52113	5000816588	LIMITER REPAIR SET	1	10	G0137	3
01-02-52114	5000816647	FAN	1	20	G1421	4
01-02-52115	5000816874	ROTOR + BEARING	1	30	G1421	7
01-02-52116	5000820873	JOINT	1	25	G0215	19
01-02-52117	5000821308	CLIP	1	30	G0206	4
01-02-52118	5000821309	CLIP	3	30	G0206	3
01-02-52119	5000821312	CLIP	1	30	G0206	2
01-02-52120	5000824130	BRUSH HOLDER ASSY	1	50	G1421	2
01-02-52121	5000824131	BEARING + BUSH	1	50	G1421	3
01-02-52122	5000849311	JOINT (393X7)	1	5	G0912	7
01-02-52123	5000850164	HOIST	1	30	G0421	1
01-02-52124	5000946891	PUMP	1	30	G1531	3
01-02-52125	5001014033	JACK	1	15	G1124	7
01-02-52126	5001014786	CORRECTOR	1	20	G0207	4
01-02-52127	5001821529	SUPPLY PUMP	1	20	G0207	3
01-02-52128	5001821529	SUPPLY PUMP	1	25	G0138	3
01-02-52129	5001821826	CYLINDER UNIT	6	30	G0123	1
01-02-52130	5001821828	RING SET	6	30	G0123	5
01-02-52131	5001822946	DIODE BRIDE ASSY	1	30	G1421	10
01-02-52132	5001823275	COMPLETE ROD	2	20	G1129	17
01-02-52133	5001823288	PISTON ASSY (65.5)	2	30	G1129	2
01-02-52134	5001824413	HALF BEARING (0.25)	6	18	G0119	5
01-02-52135	5001824414	HALF BEARING (0.5)	8	18	G0119	5
01-02-52136	5001824415	HALF BEARING (0.75)	6	18	G0119	5
01-02-52137	5001824416	HALF BEARING (1)	6	18	G0119	5

01-02-52138	5001824419	BEARING SET (STD DIMENSION)	1	3	G0119	3
01-02-52139	5001824956	FILLER PLUG	1	10	G1349	18
01-02-52140	5001825391	SET OF PARTS AND JOINT	1	10	G1420	8
01-02-52141	5001825394	STATOR BRACKET	1	10	G1420	4
01-02-52142	5001825395	INTERMEDIATE BEARING	1	10	G1420	7
01-02-52143	5001826447	LOWER GASKET SET	1	10	G0146	2
01-02-52144	5001831140	RELAY	1	30	G1420	3
01-02-52145	5001831644	ARMATURE	1	10	G1420	12
01-02-52146	5001831645	INDUCTOR	1	20	G1420	9
01-02-52147	5001831646	BRUSH HOLDER	1	20	G1420	10
01-02-52148	5001831996	BRUSH SET	1	50	G1420	2
01-02-52149	5003009151	SCREW	6	30	G0121	3
01-02-52150	5003009338	SCREW	18	24	G0114	21
01-02-52151	5003009362	SCREW (12X30)	3	45	G0913	12
01-02-52152	5003009367	SCREW	2	6	G0124	5
01-02-52153	5003009388	SCREW	8	40	G0914	2
01-02-52154	5003034220	NUT	32	160	G1016	11
01-02-52155	5003053265	WASHER	8	40	G0120	4
01-02-52156	5003053383	WASHER	2	20	G0136	6
01-02-52157	5003057051	WASHER (10)	6	18	G0143	4
01-02-52158	5003062003	JOINT	1	5	G0912	5
01-02-52159	5003062008	JOINT (24.4X32X2)	2	10	G0911	9
01-02-52160	5003062014	JOINT	1	20	G0112	9
01-02-52161	5003062028	JOINT	1	40	G0113	2
01-02-52162	5003062038	JOINT	2	112	G0117	6
01-02-52163	5003065006	O - RING	1	20	G0417	4
01-02-52164	5003065016	JOINT	1	5	G0917	2
01-02-52165	5003065041	O - RING	1	20	G0128	14
01-02-52166	5003065044	JOINT	1	30	G0138	5
01-02-52167	5003065051	O - RING	1	10	G0133	2
01-02-52168	5003065052	O - RING	1	10	G0133	4
01-02-52169	5003065058	JOINT	1	20	G0136	3
01-02-52170	5003065077	JOINT (425X3)	1	5	G0911	3
01-02-52171	5003065096	ADJUSTING SHIM (3.5)	1	5	G0913	18
01-02-52172	5003065097	JOINT	1	5	G0917	3
01-02-52173	5003065109	JOINT	1	20	G0138	24
01-02-52174	5003065117	JOINT	1	20	G0128	11
01-02-52175	5003065148	O - RING	1	20	G0121	6
01-02-52176	5003065151	O - RING	1	20	G0134	14
01-02-52177	5003067014	PIN (8X50)	4	5	G0417	11
01-02-52178	5003067122	PIN	3	9	G0425	8
01-02-52179	5003070000	KEY	1	5	G0124	2
01-02-52180	5003075042	PLUG	1	20	G0420	5
01-02-52181	5003083055	CLIP	2	40	G0132	20
01-02-52182	5003087017	SEALING BUSH (62X85X10)	1	40	G0427	2
01-02-52183	5003087029	SEALING BUSH	1	40	G0109	8
01-02-52184	5003087038	SEALING BUSH	1	40	G0420	7
01-02-52185	5003090110	BEARING (50X68X63)	1	15	G0410	6
01-02-52186	5003090112	BEARING (65X73X48)	2	15	G0410	4
01-02-52187	5003090113	BEARING (60X68X46)	1	15	G0414	5
01-02-52188	5003090114	BEARING (50X68X55.2)	1	15	G0414	9
01-02-52189	5003101738	JOINT	1	20	G0128	12
01-02-52190	5003101745	SCREW (10X30)	6	30	G0914	6
01-02-52191	5005010008	BUSH (45X48X53)	2	10	G1016	2
01-02-52192	5005030007	BUSH (16/18)	2	10	G1107	6
01-02-52193	5005030017	NUT (16/18)	2	10	G1107	5
01-02-52194	5005030626	UNION	1	10	G0117	3
01-02-52195	5005130905	T. UNION	2	50	G0423	33
01-02-52196	5005130908	SIMPLE UNION (8/10X100)	2	50	G0422	17
01-02-52197	5005330166	UNION	2	50	G0424	4
01-02-52198	5010056613	BUSHED LEFT STUBAXLE	1	5	G0608	1

01-02-52199	5010056615	BUSHED RIGHT STUBAXLE	1	5	G0608	2
01-02-52200	5010056630	DISK KEY	3	50	G0608	21
01-02-52201	5010056928	PIVOT THRUST	2	20	G0608	25
01-02-52202	5010067534	SEALING BUSH (100X125X13)	2	50	G0609	8
01-02-52203	5010136663	BEARING (70X125X41)	2	50	G0609	6
01-02-52204	5010136770	BEARING (45X95X36)	2	50	G0609	5
01-02-52205	5010140083	UPPEN - PIPING	1	50	G0115	10
01-02-52206	5010140278	STOP PULL KNOB	1	40	G1347	42
01-02-52207	5010142411	AIR PRESSURE TRANSMITTER	1	30	G1409	11
01-02-52208	5010145077	TRACK ROD	1	10	G0610	1
01-02-52209	5010149022	ALTERNATOR	1	15	G0143	1
01-02-52210	5010149149	BLINKING UNIT	1	20	G1407	4
01-02-52211	5010151081	COCK	1	5	G1121	1
01-02-52212	5010165604	SHEATH	1	10	G0130	10
01-02-52213	5010217217	HORN	1	15	G1124	8
01-02-52214	5010217217	HORN	1	50	G1124	8
01-02-52215	5010217532	STARTER MOTOR	1	15	G0144	1
01-02-52216	5010240381	INJECTOR PIPE BUNDLE	1	10	G0206	1
01-02-52217	5010240656	JOINT	1	20	G0112	6
01-02-52218	5010240714	CLUTCH	1	20	G0128	17
01-02-52219	5010241099	SEALING BUSH (30X40X6)	1	20	G0417	2
01-02-52220	5010242009	STRIP	1	5	G0416	1
01-02-52221	5010242718	FORK	1	5	G0416	8
01-02-52222	5010269966	FILTER ELEMENT	1	600	G1711	1
01-02-52223	5010269967	SECURITY ELEMENT	1	600	G1711	2
01-02-52224	5010295276	CYLINDER JOINT	6	100	G0114	8
01-02-52225	5010295397	BELT (1020)	1	300	G0145	1
01-02-52226	5516004229	WINDOW REGULATOR CRANK	2	20	G1513	6
01-02-52227	5600106884	PUMP ASSY	1	20	G0429	8
01-02-52228	5600538683	INTERMEDIATE SHAFT ASSY	1	5	G0413	901
01-02-52229	5600563750	COMPLETE ENGINE	1	3	G0106	1
01-02-52230	5600585305	LUBRICATING APARATUS ASSY	1	5	G0913	901
01-02-52231	5600595255	INTER AXLE	1	30	G0903	1
01-02-52232	5600595257	REAR AXLE	1	30	G1003	1
01-02-52233	5689102882	HYLON PIPE	5M	100	G1531	6
01-02-52234	5689105748	PIPE (8X0.75)	1	50	G0419	6
01-02-52235	5689330050	POLYAMIDE PIPE	1	450	G0424	2
01-02-52236	7701003772	REPAIR KIT	1	30	G1708	901
01-02-52237	7701010516	KEY	1	20	G1408	9
01-02-52238	7701014475	DIMMER CAP	2	50	G1407	16
01-02-52239	7703066030	CIRCLIPS	1	5	G0133	15
01-02-52240	7703066032	CIRCLIP	1	20	G0425	3
01-02-52241	7703066040	CIRCLIPS	1	10	G0120	7
01-02-52242	7703066045	RING	4	30	G0135	4
01-02-52243	7703067087	PIN (5X50)	4	5	G0417	12
01-02-52244	7703075027	PLUG	1	20	G0112	10
01-02-52245	SR	TARPAULINE	1	100	----	----
SPARE PARTS FOR NISSAN PICKUP 4X2 SINGLE CABIN						
		ABEGLCFD22SKLC-AG-				
01-02-52246	15208-W1106	FILTER ASSY OIL	128000			
01-02-52247	11950-80W00	BELT - OIL PUMP	8000			
01-02-52248	11720-30W00	BELT - FAN	8000			
01-02-52249	11920-M6660	BELT - COMPRESSOR	8000			
01-02-52250	11210-18G01	INSULATOR	3200			
01-02-52251	11320-01G00	INSULATOR	1600			
01-02-52252	12033-21G00	RING SET - PISTON	1600			
01-02-52253	12010-83W11	PISTON WITH PIN	6400			
01-02-52254	13201-N8501	VALVE - INTAKE	3200			
01-02-52255	13202-N8501	VALVE - EXHAUST	3200			
01-02-52256	13028-03G00	CHAIN - CAMSHAFT	3200			

01-02-52257	13257-W0560	ROCKER - VALVE	800			
01-02-52258	13261-W0560	ROCKER - VALVE	800			
01-02-52259	10101-71G25	GASKET - ENGINE	1600			
01-02-52260	11042-09N26	GASKET - VALVE	1600			
01-02-52261	16400-41B05	STRAINER FUEL	32000			
01-02-52262	16546-G7300	ELEMENT ASSY	32000			
01-02-52263	14055-10W00	HOSE - WATER	3200			
01-02-52264	21410-3S100	RADIATOR ASSY	400			
01-02-52265	21501-3S401	HOSE TOP	3200			
01-02-52266	21505-3S411	HOSE ASSY	3200			
01-02-52267	21506-3S411	HOSE BOTTOM	3200			
01-02-52268	21430-01F02	CAP ASSY PRESSURE	3200			
01-02-52269	21010-26G27	PUMP ASSY - WATER	2000			
01-02-52270	21014-07N00	GASKET - WATER PUMP	3200			
01-02-52271	21082-T6400	COUPLING ASSY	2400			
01-02-52272	21200-F3100	THERMOSTAT ASSY	800			
01-02-52273	23300-W0403	MOTOR STARTER	200			
01-02-52274	23100-VJ610	ALTERNATOR ASSY	200			
01-02-52275	22401-W8916	PLUG - SPARK	768000			
01-02-52276	26010-3S225	LAMP ASSY - HEAD RH	800			
01-02-52277	26060-3S225	LAMP ASSY - HEAD LH	800			
01-02-52278	26015-3S200	UNIT SEALED	1600			
01-02-52279	26065-3S200	UNIT SEALED	1600			
01-02-52280	26719-C9920	BULB (12V60/55W)	3200			
01-02-52281	26261-C9903	BULB (12V5W)	3200			
01-02-52282	26717-89911	BULB (12V1W)	3200			
01-02-52283	26110-2S425	LAMP - SIDE COMBI	800			
01-02-52284	26115-2S425	LAMP - SIDE COMBI	800			
01-02-52285	28890-VB005	BLADE - WIPER	1600			
01-02-52286	28895-34E00	REFILL - WIPER	3200			
01-02-52287	26521-23G60	LENS - COMBI LAMP	800			
01-02-52288	26526-23G60	LENS - COMBI LAMP	800			
01-02-52289	26717-89912	BULB (12V21W/5W)	3200			
01-02-52290	26717-89911	BULB (12V21W)	3200			
01-02-52291	B6550-23G61	LAMP - COMBI RR	800			
01-02-52292	B6555-23G61	LAMP - RR - COMBI	800			
01-02-52293	30100-VJ200	DISC ASSY - CLUTCH	3200			
01-02-52294	30210-VJ200	COVER - CLUTCH	2000			
01-02-52295	30610-3S101	CYLINDER ASSY	800			
01-02-52296	30502-69F10	BEARING C/RELEASE	2000			
01-02-52297	40014-01G50	SPINDLE KNUCKLE, RH	2000			
01-02-52298	40015-01G50	SPINDLE KNUCKLE, LH 99	800			
01-02-52299	40052-3S600	ARM - KNUCKLE, RH	800			
01-02-52300	40053-3S600	ARM - KNUCKLE, LH	800			
01-02-52301	54524-2S485	LINK COMPL - RH	800			
01-02-52302	54525-2S485	LINK COMPL - LH	800			
01-02-52303	56110-25G85	ABSORBER SHOCK	8000			
01-02-52304	56200-25G25	ABSORBER SHOCK	8000			
01-02-52305	55045-10W00	BUSH SPRING	16000			
01-02-52306	55046-01G00	BUSHING	32000			
01-02-52307	55240-15G00	BUMPER SUSPENS	1600			
01-02-52308	55020-3S400	SPRING ASSY	400			
01-02-52309	41060-2S790	PAD KIT - DISC	80000			
01-02-52310	D4100-F2985	CUP KIT - BRAKE	800			
01-02-52311	44060-2S425	SHOE SET - REAR	24000			
01-02-52312	48510-2S485	ROD KIT - TIE, RH	2000			
01-02-52313	48630-2S485	ROD KIT - TIE, LH	2000			
01-02-52314	62024-2S400	BUMPER - FRONT, RH	400			
01-02-52315	62025-2S400	BUMPER - FRONT, LH	400			
01-02-52316	62022-2S400	BUMPER - FRONT	400			
01-02-52317	62026-2S425	FASCIA FRONT BUMPER	400			

01-02-52318	62060-3S400	OVERRIDE ASSY	240			
01-02-52319	62061-3S400	OVERRIDE ASSY	240			
01-02-52320	62310-2S500	GRILLE - RADIATOR	1600			
01-02-52321	63112-2S400	FENDER - FRONT, RH	200			
01-02-52322	63113-2S900	FENDER - FRONT, LH	200			
01-02-52323	F5100-2S900	HOOD	200			
01-02-52324	72712-VJ200	GLASS - WINDSHIELD	1600			
01-02-52325	G2716-89901	RUBBER DUM	800			
01-02-52326	K3820-2S400	MUDGUARD REAR, RH	400			
01-02-52327	K3821-2S400	MUDGUARD REAR, LH	400			
01-02-52328	F3850-2S400	MUDGUARD FRONT, RH	400			
01-02-52329	F3851-2S400	MUDGUARD FRONT, LH	400			
01-02-52330	79712-1S500	GLASS - REAR WINDOW	160			
01-02-52331	79710-VJ200	WSTRIP - REAR WINDOW	80			
01-02-52332	H0100-2S400	DOOR - FRONT, RH	200			
01-02-52333	H0101-2S400	DOOR - FRONT, LH	200			
01-02-52334	80830-2S400	WSTRIP ASSY - FR	400			
01-02-52335	80831-2S400	WSTRIP ASSY - FR	400			
01-02-52336	80300-2S400	GLASS - FR DOOR, R	400			
01-02-52337	80301-2S400	GLASS - FR DOOR, L	400			
01-02-52338	85014-3S400	STEP ASSY - CENTER	200			
01-02-52339	85232-1S800	STEP BOARD - REAR BUMPER	200			
01-02-52340	85060-21G00	OVERRIDE ASSY - RR	200			
01-02-52341	85061-21G00	OVERRIDE ASSY - RR	200			
01-02-52342	96301-3S405	MIRROR ASSY DOOR, RH	800			
01-02-52343	96302-3S405	MIRROR ASSY DOOR, LH	800			
01-02-52344	11044-10W02	GASKET - CYLINDER	3200			
01-02-52345	16010-3S400	CARBURATOR ASSY	400			
01-02-52346	37000-3S200	SHAFT ASSY - PROP	400			
01-02-52347	01111-00011	BOLT - FIX PROPE	2000			
01-02-52348	12117-V0700	BEARING - CONNECTING ROD 0.25	6400			
01-02-52349	12207-U6001	BEARING CRANCK SHAFT STD	800			
01-02-52350	40210-F1700	BEARING ASSY-FR	1600			
01-02-52351	40215-F1700	BEARING ASSY-FR	1600			
01-02-52352	40210-85000	BEARING - TAPER	1600			
01-02-52353	24319-C9907	FUSE 7.5A	16000			
01-02-52354	24319-C9910	FUSE 10A	16000			
01-02-52355	24319-C9915	FUSE 15A	16000			
01-02-52356	24319-C9920	FUSE 20A	16000			
01-02-52357	11026-01M02	WAHSE - DRAIN PLUG	8000			
01-02-52358	11128-01M00	PLUG - DRAIN O/P	800			
01-02-52359	11110-VJ200	PAN ASSY - OIL	200			
01-02-52360	62500-2S400	SUPPORT - RADIAT	200			
01-02-52361	62510-2S400	BRACE ASSY R/CO	200			
01-02-52362	62550-2S401	STAY - HOOD LOCK	200			
01-02-52363	62520-2S400	SUPPORT - RADIATO	200			
01-02-52364	62210-3S100	STAY - BUMPER	200			
01-02-52365	62040-2S400	BRACKET - BUMPER	200			
01-02-52366	63842-2S400	PROTECTOR - RH	200			
01-02-52367	65400-2S400	HINGE - HOOD	200			
01-02-52368	65401-2S400	HOOD - HINGE ASSY	200			
01-02-52369	65601-3S110	MALE ASSY - HOOD	600			
01-02-52370	65621-VJ400	CABLE ASSY - HOOD	800			
01-02-52371	65892-3S400	ORNAMENT - HOOD	400			
01-02-52372	92110-3S401	CONDENSER ASSY	200			
01-02-52373	62521-2S400	SUPPORT - RADIATOR	200			
01-02-52374	62211-3S100	STAY - BUMPER	200			
01-02-52375	62041-2S400	BRACKET - BUMPER	320			
01-02-52376	63843-2S400	PROTECTOR - FRONT, LH	200			
01-02-52377	76200-2S410	PILLAR - FRONT, RH	200			

01-02-52378	80720-2S400	REGULATOR - DOOR	400			
01-02-52379	76201-2S410	PILLAR - FRONT, LH	200			
01-02-52380	80721-2S400	REGULATOR - DOOR	400			
01-02-52381	20100-2S510	MUFFLER ASSY	400			
01-02-52382	26510-23G20	LAMP LICENCE	800			
01-02-52383	85210-3S401	STAY - BUMPER	200			
01-02-52384	85211-3S401	STAY - BUMPER	200			
01-02-52385	22462-09F10	COIL - IGNITION	400			
01-02-52386	22100-3S400	DISTRIBUTOR ASSY	240			
01-02-52387	22107-2S200	GOVERNOR SET	160			
01-02-52388	24010-VJ600	HARNESS MAIN	200			
01-02-52389	24013-VJ600	HARNESS INSTRU	200			
01-02-52390	24015-2S405	HARNESS ASSY	200			
01-02-52391	24124-VJ200	HARNESS DOOR	200			
01-02-52392	24420-M7000	BEAM BATTERY SETTI	800			
01-02-52393	25540-0W000	SWITCH - TURN SIGNAL	800			
01-02-52394	25260-3S400	SWITCH ASSY	800			
01-02-52395	25335-AD000	ELEMENT LIGHTER	800			
01-02-52396	25331-AD000	LIGHTER COMPL	400			
01-02-52397	25320-75A00	SWITCH STOP LAMP 99	800			
01-02-52398	25240-89920	SWITCH - OIL PRESSURE	800			
01-02-52399	25080-89907	SENSOR	800			
01-02-52400	27230-2M100	IMPELLER - FAN	400			
01-02-52401	92600-VJ600	COMPRESSOR - COOL	800			
01-02-52402	10001-VJ6A1	ENGINE ASSY	320			
01-02-52403	10103-10W02	ENGINE ASSY -SHORT	640			
01-02-52404	32010-VJ600	TRANS MISSION ASSY	80			
01-02-52405	37521-W1029	BEARING KIT CENTER	1600			
01-02-52406	38300-K0665	FINAL DRIVE ASSY	160			
01-02-52407	37126-01G25	JOURNAL KIT	2000			
01-02-52408	12279-R4611	SEAL , OIL CRANK SHAFT, REAR	2400			
01-02-52409	12289-W0400	SEAL , OIL , REAR BENING	4000			
01-02-52410	11041-20G11	HEAD CYL, ASSY	400			
01-02-52411	13270-G2500	GASKET , ROCKER COVER	4000			
01-02-52412	12033-21G00	RING SET - PISTON STD	800			
01-02-52413	12036-21G00	RING SET - PISTON 0.5	400			
01-02-52414	12010-83W12	PISTON W PIN 0.50	1600			
01-02-52415	12201-30W80	CRANKS HAFT	40			
01-02-52416	12209-U6001	BEARING , SET CRANK SAHAFT , 0.25	800			
01-02-52417	12111-V0700	BEARING , SET CON-ROD STD	6400			
01-02-52418	13085-10W10	GUIDE , CHAIN TENSION	2000			
01-02-52419	13091-10W10	GUIDE , CHAIN TENSION	2000			
01-02-52420	13207-81W00	SEAL , OIL VALVE	3200			
01-02-52421	13042-A8601	CRANKS HAFT FORNT OIL SEAL	2000			
01-02-52422	12100-03G10	CINNECTION ROD ASSY	160			
01-02-52423	21310-85G05	FLYWHEEL ASSY	80			
01-02-52424	13070-21002	TENSIONER , CHAIN	800			
01-02-52425	11151-03G00	GUIDE OIL LABEL GAGE	80			
01-02-52426	14035-23G00	GASKET MANIFOLD	400			
01-02-52427	14036-W7060	GASKET EXHAUST MANIFOLD	800			
01-02-52428	15010-V0300	OIL PUMP ASSY	400			
01-02-52429	15040-N8500	SPINDLE OIL PUMP DRIVE	400			
01-02-52430	16011-3S400	CHAMBER ASSY CHOKE	160			
01-02-52431	16101-10W00	VALVE NEEDLE	800			
01-02-52432	16114-W8800	SCREW, ADJUST THROTTLE	400			
01-02-52433	16110-3S400	THROTTLE BODY	160			
01-02-52434	16484-10W00	BAROMETIC PRESSURE SENSOR	800			
01-02-52435	25230-79972	REALY ASSY AUTO CHOKE	400			
01-02-52436	27655-W8800	ACTUATOR	400			

01-02-52437	17042-20G00	PUMP ASSY FUEL	800			
01-02-52438	17251-79920	CAP ASSY FILLER	400			
01-02-52439	25060-VJ401	SENDER UNIT FUEL GAUGE	400			
01-02-52440	18201-21G01	WIRE ASSY ACCELERATOR	160			
01-02-52441	22450-36G25	CABLE SET , HIGH TENSION	1600			
01-02-52442	22162-78A10	CAP ASSY DISTRIBUTOR	400			
01-02-52443	22023-G5110	UNIT SETTER MODALE	800			
01-02-52444	22020-G5111	TRANS ISTOR IGNITION UNIT	800			
01-02-52445	23102-04Y11	STATOR ASSY ALTERNATOR	200			
01-02-52446	23108-0E716	ROTOR ASSY ALTERNATOR	200			
01-02-52447	23120-30R10	BALL BEARING , ALTERNATOR	1600			
01-02-52448	23120-22J20	BALL BEARING , ALTERNATOR	1600			
01-02-52449	23124-VJ610	RECTIFIER ASSY	200			
01-02-52450	23312-73Y00	PINION ASSY	720			
01-02-52451	23343-80W01	SWITCH ASSY	720			
01-02-52452	92480-2S915	HOSE FLEXIBLE, LOW	800			
01-02-52453	92490-2S905	HOSE FLEXIBLE, HIGH	800			
01-02-52454	92400-3S400	HOSE HEATER , INLET	1600			
01-02-52455	92410-3S400	HOSE HEATER , OUTLET	1600			
01-02-52456	28206-3S400	ANTENNA	1600			
01-02-52457	28920-1E400	PUMP ASSY WASHER	800			
01-02-52458	30621-69F27	REPAIR KIT CLUTCH CYL	800			
01-02-52459	46211-79911	HOSE ASSY CHUTCH	400			
01-02-52460	41001-09W00	CALLIPER ASSY FRONT RH	200			
01-02-52461	41011-09W00	CALLIPER ASSY FRONT LH	200			
01-02-52462	41080-41L87	HARDWARE KIT FRONT DISC	160			
01-02-52463	41120-51S26	SEAL KIT DISC BRAKE	800			
01-02-52464	44100-08G12	CYL. ASSY REAR WHEEL	800			
01-02-52465	46010-3S110	CYL. ASSY BRAKE MASTER	400			
01-02-52466	46011-49L27	REPAIR KIT MASTER CYL.	1600			
01-02-52467	46210-3S410	HOSE BRAKE FONT RH	200			
01-02-52468	46211-3S410	HOSE BRAKE FONT LH	200			
01-02-52469	47210-3S100	BOOSTER ASSY BRAKE	800			
01-02-52470	47478-04F03	VALVE CHECK , BOOSTER	160			
01-02-52471	48560-3S185	ROD KIT RELAY	2000			
01-02-52472	48530-3S185	IDLER KIT STEERING	2000			
01-02-52473	49110-66G10	PUMP ASSY POWOR STEERING	800			

SPARE PARTS FOR NISSAN SUNNY CAR FOR TAXI

TYPE 1.6EX-SALOON

CODE		CDGALSFN16EKAK-B-A				
01-02-52474	15208-65F00	FILTER ASSY-OIL	60000			
01-02-52475	11720-V7302	BELT-POWER STEERING OIL PUMP	12000			
01-02-52476	11920-6J900	BELT-COMPRESSOR	10000			
01-02-52477	12033-8M500	RING SET-PISTON	1120			
01-02-52478	A2010-8M510	PISTON,W/PIN	800			
01-02-52479	12207-4M501	BEARING-CRANKSHAFT	320			
01-02-52480	12111-4M501	BEARING-CONNECTING ROD	320			
01-02-52481	12201-4M525	CRANKSHAFT ASSY	200			
01-02-52482	13201-0M600	VALVE-INTAKE	4000			
01-02-52483	13202-8M100	VALVE-EXHAUST	4000			
01-02-52484	13020-8M100	CAMSHAFT ASSY	100			
01-02-52485	13020-2M010	CAMSHAFT ASSY	100			
01-02-52486	13028-4M501	CHAIN-CAMSHAFT	1000			
01-02-52487	10101-8M025	GASKET KIT-ENGINE REPAIR	2000			
01-02-52488	11042-8M025	GASKET KIT-VALVE REGRIND	2000			
01-02-52489	12279-0M300	SEAL-OIL, CRANKSHAFT REAR	2000			
01-02-52490	11128-01M00	PLUG-DRAIN	2000			
01-02-52491	11026-01M02	WASHER-DRAIN PLUG	2000			
01-02-52492	KP710-00150	GASKET-LIQUID	2000			

01-02-52493	13270-4M500	GASKET-ROCKER COVER	2000			
01-02-52494	11044-8M010	GASKET-CYLINDER HEAD	800			
01-02-52495	11040-8M500	HEAD ASSY-CYLINDER	400			
01-02-52496	14035-4M500	GASKET-MANIFOLD	400			
01-02-52497	14036-0M300	GASKET-EXHAUST MANIFOLD, A	2000			
01-02-52498	14004-8M101	MANIFOLD ASSY-EXHAUST	200			
01-02-52499	11270-4M400	INSULATOR ASSY-ENGINE MOUNTING, FRONT RH	400			
01-02-52500	11210-6N000	INSULATOR -ENGINE MOUNTING, FRONT	400			
01-02-52501	11220-4M405	INSULATOR ASSY-ENGINE MOUNTING, FRONT LH	400			
01-02-52502	11320-4M400	INSULATOR-ENGINE MOUNTING, REAR	400			
01-02-52503	16600-5L300	INJECTOR ASSY-FUEL	2000			
01-02-52504	16546-1W900	ELEMENT ASSY-AIR	40000			
01-02-52505	17042-4M400	PUMP ASSY-FUEL	8000			
01-02-52506	16400-4M501	STRAINER ASSY-FUEL	80000			
01-02-52507	10001-8M550	ENGINE ASSY	48			
01-02-52508	10103-8M550	ENGINE ASSY-SHORT	80			
01-02-52509	14055-4M500	HOSE-WATER	800			
01-02-52510	14055-4M510	HOSE-WATER	800			
01-02-52511	21486-1L000	FAN-MOTOR	2000			
01-02-52512	21486-1L010	FAN-MOTOR	2000			
01-02-52513	21487-1L000	MOTOR ASSY-FAN	2000			
01-02-52514	21483-5M300	SHROUD ASSY	400			
01-02-52515	21410-4M403	RADIATOR ASSY	800			
01-02-52516	21430-01F02	CAP ASSY-RADIATOR	4000			
01-02-52517	21503-4M400	HOSE-RADIATOR, LOWER	1600			
01-02-52518	21501-4M401	HOSE-RADIATOR, UPPER	1600			
01-02-52519	21711-4U000	TANK ASSY-RESERVE	80			
01-02-52520	20300-8M400	MUFFLER ASSY-EXHAUST,SUB	120			
01-02-52521	20651-4M410	MOUNTING-EXHAUST, RUBBER	2000			
01-02-52522	20651-4M400	MOUNTING-EXHAUST, RUBBER	2000			
01-02-52523	20100-4M400	MUFFLER ASSY-EXHAUST MAIN	160			
01-02-52524	20010-8M400	TUBE ASSY-EXHAUST, FRONT	80			
01-02-52525	20692-65J00	GASKET-EXHAUST	5000			
01-02-52526	20651-4M400	MOUNTING-EXHAUST, RUBBER	5000			
01-02-52527	21014-4M500	GASKET-WATER PUMP	5000			
01-02-52528	21010-4M525	PUMP ASSY-WATER	10000			
01-02-52529	21200-4M500	THERMOSTAT ASSY	2000			
01-02-52530	11072-4M500	GASKET-THERMOSTAT HOUSING	5000			
01-02-52531	23100-4M510	ALTERNATOR ASSY	320			
01-02-52532	23102-85L10	STATOR ASSY	200			
01-02-52533	23150-AG010	PULLEY ASSY	40			
01-02-52534	23300-73Y10	MOTOR ASSY-STARTER	320			
01-02-52535	23302-73Y10	YOKE	200			
01-02-52536	23310-41B70	ARMATURE ASSY	200			
01-02-52537	23343-73Y10	SWITCH ASSY-MAGNETIC	800			
01-02-52538	23378-M8011	HOLDER ASSY-BRUSH	400			
01-02-52539	23354-42L11	CLUTCH ASSY	400			
01-02-52540	23731-4M500	CAMSHAFT POSITION SENSOR	400			
01-02-52541	22401-20J06	PLUG-SPARK	320000			
01-02-52542	22448-4M500	COIL ASSY-IGNITION	1000			
01-02-52543	26010-4M529	LAMP ASSY-HEAD, RH	1200			
01-02-52544	26060-4M529	LAMP ASSY-HEAD, LH	1200			
01-02-52545	26294-89900	BULB	4000			
01-02-52546	26261-C9903	BULB	4000			
01-02-52547	26130-4M500	LAMP ASSY-TURN SIGNAL, FRONT RH	1200			

01-02-52548	26135-4M500	LAMP ASSY-TURN SIGNAL, FRONT LH	1200			
01-02-52549	26271-89906	BULB	2000			
01-02-52550	26134-4M500	BODY ASSY-FRONT TURN SIGNAL, RH	1200			
01-02-52551	26139-4M500	BODY ASSY-FRONT TURN SIGNAL, LH	1200			
01-02-52552	24012-8M200	HARNESS ASSY-ENGINE ROOM	120			
01-02-52553	24011-5M462	HARNESS ASSY-EGI	120			
01-02-52554	24319-C9910	FUSE	8000			
01-02-52555	24319-C9915	FUSE	8000			
01-02-52556	24017-5M400	HARNESS-BODY, NO2	40			
01-02-52557	24059-4M500	HARNESS-DEFOGGER, EARTH	20			
01-02-52558	24126-4M400	HARNESS ASSY-DOOR, REAR	40			
01-02-52559	24127-4M400	HARNESS ASSY-DOOR, REAR LH	40			
01-02-52560	26150-4M426	LAMP ASSY-FOG, RH	1000			
01-02-52561	26155-4M426	LAMP ASSY-FOG, LH	1000			
01-02-52562	26293-C9906	BULB	4000			
01-02-52563	25240-89920	SWITCH ASSY-OIL PRESSURE	200			
01-02-52564	25080-89907	SENSOR-TEMPERATURE	1000			
01-02-52565	28590-C9917	CONTROL UNIT-IMMOBILISER	1000			
01-02-52566	28890-5M410	BLADE ASSY-WINDSHIELD WIPER	800			
01-02-52567	28890-5M501	BLADE ASSY-WINDSHIELD WIPER	800			
01-02-52568	28895-79905	REFILL-WIPER BLADE, DRIVER	10000			
01-02-52569	28895-89900	REFILL-WIPER BLADE ASSIST	10000			
01-02-52570	28810-5M500	MOTOR ASSY-WINDSHIELD WIPER	80			
01-02-52571	26160-1N000	LAMP ASSY-SIDE FLASHER	1200			
01-02-52572	26261-C9903	BULB	4000			
01-02-52573	26161-3E600	LENS-SIDE FLASHER LAMP, RH	2000			
01-02-52574	26550-5M427	LAMP ASSY-REAR COMBINATION, RH	1200			
01-02-52575	26555-5M427	LAMP ASSY-REAR COMBINATION, LH	1200			
01-02-52576	26550-5M428	LAMP ASSY-REAR COMBINATION, RH	1200			
01-02-52577	26555-5M428	LAMP ASSY-REAR COMBINATION, LH	1200			
01-02-52578	26261-89949	BULB	4000			
01-02-52579	26261-89947	BULB	4000			
01-02-52580	26554-5M427	BODY ASSY-COMBINATION LAMP, RH	1200			
01-02-52581	26559-5M427	BODY ASSY-COMBINATION LAMP, LH	1200			
01-02-52582	26554-5M428	BODY ASSY-COMBINATION LAMP, RH	1200			
01-02-52583	26559-5M428	BODY ASSY-COMBINATION LAMP, LH	1200			
01-02-52584	26261-89917	BULB STOP LAMP	10000			
01-02-52585	25401-4M501	SWITCH ASSY-POWER WINDOW, MAIN	200			
01-02-52586	92110-5M000	CONDENSER ASSY	200			
01-02-52587	92130-4M400	TANK ASSY-LIQUID	320			
01-02-52588	92600-4M410	COMPRESSOR-COOLER	200			
01-02-52589	92665-4M400	CLUTCH ASSY-COMPRESSOR	240			
01-02-52590	24014-8M211	HARNESS ASSY-BODY	40			
01-02-52591	24015-8M200	HARNESS ASSY-TAIL	40			
01-02-52592	24124-8M200	HARNESS ASSY-DOOR, FRONT	40			
01-02-52593	24125-8M200	HARNESS ASSY-DOOR, FRONT	40			
01-02-52594	24010-8M279	HARNESS ASSY-MAIN	40			
01-02-52595	25540-0W000	SWITCH ASSY-TURN SIGNAL	320			

01-02-52596	25260-2Y920	SWITCH ASSY-WIPER	160			
01-02-52597	30610-5M000	CYLINDER ASSY-CLUTCH MASTER	500			
01-02-52598	30611-21U25	PISTON KIT-CLUTCH MASTER CYLINDER	1000			
01-02-52599	30502-53J01	BEARING-CLUTCH RELEASE	1200			
01-02-52600	32005-6J000	SWITCH ASSY-REVERSE LAMP	200			
01-02-52601	39741-01E89	REPAIR KIT-DUST BOOT, INNER	1000			
01-02-52602	39268-4M725	DAMPER KIT-DYNAMIC, FRONT DRIVE SHAFT	1000			
01-02-52603	39100-4M761	SHAFT ASSY-FRONT DRIVE,RH	1000			
01-02-52604	39711-64J01	JOINT ASSY-INNER	1000			
01-02-52605	39268-6M026	DAMPER KIT-DYNAMIC, FRONT DRIVE SHAFT	1000			
01-02-52606	39101-4M761	SHAFT ASSY-FRONT DRIVE, LH	1000			
01-02-52607	30100-WA101	DISC ASSY-CLUTCH	1200			
01-02-52608	30210-53J19	COVER ASSY-CLUTCH	800			
01-02-52609	54302-6N025	STRUT KIT-FRONT SUSPENSION, RH	2000			
01-02-52610	54303-6N025	STRUT KIT-FRONT SUSPENSION, LH	2000			
01-02-52611	54010-4M403	SPRING-FRONT	400			
01-02-52612	54040-4M400	SEAT ASSY-FRONT SPRING, UPPER	600			
01-02-52613	54500-4M410	LINK COMPL-TRANSVERSE, RH	1000			
01-02-52614	54501-4M410	LINK COMPL-TRANSVERSE, LH	1000			
01-02-52615	40206-4M404	ROTOR-DISC BRAKE, FRONT	10000			
01-02-52616	40224-21001	NUT ROAD WHEEL	20000			
01-02-52617	56210-4M425	ABSORBER KIT-SHOCK,REAR	2000			
01-02-52618	55020-4M412	SPRING-REAR SUSPENSION	400			
01-02-52619	43200-4M400	HUB ASSY-REAR	200			
01-02-52620	43206-4M400	DRUM-BRAKE, REAR	1200			
01-02-52621	41060-8M190	PAD KIT-DISC BRAKE	40000			
01-02-52622	41120-6M025	SEAL KIT-DISC BRAKE	4000			
01-02-52623	46010-8M101	CYLINDER ASSY-BRAKE MASTER	400			
01-02-52624	46011-69C29	PISTON KIT-TANDEM BRAKE MASTER CYLINDER	2000			
01-02-52625	44060-8M125	SHOE SET-REAR BRAKE	16000			
01-02-52626	44100-7E611	CYLINDER ASSY-REAR WHEEL	800			
01-02-52627	D4100-7E626	CUP KIT-BRAKE WHEEL CYLINDER, REAR	2000			
01-02-52628	K851M-4M520	MODULE ASSY-AIR BAG, DRIVER	400			
01-02-52629	48520-15U25	SOCKET KIT-TIE ROD, OUTER	2000			
01-02-52630	48521-4M527	SOCKET KIT-TIE ROD, INNER	1000			
01-02-52631	48521-4M587	SOCKET KIT-TIE ROD, INNER	1000			
01-02-52632	62022-8M425	FASCIA KIT-FRONT BUMPER	400			
01-02-52633	62075-8M400	MOULDING-FRONT BUMPER, LH	400			
01-02-52634	62074-8M400	MOULDING-FRONT BUMPER, RH	400			
01-02-52635	62256-4M441	FINISHER-FRONT FASCIA, RH	400			
01-02-52636	62257-4M441	FINISHER-FRONT FASCIA, LH	400			
01-02-52637	62310-8M400	GRILLE KIT-FRONT	480			
01-02-52638	63100-4M730	FENDER-FRONT, RH	320			
01-02-52639	63101-4M730	FENDER-FRONT, LH	240			
01-02-52640	F5100-4M5MM	HOOD	240			
01-02-52641	72700-4M705	GLASS-WINDSHIELD	500			
01-02-52642	G2716-89900	DAM RUBBER-SEALANT	1000			
01-02-52643	H0100-4M7MM	DOOR-FRONT, RH	60			
01-02-52644	H0101-4M7MM	DOOR-FRONT, LH	40			
01-02-52645	80830-4M722	WEATHERSTRIP-FRONT DOOR, RH	200			

01-02-52646	80831-4M722	WEATHERSTRIP-FRONT DOOR, LH	200			
01-02-52647	H2100-4M5MM	DOOR-REAR, RH	48			
01-02-52648	H2101-4M5MM	DOOR-REAR, LH	40			
01-02-52649	82830-4M421	WEATHERSTRIP-REAR DOOR, RH	200			
01-02-52650	82831-4M421	WEATHERSTRIP-REAR DOOR, LH	200			
01-02-52651	80300-4M700	GLASS ASSY-DOOR WINDOW, RH	160			
01-02-52652	80301-4M700	GLASS ASSY-DOOR WINDOW, LH	120			
01-02-52653	80330-4M700	GLASS RUN RUBBER-FRONT DOOR, RH	80			
01-02-52654	80331-4M700	GLASS RUN RUBBER-FRONT DOOR, LH	80			
01-02-52655	82300-4M500	GLASS ASSY-REAR DOOR WINDOW, RH	120			
01-02-52656	82301-4M500	GLASS ASSY-REAR DOOR WINDOW, LH	80			
01-02-52657	82262-4M500	GLASS-REAR DOOR CORNER, RH	160			
01-02-52658	82263-4M500	GLASS-REAR DOOR CORNER, LH	160			
01-02-52659	82272-4M500	WEATHERSTRIP-REAR CORNER, RH	120			
01-02-52660	82273-4M500	WEATHERSTRIP-REAR CORNER, LH	120			
01-02-52661	82330-4M501	GLASS RUN-REAR DOOR WINDOW, RH	120			
01-02-52662	82331-4M501	GLASS RUN-REAR DOOR WINDOW, LH	120			
01-02-52663	78112-4M530	FENDER-REAR, RH	160			
01-02-52664	78113-4M530	FENDER-REAR, LH	160			
01-02-52665	85022-8M125	FASCIA KIT-REAR BUMPER	240			
01-02-52666	85072-8M100	MOULDING-REAR BUMPER	240			
01-02-52667	85074-8M100	MOULDING-REAR BUMPER, RH	240			
01-02-52668	85075-8M100	MOULDING-REAR BUMPER, LH	240			
01-02-52669	H4300-8M2MM	LID-TRUNK	160			
01-02-52670	79712-4M500	GLASS-REAR WINDOW	240			
01-02-52671	G2716-89901	DAM RUBBER-SEALANT	240			
01-02-52672	82870-4M500	MOULDING-REAR DOOR, RH	320			
01-02-52673	82871-4M500	MOULDING-REAR DOOR, LH	320			
01-02-52674	80870-4M500	MOULDING-FRONT DOOR, RH	320			
01-02-52675	80871-4M500	MOULDING-FRONT DOOR, LH	320			
01-02-52676	96365-8M000	GLASS-MIRROR, RH	1000			
01-02-52677	96366-8M000	GLASS-MIRROR, LH	800			
01-02-52678	96301-8M105	MIRROR ASSY-DOOR, RH	480			
01-02-52679	96302-8M105	MIRROR ASSY-DOOR, LH	360			
01-02-52680	J6373-4M401	COVER-MIRROR BODY, RH	800			
01-02-52681	J6374-4M401	COVER-MIRROR BODY, LH	600			
01-02-52682	H0564-2W600	KEY-BLANK, MASTER	1000			
01-02-52683	62890-8M100	EMBLEM-FRONT	400			
01-02-52684	23124-4M510	RECTIFIER -ASSY	400			
01-02-52685	23215-4M510	REGULATOR-ASSY	400			
01-02-52686	23120-22J20	BEARINGBALL	400			
01-02-52687	13500-4M501	COVER ASSY FORNT	80			
01-02-52688	11240-4M400	MEMBER ASSY - ENGINE MOUNTING	80			
01-02-52689	32010-7J006	TRANSMISSION - ASSY MANUAL	20			
01-02-52690	54401-5M110	MEMBER COMPLETE F. SUSPENSION	40			
01-02-52691	40300-4M600	WHEEL ASSY DISC	400			
01-02-52692	22680-4M500	MASS AIR FLOW	160			

01-02-52693	16578-5M000	HOSE AIR	120			
01-02-52694	40210-4M400	BEARING ASSY F.WHEEL	1200			
01-02-52695	43222-70T00	BOLT - HUB	3200			
01-02-52696	40202-4M400	HUB ASSY F. WHEEL	240			
01-02-52697	49001-5M405	GEAR & LINAGE - STEARING	100			
01-02-52698	49297-5M25	SEAL KIT - POWER STEARING	200			
01-02-52699	49210-5M406	GEAR SUB ASSY - STEERING	80			
01-02-52700	49110-5M700	PUMP ASSY - STEERING	240			

SPARE PARTS FOR NISSAN BUS CIVILLIN DX2.8L

CODE						
01-02-52701		UGAVLCFW41SCBHGAKA				
01-02-52702	11750-V2000	BELT - P/STEERING OIL PUMP	8000			
01-02-52703	11720-S9701	BLET - FAN & ALTERNATOR	10000			
01-02-52704	11920-S9711	BELT - COMPRESSOR	6000			
01-02-52705	15208-W1103	FILTER ASSY - OIL	120000			
01-02-52706	12033-T8400	RING SET - PISTON	320			
01-02-52707	12010-C6421	PISTON, W/PIN	1920			
01-02-52708	12111-73400	BEARING - CONNECTING ROD	3600			
01-02-52709	12207-73400	BEARING SET - CRANKSHAFT	300			
01-02-52710	11042-42T25	GASKET KIT - VALVE REGRIND	1000			
01-02-52711	10101-42T25	GASKET KIT - ENGINE REPAIR	1000			
01-02-52712	13201-N4200	VALVE - INTAKE	6800			
01-02-52713	13202-N0401	VALVE - EXHAUST	4800			
01-02-52714	13257-W0300	ROCKET - VALVE	7200			
01-02-52715	13028-21000	CHAIN - CAMSHAFT	520			
01-02-52716	13091-N4201	GUIDE - CHAIN, SLACK SIDE	480			
01-02-52717	13085-21002	GUIDE - CHAIN, TENSION SIDE	480			
01-02-52718	13001-P7980	CAMSHAFT ASSY	120			
01-02-52719	16400-V2705	STRAINER ASSY - FUEL	32000			
01-02-52720	16546-J5571	ELEMENT ASSY - AIR	24000			
01-02-52721	16010-T8403	CARBURETOR	200			
01-02-52722	16455-C6401	GASKET KIT	1200			
01-02-52723	16465-C6400	SCREW & WASHER KIT - A	600			
01-02-52724	16475-P3010	SCREW & WASHER KIT - B	600			
01-02-52725	21410-WJ610	RADIATOR ASSY	200			
01-02-52726	21430-01F02	CAP ASSY - RADIATOR	4800			
01-02-52727	21501-WJ610	HOSE - RADIATOR UPPER	600			
01-02-52728	21503-WJ610	HOSE - RADIATOR LOWER	600			
01-02-52729	21741-WJ610	HOSE - RESERVE TANK	400			
01-02-52730	21060-Y4100	FAN - COOLING	120			
01-02-52731	21010-W3686	PUMP ASSY - WATER	1200			
01-02-52732	21014-07N00	GASKET - WATER PUMP	400			
01-02-52733	20691-77A00	GASKET - EXHAUST	2400			
01-02-52734	23100-63T10	ALTERNATOR ASSY	200			
01-02-52735	23300-Y0701	MOTOR ASSY - STARTER	200			
01-02-52736	22401-W8916	PLUG - SPARK	200000			
01-02-52737	22433-U3140	COIL ASSY - IGNITION	240			
01-02-52738	22100-V2501	DISTRIBUTOR ASSY	200			
01-02-52739	26010-WJ629	LAMP ASSY - HEAD, RH	800			
01-02-52740	26060-WJ629	LAMP ASSY - HEAD, LH	800			
01-02-52741	26015-WJ601	HEAD LAMP UNIT	2000			
01-02-52742	26065-WJ601	HEAD LAMP UNIT	2000			
01-02-52743	26294-89905	BULB (12V60/55W)	12000			
01-02-52744	26293-C9906	BULB	3200			
01-02-52745	26110-WJ625	LAMP ASSY - SIDE COMBI RH	1200			
01-02-52746	26115-WJ625	LAMP ASSY - SIDE COMBI LH	1200			
01-02-52747	26114-WJ100	HOUSING ASSY - SIDE COMBI RH	160			
01-02-52748	26119-WJ100	HOUSING ASSY - SIDE COMBI LH	160			

01-02-52749	26717-89909	BULB	4000			
01-02-52750	28890-WJ605	BLADE ASSY - WINDSHIELD WIPER	800			
01-02-52751	28890-WJ600	BLADE ASSY - WINDSHIELD WIPER	800			
01-02-52752	28895-WJ600	REFILL - WIPER BLADE, DRIVER	4000			
01-02-52753	28895-WJ605	REFILL - WIPER BLADE, ASSIST	4000			
01-02-52754	26550-WJ625	LAMP ASSY - REAR COMBI RH	800			
01-02-52755	26555-WJ625	LAMP ASSY - REAR COMBI LH	800			
01-02-52756	26554-WJ600	BODY ASSY - COMBI LAMP, RH	800			
01-02-52757	26559-WJ600	BODY ASSY - COMBI LAMP, LH	800			
01-02-52758	26717-89911	BULB (12V21W)	12000			
01-02-52759	26717-89912	BULB (12V21/5W)	3200			
01-02-52760	92110-WJ610	CONDENSER ASSY	100			
01-02-52761	92121-S9202	FAN - CONDENSER	80			
01-02-52762	92600-WJ610	COMPRESSOR - COOLER	200			
01-02-52763	30100-07N67	DISC ASSY - CLUTCH	1800			
01-02-52764	30210-48N05	COVER ASSY - CLUTCH	1600			
01-02-52765	30502-69F10	BEARING - CLUTCH RELEASE	1800			
01-02-52766	54010-WJ600	SPRING - FRONT	24			
01-02-52767	54010-WJ601	SPRING - FRONT	24			
01-02-52768	56110-WJ225	ABSORBER KIT - SHOCK, FRONT	1200			
01-02-52769	56210-WJ225	ABSORBER KIT - SHOCK, REAR	1200			
01-02-52770	55020-WJ500	SPRING ASSY - LEAF, REAR	40			
01-02-52771	40215-0T100	BEARING ASSY - FRONT WHEEL	1200			
01-02-52772	40210-0T100	BEARING ASSY - FRONT WHEEL	1200			
01-02-52773	40010-0T300	KNUCKLE ASSY, RH	40			
01-02-52774	40011-0T300	KNUCKLE ASSY, LH	40			
01-02-52775	43215-0T000	BEARING - REAR AXLE, OUTER	960			
01-02-52776	43210-50T00	BEARING - REAR AXLE, INNER	960			
01-02-52777	38164-0T003	SHAFT ASSY - REAR AXLE	160			
01-02-52778	41060-WJ185	PAD KIT - DISC BRAKE	48000			
01-02-52779	41120-WJ125	SEAL KIT - DISC BRAKE	800			
01-02-52780	41060-0T925	SHOE SET - REAR BRAKE	12000			
01-02-52781	D4100-0T092	CUP KIT - BRAKE WHEEL CYL REAR	400			
01-02-52782	44100-0T010	CYLINDER ASSY - REAR WHEEL, FORE RH	240			
01-02-52783	44102-0T010	CYLINDER ASSY - REAR WHEEL, FORE LH	240			
01-02-52784	44101-0T010	CYLINDER ASSY - REAR WHEEL, AFTER RH	240			
01-02-52785	44103-0T010	CYLINDER ASSY - REAR WHEEL, AFTER LH	240			
01-02-52786	46010-WJ600	CYLINDER ASSY - BRAKE MASTER	400			
01-02-52787	49110-42T00	PUMP ASSY - POWER STEERING	160			
01-02-52788	49200-42T00	GEAR ASSY - POWER STEERING	160			
01-02-52789	48520-0T825	SOCKET KIT - TIE ROD, OUTER	1200			
01-02-52790	48570-0T825	SOCKET KIT - TIE ROD, OUTER	1200			
01-02-52791	40053-1T510	ARM - KNUCKLE, LH	24			
01-02-52792	40052-1T500	ARM - KNUCKLE, RH	24			
01-02-52793	48502-42T00	ARM - PITMAN	16			
01-02-52794	72700-WJ100	GLASS - WINDSHIELD	480			
01-02-52795	72716-WJ100	DAM RUBBER - SEALANT	320			
01-02-52796	62256-WJ100	GRILLE - FRONT BUMPER	280			
01-02-52797	62255-WJ100	GRILLE - FRONT BUMPER, LH	200			
01-02-52798	62254-WJ100	GRILLE - FRONT BUMPER, RH	200			
01-02-52799	62022-WJ125	FASCIA KIT - FRONT BUMPER	160			
01-02-52800	H0101-WJ6MM	DOOR - FRONT, LH	32			

01-02-52801	80831-WJ600	WEATHERSTRIP - FRONT DOOR, LH	40			
01-02-52802	80321-WJ600	GLASS - FRONT DOOR, OUTER LH	40			
01-02-52803	80323-WJ600	GLASS - FRONT DOOR, INNER LH	40			
01-02-52804	80331-WJ600	GLASS RUN RUBBER - FRONT DOOR, LH	40			
01-02-52805	79712-WJ100	GLASS - REAR WINDOW	100			
01-02-52806	79714-WJ100	WLET - BACK WINDOW	80			
01-02-52807	85022-WJ125	FASCIA KIT - REAR BUMPER	24			
01-02-52808	84300-WJ600	LID - TRUNK	60			
01-02-52809	84431-WJ100	STAY ASSY - TRUNK LID A, LH	200			
01-02-52810	83233-WJ100	GLASS - SIDE WINDOW 3RD INNER, LH	40			
01-02-52811	83231-WJ100	GLASS - SIDE WINDOW 3RD OUTER, LH	40			
01-02-52812	83232-WJ100	GLASS - SIDE WINDOW 3RD INNER, RH	40			
01-02-52813	83230-WJ100	GLASS - SIDE WINDOW 3RD OUTER, RH	40			
01-02-52814	83222-WJ120	GLASS - SIDE WINDOW 2ND INNER RH	40			
01-02-52815	83220-WJ100	GLASS - SIDE WINDOW 2ND OUTER RH	40			
01-02-52816	83210-WJ100	GLASS - SIDE WINDOW, 1ST RH	40			
01-02-52817	27140-R8570	CORE ASSY - FRONT HEATER	24			
01-02-52818	27325-WJ100	CORE ASSY - REAR HEATER	24			
01-02-52819	27325-WJ100	CORE ASSY - REAR HEATER	24			
01-02-52820	27365-WJ100	PACKING - HEATER	40			
01-02-52821	27365-WJ100	PACKING - HEATER	40			
01-02-52822	27582-WJ100	HARNESS - CONTROL, RR HEATER	16			
01-02-52823	74370-WJ600	BRACKET - HEATER	40			
01-02-52824	96301-WJ620	MIRROR ASSY - OUTSIDE, RH	960			
01-02-52825	96302-WJ620	MIRROR ASSY - OUTSIDE, LH	400			
01-02-52826	81101-WJ610	DOOR ASSY - ENTRANCE, LH	24			
01-02-52827	81308-WJ100	GLASS ENTRANCE DOOR WINDOW	40			
01-02-52828	81312-WJ100	WEATHERSTRIP - ENTRANCE DOOR WINDOW	32			
01-02-52829	81310-WJ100	WEATHERSTRIP - ENTRANCE DOOR WINDOW	32			
01-02-52830	81836-WJ101	WEATHERSTRIP - ENTRANCE DOOR	32			
01-02-52831	81833-WJ100	WEATHERSTRIP - ENTRANCE DOOR	32			
01-02-52832	81834-WJ100	WEATHERSTRIP - ENTRANCE DOOR	32			
01-02-52833	12200-P3000	CRANKSHAFT ASSY	160			
01-02-52834	12100-16G10	ROD COMPL - CONNECTING	720			
01-02-52835	11041-N4283	HEAD ASSY - CYLINDER	120			
01-02-52836	48430-WJ200	WHEEL ASSY - STRG, LESS PAD	32			
01-02-52837	61202-WJ600	PANEL ASSY - FRONT	80			
01-02-52838	78841-S9625	CYLINDER SET - GAS FILLER LOCK	280			
01-02-52839	H0601-50J02	CYLINDER SET - DOOR LOCK, LH	160			
01-02-52840	20050-WJ600	TUBE ASSY - EXHAUST REAR	160			
01-02-52841	20100-S9600	MUFFLER ASSY - EXHAUST MAIN	320			
01-02-52842	26510-WJ601	LAMP ASSY - LICENCE	80			
01-02-52843	28205-WJ600	ANTENNA ASSY	80			
01-02-52844	81835-WJ100	WEATHERSTRIP - ENTRANCE DOOR	40			

01-02-52845	10001-42TD0	ENGINE ASSY	80			
01-02-52846	10103-T8400	ENGINE ASSY -SHORT	140			
01-02-52847	12310-N4256	FLY WHEEL- ASSY	80			
01-02-52848	13042-A3510	SEAL OIL CRANK - FRANT	320			
01-02-52849	12279-R4601	SEAL OIL CRANK - REAR	240			
01-02-52850	11110-P8001	PAN ASSY - OIL	32			
01-02-52851	11121-E3001	GASKET OIL PAN	200			
01-02-52852	13270-06J00	GASKET ROCKER COVER	4000			
01-02-52853	21082-T8400	COUPLING ASSY FAN	160			
01-02-52854	23120-22J20	BEARING BALL - ALTER	360			
01-02-52855	23120-30R10	BEARING BALL - ALTER	360			
01-02-52856	23215-63T10	REG ULATOR ASSY	280			
01-02-52857	23124-63T10	RECTIFIER ASSY	320			
01-02-52858	23343-N3301	SWITCH ASSY - MAGNETIC	240			
01-02-52859	23312-Y0700	PINION ASSY	240			
01-02-52860	23378-N3301	HOLDER ASSY BRUSH	320			
01-02-52861	23322-U0100	LERVER SET SHIFT	40			
01-02-52862	13501-A8600	COVER ASSY - FRONT	24			
01-02-52863	13049-P0300	INLET - WATER	60			
01-02-52864	22450-42T25	CABLE SET HIGH TEUSION	240			
01-02-52865	43010-WJ600	CASE ASSY REAR AXLE	24			
01-02-52866	43206-0T611	DRUM BRAKE REAR	320			
01-02-52867	40001-0T801	AXLE FRONT CENTER	8			
01-02-52868	40030-0T000	BERA ASSY - KING PIN	120			
01-02-52869	11220-38T00	INSALATOR ENGINE M.FRONT	320			
01-02-52870	11320-38T00	INSALATOR ENGINE M REA	80			
01-02-52871	38300-95E09	FINAL DRIVE ASSY	72			
01-02-52872	38210-T9005	FLEANGE ASSY	32			
01-02-52873	37000-37T10	SHAFT ASSY PROPELLER	80			
01-02-52874	37521-59225	BEARING KIT CENTRE	280			
01-02-52875	37126-C9425	JOURNAL - KIT	400			
01-02-52876	40211-50000	BEARING DIFF	160			
01-02-52877	38120-13201	BEARING DRIVE PINION.F	128			
01-02-52878	38120-76510	BEARING DRIVE PINION.R	128			
01-02-52879	38165-76000	SPACER PINION	80			
01-02-52880	38166-76000	SPACER PINION	80			
01-02-52881	38167-76000	SPACER PINION	80			
01-02-52882	38153-82102	WASHER PINION ADJUST	80			
01-02-52883	38153-82104	WASHER PINION ADJUST	80			
01-02-52884	38153-82106	WASHER PINION ADJUST	80			
01-02-52885	38153-82108	WASHER PINION ADJUST	80			
01-02-52886	38153-82110	WASHER PINION ADJUST	80			
01-02-52887	38153-82112	WASHER PINION ADJUST	80			
01-02-52888	38153-82114	WASHER PINION ADJUST	80			
01-02-52889	38153-82116	WASHER PINION ADJUST	80			
01-02-52890	38153-82118	WASHER PINION ADJUST	80			
01-02-52891	38100-J8110	GEAR SET FINAL DRIVE	40			
01-02-52892	40227-0T000	SEAL DUST FRONT WHEEL	1200			
01-02-52893	30610-T8910	CYLINDER ASSY CLUTCH MASTER	280			
01-02-52894	30611-C3625	PISTION KIT CLUTCH MASTER	800			
01-02-52895	30620-TB021	CYLINDER ASSY - SLAVE	400			
01-02-52896	30621-69F27	PISTION KIT - SLAVE	800			
01-02-52897	30630-WJ000	BOOSTER ASSY - CLUTCH	64			
01-02-52898	46011-WJ126	PISTION KIT BRAKE MASTER	960			
01-02-52899	46210-WJ100	TUBE ASSY - F. BRAKE . R	480			
01-02-52900	46211-0M644	TUBE ASSY - REAR	160			
01-02-52901	40300-0T005	WHEEL ASSY - DISC	240			
01-02-52902	40224-WJ100	NUT- ROAD WHEEL .R	4800			
01-02-52903	40225-WJ100	NUT- ROAD WHEEL .L	4800			
01-02-52904	43224-WJ100	NUT- ROAD WHEEL .R	4800			

01-02-52905	43225-WJ100	NUT- ROAD WHEEL .L	4800			
01-02-52906	43226-WJ100	NUT- ROAD WHEEL .R	8000			
01-02-52907	43227-WJ100	NUT- ROAD WHEEL .L	8000			
01-02-52908	47210-WJ620	BOOSTER ASSY - BRAKE	120			
01-02-52909	41001-WJ100	CALIPER ASSY FRPNT .R	240			
01-02-52910	41011-WJ100	CALIPER ASSY FRPNT .L	240			
01-02-52911	41133-OT300	PIN BRAKE . R	240			
01-02-52912	41134-OT300	PIN BRAKE . L	240			
01-02-52913	D4100-OT092	CUP KIT - BRAKE WHEEL . R	800			
01-02-52914	48680-42T25	LINK KIT DRAG	400			
01-02-52915	49591-42T25	SEAL KIT - POWER STEERING	320			
01-02-52916	49140-15V00	ROTOR - POWER STEERING	200			
01-02-52917	49321-63T25	SEAL KIT OIL SECTOR SHAFT	240			
01-02-52918	49345-OT025	SEAL KIT OIL REAR HOUSING	240			
01-02-52919	15010-21001	PUMP ASSY OIL	280			
01-02-52920	15050-P6500	STRAINER ASSY - OIL	60			
01-02-52921	48511-OT800	ROD- TIE	120			
01-02-52922	40202-WJ125	HUB ASSY R ROAD WHEEL	32			
01-02-52923	40203-WJ125	HUB ASSY R ROAD WHEEL . . L	32			
01-02-52924	96303-WJ620	MIRROR - OUT SIDE R	2400			
01-02-52925	96304-62T00	MIRROR - OUT SIDE L	1600			
01-02-52926	96305-T6000	MIRROR ASSY - UNDER	1000			
01-02-52927	14035-N3500	GASKET MANIFOLD	2400			
01-02-52928	21200-P7901	THERMOSTAT ASSY	1000			
01-02-52929	11060-Y7010	OUTLET WATER THERMO	720			
01-02-52930	11061-V1501	HOUSING THEROSTAT	72			
01-02-52931	11062-D5700	GASKET THERMOSTAT	1600			
01-02-52932	43202-WJ125	HUB ASSY REAR R	32			
01-02-52933	43203-WJ125	HUB ASSY REAR L	32			
01-02-52934	14331-34210	GASKET HEAT PLATE	240			
01-02-52935	16174-C6401	INSULATOR - CABORATOR	240			
01-02-52936	16011-T8402	CAMBER - CHOCKE	80			
01-02-52937	16033-P3010	JET MAIN	360			
01-02-52938	16033-P3011	JET MAIN	360			
01-02-52939	16051-P3010	BLEED STEP AIR	320			
01-02-52940	16053-08000	JET -SLOW	360			
01-02-52941	16061-23010	FLOOT	320			
01-02-52942	16095-36710	INJECTOR PUMP	240			
01-02-52943	16125-U6700	GAUGE LEVEL	60			
01-02-52944	16182-V1200	ILE SPEED CONTROL IDLE	120			
01-02-52945	16313-T8400	DIAPHRAM ASSY	120			
01-02-52946	24370-C9910	FUSEABLE LINK 30A	3200			
01-02-52947	24370-C9920	FUSEABLE LINK 40A	3200			
01-02-52948	24319-C9910	FUSE 10A	40000			
01-02-52949	24319-C9920	FUSE 20A	40000			
01-02-52950	24820-WJ606	SPEEDOMETER -ASSY	100			
01-02-52951	24813-WJ101	COVER FRONT -CLUSTER	40			
01-02-52952	24812-WJ101	HOUSING-METER	16			
01-02-52953	25260-WJ100	SWITCH WIPER	160			
01-02-52954	25261-OT007	SWITCH ASSY WIPPER	160			
01-02-52955	25350-41T00	SWITCH-DEFOGGER	60			
01-02-52956	25541-OT004	SWITCH TURN SIGNAL	240			
01-02-52957	25567-OT000	BODY COBINATION-SWITCH	160			
01-02-52958	25290-41T00	SWITCH HAZARD	160			
01-02-52959	25230-79981	RELAY-HEATER &COOLER	4000			
01-02-52960	25230-79972	RELAY-HEATER &COOLER	1000			
01-02-52961	25630-79960	RELAY -HORN	360			
01-02-52962	25730-08T00	FLASHER ASSY	240			
01-02-52963	28510-WJ500	AMPLUFIRE ASSY-WIPER	100			
01-02-52964	92122-S9700	MOTOR-CONDENSOR	200			
01-02-52965	92131-WJ600	TANK-A/C	200			

01-02-52966	25620-R8460	HORN-LOW	800			
01-02-52967	25610-R8460	HORN-HIGH	800			
01-02-52968	25240-89910	SWITCH-OIL	320			
01-02-52969	25080-89902	SENSOR-TEMP	320			
01-02-52970	11140-P6502	GAUGE-OIL LEVEL	100			
01-02-52971	11044-P9600	GASKET CYL -HEAD	560			
01-02-52972	13212-21011	GUIDE VALVE IN TAKE	2880			
01-02-52973	13213-21011	GUIDE VALVE EXH	1920			
01-02-52974	1325-21003	SPRING -ROCKER	480			
01-02-52975	13234-21000	PIVOT-ROCKER	1920			
01-02-52976	13070-E3000	TENSIONER-CHAIN	480			
01-02-52977	13207-81W00	SEAL OIL-VALVE	9600			
01-02-52978	13218-Y7000	GUIDE ROCKER VALVE	1920			
01-02-52979	13203-E4100	SPRING VALVE-OUTER	480			
01-02-52980	13204-23000	SPRING VALVE-INNER	480			
01-02-52981	12312-19G01	GEAR RING	60			
01-02-52982	13021-U8010	SPROCKET-CRANKSHAFT	40			
01-02-52983	14004-23L00	MANIFOLD-EXHAUST	120			
01-02-52984	17020-S9701	PUMP-ASSY-FUEL FRONT	1600			
01-02-52985	17020-S9711	PUMP -ASSY-FUEL REAR	1600			
01-02-52986	16404-28530	FILTER-FUEL PUMP	12000			
01-02-52987	16406-29900	GASKET	8000			
01-02-52988	17530-S9701	SEPERATOR-ASSY	400			
01-02-52989	17201-WJ610	TANK ASSY-FUEL	24			
01-02-52990	18201-37T00	WIRE-ASSY-ACCELERATOR	240			
01-02-52991	21475-WJ610	SHROUD ASSY-FAN	120			
01-02-52992	22178-21001	SUPPORT-DISTRIBUTOR	48			
01-02-52993	79100-WJ600	PANEL-ASSY- BACK	20			
01-02-52994	80607-70N00	HANDLE ASSY-DOOR OUTSIDE	120			
01-02-52995	22162-57L03	CAPASSY -DISTRIBUTOR	320			
01-02-52996	25157-57L03	ROTOR HEAD	400			
01-02-52997	22145-89901	CONTACT SET	32000			
01-02-52998	22301-V2501	CONTROL VACUME	120			
01-02-52999	22102-V2501	CONDENSOR ASSY	12000			
01-02-53000	32010-42T00	TRANSMISSION ASSY	40			
01-02-53001	32111-J2000	COVER ASSY FRONT	24			
01-02-53002	30501-C6980	SLEEVE CLUTCH RELEASE	80			
01-02-53003	32133-J2000	BEARING	160			
01-02-53004	32219-J6500	BEARING	160			
01-02-53005	32273-C8000	BEARING	160			
01-02-53006	32272-J2000	BEARING PILOT	160			
01-02-53007	32264-86401	BEARING NEEDLE	160			
01-02-53008	32263-86400	BEARING NEEDLE	200			
01-02-53009	32349-86400	BUSH	80			
01-02-53010	32319-0H700	BEARING COUNTER SHAFT	120			
01-02-53011	32607-86402	RING BAULK	720			
01-02-53012	32604-T8000	RING BAULK	480			
01-02-53013	32201-T8100	GEAR -MANI DRIVE	32			
01-02-53014	32603-86400	SPRING SHIFTS	120			
01-02-53015	32605-J2003	HUB SYNCRON 3RD &4TH	32			
01-02-53016	32606-J2001	SLEEVE COUPLIN	32			
01-02-53017	32261-T9000	GEAR-3RD	32			
01-02-53018	32241-J2000	SHAFT-MAIU	32			
01-02-53019	32251-J2000	GEAR ASSY-2ND	32			
01-02-53020	32601-86400	HUB SYNCRO 1ST&2ND	32			
01-02-53021	32602-86400	SPRING SHIFTING	100			
01-02-53022	32245-J2000	GEAR-REUERSE	24			
01-02-53023	32243-J2000	GEAR-1ST	32			
01-02-53024	32213-T9100	GEAR -COUNTER	40			
01-02-53025	32312-T9012	GEAR VER DRIVE	40			
01-02-53026	32258-86400	HUB SYNCRO-OVER	40			

01-02-53027	32608-86400	INSERT SHIFTING	560			
01-02-53028	32609-J2000	INSERT SHIFTING	560			
01-02-53029	32609-86400	INSERT SHIFTING	400			
01-02-53030	32611-86400	SLEEVE COUPLING	40			
01-02-53031	32283-86401	BEARING REVERSE	80			
	SPARE PARTS FOR NISSAN PICKUP 4X2 DOUBLE CABIN					
01-02-53032		DECS	QTY			
01-02-53033	15208-W1106	FILTER ASSY OIL	64000			
01-02-53034	11950-80W00	BELT - OIL PUMP	4000			
01-02-53035	11720-30W00	BELT - FAN	4000			
01-02-53036	11920-M6660	BELT - COMPRESSOR	4000			
01-02-53037	11210-18G01	INSULATOR	800			
01-02-53038	11320-01G00	INSULATOR	400			
01-02-53039	12033-21G00	RING SET - PISTON	400			
01-02-53040	12010-83W11	PISTON WITH PIN	1600			
01-02-53041	13201-N8501	VALVE - INTAKE	800			
01-02-53042	13202-N8502	VALVE - EXHAUST	800			
01-02-53043	13028-03G00	CHAIN - CAMSHAFT	400			
01-02-53044	13257-W0560	ROCKER - VALVE	200			
01-02-53045	13261-W0560	ROCKER - VALVE	200			
01-02-53046	10101-71G25	GASKET - ENGINE	400			
01-02-53047	11042-09N26	GASKET - VALVE	400			
01-02-53048	16400-41B05	STRAINER FUEL	24000			
01-02-53049	16546-G7300	ELEMENT ASSY	24000			
01-02-53050	14055-10W00	HOSE - WATER	400			
01-02-53051	21410-3S100	RADIATOR ASSY	200			
01-02-53052	21501-3S401	HOSE TOP	400			
01-02-53053	21505-3S411	HOSE ASSY	400			
01-02-53054	21506-3S411	HOSE BOTTOM	400			
01-02-53055	21430-01F02	CAP ASSY PRESSURE	800			
01-02-53056	21010-26G27	PUMP ASSY - WATER	800			
01-02-53057	21014-07N00	GASKET - WATER PUMP	800			
01-02-53058	21082-T6400	COUPLING ASSY	400			
01-02-53059	21200-V0201	THERMOSTAT ASSY	200			
01-02-53060	23300-W0403	MOTOR STARTER	80			
01-02-53061	23100-VJ610	ALTERNATOR ASSY	80			
01-02-53062	22401-W8916	PLUG - SPARK	192000			
01-02-53063	26010-3S225	LAMP ASSY - HEAD RH	200			
01-02-53064	26060-3S225	LAMP ASSY - HEAD LH	200			
01-02-53065	26015-3S200	UNIT SEALED	400			
01-02-53066	26065-3S200	UNIT SEALED	400			
01-02-53067	26719-C9920	BULB (12V60/55W)	800			
01-02-53068	26261-C9903	BULB (12V5W)	800			
01-02-53069	26717-89911	BULB (12V1W)	800			
01-02-53070	26110-2S425	LAMP - SIDE COMBI	400			
01-02-53071	26115-2S425	LAMP - SIDE COMBI	400			
01-02-53072	28890-VB005	BLADE - WIPER	800			
01-02-53073	28895-34E00	REFILL - WIPER	4000			
01-02-53074	26521-23G60	LENS - COMBI LAMP	400			
01-02-53075	26526-23G60	LENS - COMBI LAMP	400			
01-02-53076	26717-89912	BULB (12V21W/5W)	800			
01-02-53077	26717-89911	BULB (12V21W)	800			
01-02-53078	B6550-23G61	LAMP - COMBI RR	400			
01-02-53079	B6555-23G61	LAMP - RR - COMBI	400			
01-02-53080	30100-VJ200	DISC ASSY - CLUTCH	400			
01-02-53081	30210-VJ200	COVER - CLUTCH	200			
01-02-53082	30610-3S104	CYLINDER ASSY	200			
01-02-53083	30502-69F10	BEARING C/RELEASE	200			
01-02-53084	40014-01G50	SPINDLE KNUCKLE, RH	400			

01-02-53085	40015-01G50	SPINDLE KNUCKLE, LH 99	400			
01-02-53086	40052-3S600	ARM - KNUCKLE, RH	400			
01-02-53087	40053-3S600	ARM - KNUCKLE, LH	400			
01-02-53088	54524-2S485	LINK COMPL - RH	400			
01-02-53089	54525-2S485	LINK COMPL - LH	400			
01-02-53090	56110-25G85	ABSORBER SHOCK	4000			
01-02-53091	56200-25G25	ABSORBER SHOCK	4000			
01-02-53092	55045-10W00	BUSH SPRING	8000			
01-02-53093	55046-01G00	BUSHING	16000			
01-02-53094	55240-15G00	BUMPER SUSPENS	800			
01-02-53095	55020-2S402	SPRING ASSY	160			
01-02-53096	41060-31E94	PAD KIT - DISC	24000			
01-02-53097	D4100-F2985	CUP KIT - BRAKE	400			
01-02-53098	44060-2S425	SHOE SET - REAR	2256			
01-02-53099	48510-2S485	ROD KIT - TIE, RH	400			
01-02-53100	48630-2S485	ROD KIT - TIE, LH	400			
01-02-53101	62024-2S400	BUMPER - FRONT, RH	200			
01-02-53102	62025-2S400	BUMPER - FRONT, LH	200			
01-02-53103	62022-2S400	BUMPER - FRONT	80			
01-02-53104	62026-2S425	FASCIA FRONT BUMPER	200			
01-02-53105	62310-2S500	GRILLE - RADIATOR	400			
01-02-53106	63112-2S400	FENDER - FRONT, RH	80			
01-02-53107	63113-2S900	FENDER - FRONT, LH	80			
01-02-53108	F5100-2S900	HOOD	80			
01-02-53109	72712-VJ200	GLASS - WINDSHIELD	400			
01-02-53110	G2716-89901	RUBBER DUM	400			
01-02-53111	K3820-2S400	MUDGUARD REAR, RH	120			
01-02-53112	K3821-2S400	MUDGUARD REAR, LH	120			
01-02-53113	F3850-2S400	MUDGUARD FRONT, RH	120			
01-02-53114	F3851-2S400	MUDGUARD FRONT, LH	120			
01-02-53115	79712-1S500	GLASS - REAR WINDOW	80			
01-02-53116	79710-VJ200	WSTRIP - REAR WINDOW	40			
01-02-53117	H0100-2S900	DOOR - FRONT, RH	40			
01-02-53118	H0101-2S900	DOOR - FRONT, LH	40			
01-02-53119	80830-2S400	WSTRIP ASSY - FR	100			
01-02-53120	80831-2S400	WSTRIP ASSY - FR	100			
01-02-53121	80300-2S400	GLASS - FR DOOR, R	80			
01-02-53122	80301-2S400	GLASS - FR DOOR, L	80			
01-02-53123	H2100-VJ4MM	DOOR - REAR, RH	40			
01-02-53124	H2101-VJ4MM	DOOR - REAR, LH	40			
01-02-53125	82830-2S400	WSTRIP - RR DOOR, RH	100			
01-02-53126	82831-2S400	WSTRIP - RR DOOR, LH	100			
01-02-53127	82300-2S700	GLASS RR DOOR, RH	80			
01-02-53128	82301-2S700	GLASS RR DOOR, LH	80			
01-02-53129	85014-3S400	STEP ASSY - CENTER	40			
01-02-53130	85232-1S800	STEP BOARD - REAR BUMPER	80			
01-02-53131	85060-21G00	OVERRIDER ASSY - RR	40			
01-02-53132	85061-21G00	OVERRIDER ASSY - RR	40			
01-02-53133	96301-19G10	MIRROR ASSY DOOR, RH	160			
01-02-53134	96302-19G10	MIRROR ASSY DOOR, LH	160			
01-02-53135	11044-10W02	GASKET - CYLINDER	800			
01-02-53136	16010-3S400	CARBURATOR ASSY	40			
01-02-53137	37000-3S200	SHAFT ASSY - PROP	200			
01-02-53138	01111-00011	BOLT - FIX PROPE	1600			
01-02-53139	12117-V0700	BEARING - CONNECTING ROD	400			
01-02-53140	12207-U6001	BUSHING SET	400			
01-02-53141	40210-F1700	BEARING ASSY-FR	800			
01-02-53142	40215-F1700	BEARING ASSY-FR	800			
01-02-53143	40210-85000	BEARING - TAPER	800			
01-02-53144	24319-C9907	FUSE 7.5A	4000			
01-02-53145	24319-C9910	FUSE 10A	4000			

01-02-53146	24319-C9915	FUSE 15A	4000			
01-02-53147	24319-C9920	FUSE 20A	4000			
01-02-53148	11026-01M02	WAHSEY - DRAIN PLUG	200			
01-02-53149	11128-01M00	PLUG - DRAIN O/P	120			
01-02-53150	11110-VJ200	PAN ASSY - OIL	80			
01-02-53151	62500-2S400	SUPPORT - RADIAT	40			
01-02-53152	62510-2S400	BRACE ASSY R/CO	40			
01-02-53153	62550-2S401	STAY - HOOD LOCK	40			
01-02-53154	62520-2S400	SUPPORT - RADIATO RH	80			
01-02-53155	62210-3S100	STAY - BUMPER	40			
01-02-53156	62040-2S400	BRACKET - BUMPER	80			
01-02-53157	63842-2S400	PROTECTOR - RH	40			
01-02-53158	65400-2S400	HINGE - HOOD RH	40			
01-02-53159	65401-2S400	HOOD - HINGE ASSY LH	40			
01-02-53160	65601-3S110	MALE ASSY - HOOD	80			
01-02-53161	65621-VJ400	CABLE ASSY - HOOD	120			
01-02-53162	65892-3S400	ORNAMENT - HOOD	120			
01-02-53163	92110-3S401	CONDENSER ASSY	40			
01-02-53164	62521-2S400	SUPPORT - RADIATOR LH	80			
01-02-53165	62211-3S100	STAY - BUMPER	40			
01-02-53166	62041-2S400	BRACKET - BUMPER	80			
01-02-53167	63843-2S400	PROTECTOR - FRONT, LH	40			
01-02-53168	76200-2S410	PILLAR - FRONT, RH	20			
01-02-53169	76500-VJ360	PILLAR - CENTER	20			
01-02-53170	80720-2S400	REGULATOR - DOOR	80			
01-02-53171	82720-VJ300	REGULATOR - DOOR	80			
01-02-53172	76201-2S410	PILLAR - FRONT, LH	20			
01-02-53173	80721-2S400	REGULATOR - DOOR	80			
01-02-53174	82721-VJ300	REGULATOR - DOOR	80			
01-02-53175	20100-2S510	MUFFLER ASSY	200			
01-02-53176	26510-23G20	LAMP LICENCE	200			
01-02-53177	85210-3S401	STAY - BUMPER	80			
01-02-53178	85211-3S401	STAY - BUMPER	80			
01-02-53179	22462-09F10	COIL - IGNITION	200			
01-02-53180	22100-3S400	DISTRIBUTOR ASSY	80			
01-02-53181	22107-2S200	GOVERNOR SET	80			
01-02-53182	24010-VJ406	HARNESS MAIN	40			
01-02-53183	24013-VJ461	HARNESS INSTRU	40			
01-02-53184	24015-2S400	HARNESS ASSY	40			
01-02-53185	24124-VJ200	HARNESS DOOR	40			
01-02-53186	24425-89903	ROD - BATTERY FIX	40			
01-02-53187	24420-M7000	BEAM BATTERY SETTI	40			
01-02-53188	25540-0W000	SWITCH - TURN SIGNAL	200			
01-02-53189	25260-3S400	SWITCH ASSY	200			
01-02-53190	25335-AD000	ELEMENT LIGHTER	200			
01-02-53191	25331-AD000	LIGHTER COMPL	80			
01-02-53192	25320-75A00	SWITCH STOP LAMP 99	200			
01-02-53193	25240-89920	SWITCH - OIL PRESSURE	200			
01-02-53194	25080-89907	SENSOR	200			
01-02-53195	27230-2M100	IMPELLER - FAN	100			
01-02-53196	21060-57W00	FAN COOLING	80			
01-02-53197	21051-S9100	PULLEY - FAN & WP	80			
01-02-53198	26261-C9909	BULB (12V5W)	800			
01-02-53199	26160-70N00	LAMP - SIDE FLASH	800			
01-02-53200	26716-89909	BULB (12V10W)	800			
01-02-53201	46010-3S100	CYLINDER ASSY	160			
01-02-53202	93400-2S410	GATE - REAR	40			
01-02-53203	48430-2S900	WHEEL ASSY - STEERING LESS PAD	20			
01-02-53204	48805-3S100	COLUMN ASSY - STEERING	40			
01-02-53205	26515-23G20	LAMP ASSY - LICENCE LH	120			

01-02-53206	27220-VJ400	FAN WITH MOTOR	80			
01-02-53207	76501-VJ360	PILLAR - CENTER	20			
01-02-53208	K9038-VJ400	STRIPE - ACCENT	200			
01-02-53209	K9039-VJ400	STRIPE - ACCENT	200			
01-02-53210	80240-1S900	GLASS - DOOR VENT	100			
01-02-53211	80241-1S900	GLASS - FR DOOR C	100			
01-02-53212	92600-VJ200	COMPRESSOR - COOL	200			
01-02-53213	10001-VJ6A1	ENGINE ASSY	56			
01-02-53214	10103-10W02	ENGINE ASSY -SHORT	200			
R SCHMIT BPW AND AXLE GIGANT						
CODE	PART NO	DESC				
01-02-53215	16118	SCREW	64			
01-02-53216	16357	RING	200			
01-02-53217	16358	CASTLE NUT	800			
01-02-53218	11834	CAMSHAFT ,LH	16			
01-02-53219	11835	CAMSHAFT ,RH	16			
01-02-53220	10675	LOCK RING	16			
01-02-53221	13166	RING	16			
01-02-53222	10676	O-RING	80			
01-02-53223	13122	SEAL	80			
01-02-53224	11197	RIM	56			
01-02-53225	820939	STOP NUT	16			
01-02-53226	12503	SEAL	32			
01-02-53227	12502	SEAL	16			
01-02-53228	13419	RETURN SPRING	80			
01-02-53229	13457	SLACK ADJUSTER	40			
01-02-53230	16359	BRAKE SHOE ASSY.WITH LINING(IT74,79,80)	64			
01-02-53231	14493	ROLLER	80			
01-02-53232	14494	PIN	40			
01-02-53233	14495	RING	40			
01-02-53234	13181	BRAKE LINING	6400			
01-02-53235	10685	RIVET	80000			
01-02-53236	14613	RETURN SPRING	800			
01-02-53237	15562	RETURN SPRING	200			
01-02-53238	15563	RETURN SPRING	200			
01-02-53239	16361	SPOKE WHEEL	16			
01-02-53240	16362	SCREW	2000			
01-02-53241	16363	CLAMPING PLATE	600			
01-02-53242	16364	NUT	2000			
01-02-53243	16365	CLIP	2000			
01-02-53244	16366	WASHER	960			
01-02-53245	12632	BRAKE DRUM	100			
01-02-53246	11112	SCREW ASSEMBLY(INCL.IT.92)	960			
01-02-53247	11113	HEXAGON NUT	960			
01-02-53248	11362	ROLLER BEARING	160			
01-02-53249	11363	ROLLER BEARING	160			
01-02-53250	12668	HUB CAP	20			
01-02-53251	20125	LEAF SPRING	16			
01-02-53252	16374	U-BOLT	32			
01-02-53253	13252	LOCK NUT	32			
01-02-53254	16378	THREAD BOLT	80			
01-02-53255	15049	BUSH	160			
01-02-53256	16380	LOCK NUT	80			
01-02-53257	12886	RUBBER ROLL	40			
01-02-53258	12888	TUBE	72			
01-02-53259	13584	HEXAGON SCREW	136			
01-02-53260	10994	LOCK NUT	168			
01-02-53261	13585	SLEEVE	80			
01-02-53262	16383	BUSH	40			
01-02-53263	16384	BUSH	40			

01-02-53264	13589	SLEEVE	16			
01-02-53265	13591	HEXAGON SCREW	72			
01-02-53266	13605	BUSH	32			
01-02-53267	16389	CONNECTING ROD(INCL.IT.164)	8			
01-02-53268	16390	CONNECTING ROD(INCL.IT.164)	8			
01-02-53269	13594	BUSH	112			
01-02-53270	13595	SCREW	16			
01-02-53271	11404	SCREW	16			
01-02-53272	11402	LOCK NUT	24			
01-02-53273	16391	CONNECTING ROD(INCL.IT.173-176)	8			
01-02-53274	16392	CONNECTING ROD(INCL.IT.173-176)	8			
01-02-53275	13597	HEXAGON SCREW	32			
01-02-53276	11403	SCREW	8			
01-02-53277	16388	LOCK NUT	72			
01-02-53278	254164	KING PIN	96			
01-02-53279	254165	RETENTION PLATE	8			
01-02-53280	250035	SELF-SECURING SCREW(SET,8 PIECES)	40			
01-02-53281	274028	LANDING GEAR	12			
01-02-53282	51424	COUPLING HEAD,RED	200			
01-02-53283	51425	COUPLING HEAD,YELLOW	200			
01-02-53284	51432	AIR LINE FILTER	220			
01-02-53285	54716	AUTOMATIC LOAD PROPORTIONING VALVE	20			
01-02-53286	50005	RELAY EMERGENCY VALVE	20			
01-02-53287	51017	DIAPHRAGM BRAKE ACTUATOR	288			
01-02-53288	50512	RELIEF VALVE	20			
01-02-53289	54767	RELIEF VALVE JET	20			
01-02-53290	54711	STOP COCK	8			
01-02-53291	54660	MATCHING VALVE	20			
01-02-53292	51516	TILT DRAIN VALVE	8			
01-02-53293	53010	RELEASE VALVE	20			
01-02-53294	62770	JUNCTION BOX	20			
01-02-53295	62783	3-CHAMBER REAR LIGHT(DOUBLE ILLUMINATION)	440			
01-02-53296	63105	LENS FOR 3-CHAMBER REAR LIGHT	120			
01-02-53297	61728	SIDE MARKER LAMP	80			
01-02-53298	290923	DIRT TRAP	40			
01-02-53299	360249	FUEL TANK	8			
01-02-53300	360268	COVER FOR FUEL TANK	20			
01-02-53301	821280	SCREW	2000			
01-02-53302	821278	SCREW	200			
01-02-53303	814611	SPRING WASHER	400			
01-02-53304	820227	NUT	2200			
01-02-53305	104524	DRIVING ROD	20			
01-02-53306	15878	BUSH	80			
01-02-53307	15913	SLACK ADJUSTER	184			
01-02-53308	15880	BUSH	80			
01-02-53309	12046	RETURN SPRING	80			
01-02-53310	15882	BUSH	80			
01-02-53311	15912	RETURN SPRING	80			
01-02-53312	15928	RETURN SPRING	80			
01-02-53313	15888	SCREW ASSEMBLY	200			
01-02-53314	15886	LOCK WASHER	200			
01-02-53315	15889	NUT	200			
01-02-53316	15892	DUST COVER	16			
01-02-53317	15938	SHAPED PLATE	40			
01-02-53318	15898	CAMSHAFT	16			
01-02-53319	15899	CAMSHAFT	16			

01-02-53320	15902	SEAL	160			
01-02-53321	15905	CIRCLIP	240			
01-02-53322	15919	BRAKE SHOE ASSY	400			
01-02-53323	15920	ROLLER	40			
01-02-53324	15937	TRILEX WHEEL HUB	72			
01-02-53325	15897	ANTI LEAK RING	800			
01-02-53326	15883	RING	800			
01-02-53327	11990	SPACER RING	80			
01-02-53328	15200	SCREW	3200			
01-02-53329	18752	CLAMPING PLATE	1200			
01-02-53330	18749	NUT	6400			
01-02-53331	18748	CLIP	6400			
01-02-53332	18758	WASHER	6400			
01-02-53333	15930	BRAKE DRUM	120			
01-02-53334	15932	NUT	400			
01-02-53335	15934	ROLLER BEARING	240			
01-02-53336	15935	DUST COVER	16			
01-02-53337	15936	ROLLER BEARING	240			
01-02-53338	15939	DUST COVER (L)	16			
01-02-53339	12032	SLIDING BEARING	160			
01-02-53340	13651	GREASE NIPPLE	400			
01-02-53341	12031	PACKING RING	400			
01-02-53342	12042	LOCK NUT	160			
01-02-53343	12414	U-BOLT	64			
01-02-53344	63507	7- WAY- SOCKET	16			
01-02-53345	54391	RELAY EMERGERNCY VALVE	80			
01-02-53346	50818	RELAY VALVE	200			
01-02-53347	53469	DRAIN VALVE	400			
01-02-53348	50601	PRESSUR RELIEF VALVE	200			
01-02-53349	462004	BALL VALVE	80			
01-02-53350	254162	KING PIN SCREW	200			
01-02-53351	270949	LANDING GEAR	8			
01-02-53352	63506	POSITION LAMP	400			
01-02-53353	63020	SIDE LAMP	400			
01-02-53354	61720	LINCENCE PLATE LAMP	160			
01-02-53355	60235	JUNCTION BOX	16			
01-02-53356	61702	TRIANGULAR REFLECTOR	160			
01-02-53357	15876	BALANCE CRADLE	8			
01-02-53358	12030	SEMI CLAMP	80			
01-02-53359	12039	TORQUE ARM BOLT	400			
01-02-53360	12041	TORQUE ARM BOLT	400			
01-02-53361	12047	TORQUE ARM BRACKET	160			
01-02-53362	12048	TORQUE ARM	240			
01-02-53363	12029	CARRIER SHAFT	64			
01-02-53364	12049	SILENT BLOCK	1600			

SPECIFICATION OF SPARE PARTS & SPARE EQUIPMENT

CODE	Part No.	Description	QTY			
01-02-53365	4320IA-1001035	SIDE SUPPPORT CUSHION	200			
01-02-53366	432IA-1001020	CUSHION	200			
01-02-53367	4320IA-1001029	SHOCK ABSORBER	200			
01-02-53368	5323-1013010	OIL COOLER	40			
01-02-53369	4320IA2-1013105	OIL COOLER HOSE	200			
01-02-53370	4320-8101222	OIL COOLER HOSE	200			
01-02-53371	5920-1101010	FUEL TANK (210 L)	8			
01-02-53372	4322-1104059	HOSE	100			
01-02-53373	4320-1104069	HOSE	100			
01-02-53374	4320-3125090	HOSE	100			
01-02-53375	375-4245043-10	HOSE	100			
01-02-53376	5323-1104337	HOSE	100			

01-02-53377	4320-1104012	INLET PIPE ASSY	100			
01-02-53378	4320-1104134	FUEL-LINE BOLT	200			
01-02-53379	4320-1104139	GASKET	200			
01-02-53380	4320-1108196-10	TIP	100			
01-02-53381	4320IA2-1109189	AIR-LINE HOSE	200			
01-02-53382	4322-1109428	HOSE	200			
01-02-53383	5323IA-1301010	RADIATOR	40			
01-02-53384	4320IA-1303010	OUTLET HOSE	160			
01-02-53385	4320-1304010	RADIATOR PLUG	200			
01-02-53386	432007-1201010-20	SILENCER ASSY	40			
01-02-53387	432007-1203006-21	REAR PIPE R.H.	40			
01-02-53388	432007-1203008-10	FRONT PIPE L.H.	40			
01-02-53389	432007-1203010-20	FRONT PIPE L.H.	40			
01-02-53390	432007-1203011-21	REAR PIPE, L.H.	40			
01-02-53391	432007-1203153	COMPENSATOR ADAPTER	80			
01-02-53392	432007-1203154	COMPENSATOR ADAPTER	80			
01-02-53393	4320IA-1203460	COMPENSATOR SPACER	80			
01-02-53394	4320IA-1203165	GASKET	200			
01-02-53395	4320-1203165	GASKET	400			
01-02-53396	375-1303030	HOSE	80			
01-02-53397	2101-1311014	EXPANSION TANK	80			
01-02-53398	4320IA-1311044	HOSE	120			
01-02-53399	4320-1311068	TANK PLUG	200			
01-02-53400	5557IA2-1602160-01	TIE ROD WITH VALVE	60			
01-02-53401	5557IA-1609005	AIR BOOSTER CYLINDER	60			
01-02-53402	55571-1800018-10	TRANSFER BOX	20			
01-02-53403	4320-2201010-01	REAR AXLE CARDAN SHAFT	40			
01-02-53404	375-2202010-01	INTERMED. CARDAN SHAFT	40			
01-02-53405	375-2203010-02	FRONT AXLE CARDAN SHAFT	40			
01-02-53406	4322-2205010	INTERMED., AXLE CARDAN SHAFT	40			
01-02-53407	375-2303065-10	FRONT SEMI-AXLE	40			
01-02-53408	375-2303068-A	INNER SEMI-AXLE R.H.	20			
01-02-53409	375-2303071-A	INNER SEMI-AXLE L.H.	20			
01-02-53410	375-2304093-B1	COLLAR	400			
01-02-53411	55571-2304096	PACKING RING	400			
01-02-53412	375-2403070-11	REAR SEMI-AXLE	20			
01-02-53413	375-2402052-07	COLLAR	400			
01-02-53414	55571-2902012-01	FRONT SPRING	16			
01-02-53415	4320-2902408	FRONT SPRING U-BOLT	80			
01-02-53416	334932-P29	NUT M22	400			
01-02-53417	A1-275/475.2905006	SHOCK ABSORBER	200			
01-02-53418	4320-2905410	SHOCK ABSORBER HEAD BUSH	400			
01-02-53419	55571-2912122	REAR SPRING	40			
01-02-53420	4322-2912410	U-BOLT NUT	400			
01-02-53421	55571-2912408	REAR SPRING U-BOLT	120			
01-02-53422	375-2919006-05	UPPER TORQUE ROD	40			
01-02-53423	375-3104033-02	COLLAR	400			
01-02-53424	375-3003055	SET OF SHELLS	100			
01-02-53425	375-3003065	PIN	100			
01-02-53426	375-3003056-01	TIP R.H.	40			
01-02-53427	375-3003057-01	TIP L.H.	40			
01-02-53428	375-3101040-B	WHEEL NUT	800			
01-02-53429	4320-3103009	WHEEL STUD	800			
01-02-53430	4320IA2-3400020	STEERING GEAR	40			
01-02-53431	5557IA2-3405012	STEERING BOOSTER	60			
01-02-53432	503-3407209	HYDRAULIC BOOSTER BELT	200			
01-02-53433	375-3405084	PACKING RING	200			
01-02-53434	022-028-36-1-2	PACKING RING	200			
01-02-53435	060-070-58-2-2	PACKING RING	200			
01-02-53436	M22X42-2	COLLAR	200			

01-02-53437	55571A2-3407200-01	HYDRAULIC BOOSTER PUMP	60			
01-02-53438	555707-3408669-10	DELIVERY HOSE	200			
01-02-53439	555707-34008678-10	HYDRAULIC BOOSTER HOSE	200			
01-02-53440	555707-3408679-10	HYDRAULIC BOOSTER HOSE	200			
01-02-53441	5323-3408670	DRAINING HOSE	200			
01-02-53442	55571A-3408727	INTAKE HOSE	200			
01-02-53443	375-3501010-10	BRAKE ASSY	40			
01-02-53444	375-3501030-01	WHEEL CYLINDER	400			
01-02-53445	51-3501051	COLLAR	1600			
01-02-53446	375-3501050-02	PISTON	400			
01-02-53447	4320-3501070	BRAKE DRUM	120			
01-02-53448	55571-3501090	SHOE ASSY	480			
01-02-53449	4320-3505010	MAIN BRAKE CYLINDER	40			
01-02-53450	375-3505020	VALVE	80			
01-02-53451	375-3505033-01	OUTER COLLAR	400			
01-02-53452	375-3505035-01	INNER COLLAR	400			
01-02-53453	375-3506024-01	HOSE	400			
01-02-53454	375-3506045-01	HOSE	400			
01-02-53455	432007-3506083	PIPE	40			
01-02-53456	375-3506091-01	T-PIECE	40			
01-02-53457	4320-3506099	T-PIECE	40			
01-02-53458	432007-3506100	PIPE	64			
01-02-53459	432007-3506113	PIPE LINE	64			
01-02-53460	4320-3506182-10	PIPE	40			
01-02-53461	4320-3506190	PIPE	40			
01-02-53462	432057-3506293	AIR LINE	40			
01-02-53463	375-3506380	HOSE	40			
01-02-53464	4320-3506398-01	HOSE	40			
01-02-53465	336613	RIVET	12000			
01-02-53466	4331-3509009	COMPRESSOR	80			
01-02-53467	238NB-1307170	COMPRESSOR BELT	200			
01-02-53468	55571A-3510010	AIR BOOSTER	40			
01-02-53469	353-3401022-01	COLLAR	400			
01-02-53470	130-135-25-2-2	RING	60			
01-02-53471	4320-3510060	COLLAR	60			
01-02-53472	100-3512010	PRESSURE REGULATOR	60			
01-02-53473	100-3514008	BRAKE VALVE	60			
01-02-53474	100-3515010	SINGLE PROTECTION VALVE	20			
01-02-53475	100-3515210	PRIPLE PROTECTION VALVE	20			
01-02-53476	100-3537110	AIR VALVE	60			
01-02-53477	2712-3702010	VOLTAGE REGULATOR	100			
01-02-53478	VK353-3704000-0	STARTER & INSTRUMENT SWITCH	100			
01-02-53479	P110-3709000-V01	TURN INDICATOR RELAY	100			
01-02-53480	VK343-3709000-01 08	ROOF LAMP SWITCH	100			
01-02-53481	VK343-3709000-02 16	ROAD TRAIN SIGN SWITCH	100			
01-02-53482	P305-3709010	LIGHT CENTRAL CHANGE-OVER SWITCH	100			
01-02-53483	P53A-3710000-0	FOOT LIGHT SWITCH	100			
01-02-53484	VK503-3710110-0	BRAKE FAILURE SIGNALING SWITCH	100			
01-02-53485	401	HEADLAMP	160			
01-02-53486	PF133AB-3712010	FRONT LIGHT	80			
01-02-53487	FP133AB-3716010	REAR LIGHT	80			
01-02-53488	VK12B-3720000	STOP SIGNAL SWITCH	100			
01-02-53489	RS530-3721000	STARTER RELAY	100			
01-02-53490	UP101-3726010-B1	TURN INDICATOR REPEATER	200			
01-02-53491	RS951A-3726010-T	TURN INDICATOR INTERRUPTER	100			
01-02-53492	1402.3737000-0	BATTERIES SWITCH	100			
01-02-53493	11	RELAY	200			
01-02-53494	16	SPEEDOMETER	40			

01-02-53495	GV300-3802600-05	FLEXIBLE SHAFT	40			
01-02-53496	4320-3805012-10	DASHBOARD R.H.	40			
01-02-53497	4320-3805013	DASHBOARD L.H.	40			
01-02-53498	UB170M-3806010-T	OIL LEVEL INDICATOR	40			
01-02-53499	BM158D-3806600	OIL LEVEL SENDER	60			
01-02-53500	UK171M-3807010-T	WATER TEMPERATURE INDICATOR	40			
01-02-53501	TM100A-3808000-0	WATER TEMPERATURE SENDER	40			
01-02-53502	UK170M-3810010-T	OIL INDICATOR	40			
01-02-53503	MM111D-3810600	EMERGENCY OIL PRESSURE SENDER	40			
01-02-53504	MM124D-3810600	EMERGENCY AIR PRESSURE SENDER	40			
01-02-53505	AP171A-3811010	CURRENT INDICATOR	40			
01-02-53506	2531-3813010	TACHOMETER	40			
01-02-53507	MM370-3829010-U-HL	OIL PRESSURE SENDER	40			
01-02-53508	1901-3830010	TWO-POINTER PRESSURE GAUGE	40			
01-02-53509	A24-55+50	LAMP	160			
01-02-53510	A24-21-3	LAMP	200			
01-02-53511	A24-5	LAMP	200			
01-02-53512	S306G	ELECTRIC HORN	40			
01-02-53513	S307G	ELECTRIC HORN	60			
01-02-53514	375-4224017-03	COLLAR	400			
01-02-53515	375-4224020-01	COLLAR HOLDER	200			
01-02-53516	375-4224120-J	WHEEL VALVE	400			
01-02-53517	375-4225073-02	HOSE	200			
01-02-53518	375-4225075-02	HOSE	200			
01-02-53519	375-4245070-02	AIR HOSE	400			
01-02-53520	375-5001118-02	BOLT	80			
01-02-53521	16	WINDSHIELD WIPER DRIVE	80			
01-02-53522	P147-3709000-07.09	WINDSHIELD WIPER SWITCH	80			
01-02-53523	377-5206050-01	SEALER	200			
01-02-53524	377-5206051	SEALER LOCK	200			
01-02-53525	4320-6104016	WINDOW RAISER R.H.	80			
01-02-53526	4320-6104017	WINDOW RAISER L.H.	80			
01-02-53527	377-6105012-01	DOOR LOCK R.H.	40			
01-02-53528	377-6105013-01	DOOR LOCK L.H.	40			
01-02-53529	4320-8201020-10	REAR-VIEW MIRROR	200			
01-02-53530	150	KEY 150	80			
01-02-53531	80	KEY 80	80			
01-02-53532	1-525-5	NAGGER	40			
01-02-53533	OPU-2	FIRE EXTINGUISHER	40			
01-02-53534	RT-80U	3-WAY D80 BRANCHING	80			
01-02-53535	V-1-125	HOSE REINFORCED, L=4M,	0			
01-02-53536		COMPLETE WITH COUPLING D125	80			
01-02-53537	KSC-1-32-3	HOSE (FOAMMAKER-PROOF),	0			
01-02-53538		L=4M, COMPLETE WITH COUPLING	40			
01-02-53539	V-2-75	HOSE REINFORCED, L=4M,	40			
01-02-53540		COMPLETE WITH COUPLING D80	160			
01-02-53541	L20	PRESSURE HOSE, L=20M,	40			
01-02-53542		COMPLETE WITH COUPLING D77	240			
01-02-53543	L20M	PRESSURE HOSE, L=20M,	40			
01-02-53544		COMPLETE WITH COUPLING D51	240			
01-02-53545	OST12963	GRID, SV-125 TYPE, COMPLETE	0			
01-02-53546		WITH CORD	40			
01-02-53547	RSK3-70	PORTABLE MONITOR	40			

01-02-53548	RSP-70	PORTABLE MONITOR	40			
01-02-53549	A2	AXE A2	40			
01-02-53550	PN-40UV	FIRE PUMP	40			
01-02-53551	FP310G	RED COLOR LIGHT REFLECTOR	80			
01-02-53552	TU 37.003.517-81	SEARCH LIGHT	80			
01-02-53553	TU37.003.292-72	LIGHT, FG-152A TYPE	80			
01-02-53554	262	TAIL FENDER LIGHT	80			
01-02-53555	264	FRONT FENDER LIGHT	80			
01-02-53556	FP-135	REAR LIGHT FP135G	40			
01-02-53557	4320IA-1001041	ENGINE SIDE SUPPORT	80			
01-02-53558	5557-8101180	HEATER COCK	20			
01-02-53559	375-1103011	PLUG	100			
01-02-53560	375-1108120	STOP TIE ROD	40			
01-02-53561	100-3570110	AIR CYLINDER	20			
01-02-53562	740-1109552	ELEMENT GASKET	40			
01-02-53563	740-1109560-02	FILTER ELEMENT	200			
01-02-53564	740-1109574	PRELIMINARY FILTER	40			
01-02-53565	740-1109582	FILTER CAP	20			
01-02-53566	130-2201023	FLANGE FORK	40			
01-02-53567	131-2201025A2	SPIDER	160			
01-02-53568	130-2201025	SPIDER	400			
01-02-53569	130-2202048	SLIDING FORK	40			
01-02-53570	375-2902414	FRONT SPRING BUFFER	400			
01-02-53571	375-2912624	BUFFER	160			
01-02-53572	55571-2918050	REAR BOGIE SHAFT	16			
01-02-53573	4320-3103002	WHEEL HUB	16			
01-02-53574	4320-3103014	HUB COVER	16			
01-02-53575	375-3104033	COLLAR ASSY	600			
01-02-53576	2007124M	TAPPER ROLLING BEARING	480			
01-02-53577	250712-P29	NUT	400			
01-02-53578	2.1-45X70-1	COLLAR ASSY	200			
01-02-53579	375-3501105D	SHOE FRICTION LINING	720			
01-02-53580	353-3401022	COLLAR ASSY	60			
01-02-53581	100-3514010	DUBLE SECTION BRAKE VALVE	20			
01-02-53582	238M2-6-1000186	ENGINE WITHOUT GEAR BOX	8			
01-02-53583	238-1000102B2	SET OF MAIN BEARING 110 MM	8			
01-02-53584	238-1000102B2-R1	SET OF MAIN BEARING 109.75 MM	20			
01-02-53585	238-1000102B2-R2	SET OF MAIN BEARING 109.50 MM	20			
01-02-53586	238-1000102B2-R3	SET OF MAIN BEARING 109.25 MM	20			
01-02-53587	238-1000104V2	SET OF CONNECTING ROD BEARING88MM	8			
01-02-53588	238-1000104V2-R1	SET OF CONNECTING ROD BEARING87.75	20			
01-02-53589	238-1000104V2-R2	SET OF CONNECTING ROD BEARING87.50	20			
01-02-53590	238-1000104V2-R3	SET OF CONNECTING ROD BEARING87.25	20			
01-02-53591	238-1000107V4	CRANKSHAFT	8			
01-02-53592	201-1005034B4	COLLAR	200			
01-02-53593	236-1005160-A3	COLLAR	200			
01-02-53594	238-1002012V	CYLINDER BLOCK	8			
01-02-53595	238-1003013D3	CYLINDER HEAD	40			
01-02-53596	238-1003210V2	CYLINDER HEAD GASKET	200			
01-02-53597	238-1003270	GASKET	200			
01-02-53598	236-1004008B	SET LINER & PISTON(PER 1 CYLINDER)	160			
01-02-53599	236-1004002-A3	PISTON RINGS PER 1 PISTON	64			
01-02-53600	236-1004045B2	CONNECTING ROD	40			
01-02-53601	236-1004052B2	UPPER BUSHING	160			

01-02-53602	236-1005115ZH	FLYWHEEL	20			
01-02-53603	236-1005183D	HALF RING	40			
01-02-53604	238-1006015G2	CAMSHAFT	8			
01-02-53605	236-1006026	BUSHING	20			
01-02-53606	236-1006037	BUSHING	20			
01-02-53607	236-1007010V	INTAKE VALVE	160			
01-02-53608	236-1007015	EXHAUST VALVE	160			
01-02-53609	236-1007020	SPRING OUTER	64			
01-02-53610	236-1007021	SPRING INNER	64			
01-02-53611	236-1007118	BUSHING	288			
01-02-53612	236-1007144V2	ROCKER	80			
01-02-53613	236-1007148	ADJUSTING SCREW	80			
01-02-53614	236-1007176	TAPPED ROD	200			
01-02-53615	238F-1009010	OIL PAN	8			
01-02-53616	238-1009040	OIL PAN GASKET	200			
01-02-53617	236-1009050	OIL DIPSTICK	20			
01-02-53618	236-1011014	OIL PUMP	20			
01-02-53619	236-1012027	OIL FILTER ELEMENT	800			
01-02-53620	236-1029240	COLLAR ASSY	40			
01-02-53621	236-1104034	FUEL LEAK OFF PIPE	20			
01-02-53622	238-1104308V	FUEL PIPE	20			
01-02-53623	201-1105540	FUEL FILTER ELEMENT	800			
01-02-53624	236-1110040	FLYWEIGHT CARRIER	20			
01-02-53625	80.1111006-30	FUEL INJECTION PUMP	60			
01-02-53626	60	PLUNGER AND BARREL	60			
01-02-53627	26.1112010-03	INJECTOR	160			
01-02-53628	26.1112110-01	SPRAY TIP	640			
01-02-53629	236-1117038-A	FUEL FILTERING ELEMENT	800			
01-02-53630	236-1307010-B	WATER PUMP	200			
01-02-53631	236-1307029-A	WATER PUMP REPAIR KIT	200			
01-02-53632	236-1307170	PUMP DRIVE BELT	400			
01-02-53633	238-1308012	FAN IMPELLER	20			
01-02-53634	236-1308050	SHAFT	40			
01-02-53635	236-1308090	FAN DRIVE	20			
01-02-53636	238-1601090-G4	PRESSURE PLATE&COVER PLATE	100			
01-02-53637	238-1601130G	DRIVEN CLUTCH DISC	200			
01-02-53638	238-1601131	DRIVEN CLUTCH DISC	200			
01-02-53639	236U-1700003	GEAR BOX	20			
01-02-53640	236-1701027-B	DRIVE SHAFT	8			
01-02-53641	236-1701048	COUNTER SHAFT	8			
01-02-53642	236-1701105-B	MAIN SHAFT	8			
01-02-53643	236-1701150B2	2-3SHIFTS SYNCHRONIZER	20			
01-02-53644	236-1701151-A	4-5 SHIFTS SYNCHRONIZER	20			
01-02-53645	G288E-3701000	ALTERNATOR	40			
01-02-53646	G272-3701010	BRUSH HOLDER	40			
01-02-53647	BPV7-100-02	RECTIFIER UNIT	40			
01-02-53648	G288E-3701100	STATOR	40			
01-02-53649	G288E-3701200	ROTOR	40			
01-02-53650	G287-3701054	BUSHING	40			
01-02-53651	25-3708000	STARTER	40			
01-02-53652	ST103-3708120	COIL	40			
01-02-53653	ST103-3708150	COIL	40			
01-02-53654	25-3708230	BRUSH ROCKER ARM	40			
01-02-53655	25-3708050	BRUSH	40			
01-02-53656	25-3708600	DRIVE	40			
01-02-53657	25-3708200	ARMATURE	40			
01-02-53658	25-3708800	SOLENOID SWITCH	40			
01-02-53659	305	BALL BEARING	60			
01-02-53660	6-205K	BALL BEARING	60			
01-02-53661	60205K4	DRIVE SHAFT FRONT BEARING	20			

01-02-53662	170314	DRIVE SHAFT REAR BEARING	20			
01-02-53663	50411	MAIN SHAFT REAR BEARING	20			
01-02-53664	102308K1	COUNTER SHAFT ROLLER BEARING	20			
01-02-53665	692409KM	REAR ROLLER BEARING	20			
01-02-53666	G-1180304K1S9	BEARING	40			
01-02-53667	G-180603K1S9	BEARING	40			

SPARE PARTS FOR MERCEDES ACTROS TRUCK TYPE 3331 (6X4)42

01-02-53668	Number	Description	QTY			
01-02-53669	N007603 033102	SEAL RING	300			
01-02-53670	N000000 001103	SEAL RING	300			
01-02-53671	N000000 001069	SEAL RING, VLRUB	300			
01-02-53672	A 001 987 71 40	RUBBER BUFFER	300			
01-02-53673	A 541 010 05 05	GASKET KIT	300			
01-02-53674	A 541 010 20 33	GASKET KIT	300			
01-02-53675	A 541 010 00 80	GASKET KIT	300			
01-02-53676	A 541 018 07 12	BREATHER PIPE	300			
01-02-53677	A 403 997 00 32	SCREW PLUG	300			
01-02-53678	N007603 026109	SEAL RING	300			
01-02-53679	A 422 014 00 76	WASHER	300			
01-02-53680	A 004 153 44 28	SENDER UNIT	300			
01-02-53681	A 541 010 07 72	OIL DIPSTICK	300			
01-02-53682	A 541 010 27 20	CYLINDER HEAD	300			
01-02-53683	A 541 997 03 45	SEAL RING	300			
01-02-53684	A 541 050 02 26	INTAKE VALVE	300			
01-02-53685	A 541 050 02 27	EXHAUST VALVE	300			
01-02-53686	A 541 016 06 91	VALVE	300			
01-02-53687	A 102 053 00 26	CONE HALF	300			
01-02-53688	N005401 999012	BALL	300			
01-02-53689	A 541 050 06 33	ROCKER ARM	300			
01-02-53690	A 541 050 05 34	ROCKER ARM	300			
01-02-53691	A 422 990 00 51	NUT	300			
01-02-53692	N000471 024000	LOCK RING	300			
01-02-53693	A 906 055 01 20	SET SCREW	300			
01-02-53694	A 326 990 01 51	NUT	300			
01-02-53695	A 005 017 14 21	NOZZLE HOLDER	300			
01-02-53696	A 541 997 05 45	SEAL RING	300			
01-02-53697	A 906 017 02 60	SEAL RING	300			
01-02-53698	A 541 016 03 21	GASKET	300			
01-02-53699	A 541 010 10 55	PIPE	300			
01-02-53700	N000000 001068	SEAL RING	300			
01-02-53701	A 541 010 11 55	PIPE	300			
01-02-53702	A 541 990 01 88	BANJO UNION	300			
01-02-53703	A 541 054 05 05	PUSH ROD	300			
01-02-53704	A 541 050 03 22	ROLLER TAPPET	300			
01-02-53705	A 541 030 02 01	CRANKSHAFT	300			
01-02-53706	A 541 050 02 03	CRANKSHAFT GEAR	300			
01-02-53707	A 541 030 01 03	VIBRATION ABSORBER	300			
01-02-53708	A 541 035 02 12	PULLEY	300			
01-02-53709	A 541 035 02 14	INTERMEDIATE PIECE	300			
01-02-53710	A 541 030 01 05	FLYWHEEL	300			
01-02-53711	A 004 981 21 25	BALL BEARING (S)	300			
01-02-53712	A 541 030 04 20	CONNECTING ROD	300			
01-02-53713	A 541 030 03 37	PISTON	300			
01-02-53714	A 541 011 00 59	SEAL RING	300			
01-02-53715	A 541 997 09 45	SEAL RING	300			
01-02-53716	A 028 074 59 02	INJECTION PUMP	300			
01-02-53717	A 023 997 64 48	SEAL RING	300			
01-02-53718	A 023 997 65 48	SEAL RING	300			

01-02-53719	A 541 990 03 01	SCREW	300			
01-02-53720	A 541 070 57 32	LINE	300			
01-02-53721	A 326 990 01 63	HOLLOW SCREW	300			
01-02-53722	N000000 001066	SEAL RING	300			
01-02-53723	N000000 001070	SEAL RING, VLRUB	300			
01-02-53724	A 541 090 01 51	FILTER ELEMENT	300			
01-02-53725	A 541 090 04 52	FILTER	300			
01-02-53726	A 001 990 42 05	SCREW	300			
01-02-53727	A 000 990 31 50	NUT	300			
01-02-53728	A 541 997 00 83	SLEEVE	300			
01-02-53729	N000000 000644		300			
01-02-53730	A 541 098 01 37	INTAKE PIPE SOCKET	300			
01-02-53731	A 024 997 16 48	SEAL RING	300			
01-02-53732	A 541 130 02 30	GEAR	300			
01-02-53733	A 442 130 03 14	CRANKSHAFT	300			
01-02-53734	N001473 005024	GROOVED PIN	300			
01-02-53735	N308752 002000	CLAMPING PIN	300			
01-02-53736	A 541 131 01 42	FLANGE	300			
01-02-53737	A 014 997 61 48	SEAL RING.TRANSMISN.VLRUB	300			
01-02-53738	A 541 130 00 08	CYLINDER LINER	300			
01-02-53739	A 541 131 07 19	CYLINDER HEAD	300			
01-02-53740	A 541 130 06 20	VALVE	300			
01-02-53741	N000000 001104	SEAL RING	300			
01-02-53742	N000000 001073	SEAL RING, VLRUB	300			
01-02-53743	A 541 098 06 80	GASKET	300			
01-02-53744	A 541 098 01 72	NUT	300			
01-02-53745	A 541 090 03 89	BEARING	300			
01-02-53746	A 003 153 76 28	SENDER UNIT	300			
01-02-53747	A 004 153 03 28	SENDER UNIT	300			
01-02-53748	N007603 020101	RING,GENERAL,METAL	300			
01-02-53749	A 001 159 07 01	HEATER PLUG	300			
01-02-53750	A 442 078 01 80	GAS KET	300			
01-02-53751	A 541 142 01 80	GASKET	300			
01-02-53752	A 403 142 02 12	CLAMPING PIECE	300			
01-02-53753	A 447 990 67 04	SCREW	300			
01-02-53754	A 004 151 94 01	STARTING MOTOR	300			
01-02-53755	A 000 150 10 31	GEARING	300			
01-02-53756	A 001 152 24 10	SOLENOID SWITCH	300			
01-02-53757	A 001 152 43 10	SOLENOID SWITCH	300			
01-02-53758	A 000 150 02 29	TERMINAL	300			
01-02-53759	A 000 151 62 15	ARMATURE	300			
01-02-53760	A 001 990 09 21	SCREW	300			
01-02-53761	A 007 981 66 25	BALL BEARING	300			
01-02-53762	A 001 154 22 16	RECTIFIER	300			
01-02-53763	A 003 154 00 06	REGULATOR AND CUT-OUT	300			
01-02-53764	A 001 155 19 15	PULLEY	300			
01-02-53765	A 001 153 21 20	SPEED SENDER UNIT	300			
01-02-53766	A 655 540 68 81	PLUG SOCKET	300			
01-02-53767	A 541 180 01 01	OIL PUMP	300			
01-02-53768	A 422 180 03 15	PRESSER RELIEF VALVE	300			
01-02-53769	A 541 188 00 02	COVER	300			
01-02-53770	A 541 188 00 80	GASKET	300			
01-02-53771	A 012 542 05 17	SENDER UNIT	300			
01-02-53772	A 003 153 84 28	SENDER UNIT	300			
01-02-53773	A 004 153 43 28	SENDER UNIT	300			
01-02-53774	N917003 028002	GASKET	300			
01-02-53775	A 541 184 06 80	GASKET	300			
01-02-53776	A 541 180 11 20	OIL LINE	300			
01-02-53777	A 541 187 00 80	GASKET	300			
01-02-53778	A 542 200 19 01	WATER PUMP	300			
01-02-53779	A 542 200 01 04	IMPELLER	300			

01-02-53780	A 541 202 01 10	PULLEY	300			
01-02-53781	A 541 201 01 80	GASKET	300			
01-02-53782	A 003 205 01 06	FAN	300			
01-02-53783	A 542 200 05 22	FAN DRIVE	300			
01-02-53784	A 000 200 42 22	FAN DRIVE	300			
01-02-53785	A 541 200 03 22	FAN DRIVE	300			
01-02-53786	A 541 200 03 70	BELT TIGHTENER	300			
01-02-53787	A 541 202 01 20	PIVOT PIN	300			
01-02-53788	A 541 997 08 92	V-BELT	300			
01-02-53789	A 002 460 07 80	HYDRAULIC PUMP	300			
01-02-53790	A 002 460 12 80	HYDRAULIC PUMP	300			
01-02-53791	A 002 460 10 80	HYDRAULIC PUMP	300			
01-02-53792	A 000 460 42 84	REPAIR KIT	300			
01-02-53793	A 541 055 03 20	SET SCREW	300			
01-02-53794	A 442 990 57 63	Hollow Screw	300			
01-02-53795	A442 990 55 63	Hollow Screw	300			
01-02-53796	A 941 660 20 28	ROCKER PANEL	300			
01-02-53797	A 941 671 01 20	SEAL	300			
01-02-53798	A 005 820 90 42	ELECTRIC MOTOR	300			
01-02-53799	A 005 820 91 42	ELECTRIC MOTOR	300			
01-02-53800	A 000 890 74 67	OUTFIT(LOCK,KEY,HANDLE)	300			
01-02-53801	A 941 750 12 72	FRAME	300			
01-02-53802	A 941 751 12 18	GRILLE	300			
01-02-53803	A 641 751 19 18	GRILLE	300			
01-02-53804	A 941 817 01 16	BADGE	300			
01-02-53805	A 001 980 84 64	PNEUMATIC-SPRIN	300			
01-02-53806	A 941 750 12 18	GRILLE	300			
01-02-53807	A 941 751 01 70	HANDLE	300			
01-02-53808	A 000 810 96 16	MIRROR HOUSING	300			
01-02-53809	A 000 810 94 16	MIRROR HOUSING	300			
01-02-53810	A 005 820 63 42	ELECTRIC MOTOR	300			
01-02-53811	A 001 811 20 33	MIRROR GLASS	300			
01-02-53812	A 001 811 21 33	MIRROR GLASS	300			
01-02-53813	A 000 811 13 07	CLIP	300			
01-02-53814	A 001 810 44 14	BRACKET	300			
01-02-53815	A 001 810 45 14	BRACKET	300			
01-02-53816	A 001 811 22 33	MIRROR GLASS	300			
01-02-53817	A 941 820 39 61	LIGHTING UNIT	300			
01-02-53818	A 941 820 40 61	LIGHTING UNIT	300			
01-02-53819	A 004 826 06 90	LENS	300			
01-02-53820	A 004 826 07 90	LENS	300			
01-02-53821	N072601 024802	BULB	300			
01-02-53822	N072601 024250	BULB	300			
01-02-53823	A 941 880 04 85	RADIATOR GRILLE	300			
01-02-53824	A 941 880 05 85	RADIATOR GRILLE	300			
01-02-53825	A 941 820 13 21	BLINKER LAMP	300			
01-02-53826	N072601 024210	BULB	300			
01-02-53827	A 002 820 01 56	SIDE MARKER LAMP	300			
01-02-53828	N072601 024131	BULB	300			
01-02-53829	A 001 820 75 01	INTERIOR LAMP	300			
01-02-53830	A 941 880 00 20	HANDLE	300			
01-02-53831	A 005 820 21 42	ELECTRIC MOTOR	300			
01-02-53832	A 941 820 03 44	WIPER ARM	300			
01-02-53833	A 001 820 12 45	WIPER BLADE	300			
01-02-53834	A 000 824 60 27	WIPER RUBBER	300			
01-02-53835	A 000 830 12 72	TEMPERATURE SENSOR	300			
01-02-53836	A 000 830 15 18	FILTER	300			
01-02-53837	A 000 830 78 72	TEMPERATURE SENSOR	300			
01-02-53838	A 140 997 07 45	SEAL RING,VLRUB	300			
01-02-53839	A 140 997 08 45	SEAL RING,VLRUB	300			
01-02-53840	A 002 830 82 84	VALVE	300			

01-02-53841	A 140 997 06 45	SEAL RING,VLRUB	300			
01-02-53842	A 140 997 09 45	SEAL RING,VLRUB	300			
01-02-53843	A 941 830 02 15	PIPE LINE	300			
01-02-53844	A 941 830 03 15	PIPE LINE	300			
01-02-53845	A 000 830 17 83	TANK	300			
01-02-53846	A 006 820 58 10	SWITCH	300			
01-02-53847	A 002 830 27 84	VALVE	300			
01-02-53848	A 941 830 33 44	AIR DUCT	300			
01-02-53849	A 000 094 41 65	VALVE	300			
01-02-53850	A 941 830 01 66	AIR BAFFLE	300			
01-02-53851	A 002 987 09 40	RUBBER BUFFER	300			
01-02-53852	A 941 869 01 20	RESERVOIR	300			
01-02-53853	A 941 860 00 62	VALVE	300			
01-02-53854	A 000 869 40 21	PUMP	300			
01-02-53855	A 941 869 01 17	TUBE	300			
01-02-53856	A 001 860 21 69	LOCK	300			
01-02-53857	A 000 869 13 19	VALVE	300			
01-02-53858	A 941 880 61 70 7354	FRONT BUMPER FACE BAR	300			
01-02-53859	A 941 880 62 70 7354	FRONT BUMPER FACE BAR	300			
01-02-53860	A 941 885 14 01 7C72	FRONT BUMPER FACE BAR	300			
01-02-53861	A 941 984 07 61	CLIP	300			
01-02-53862	A 941 885 15 01 7354	FRONT BUMPER FACE BAR	300			
01-02-53863	A 940 885 10 31	CONSOLE	300			
01-02-53864	A 940 885 11 31	CONSOLE	300			
01-02-53865	A 941 880 53 70 7354	FRONT BUMPER FACE BAR	300			
01-02-53866	A 941 880 09 31	ROCKER PANEL	300			
01-02-53867	A 941 884 02 22	COVERING	300			
01-02-53868	A 941 884 03 22	COVERING	300			
01-02-53869	A 941 241 51 13	RUBBER MOUNTING	300			
01-02-53870	A 941 241 57 13	RUBBER MOUNTING	300			
01-02-53871	A 007 250 51 04	CLUTCH PRESSURE PLATE	300			
01-02-53872	A 019 250 61 03	CLUTCH DISC	300			
01-02-53873	A 005 990 28 04	SCREW	300			
01-02-53874	A 655 250 15 13	RELEASE LEVER	300			
01-02-53875	A 000 254 03 35	BEARING	300			
01-02-53876	A 002 992 15 01	BUSHING	300			
01-02-53877	A 655 254 02 06	SPINDLE	300			
01-02-53878	A 941 295 00 15	RESERVOIR	300			
01-02-53879	A 002 295 04 06	MASTER CYLINDER	300			
01-02-53880	A 941 291 04 74	PIN	300			
01-02-53881	A 000 295 28 18	CLUTCH BOOSTER	300			
01-02-53882	A 003 990 59 68	FITTING	300			
01-02-53883	A 003 545 47 07	SWITCH	300			
01-02-53884	A 655 545 01 28	PLUG	300			
01-02-53885	A 941 268 00 97 5B21	BOOT	300			
01-02-53886	A 000 260 40 98	SHIFT MECHANISM	300			
01-02-53887	A 003 997 91 72	FITTING	300			
01-02-53888	A 001 260 18 63	SHIFTING CYLINDER	300			
01-02-53889	A 000 987 26 27	PLASTIC PIPE	300			
01-02-53890	A 000 990 65 78	CONNECTOR,POLLUTION CNTRL	300			
01-02-53891	A 001 990 78 71	ELBOW FIT,POLLUTION CNTRL	300			
01-02-53892	A 003 990 29 71	ELBOW FITTING	300			
01-02-53893	A 001 990 70 78	CONNECTOR	300			
01-02-53894	A 645 990 03 78	CONNECTOR	300			
01-02-53895	A 000 429 42 37	DISTRIBUTOR	300			
01-02-53896	N915052 004015	BANJO UNION	300			
01-02-53897	N915052 004016	BANJO UNION	300			
01-02-53898	A 645 990 11 78	CONNECTOR	300			
01-02-53899	N915036 008202	HOLLOW SCREW	300			
01-02-53900	A 389 997 02 72	FITTING	300			

01-02-53901	N007603 012405	SEAL RING,VLRUB	300			
01-02-53902	A 381 997 02 72	FITTING	300			
01-02-53903	N915036 006202	HOLLOW SCREW	300			
01-02-53904	N007603 010404	SEAL RING,VLRUB	300			
01-02-53905	A 941 990 08 40	WASHER	300			
01-02-53906	A 201 291 02 82	PAD,FOOT PEDALS	300			
01-02-53907	A 201 292 00 82	PAD,FOOT PEDALS	300			
01-02-53908	N071752 008003	YOKE	300			
01-02-53909	A 385 292 01 74	PIN	300			
01-02-53910	N912002 016001	LOCK	300			
01-02-53911	A 655 993 00 10	SPRING	300			
01-02-53912	A 941 300 01 04	ACCELERATOR PEDAL	300			
01-02-53913	A 943 320 03 02	FRONT SPRING	300			
01-02-53914	A 000 322 12 85	RUBBER BEARING	300			
01-02-53915	A 000 322 02 44	RUBBER BUFFER	300			
01-02-53916	A 949 331 05 25	U-BOLT	300			
01-02-53917	N308765 024014	SCREW	300			
01-02-53918	A 000 324 09 08	HELPER SPRING	300			
01-02-53919	N000912 014090	SCREW	300			
01-02-53920	A 943 323 05 65	TORSION BAR	300			
01-02-53921	A 000 323 79 85	RUBBER MOUNTING	300			
01-02-53922	A 000 326 24 81	RUBBER MOUNTING	300			
01-02-53923	A 005 323 97 00	SHOCK ABSORBER	300			
01-02-53924	A 948 320 11 05	REAR SPRING	300			
01-02-53925	A 389 324 00 71	SPRING BOLT	300			
01-02-53926	N007349 019003	WASHER	300			
01-02-53927	N910113 018004	NUT	300			
01-02-53928	A 947 351 05 25	U-BOLT	300			
01-02-53929	N000000 000254	SCREW	300			
01-02-53930	A 000 325 05 96	RUBBER MOUNTING	300			
01-02-53931	A 948 325 05 53	SPACER TUBE	300			
01-02-53932	N000912 014087	SCREW	300			
01-02-53933	N910105 014024	SCREW	300			
01-02-53934	N913023 014003	NUT	300			
01-02-53935	A 948 423 02 33	BEARING BRACKET	300			
01-02-53936	A 947 325 02 09 7390	LA.	300			
01-02-53937	A 389 325 00 74	PIN	300			
01-02-53938	A 948 350 17 05	CONTROL ARM	300			
01-02-53939	A 000 350 29 05	CONTROL ARM	300			
01-02-53940	A 000 350 27 05	CONTROL ARM	300			
01-02-53941	A 005 326 09 00	SHOCK ABSORBER	300			
01-02-53942	A 000 320 06 44	RUBBER BUFFER	300			
01-02-53943	A 000 320 01 44	RUBBER BUFFER	300			
01-02-53944	A 000 987 28 27	PLASTIC PIPE	300			
01-02-53945	A 002 990 61 71	FITTING	300			
01-02-53946	A 673 997 01 45	AIR LINE CONNECTOR	300			
01-02-53947	A 673 997 02 45	REPAIR KIT	300			
01-02-53948	A 000 987 27 27	PLASTIC PIPE	300			
01-02-53949	A 002 990 59 71	FITTING	300			
01-02-53950	A 673 997 00 45	AIR LINE CONNECTOR	300			
01-02-53951	A 387 401 00 57	RIM BOW	300			
01-02-53952	A 387 401 01 57	RIM BOW	300			
01-02-53953	A 620 401 00 69	CLAMPING PLATE	300			
01-02-53954	A 620 402 00 68	CLAMPING SHOE	300			
01-02-53955	A 620 401 00 70	SCREW	300			
01-02-53956	A 620 401 01 70	SCREW	300			
01-02-53957	A 000 994 22 60	LOCK	300			
01-02-53958	A 620 990 02 40	WASHER	300			
01-02-53959	A 346 401 50 72	WHEEL NUT	300			
01-02-53960	A 331 402 05 07	RING	300			
01-02-53961	A 620 401 04 03	WHEEL SPIDER	300			

01-02-53962	A 620 402 04 04	WHEEL SPIDER	300			
01-02-53963	N074361 022351	LOCK WASHER	300			
01-02-53964	N074361 022205	NUT	300			
01-02-53965	A 000 583 50 45	ROD	300			
01-02-53966	A 000 403 00 36	GABLE	300			
01-02-53967	N308676 014010	SCREW	300			
01-02-53968	N308673 014002	NUT	300			
01-02-53969	A 656 410 68 02	PROPELLER SHAFT	300			
01-02-53970	A 656 411 00 11	DRIVE FLANGE	300			
01-02-53971	A 942 410 00 31	UNIVERSAL JOINT CROSS	300			
01-02-53972	A 395 411 00 59	SEAL RING	300			
01-02-53973	A 654 410 39 02	PROPELLER SHAFT	300			
01-02-53974	A 942 410 01 31	UNIVERSAL JOINT CROSS	300			
01-02-53975	A 006 994 23 41	LOCK	300			
01-02-53976	A 006 994 27 41	LOCK	300			
01-02-53977	A 389 411 00 80	GASKET	300			
01-02-53978	A 007 990 13 01	SCREW	300			
01-02-53979	N308673 012003	NUT	300			
01-02-53980	A 000 987 29 27	PLASTIC PIPE	300			
01-02-53981	A 005 997 43 72	REPAIR KIT	300			
01-02-53982	A 000 430 29 15	ANTI-FREEZE DEVICE	300			
01-02-53983	A 000 429 36 95	FILTER ELEMENT	300			
01-02-53984	A 000 430 33 07	PARTS KIT	300			
01-02-53985	A 000 430 14 15	REPAIR KIT	300			
01-02-53986	A 000 430 02 79	PARTS KIT	300			
01-02-53987	A 000 430 18 15	GASKET KIT	300			
01-02-53988	A 003 431 57 06	VALVE	300			
01-02-53989	A 001 542 92 18	SENSOR	300			
01-02-53990	A 000 420 29 71	REPAIR KIT	300			
01-02-53991	A 004 432 43 01	RESERVOIR	300			
01-02-53992	A 004 432 19 01	RESERVOIR	300			
01-02-53993	A 004 432 07 01	RESERVOIR	300			
01-02-53994	A 004 432 05 01	RESERVOIR	300			
01-02-53995	A 945 430 00 40	STRAP	300			
01-02-53996	A 941 430 01 40	STRAP	300			
01-02-53997	A 004 431 49 05	BRAKE VALVE	300			
01-02-53998	A 003 431 27 12	BRAKE PRESSURE REGULATOR	300			
01-02-53999	A 970 431 04 39	LEVER	300			
01-02-54000	A 942 431 02 92	ROD	300			
01-02-54001	A 001 991 03 22	BALL SOCKET	300			
01-02-54002	A 395 431 01 92	ROD	300			
01-02-54003	A 000 431 07 35	CONNECTOR	300			
01-02-54004	A 004 429 62 44	VALVE	300			
01-02-54005	A 002 430 30 60	REPAIR KIT	300			
01-02-54006	A 005 997 12 36	VALVE	300			
01-02-54007	A 003 430 77 81	VALVE	300			
01-02-54008	A 004 429 65 44	VALVE	300			
01-02-54009	A 000 420 51 71	VALVE	300			
01-02-54010	A 000 429 65 01	LINE	300			
01-02-54011	A 000 429 68 34	ADAPTER FITTING	300			
01-02-54012	A 000 429 80 30	BRAKE LINE COUPLING	300			
01-02-54013	A 000 429 81 30	BRAKE LINE COUPLING	300			
01-02-54014	A 000 420 00 58	REPAIR KIT	300			
01-02-54015	A 000 466 75 02	TANK	300			
01-02-54016	A 000 466 06 68	FILLER CAP	300			
01-02-54017	A 000 466 17 60	SEAL RING,VLRUB	300			
01-02-54018	A 000 466 06 04	FILTER	300			
01-02-54019	A 001 997 27 52	HOSE	300			
01-02-54020	N007603 016103	RING,GENERAL,METAL	300			
01-02-54021	A 001 990 19 67	SEAL CONE,P/S PUMP	300			

01-02-54022	A 001 990 10 67	SEAL CONE	300			
01-02-54023	A 942 466 04 81	HOSE	300			
01-02-54024	A 001 990 12 67	SEAL CONE	300			
01-02-54025	A 010 997 40 45	SEAL RING,VLRUB	300			
01-02-54026	A 943 460 00 04	STEERING LOCK	300			
01-02-54027	A 000 545 95 08	SWITCH	300			
01-02-54028	A 901 462 01 79	TUMBLER	300			
01-02-54029	A 020 545 39 32	TRANSPONDER	300			
01-02-54030	A 942 463 04 01	PITMAN ARM	300			
01-02-54031	A 002 460 45 05	DRAG LINK	300			
01-02-54032	A 001 460 42 48	DRAG LINK END	300			
01-02-54033	A 004 990 50 51	NUT	300			
01-02-54034	N916027 013006	HOSE,VLRUB	300			
01-02-54035	A 000 090 60 50	FUEL FEED PUMP	300			
01-02-54036	A 000 090 07 51	FILTER ELEMENT	300			
01-02-54037	N915036 010108	HOLLOW SCREW	300			
01-02-54038	N007603 014405	SEAL RING COP.C	300			
01-02-54039	A 000 471 04 35	FUEL STRAINER	300			
01-02-54040	A 000 470 04 05	FILLER CAP	300			
01-02-54041	A 303 470 00 31	CHAIN,OIL FILLER CAP	300			
01-02-54042	A 670 760 02 05	TUMBLER	300			
01-02-54043	A 013 542 71 17	SENDER UNIT	300			
01-02-54044	A 000 471 10 35	FUEL STRAINER	300			
01-02-54045	A 941 470 01 40	STRAP	300			
01-02-54046	A 942 490 30 19	EXHAUST PIPE	300			
01-02-54047	A 942 997 02 90	CLAMP	300			
01-02-54048	A 352 990 46 01	SCREW	300			
01-02-54049	A 942 490 00 41	CLAMP	300			
01-02-54050	A 942 490 27 01	EXHAUST MUFFLER	300			
01-02-54051	A 942 492 07 41 7390	BRACKET	300			
01-02-54052	A 942 490 12 40	BRACKET	300			
01-02-54053	A 942 500 12 03	RADIATOR	300			
01-02-54054	A 942 504 02 14	BEARING	300			
01-02-54055	A 942 505 09 55	FAN SHROUD	300			
01-02-54056	A 000 500 30 49	TANK	300			
01-02-54057	A 000 501 64 15	RADIATOR CAP	300			
01-02-54058	A 000 501 70 15	RADIATOR CAP	300			
01-02-54059	A 000 500 02 06	FILLER CAP	300			
01-02-54060	A 942 542 02 17	SENDER UNIT	300			
01-02-54061	A 941 501 03 82	HOSE	300			
01-02-54062	A 942 501 00 80	GASKET	300			
01-02-54063	A 942 501 01 56	PIPE ELBOW	300			
01-02-54064	A 942 501 03 56	PIPE ELBOW	300			
01-02-54065	N900271 060004	HOSE	300			
01-02-54066	N000000 001468	CLAMP	300			
01-02-54067	A 942 501 07 82	HOSE	300			
01-02-54068	N000000 000668	CLAMP	300			
01-02-54069	A 942 506 31 35	HOSE	300			
01-02-54070	N000000 000667	CLAMP	300			
01-02-54071	A 942 506 35 35	HOSE	300			
01-02-54072	A 942 506 41 35	HOSE	300			
01-02-54073	A 942 506 10 35	HOSE	300			
01-02-54074	A 942 501 09 01	RADIATOR	300			
01-02-54075	A 002 094 55 82	HOSE	300			
01-02-54076	A 943 260 12 85	PIPE	300			
01-02-54077	A 943 260 13 85	PIPE	300			
01-02-54078	A 942 500 01 54	CONDENSER	300			
01-02-54079	A 942 830 16 15	PIPE LINE	300			
01-02-54080	A 942 830 17 15	PIPE LINE	300			
01-02-54081	A 942 830 18 15	PIPE LINE	300			
01-02-54082	A 942 830 19 15	PIPE LINE	300			

01-02-54083	A 942 500 21 17	PROTECTIVE GRILL	300			
01-02-54084	A 942 500 16 17	PROTECTIVE GRILL	300			
01-02-54085	A 352 010 04 68	CAP	300			
01-02-54086	A 942 528 12 82	HOSE	300			
01-02-54087	A 011 542 50 17	SENDER UNIT	300			
01-02-54088	A 941 528 02 91	BOOT	300			
01-02-54089	A 942 528 00 91	BOOT	300			
01-02-54090	A 003 094 91 04	FILTER ELEMENT	300			
01-02-54091	A 000 094 20 60	SEAL RING	300			
01-02-54092	A 024 997 11 48	SEAL RING	300			
01-02-54093	A 000 094 21 60	SEAL RING	300			
01-02-54094	A 001 094 30 03	FILTER BOWL	300			
01-02-54095	A 942 528 03 82	HOSE	300			
01-02-54096	A 941 528 03 82	HOSE	300			
01-02-54097	A 003 545 95 07	SWITCH	300			
01-02-54098	A 003 545 96 07	SWITCH	300			
01-02-54099	A 004 545 22 07 5B20	SWITCH	300			
01-02-54100	A 000 545 67 04	LIGHT SWITCH	300			
01-02-54101	A 202 545 00 81	KNOB	300			
01-02-54102	A 002 544 17 94	BULB	300			
01-02-54103	A 000 545 70 04 5B20	SWITCH	300			
01-02-54104	A 007 545 31 24 5C38	STEER.COLUMN MOUT. SWITCH	300			
01-02-54105	A 008 545 01 24 5B21	SWITCH,AUTOMATIC	300			
01-02-54106	A 001 540 62 70	TAIL LAMP	300			
01-02-54107	A 001 540 63 70	TAIL LAMP	300			
01-02-54108	A 002 544 16 90	LENS	300			
01-02-54109	A 002 544 12 90	LENS	300			
01-02-54110	N072601 024192	BULB	300			
01-02-54111	N072601 024704	BULB	300			
01-02-54112	A 000 525 07 39	BRACKET	300			
01-02-54113	A 000 553 99 01	PUMP	300			
01-02-54114	A 000 550 44 83	GASKET KIT	300			
01-02-54115	A 655 332 02 01	STEERING KNUCKLE	300			
01-02-54116	A 942 332 00 06	KINGPIN	300			
01-02-54117	A 655 330 06 19	KING PIN	300			
01-02-54118	A 655 330 07 19	KING PIN	300			
01-02-54119	A 943 338 15 01	STEERING ARM	300			
01-02-54120	A 625 338 07 05	STEERING ARM	300			
01-02-54121	A 625 338 06 06	STEERING ARM	300			
01-02-54122	A 949 330 06 03	TIE ROD	300			
01-02-54123	A 001 460 17 48	DRAG LINK END	300			
01-02-54124	A 624 334 03 01	WHEEL HUB	300			
01-02-54125	A 019 997 48 47	SEAL RING	300			
01-02-54126	A 652 330 00 88	NUT	300			
01-02-54127	A 389 334 00 25	HUB CAP	300			
01-02-54128	A 389 401 00 71	WHEEL MOUNTING BOLT	300			
01-02-54129	A 346 421 31 06	BRAKE ANCHOR	300			
01-02-54130	A 945 542 12 18	SENSOR	300			
01-02-54131	A 945 542 13 18	SENSOR	300			
01-02-54132	A 307 420 03 39	REPAIR KIT	300			
01-02-54133	A 617 423 14 30	BRAKE LINING	300			
01-02-54134	A 307 420 41 02	REPAIR KIT	300			
01-02-54135	A 346 993 08 10	SPRING	300			
01-02-54136	A 617 993 11 10	SPRING	300			
01-02-54137	A 658 421 00 01	BRAKE DRUM	300			
01-02-54138	A 655 260 01 57	REPAIR KIT	300			
01-02-54139	A 389 997 01 32	SCREW PLUG	300			
01-02-54140	N007603 038105	SEAL RING	300			
01-02-54141	A 945 260 00 57	VALVE	300			
01-02-54142	A 002 260 30 57	VALVE	300			
01-02-54143	A 001 545 17 09	SWITCH	300			

01-02-54144	A 001 545 16 09	SWITCH	300			
01-02-54145	A 012 542 10 17		300			
01-02-54146	A 346 353 07 35	SHAFT	300			
01-02-54147	A 346 350 14 45	FLANGE	300			
01-02-54148	A 946 351 00 72	NUT	300			
01-02-54149	A 346 353 08 25	SCREW COLLAR	300			
01-02-54150	A 017 997 28 47	SEAL RING	300			
01-02-54151	A 017 997 29 47	SEAL RING	300			
01-02-54152	A 352 353 00 73	LOCK	300			
01-02-54153	N000625 920066	GROOVED BALL BEARING	300			
01-02-54154	A 346 353 19 62	THRUST WASHER	300			
01-02-54155	A 346 353 18 62	THRUST WASHER	300			
01-02-54156	A 346 353 17 62	THRUST WASHER	300			
01-02-54157	N000000 000759	BALL BEARING	300			
01-02-54158	A 346 353 25 62	THRUST WASHER	300			
01-02-54159	A 346 353 06 35	SHAFT	300			
01-02-54160	A 346 353 09 25	SCREW COLLAR	300			
01-02-54161	A 017 997 30 47	SEAL RING	300			
01-02-54162	N070952 060102	LOCK PLATE	300			
01-02-54163	A 674 356 02 26	GROOVED NUT	300			
01-02-54164	A 346 353 08 55	CYLINDER	300			
01-02-54165	A 355 353 03 80	GASKET	300			
01-02-54166	A 346 993 09 01	SPRING	300			
01-02-54167	A 001 545 18 09	SWITCH	300			
01-02-54168	A 020 997 39 47	SEAL RING	300			
01-02-54169	A 381 401 07 71	WHEEL MOUNTING BOLT	300			
01-02-54170	A 027 997 22 48	SEAL RING	300			
01-02-54171	A 650 356 00 80	GASKET,REAR WHEEL,VLRUB	300			
01-02-54172	A 624 997 00 32	SCREW PLUG	300			
01-02-54173	N007603 024106	SEAL RING,VLRUB	300			
01-02-54174	A 355 997 02 32	SCREW PLUG	300			
01-02-54175	N007603 045100	SEAL RING	300			
01-02-54176	A 677 540 08 17	SENDER UNIT	300			
01-02-54177	A 945 542 16 18	SENSOR	300			
01-02-54178	A 945 542 15 18	SENSOR	300			
01-02-54179	A 000 540 36 36	ELECTRIC CABLE	300			
01-02-54180	A 000 540 41 36	SENSOR CABLE	300			
01-02-54181	A 659 423 36 10	BRAKE LINING	300			
01-02-54182	A 945 993 00 10	SPRING	300			
01-02-54183	A 305 423 04 01	BRAKE DRUM	300			
01-02-54184	X 009 800 242	ENGINE	300			
01-02-54185	A940 460 35 00	STEERING BOX ASSEMBLY	300			
01-02-54186	A941 600 41 05	BODY SHELL	300			
01-02-54187	X002 540 957	TRANSMISSION	300			
01-02-54188	A542 030 02 40	CRANKSHAFT BEARING	300			
01-02-54189	A542 030 04 40	CRANKSHAFT BEARING	300			
01-02-54190	A541 030 13 40	CRANKSHAFT BEARING	300			
01-02-54191	A541 030 14 40	CRANKSHAFT BEARING	300			
01-02-54192	A541 030 15 40	CRANKSHAFT BEARING	300			
01-02-54193	A541 030 08 60	CONNECTING ROD BEARING	300			
01-02-54194	A541 030 10 60	CONNECTING ROD BEARING	300			
01-02-54195	A541 030 11 60	CONNECTING ROD BEARING	300			
01-02-54196	A541 030 12 60	CONNECTING ROD BEARING	300			
01-02-54197	A541 030 13 60	CONNECTING ROD BEARING	300			
01-02-54198	A000 234 24 11	COMPRESSOR	300			
01-02-54199	A541 230 02 28	COUPLING	300			
01-02-54200	A005 203 26 75	THERMOSTA ELEMENT	300			
01-02-54201	A541 033 13 62	THRUST WASHER	300			
01-02-54202	A541 033 14 62	THRUST WASHER	300			
01-02-54203	A541 033 15 62	THRUST WASHER	300			
01-02-54204	A941 720 03 20	GLASS PANE	300			

01-02-54205	A000 725 00 02	WINDOW REGULATOR	300			
01-02-54206	A000 725 01 02	WINDOW REGULATOR	300			
01-02-54207	A941 720 04 20	GASS PANE	300			
01-02-54208	A541 051 03 10	CAMSHAFT BEARING	300			
01-02-54209	A541 051 00 10	CAMSHAFT BEARING	300			
01-02-54210	A541 050 10 01	CAMSHAFT	300			
01-02-54211	A002 250 41 15	RELEASE RING	300			
01-02-54212	A007 981 7005	INSIDE BEARING	300			
01-02-54213	A019 997 48 47	SEAL RING	300			
01-02-54214	A006 981 08 05	OUT SIDE BEARING	300			
01-02-54215	A541 180 00 09	OIL FILTER ELEMENT	300			
01-02-54216	A 389 262 30 55	SPACER WASHER	300			
01-02-54217	A 389 262 35 55	SPACER WASHER	300			
01-02-54218	A 389 262 40 55	SPACER WASHER	300			
01-02-54219	A 019 997 72 48	SEAL RING	300			
01-02-54220	A 389 263 55 52	SPACER WASHER	300			
01-02-54221	A 389 263 65 52	SPACER WASHER	300			
01-02-54222	A 389 263 75 52	SPACER WASHER	300			
01-02-54223	A 004 997 22 48	SEAL RING	300			
01-02-54224	A 389 262 47 52	SPACER WASHER	300			
01-02-54225	A 659 283 46 52	SPACER WASHER	300			
01-02-54226	A 659 283 51 52	SPACER WASHER	300			
01-02-54227	A 389 262 77 54	SPACER WASHER	300			
01-02-54228	A 945 261 00 80	GASKET	300			
01-02-54229	A 389 262 48 52	SPACER WASHER	300			
01-02-54230	A 659 283 48 52	SPACER WASHER	300			
01-02-54231	A 659 283 54 52	SPACER WASHER	300			
01-02-54232	A 659 283 55 52	SPACER WASHER	300			
01-02-54233	A 015 997 27 48	SEAL RING	300			
01-02-54234	A 389 262 62 01	DRIVE SHAFT	300			
01-02-54235	A 389 269 85 34	OIL LINE	300			
01-02-54236	A 000 994 98 41	SNAP RING	300			
01-02-54237	A 019 997 20 47	SEAL RING	300			
01-02-54238	A 389 262 09 73	LOCK	300			
01-02-54239	A 389 262 31 37	SYNCHRONIZER CONE	300			
01-02-54240	A 387 262 10 93	SPRING	300			
01-02-54241	A 011 981 13 05	TAPERED ROLLER BEARING	300			
01-02-54242	A 387 262 86 73	LOCK	300			
01-02-54243	A 013 997 00 48	SEAL RING	300			
01-02-54244	A 945 990 00 50	NUT	300			
01-02-54245	A 389 262 23 51	SPACER RING	300			
01-02-54246	A 389 262 33 52	SPACER WASHER	300			
01-02-54247	A 389 262 30 52	SPACER WASHER	300			
01-02-54248	A 389 262 22 55	SPACER WASHER	300			
01-02-54249	A 389 262 18 55	SPACER WASHER	300			
01-02-54250	A 389 262 14 55	SPACER WASHER	300			
01-02-54251	A 389 262 36 54	SPACER WASHER	300			
01-02-54252	A 389 262 28 54	SPACER WASHER	300			
01-02-54253	A 945 262 05 10	GEAR	300			
01-02-54254	A 015 981 20 05	TAPERED ROLLER BEARING	300			
01-02-54255	A 014 981 16 05	TAPERED ROLLER BEARING	300			
01-02-54256	A 389 262 50 34	SYNCHRONIZER RING	300			
01-02-54257	A 387 262 20 73	LOCK	300			
01-02-54258	A 389 262 47 35	SYNCHRONIZER BODY	300			
01-02-54259	A 945 262 02 13	GEAR	300			
01-02-54260	A 010 981 53 10	NEEDLE BEARING	300			
01-02-54261	A 389 262 07 37	SYNCHRONIZER CONE	300			
01-02-54262	A 387 262 08 93	SPRING	300			
01-02-54263	A 389 262 25 12	GEAR	300			
01-02-54264	A 389 262 00 34	SYNCHRONIZER RING	300			
01-02-54265	A 389 262 25 35	SYNCHRONIZER BODY	300			

01-02-54266	A 387 262 21 73	LOCK	300			
01-02-54267	A 387 262 23 73	LOCK	300			
01-02-54268	A 387 262 80 73	LOCK	300			
01-02-54269	A 387 262 20 11	GEAR	300			
01-02-54270	A 008 981 83 10	NEEDLE BEARING	300			
01-02-54271	A 389 262 01 35	SYNCHRONIZER BODY	300			
01-02-54272	A 389 262 17 23	SLIDING COLLAR	300			
01-02-54273	A 389 262 20 33	DOG CLUTCH GEAR	300			
01-02-54274	A 389 262 00 50	BUSHING	300			
01-02-54275	A 389 262 37 54	SPACER WASHER	300			
01-02-54276	A 389 262 08 09	SUN GEAR	300			
01-02-54277	A 007 994 18 41	LOCK	300			
01-02-54278	A 945 260 46 61	PLANETARY CARRIER	300			
01-02-54279	A 389 269 47 34	OIL LINE	300			
01-02-54280	N000472 060000	LOCK RING	300			
01-02-54281	A 655 260 01 97	GEAR SET	300			
01-02-54282	A 945 262 02 08	ANNULUS	300			
01-02-54283	A 389 262 14 25	DISC SUPPORT	300			
01-02-54284	A 389 262 07 73	LOCK	300			
01-02-54285	N000472 130000	LOCK RING	300			
01-02-54286	A 389 260 20 36	FOLLOWER RING	300			
01-02-54287	A 389 262 05 37	SYNCHRONIZER CONE	300			
01-02-54288	A 389 262 02 93	SPRING	300			
01-02-54289	A 389 262 20 35	SYNCHRONIZER BODY	300			
01-02-54290	N000471 120000	LOCK RING	300			
01-02-54291	A 389 262 02 51	SPACER RING	300			
01-02-54292	A 389 262 92 34	SYNCHRONIZER RING	300			
01-02-54293	A 945 262 00 45	FLANGE	300			
01-02-54294	A 389 262 03 62	THRUST WASHER	300			
01-02-54295	A 945 263 06 02	COUNTERSHAFT	300			
01-02-54296	A 389 994 00 41	LOCK	300			
01-02-54297	A 945 263 08 10	GEAR	300			
01-02-54298	A 389 262 20 11	GEAR	300			
01-02-54299	A 976 263 00 30	REVERSE IDLER SHAFT	300			
01-02-54300	A 389 263 10 31	REVERSE IDLER GEAR	300			
01-02-54301	A 389 263 08 50	BUSHING	300			
01-02-54302	A 012 981 89 10	NEEDLE BEARING	300			
01-02-54303	A 945 263 00 41	BRACKET	300			
01-02-54304	A 389 269 03 10	OIL PUMP SHAFT	300			
01-02-54305	A 389 260 06 90	OIL PUMP	300			
01-02-54306	A 389 262 51 54	SPACER WASHER	300			
01-02-54307	A 389 262 56 54	SPACER WASHER	300			
01-02-54308	A 389 262 62 54	SPACER WASHER	300			
01-02-54309	A 945 269 00 67	PIPE	300			
01-02-54310	A 945 269 00 34	OIL LINE	300			
01-02-54311	A 126 994 05 35	SNAP RING	300			
01-02-54312	A 655 260 01 57	REPAIR KIT	300			
01-02-54313	A 389 261 00 50	BUSHING	300			
01-02-54314	A 389 993 21 01	SPRING	300			
01-02-54315	A 389 997 01 32	SCREW PLUG	300			
01-02-54316	N007603 038105	SEAL RING	300			
01-02-54317	A 389 997 15 72	FITTING	300			
01-02-54318	N007346 011013	CLAMPING SLEEVE	300			
01-02-54319	A 389 265 27 49	SLIDE	300			
01-02-54320	A 945 265 01 49	SLIDE	300			
01-02-54321	A 389 265 27 74	PIN	300			
01-02-54322	A 009 981 05 10	NEEDLE BEARING	300			
01-02-54323	A 945 267 08 19	SHIFTING CYLINDER	300			
01-02-54324	A 000 267 01 97	BOOT	300			
01-02-54325	A 387 267 06 50	BUSHING	300			
01-02-54326	A 945 267 02 17	ROD	300			

01-02-54327	A 389 268 09 50	BUSHING	300			
01-02-54328	A 387 263 28 52	SPACER WASHER	300			
01-02-54329	A 387 263 30 52	SPACER WASHER	300			
01-02-54330	A 945 267 02 18	PISTON	300			
01-02-54331	A 945 265 00 01	SHIFTING FORK	300			
01-02-54332	A 389 262 25 55	SPACER WASHER	300			
01-02-54333	A 389 262 20 52	SPACER WASHER	300			
01-02-54334	A 389 262 32 52	SPACER WASHER	300			
01-02-54335	A 006 994 42 41	LOCK	300			
01-02-54336	A 389 267 11 74	PIN	300			
01-02-54337	A 387 993 44 01	SPRING	300			
01-02-54338	A 387 993 45 01	SPRING	300			
01-02-54339	A 389 267 23 50	BUSHING	300			
01-02-54340	A 389 267 73 17	ROD	300			
01-02-54341	A 389 267 10 18	PISTON	300			
01-02-54342	A 389 267 09 74	PIN	300			
01-02-54343	A 389 993 06 01	SPRING	300			
01-02-54344	A 945 268 00 56	SCREW PLUG	300			
01-02-54345	A 389 265 24 49	SLIDE	300			
01-02-54346	A 389 265 09 74	PIN	300			
01-02-54347	A 003 990 29 40	WASHER	300			
01-02-54348	A 945 267 13 19	SHIFTING CYLINDER	300			
01-02-54349	A 389 990 09 01	SCREW	300			
01-02-54350	A 945 268 02 74	PIN	300			
01-02-54351	A 945 993 04 01	SPRING	300			
01-02-54352	N000472 019000	SNAP RING	300			
01-02-54353	N005401 312000	BALL	300			
01-02-54354	A 945 268 02 33	SHIFTING FINGER	300			
01-02-54355	N001481 012020	CLAMPING SLEEVE	300			
01-02-54356	A 945 268 01 46	SHIFTING SEGMENT	300			
01-02-54357	A 389 997 03 19	THREADED PIN	300			
01-02-54358	N000471 038002	LOCK RING	300			
01-02-54359	A 945 268 00 13	SHIFTING SEGMENT	300			
01-02-54360	A 389 997 04 19	THREADED PIN	300			
01-02-54361	A 945 268 04 74	PIN	300			
01-02-54362	A 387 993 21 01	SPRING	300			
01-02-54363	A 387 268 10 76	WASHER	300			
01-02-54364	A 945 993 06 01	SPRING	300			
01-02-54365	N912009 028200	SNAP RING	300			
01-02-54366	A 976 268 00 76	WASHER	300			
01-02-54367	A 945 268 09 29	SHIFTING ROD	300			
01-02-54368	A 945 268 19 50	BUSHING	300			
01-02-54369	A 945 268 22 50	BUSHING	300			
01-02-54370	A 945 260 02 47	SHIFTING TUBE	300			
01-02-54371	A 976 261 13 33	COVER	300			
01-02-54372	A 945 260 15 13	TRANSMISSION CASE COVER	300			
01-02-54373	A 945 268 20 50	BUSHING	300			
01-02-54374	A 945 260 04 37	LEVER	300			
01-02-54375	N000007 004123	CILINDRICAL PIN	300			
01-02-54376	A 945 268 03 33	SHIFTING FINGER	300			
01-02-54377	N006888 005012	WOODRUFF KEY	300			
01-02-54378	A 387 268 00 52	SPACER WASHER	300			
01-02-54379	A 387 268 01 52	SPACER WASHER	300			
01-02-54380	N080705 016003	NUT	300			
01-02-54381	A 945 261 05 33	COVER	300			
01-02-54382	A 001 990 42 04	SCREW	300			
01-02-54383	N910105 008043	SCREW	300			
01-02-54384	A 945 268 02 25	SHIFTING ROD	300			
01-02-54385	N007993 012200	SNAP RING	300			
01-02-54386	A 389 268 00 51	SPACER RING	300			
01-02-54387	A 389 268 06 74	PIN	300			

01-02-54388	N000988 006019	FITTED WASHER	300			
01-02-54389	A 389 261 17 33	COVER	300			
01-02-54390	N000137 008204	SPRING WASHER	300			
01-02-54391	A 124 281 00 82	BREATHER CAP	300			
01-02-54392	A 945 268 01 74	PIN	300			
01-02-54393	N001481 004006	DOWEL PIN	300			
01-02-54394	A 945 268 02 50	BUSHING	300			
01-02-54395	A 945 268 02 46	SHIFTING SEGMENT	300			
01-02-54396	A 023 997 77 48	SEAL RING	300			
01-02-54397	A 016 981 28 10	NEEDLE BEARING	300			
01-02-54398	A 945 268 38 34	BEARING COVER	300			
01-02-54399	A 000 997 36 34	SCREW	300			
01-02-54400	A 012 981 33 10	NEEDLE BEARING	300			
01-02-54401	A 012 997 82 47	SEAL RING	300			
01-02-54402	A 000 990 46 77	SCREW	300			
01-02-54403	A 001 545 17 09	SWITCH	300			
01-02-54404	A 013 542 57 17	SENDER UNIT	300			
01-02-54405	A 942 540 00 13	CABLE HARNESS	300			
01-02-54406	A 009 981 43 05	TAPERED ROLLER BEARING	300			
01-02-54407	A 004 981 09 05	TAPERED ROLLER BEARING	300			
01-02-54408	A 673 997 02 45	REPAIR KIT	300			
01-02-54409	A 003 981 29 05	BALL BEARING	300			
01-02-54410	A 387 350 00 40	REPAIR KIT	300			
01-02-54411	A 346 350 36 39	RING GEAR AND PINION	300			
01-02-54412	A 346 353 08 55	CYLINDER	300			
01-02-54413	A 346 353 00 90	PROTECTIVE CAP	300			
01-02-54414	A 017 997 31 47	SEAL RING	300			
01-02-54415	A 019 997 05 47	SEAL RING	300			
01-02-54416	A 389 262 31 55	SPACER WASHER	300			
01-02-54417	A 389 263 59 52	SPACER WASHER	300			
01-02-54418	A 389 263 69 52	SPACER WASHER	300			
01-02-54419	A 945 262 03 23	SLIDING COLLAR	300			
01-02-54420	A 945 262 16 10	GEAR	300			
01-02-54421	A 016 981 00 10	NEEDLE BEARING	300			
01-02-54422	A 013 981 11 05	TAPERED ROLLER BEARING	300			
01-02-54423	A 945 262 04 23	SLIDING COLLAR	300			
01-02-54424	A 009 981 15 10	NEEDLE BEARING(1.0X4.0)	300			
01-02-54425	A 012 981 93 05	TAPERED ROLLER BEARING	300			
01-02-54426	A 004 981 88 25	BEARING	300			
01-02-54427	A 945 262 08 23	SLIDING COLLAR	300			
01-02-54428	A 007 981 40 25	BALL BEARING	300			
01-02-54429	A 014 997 51 48	SEAL RING	300			
01-02-54430	A 014 981 14 05	TAPERED ROLLERBEARING	300			
01-02-54431	A 945 263 05 13	GEAR	300			
01-02-54432	A 004 981 92 25	BALL BEARING	300			
01-02-54433	A 015 997 36 48	SEAL RING	300			
01-02-54434	A 015 997 60 48	SEAL RING	300			
01-02-54435	A 389 269 03 21	STRAINER	300			
01-02-54436	A 006 997 64 47	SEAL RING	300			
01-02-54437	N007603 016105	SEAL RING,VLRUB	300			
01-02-54438	A 014 997 36 47	SEAL RING	300			
01-02-54439	A 389 265 28 74	PIN	300			
01-02-54440	A 015 997 40 48	SEAL RING	300			
01-02-54441	A 021 997 77 48	SEAL RING	300			
01-02-54442	A 013 997 75 48	SEAL RING	300			
01-02-54443	A 387 268 11 50	BUSHING	300			
01-02-54444	A 945 268 36 34	BEARING COVER	300			
01-02-54445	A 945 262 19 05	MAIN SHAFT	300			
SPARE PARTS FOR MERCEDES ACTROS TRUCK TYPE 3331 (6X4)42			300			

CODE	Number	Description	300			
01-02-54446	N007603 033102	SEAL RING	300			
01-02-54447	N000000 001103	SEAL RING	300			
01-02-54448	N000000 001069	SEAL RING, VLRUB	300			
01-02-54449	A 001 987 71 40	RUBBER BUFFER	300			
01-02-54450	A 541 010 05 05	GASKET KIT	300			
01-02-54451	A 541 010 20 33	GASKET KIT	300			
01-02-54452	A 541 010 00 80	GASKET KIT	300			
01-02-54453	A 541 018 07 12	BREATHER PIPE	300			
01-02-54454	A 403 997 00 32	SCREW PLUG	300			
01-02-54455	N007603 026109	SEAL RING	300			
01-02-54456	A 422 014 00 76	WASHER	300			
01-02-54457	A 004 153 44 28	SENDER UNIT	300			
01-02-54458	A 541 010 07 72	OIL DIPSTICK	300			
01-02-54459	A 541 010 27 20	CYLINDER HEAD	300			
01-02-54460	A 541 997 03 45	SEAL RING	300			
01-02-54461	A 541 050 02 26	INTAKE VALVE	300			
01-02-54462	A 541 050 02 27	EXHAUST VALVE	300			
01-02-54463	A 541 016 06 91	VALVE	300			
01-02-54464	A 102 053 00 26	CONE HALF	300			
01-02-54465	N005401 999012	BALL	300			
01-02-54466	A 541 050 06 33	ROCKER ARM	300			
01-02-54467	A 541 050 05 34	ROCKER ARM	300			
01-02-54468	A 422 990 00 51	NUT	300			
01-02-54469	N000471 024000	LOCK RING	300			
01-02-54470	A 906 055 01 20	SET SCREW	300			
01-02-54471	A 326 990 01 51	NUT	300			
01-02-54472	A 005 017 14 21	NOZZLE HOLDER	300			
01-02-54473	A 541 997 05 45	SEAL RING	300			
01-02-54474	A 906 017 02 60	SEAL RING	300			
01-02-54475	A 541 016 03 21	GASKET	300			
01-02-54476	A 541 010 10 55	PIPE	300			
01-02-54477	N000000 001068	SEAL RING	300			
01-02-54478	A 541 010 11 55	PIPE	300			
01-02-54479	A 541 990 01 88	BANJO UNION	300			
01-02-54480	A 541 054 05 05	PUSH ROD	300			
01-02-54481	A 541 050 03 22	ROLLER TAPPET	300			
01-02-54482	A 541 030 02 01	CRANKSHAFT	300			
01-02-54483	A 541 050 02 03	CRANKSHAFT GEAR	300			
01-02-54484	A 541 030 01 03	VIBRATION ABSORBER	300			
01-02-54485	A 541 035 02 12	PULLEY	300			
01-02-54486	A 541 035 02 14	INTERMEDIATE PIECE	300			
01-02-54487	A 541 030 01 05	FLYWHEEL	300			
01-02-54488	A 004 981 21 25	BALL BEARING (S)	300			
01-02-54489	A 541 030 04 20	CONNECTING ROD	300			
01-02-54490	A 541 030 03 37	PISTON	300			
01-02-54491	A 541 011 00 59	SEAL RING	300			
01-02-54492	A 541 997 09 45	SEAL RING	300			
01-02-54493	A 028 074 59 02	INJECTION PUMP	300			
01-02-54494	A 023 997 64 48	SEAL RING	300			
01-02-54495	A 023 997 65 48	SEAL RING	300			
01-02-54496	A 541 990 03 01	SCREW	300			
01-02-54497	A 541 070 57 32	LINE	300			
01-02-54498	A 326 990 01 63	HOLLOW SCREW	300			
01-02-54499	N000000 001066	SEAL RING	300			
01-02-54500	N000000 001070	SEAL RING, VLRUB	300			
01-02-54501	A 541 090 01 51	FILTER ELEMENT	300			
01-02-54502	A 541 090 04 52	FILTER	300			
01-02-54503	A 001 990 42 05	SCREW	300			
01-02-54504	A 000 990 31 50	NUT	300			
01-02-54505	A 541 997 00 83	SLEEVE	300			

01-02-54506	N000000 000644		300			
01-02-54507	A 541 098 01 37	INTAKE PIPE SOCKET	300			
01-02-54508	A 024 997 16 48	SEAL RING	300			
01-02-54509	A 541 130 02 30	GEAR	300			
01-02-54510	A 442 130 03 14	CRANKSHAFT	300			
01-02-54511	N001473 005024	GROOVED PIN	300			
01-02-54512	N308752 002000	CLAMPING PIN	300			
01-02-54513	A 541 131 01 42	FLANGE	300			
01-02-54514	A 014 997 61 48	SEAL RING.TRANSMISN.VLRUB	300			
01-02-54515	A 541 130 00 08	CYLINDER LINER	300			
01-02-54516	A 541 131 07 19	CYLINDER HEAD	300			
01-02-54517	A 541 130 06 20	VALVE	300			
01-02-54518	N000000 001104	SEAL RING	300			
01-02-54519	N000000 001073	SEAL RING, VLRUB	300			
01-02-54520	A 541 098 06 80	GASKET	300			
01-02-54521	A 541 098 01 72	NUT	300			
01-02-54522	A 541 090 03 89	BEARING	300			
01-02-54523	A 003 153 76 28	SENDER UNIT	300			
01-02-54524	A 004 153 03 28	SENDER UNIT	300			
01-02-54525	N007603 020101	RING,GENERAL,METAL	300			
01-02-54526	A 001 159 07 01	HEATER PLUG	300			
01-02-54527	A 442 078 01 80	GAS KET	300			
01-02-54528	A 541 142 01 80	GASKET	300			
01-02-54529	A 403 142 02 12	CLAMPING PIECE	300			
01-02-54530	A 447 990 67 04	SCREW	300			
01-02-54531	A 004 151 94 01	STARTING MOTOR	300			
01-02-54532	A 000 150 10 31	GEARING	300			
01-02-54533	A 001 152 24 10	SOLENOID SWITCH	300			
01-02-54534	A 001 152 43 10	SOLENOID SWITCH	300			
01-02-54535	A 000 150 02 29	TERMINAL	300			
01-02-54536	A 000 151 62 15	ARMATURE	300			
01-02-54537	A 001 990 09 21	SCREW	300			
01-02-54538	A 007 981 66 25	BALL BEARING	300			
01-02-54539	A 001 154 22 16	RECTIFIER	300			
01-02-54540	A 003 154 00 06	REGULATOR AND CUT-OUT	300			
01-02-54541	A 001 155 19 15	PULLEY	300			
01-02-54542	A 001 153 21 20	SPEED SENDER UNIT	300			
01-02-54543	A 655 540 68 81	PLUG SOCKET	300			
01-02-54544	A 541 180 01 01	OIL PUMP	300			
01-02-54545	A 422 180 03 15	PRESSER RELIEF VALVE	300			
01-02-54546	A 541 188 00 02	COVER	300			
01-02-54547	A 541 188 00 80	GASKET	300			
01-02-54548	A 012 542 05 17	SENDER UNIT	300			
01-02-54549	A 003 153 84 28	SENDER UNIT	300			
01-02-54550	A 004 153 43 28	SENDER UNIT	300			
01-02-54551	N917003 028002	GASKET	300			
01-02-54552	A 541 184 06 80	GASKET	300			
01-02-54553	A 541 180 11 20	OIL LINE	300			
01-02-54554	A 541 187 00 80	GASKET	300			
01-02-54555	A 542 200 19 01	WATER PUMP	300			
01-02-54556	A 542 200 01 04	IMPELLER	300			
01-02-54557	A 541 202 01 10	PULLEY	300			
01-02-54558	A 541 201 01 80	GASKET	300			
01-02-54559	A 003 205 01 06	FAN	300			
01-02-54560	A 542 200 05 22	FAN DRIVE	300			
01-02-54561	A 000 200 42 22	FAN DRIVE	300			
01-02-54562	A 541 200 03 22	FAN DRIVE	300			
01-02-54563	A 541 200 03 70	BELT TIGHTENER	300			
01-02-54564	A 541 202 01 20	PIVOT PIN	300			
01-02-54565	A 541 997 08 92	V-BELT	300			
01-02-54566	A 002 460 07 80	HYDRAULIC PUMP	300			

01-02-54567	A 002 460 12 80	HYDRAULIC PUMP	300			
01-02-54568	A 002 460 10 80	HYDRAULIC PUMP	300			
01-02-54569	A 000 460 42 84	REPAIR KIT	300			
01-02-54570	A 541 055 03 20	SET SCREW	300			
01-02-54571	A 442 990 57 63	Hollow Screw	300			
01-02-54572	A442 990 55 63	Hollow Screw	300			
01-02-54573	A 941 660 20 28	ROCKER PANEL	300			
01-02-54574	A 941 671 01 20	SEAL	300			
01-02-54575	A 005 820 90 42	ELECTRIC MOTOR	300			
01-02-54576	A 005 820 91 42	ELECTRIC MOTOR	300			
01-02-54577	A 000 890 74 67	OUTFIT(LOCK,KEY,HANDLE)	300			
01-02-54578	A 941 750 12 72	FRAME	300			
01-02-54579	A 941 751 12 18	GRILLE	300			
01-02-54580	A 641 751 19 18	GRILLE	300			
01-02-54581	A 941 817 01 16	BADGE	300			
01-02-54582	A 001 980 84 64	PNEUMATIC-SPRIN	300			
01-02-54583	A 941 750 12 18	GRILLE	300			
01-02-54584	A 941 751 01 70	HANDLE	300			
01-02-54585	A 000 810 96 16	MIRROR HOUSING	300			
01-02-54586	A 000 810 94 16	MIRROR HOUSING	300			
01-02-54587	A 005 820 63 42	ELECTRIC MOTOR	300			
01-02-54588	A 001 811 20 33	MIRROR GLASS	300			
01-02-54589	A 001 811 21 33	MIRROR GLASS	300			
01-02-54590	A 000 811 13 07	CLIP	300			
01-02-54591	A 001 810 44 14	BRACKET	300			
01-02-54592	A 001 810 45 14	BRACKET	300			
01-02-54593	A 001 811 22 33	MIRROR GLASS	300			
01-02-54594	A 941 820 39 61	LIGHTING UNIT	300			
01-02-54595	A 941 820 40 61	LIGHTING UNIT	300			
01-02-54596	A 004 826 06 90	LENS	300			
01-02-54597	A 004 826 07 90	LENS	300			
01-02-54598	N072601 024802	BULB	300			
01-02-54599	N072601 024250	BULB	300			
01-02-54600	A 941 880 04 85	RADIATOR GRILLE	300			
01-02-54601	A 941 880 05 85	RADIATOR GRILLE	300			
01-02-54602	A 941 820 13 21	BLINKER LAMP	300			
01-02-54603	N072601 024210	BULB	300			
01-02-54604	A 002 820 01 56	SIDE MARKER LAMP	300			
01-02-54605	N072601 024131	BULB	300			
01-02-54606	A 001 820 75 01	INTERIOR LAMP	300			
01-02-54607	A 941 880 00 20	HANDLE	300			
01-02-54608	A 005 820 21 42	ELECTRIC MOTOR	300			
01-02-54609	A 941 820 03 44	WIPER ARM	300			
01-02-54610	A 001 820 12 45	WIPER BLADE	300			
01-02-54611	A 000 824 60 27	WIPER RUBBER	300			
01-02-54612	A 000 830 12 72	TEMPERATURE SENSOR	300			
01-02-54613	A 000 830 15 18	FILTER	300			
01-02-54614	A 000 830 78 72	TEMPERATURE SENSOR	300			
01-02-54615	A 140 997 07 45	SEAL RING,VLRUB	300			
01-02-54616	A 140 997 08 45	SEAL RING,VLRUB	300			
01-02-54617	A 002 830 82 84	VALVE	300			
01-02-54618	A 140 997 06 45	SEAL RING,VLRUB	300			
01-02-54619	A 140 997 09 45	SEAL RING,VLRUB	300			
01-02-54620	A 941 830 02 15	PIPE LINE	300			
01-02-54621	A 941 830 03 15	PIPE LINE	300			
01-02-54622	A 000 830 17 83	TANK	300			
01-02-54623	A 006 820 58 10	SWITCH	300			
01-02-54624	A 002 830 27 84	VALVE	300			
01-02-54625	A 941 830 33 44	AIR DUCT	300			
01-02-54626	A 000 094 41 65	VALVE	300			
01-02-54627	A 941 830 01 66	AIR BAFFLE	300			

01-02-54628	A 002 987 09 40	RUBBER BUFFER	300			
01-02-54629	A 941 869 01 20	RESERVOIR	300			
01-02-54630	A 941 860 00 62	VALVE	300			
01-02-54631	A 000 869 40 21	PUMP	300			
01-02-54632	A 941 869 01 17	TUBE	300			
01-02-54633	A 001 860 21 69	LOCK	300			
01-02-54634	A 000 869 13 19	VALVE	300			
01-02-54635	A 941 880 61 70 7354	FRONT BUMPER FACE BAR	300			
01-02-54636	A 941 880 62 70 7354	FRONT BUMPER FACE BAR	300			
01-02-54637	A 941 885 14 01 7C72	FRONT BUMPER FACE BAR	300			
01-02-54638	A 941 984 07 61	CLIP	300			
01-02-54639	A 941 885 15 01 7354	FRONT BUMPER FACE BAR	300			
01-02-54640	A 940 885 10 31	CONSOLE	300			
01-02-54641	A 940 885 11 31	CONSOLE	300			
01-02-54642	A 941 880 53 70 7354	FRONT BUMPER FACE BAR	300			
01-02-54643	A 941 880 09 31	ROCKER PANEL	300			
01-02-54644	A 941 884 02 22	COVERING	300			
01-02-54645	A 941 884 03 22	COVERING	300			
01-02-54646	A 941 241 51 13	RUBBER MOUNTING	300			
01-02-54647	A 941 241 57 13	RUBBER MOUNTING	300			
01-02-54648	A 007 250 51 04	CLUTCH PRESSURE PLATE	300			
01-02-54649	A 019 250 61 03	CLUTCH DISC	300			
01-02-54650	A 005 990 28 04	SCREW	300			
01-02-54651	A 655 250 15 13	RELEASE LEVER	300			
01-02-54652	A 000 254 03 35	BEARING	300			
01-02-54653	A 002 992 15 01	BUSHING	300			
01-02-54654	A 655 254 02 06	SPINDLE	300			
01-02-54655	A 941 295 00 15	RESERVOIR	300			
01-02-54656	A 002 295 04 06	MASTER CYLINDER	300			
01-02-54657	A 941 291 04 74	PIN	300			
01-02-54658	A 000 295 28 18	CLUTCH BOOSTER	300			
01-02-54659	A 003 990 59 68	FITTING	300			
01-02-54660	A 003 545 47 07	SWITCH	300			
01-02-54661	A 655 545 01 28	PLUG	300			
01-02-54662	A 941 268 00 97 5B21	BOOT	300			
01-02-54663	A 000 260 40 98	SHIFT MECHANISM	300			
01-02-54664	A 003 997 91 72	FITTING	300			
01-02-54665	A 001 260 18 63	SHIFTING CYLINDER	300			
01-02-54666	A 000 987 26 27	PLASTIC PIPE	300			
01-02-54667	A 000 990 65 78	CONNECTOR,POLLUTION CNTRL	300			
01-02-54668	A 001 990 78 71	ELBOW FIT,POLLUTION CNTRL	300			
01-02-54669	A 003 990 29 71	ELBOW FITTING	300			
01-02-54670	A 001 990 70 78	CONNECTOR	300			
01-02-54671	A 645 990 03 78	CONNECTOR	300			
01-02-54672	A 000 429 42 37	DISTRIBUTOR	300			
01-02-54673	N915052 004015	BANJO UNION	300			
01-02-54674	N915052 004016	BANJO UNION	300			
01-02-54675	A 645 990 11 78	CONNECTOR	300			
01-02-54676	N915036 008202	HOLLOW SCREW	300			
01-02-54677	A 389 997 02 72	FITTING	300			
01-02-54678	N007603 012405	SEAL RING,VLRUB	300			
01-02-54679	A 381 997 02 72	FITTING	300			
01-02-54680	N915036 006202	HOLLOW SCREW	300			
01-02-54681	N007603 010404	SEAL RING,VLRUB	300			
01-02-54682	A 941 990 08 40	WASHER	300			
01-02-54683	A 201 291 02 82	PAD,FOOT PEDALS	300			
01-02-54684	A 201 292 00 82	PAD,FOOT PEDALS	300			
01-02-54685	N071752 008003	YOKE	300			
01-02-54686	A 385 292 01 74	PIN	300			
01-02-54687	N912002 016001	LOCK	300			

01-02-54688	A 655 993 00 10	SPRING	300			
01-02-54689	A 941 300 01 04	ACCELERATOR PEDAL	300			
01-02-54690	A 943 320 03 02	FRONT SPRING	300			
01-02-54691	A 000 322 12 85	RUBBER BEARING	300			
01-02-54692	A 000 322 02 44	RUBBER BUFFER	300			
01-02-54693	A 949 331 05 25	U-BOLT	300			
01-02-54694	N308765 024014	SCREW	300			
01-02-54695	A 000 324 09 08	HELPER SPRING	300			
01-02-54696	N000912 014090	SCREW	300			
01-02-54697	A 943 323 05 65	TORSION BAR	300			
01-02-54698	A 000 323 79 85	RUBBER MOUNTING	300			
01-02-54699	A 000 326 24 81	RUBBER MOUNTING	300			
01-02-54700	A 005 323 97 00	SHOCK ABSORBER	300			
01-02-54701	A 948 320 11 05	REAR SPRING	300			
01-02-54702	A 389 324 00 71	SPRING BOLT	300			
01-02-54703	N007349 019003	WASHER	300			
01-02-54704	N910113 018004	NUT	300			
01-02-54705	A 947 351 05 25	U-BOLT	300			
01-02-54706	N000000 000254	SCREW	300			
01-02-54707	A 000 325 05 96	RUBBER MOUNTING	300			
01-02-54708	A 948 325 05 53	SPACER TUBE	300			
01-02-54709	N000912 014087	SCREW	300			
01-02-54710	N910105 014024	SCREW	300			
01-02-54711	N913023 014003	NUT	300			
01-02-54712	A 948 423 02 33	BEARING BRACKET	300			
01-02-54713	A 947 325 02 09 7390	LA.	300			
01-02-54714	A 389 325 00 74	PIN	300			
01-02-54715	A 948 350 17 05	CONTROL ARM	300			
01-02-54716	A 000 350 29 05	CONTROL ARM	300			
01-02-54717	A 000 350 27 05	CONTROL ARM	300			
01-02-54718	A 005 326 09 00	SHOCK ABSORBER	300			
01-02-54719	A 000 320 06 44	RUBBER BUFFER	300			
01-02-54720	A 000 320 01 44	RUBBER BUFFER	300			
01-02-54721	A 000 987 28 27	PLASTIC PIPE	300			
01-02-54722	A 002 990 61 71	FITTING	300			
01-02-54723	A 673 997 01 45	AIR LINE CONNECTOR	300			
01-02-54724	A 673 997 02 45	REPAIR KIT	300			
01-02-54725	A 000 987 27 27	PLASTIC PIPE	300			
01-02-54726	A 002 990 59 71	FITTING	300			
01-02-54727	A 673 997 00 45	AIR LINE CONNECTOR	300			
01-02-54728	A 387 401 00 57	RIM BOW	300			
01-02-54729	A 387 401 01 57	RIM BOW	300			
01-02-54730	A 620 401 00 69	CLAMPING PLATE	300			
01-02-54731	A 620 402 00 68	CLAMPING SHOE	300			
01-02-54732	A 620 401 00 70	SCREW	300			
01-02-54733	A 620 401 01 70	SCREW	300			
01-02-54734	A 000 994 22 60	LOCK	300			
01-02-54735	A 620 990 02 40	WASHER	300			
01-02-54736	A 346 401 50 72	WHEEL NUT	300			
01-02-54737	A 331 402 05 07	RING	300			
01-02-54738	A 620 401 04 03	WHEEL SPIDER	300			
01-02-54739	A 620 402 04 04	WHEEL SPIDER	300			
01-02-54740	N074361 022351	LOCK WASHER	300			
01-02-54741	N074361 022205	NUT	300			
01-02-54742	A 000 583 50 45	ROD	300			
01-02-54743	A 000 403 00 36	GABLE	300			
01-02-54744	N308676 014010	SCREW	300			
01-02-54745	N308673 014002	NUT	300			
01-02-54746	A 656 410 68 02	PROPELLER SHAFT	300			
01-02-54747	A 656 411 00 11	DRIVE FLANGE	300			
01-02-54748	A 942 410 00 31	UNIVERSAL JOINT CROSS	300			

01-02-54749	A 395 411 00 59	SEAL RING	300			
01-02-54750	A 654 410 39 02	PROPELLER SHAFT	300			
01-02-54751	A 942 410 01 31	UNIVERSAL JOINT CROSS	300			
01-02-54752	A 006 994 23 41	LOCK	300			
01-02-54753	A 006 994 27 41	LOCK	300			
01-02-54754	A 389 411 00 80	GASKET	300			
01-02-54755	A 007 990 13 01	SCREW	300			
01-02-54756	N308673 012003	NUT	300			
01-02-54757	A 000 987 29 27	PLASTIC PIPE	300			
01-02-54758	A 005 997 43 72	REPAIR KIT	300			
01-02-54759	A 000 430 29 15	ANTI-FREEZE DEVICE	300			
01-02-54760	A 000 429 36 95	FILTER ELEMENT	300			
01-02-54761	A 000 430 33 07	PARTS KIT	300			
01-02-54762	A 000 430 14 15	REPAIR KIT	300			
01-02-54763	A 000 430 02 79	PARTS KIT	300			
01-02-54764	A 000 430 18 15	GASKET KIT	300			
01-02-54765	A 003 431 57 06	VALVE	300			
01-02-54766	A 001 542 92 18	SENSOR	300			
01-02-54767	A 000 420 29 71	REPAIR KIT	300			
01-02-54768	A 004 432 43 01	RESERVOIR	300			
01-02-54769	A 004 432 19 01	RESERVOIR	300			
01-02-54770	A 004 432 07 01	RESERVOIR	300			
01-02-54771	A 004 432 05 01	RESERVOIR	300			
01-02-54772	A 945 430 00 40	STRAP	300			
01-02-54773	A 941 430 01 40	STRAP	300			
01-02-54774	A 004 431 49 05	BRAKE VALVE	300			
01-02-54775	A 003 431 27 12	BRAKE PRESSURE REGULATOR	300			
01-02-54776	A 970 431 04 39	LEVER	300			
01-02-54777	A 942 431 02 92	ROD	300			
01-02-54778	A 001 991 03 22	BALL SOCKET	300			
01-02-54779	A 395 431 01 92	ROD	300			
01-02-54780	A 000 431 07 35	CONNECTOR	300			
01-02-54781	A 004 429 62 44	VALVE	300			
01-02-54782	A 002 430 30 60	REPAIR KIT	300			
01-02-54783	A 005 997 12 36	VALVE	300			
01-02-54784	A 003 430 77 81	VALVE	300			
01-02-54785	A 004 429 65 44	VALVE	300			
01-02-54786	A 000 420 51 71	VALVE	300			
01-02-54787	A 000 429 65 01	LINE	300			
01-02-54788	A 000 429 68 34	ADAPTER FITTING	300			
01-02-54789	A 000 429 80 30	BRAKE LINE COUPLING	300			
01-02-54790	A 000 429 81 30	BRAKE LINE COUPLING	300			
01-02-54791	A 000 420 00 58	REPAIR KIT	300			
01-02-54792	A 000 466 75 02	TANK	300			
01-02-54793	A 000 466 06 68	FILLER CAP	300			
01-02-54794	A 000 466 17 60	SEAL RING,VLRUB	300			
01-02-54795	A 000 466 06 04	FILTER	300			
01-02-54796	A 001 997 27 52	HOSE	300			
01-02-54797	N007603 016103	RING,GENERAL,METAL	300			
01-02-54798	A 001 990 19 67	SEAL CONE,P/S PUMP	300			
01-02-54799	A 001 990 10 67	SEAL CONE	300			
01-02-54800	A 942 466 04 81	HOSE	300			
01-02-54801	A 001 990 12 67	SEAL CONE	300			
01-02-54802	A 010 997 40 45	SEAL RING,VLRUB	300			
01-02-54803	A 943 460 00 04	STEERING LOCK	300			
01-02-54804	A 000 545 95 08	SWITCH	300			
01-02-54805	A 901 462 01 79	TUMBLER	300			
01-02-54806	A 020 545 39 32	TRANSPONDER	300			
01-02-54807	A 942 463 04 01	PITMAN ARM	300			
01-02-54808	A 002 460 45 05	DRAW LINK	300			

01-02-54809	A 001 460 42 48	DRAG LINK END	300			
01-02-54810	A 004 990 50 51	NUT	300			
01-02-54811	N916027 013006	HOSE,VLRUB	300			
01-02-54812	A 000 090 60 50	FUEL FEED PUMP	300			
01-02-54813	A 000 090 07 51	FILTER ELEMENT	300			
01-02-54814	N915036 010108	HOLLOW SCREW	300			
01-02-54815	N007603 014405	SEAL RING COP.C	300			
01-02-54816	A 000 471 04 35	FUEL STRAINER	300			
01-02-54817	A 000 470 04 05	FILLER CAP	300			
01-02-54818	A 303 470 00 31	CHAIN,OIL FILLER CAP	300			
01-02-54819	A 670 760 02 05	TUMBLER	300			
01-02-54820	A 013 542 71 17	SENDER UNIT	300			
01-02-54821	A 000 471 10 35	FUEL STRAINER	300			
01-02-54822	A 941 470 01 40	STRAP	300			
01-02-54823	A 942 490 30 19	EXHAUST PIPE	300			
01-02-54824	A 942 997 02 90	CLAMP	300			
01-02-54825	A 352 990 46 01	SCREW	300			
01-02-54826	A 942 490 00 41	CLAMP	300			
01-02-54827	A 942 490 27 01	EXHAUST MUFFLER	300			
01-02-54828	A 942 492 07 41 7390	BRACKET	300			
01-02-54829	A 942 490 12 40	BRACKET	300			
01-02-54830	A 942 500 12 03	RADIATOR	300			
01-02-54831	A 942 504 02 14	BEARING	300			
01-02-54832	A 942 505 09 55	FAN SHROUD	300			
01-02-54833	A 000 500 30 49	TANK	300			
01-02-54834	A 000 501 64 15	RADIATOR CAP	300			
01-02-54835	A 000 501 70 15	RADIATOR CAP	300			
01-02-54836	A 000 500 02 06	FILLER CAP	300			
01-02-54837	A 942 542 02 17	SENDER UNIT	300			
01-02-54838	A 941 501 03 82	HOSE	300			
01-02-54839	A 942 501 00 80	GASKET	300			
01-02-54840	A 942 501 01 56	PIPE ELBOW	300			
01-02-54841	A 942 501 03 56	PIPE ELBOW	300			
01-02-54842	N900271 060004	HOSE	300			
01-02-54843	N000000 001468	CLAMP	300			
01-02-54844	A 942 501 07 82	HOSE	300			
01-02-54845	N000000 000668	CLAMP	300			
01-02-54846	A 942 506 31 35	HOSE	300			
01-02-54847	N000000 000667	CLAMP	300			
01-02-54848	A 942 506 35 35	HOSE	300			
01-02-54849	A 942 506 41 35	HOSE	300			
01-02-54850	A 942 506 10 35	HOSE	300			
01-02-54851	A 942 501 09 01	RADIATOR	300			
01-02-54852	A 002 094 55 82	HOSE	300			
01-02-54853	A 943 260 12 85	PIPE	300			
01-02-54854	A 943 260 13 85	PIPE	300			
01-02-54855	A 942 500 01 54	CONDENSER	300			
01-02-54856	A 942 830 16 15	PIPE LINE	300			
01-02-54857	A 942 830 17 15	PIPE LINE	300			
01-02-54858	A 942 830 18 15	PIPE LINE	300			
01-02-54859	A 942 830 19 15	PIPE LINE	300			
01-02-54860	A 942 500 21 17	PROTECTIVE GRILL	300			
01-02-54861	A 942 500 16 17	PROTECTIVE GRILL	300			
01-02-54862	A 352 010 04 68	CAP	300			
01-02-54863	A 942 528 12 82	HOSE	300			
01-02-54864	A 011 542 50 17	SENDER UNIT	300			
01-02-54865	A 941 528 02 91	BOOT	300			
01-02-54866	A 942 528 00 91	BOOT	300			
01-02-54867	A 003 094 91 04	FILTER ELEMENT	300			
01-02-54868	A 000 094 20 60	SEAL RING	300			
01-02-54869	A 024 997 11 48	SEAL RING	300			

01-02-54870	A 000 094 21 60	SEAL RING	300			
01-02-54871	A 001 094 30 03	FILTER BOWL	300			
01-02-54872	A 942 528 03 82	HOSE	300			
01-02-54873	A 941 528 03 82	HOSE	300			
01-02-54874	A 003 545 95 07	SWITCH	300			
01-02-54875	A 003 545 96 07	SWITCH	300			
01-02-54876	A 004 545 22 07 5B20	SWITCH	300			
01-02-54877	A 000 545 67 04	LIGHT SWITCH	300			
01-02-54878	A 202 545 00 81	KNOB	300			
01-02-54879	A 002 544 17 94	BULB	300			
01-02-54880	A 000 545 70 04 5B20	SWITCH	300			
01-02-54881	A 007 545 31 24 5C38	STEER.COLUMN MOUT. SWITCH	300			
01-02-54882	A 008 545 01 24 5B21	SWITCH,AUTOMATIC	300			
01-02-54883	A 001 540 62 70	TAIL LAMP	300			
01-02-54884	A 001 540 63 70	TAIL LAMP	300			
01-02-54885	A 002 544 16 90	LENS	300			
01-02-54886	A 002 544 12 90	LENS	300			
01-02-54887	N072601 024192	BULB	300			
01-02-54888	N072601 024704	BULB	300			
01-02-54889	A 000 525 07 39	BRACKET	300			
01-02-54890	A 000 553 99 01	PUMP	300			
01-02-54891	A 000 550 44 83	GASKET KIT	300			
01-02-54892	A 655 332 02 01	STEERING KNUCKLE	300			
01-02-54893	A 942 332 00 06	KINGPIN	300			
01-02-54894	A 655 330 06 19	KING PIN	300			
01-02-54895	A 655 330 07 19	KING PIN	300			
01-02-54896	A 943 338 15 01	STEERING ARM	300			
01-02-54897	A 625 338 07 05	STEERING ARM	300			
01-02-54898	A 625 338 06 06	STEERING ARM	300			
01-02-54899	A 949 330 06 03	TIE ROD	300			
01-02-54900	A 001 460 17 48	DRAG LINK END	300			
01-02-54901	A 624 334 03 01	WHEEL HUB	300			
01-02-54902	A 019 997 48 47	SEAL RING	300			
01-02-54903	A 652 330 00 88	NUT	300			
01-02-54904	A 389 334 00 25	HUB CAP	300			
01-02-54905	A 389 401 00 71	WHEEL MOUNTING BOLT	300			
01-02-54906	A 346 421 31 06	BRAKE ANCHOR	300			
01-02-54907	A 945 542 12 18	SENSOR	300			
01-02-54908	A 945 542 13 18	SENSOR	300			
01-02-54909	A 307 420 03 39	REPAIR KIT	300			
01-02-54910	A 617 423 14 30	BRAKE LINING	300			
01-02-54911	A 307 420 41 02	REPAIR KIT	300			
01-02-54912	A 346 993 08 10	SPRING	300			
01-02-54913	A 617 993 11 10	SPRING	300			
01-02-54914	A 658 421 00 01	BRAKE DRUM	300			
01-02-54915	A 655 260 01 57	REPAIR KIT	300			
01-02-54916	A 389 997 01 32	SCREW PLUG	300			
01-02-54917	N007603 038105	SEAL RING	300			
01-02-54918	A 945 260 00 57	VALVE	300			
01-02-54919	A 002 260 30 57	VALVE	300			
01-02-54920	A 001 545 17 09	SWITCH	300			
01-02-54921	A 001 545 16 09	SWITCH	300			
01-02-54922	A 012 542 10 17		300			
01-02-54923	A 346 353 07 35	SHAFT	300			
01-02-54924	A 346 350 14 45	FLANGE	300			
01-02-54925	A 946 351 00 72	NUT	300			
01-02-54926	A 346 353 08 25	SCREW COLLAR	300			
01-02-54927	A 017 997 28 47	SEAL RING	300			
01-02-54928	A 017 997 29 47	SEAL RING	300			
01-02-54929	A 352 353 00 73	LOCK	300			
01-02-54930	N000625 920066	GROOVED BALL BEARING	300			

01-02-54931	A 346 353 19 62	THRUST WASHER	300			
01-02-54932	A 346 353 18 62	THRUST WASHER	300			
01-02-54933	A 346 353 17 62	THRUST WASHER	300			
01-02-54934	N000000 000759	BALL BEARING	300			
01-02-54935	A 346 353 25 62	THRUST WASHER	300			
01-02-54936	A 346 353 06 35	SHAFT	300			
01-02-54937	A 346 353 09 25	SCREW COLLAR	300			
01-02-54938	A 017 997 30 47	SEAL RING	300			
01-02-54939	N070952 060102	LOCK PLATE	300			
01-02-54940	A 674 356 02 26	GROOVED NUT	300			
01-02-54941	A 346 353 08 55	CYLINDER	300			
01-02-54942	A 355 353 03 80	GASKET	300			
01-02-54943	A 346 993 09 01	SPRING	300			
01-02-54944	A 001 545 18 09	SWITCH	300			
01-02-54945	A 020 997 39 47	SEAL RING	300			
01-02-54946	A 381 401 07 71	WHEEL MOUNTING BOLT	300			
01-02-54947	A 027 997 22 48	SEAL RING	300			
01-02-54948	A 650 356 00 80	GASKET,REAR WHEEL,VLRUB	300			
01-02-54949	A 624 997 00 32	SCREW PLUG	300			
01-02-54950	N007603 024106	SEAL RING,VLRUB	300			
01-02-54951	A 355 997 02 32	SCREW PLUG	300			
01-02-54952	N007603 045100	SEAL RING	300			
01-02-54953	A 677 540 08 17	SENDER UNIT	300			
01-02-54954	A 945 542 16 18	SENSOR	300			
01-02-54955	A 945 542 15 18	SENSOR	300			
01-02-54956	A 000 540 36 36	ELECTRIC CABLE	300			
01-02-54957	A 000 540 41 36	SENSOR CABLE	300			
01-02-54958	A 659 423 36 10	BRAKE LINING	300			
01-02-54959	A 945 993 00 10	SPRING	300			
01-02-54960	A 305 423 04 01	BRAKE DRUM	300			
01-02-54961	X 009 800 242	ENGINE	300			
01-02-54962	A940 460 35 00	STEERING BOX ASSEMBLY	300			
01-02-54963	A941 600 41 05	BODY SHELL	300			
01-02-54964	X002 540 957	TRANSMISSION	300			
01-02-54965	A542 030 02 40	CRANKSHAFT BEARING	300			
01-02-54966	A542 030 04 40	CRANKSHAFT BEARING	300			
01-02-54967	A541 030 13 40	CRANKSHAFT BEARING	300			
01-02-54968	A541 030 14 40	CRANKSHAFT BEARING	300			
01-02-54969	A541 030 15 40	CRANKSHAFT BEARING	300			
01-02-54970	A541 030 08 60	CONNECTING ROD BEARING	300			
01-02-54971	A541 030 10 60	CONNECTING ROD BEARING	300			
01-02-54972	A541 030 11 60	CONNECTING ROD BEARING	300			
01-02-54973	A541 030 12 60	CONNECTING ROD BEARING	300			
01-02-54974	A541 030 13 60	CONNECTING ROD BEARING	300			
01-02-54975	A000 234 24 11	COMPRESSOR	300			
01-02-54976	A541 230 02 28	COUPLING	300			
01-02-54977	A005 203 26 75	THERMOSTA ELEMENT	300			
01-02-54978	A541 033 13 62	THRUST WASHER	300			
01-02-54979	A541 033 14 62	THRUST WASHER	300			
01-02-54980	A541 033 15 62	THRUST WASHER	300			
01-02-54981	A941 720 03 20	GLASS PANE	300			
01-02-54982	A000 725 00 02	WINDOW REGULATOR	300			
01-02-54983	A000 725 01 02	WINDOW REGULATOR	300			
01-02-54984	A941 720 04 20	GASS PANE	300			
01-02-54985	A541 051 03 10	CAMSHAFT BEARING	300			
01-02-54986	A541 051 00 10	CAMSHAFT BEARING	300			
01-02-54987	A541 050 10 01	CAMSHAFT	300			
01-02-54988	A002 250 41 15	RELEASE RING	300			
01-02-54989	A007 981 7005	INSIDE BEARING	300			
01-02-54990	A019 997 48 47	SEAL RING	300			
01-02-54991	A006 981 08 05	OUT SIDE BEARING	300			

01-02-54992	A541 180 00 09	OIL FILTER ELEMENT	300			
01-02-54993	A 389 262 30 55	SPACER WASHER	300			
01-02-54994	A 389 262 35 55	SPACER WASHER	300			
01-02-54995	A 389 262 40 55	SPACER WASHER	300			
01-02-54996	A 019 997 72 48	SEAL RING	300			
01-02-54997	A 389 263 55 52	SPACER WASHER	300			
01-02-54998	A 389 263 65 52	SPACER WASHER	300			
01-02-54999	A 389 263 75 52	SPACER WASHER	300			
01-02-55000	A 004 997 22 48	SEAL RING	300			
01-02-55001	A 389 262 47 52	SPACER WASHER	300			
01-02-55002	A 659 283 46 52	SPACER WASHER	300			
01-02-55003	A 659 283 51 52	SPACER WASHER	300			
01-02-55004	A 389 262 77 54	SPACER WASHER	300			
01-02-55005	A 945 261 00 80	GASKET	300			
01-02-55006	A 389 262 48 52	SPACER WASHER	300			
01-02-55007	A 659 283 48 52	SPACER WASHER	300			
01-02-55008	A 659 283 54 52	SPACER WASHER	300			
01-02-55009	A 659 283 55 52	SPACER WASHER	300			
01-02-55010	A 015 997 27 48	SEAL RING	300			
01-02-55011	A 389 262 62 01	DRIVE SHAFT	300			
01-02-55012	A 389 269 85 34	OIL LINE	300			
01-02-55013	A 000 994 98 41	SNAP RING	300			
01-02-55014	A 019 997 20 47	SEAL RING	300			
01-02-55015	A 389 262 09 73	LOCK	300			
01-02-55016	A 389 262 31 37	SYNCHRONIZER CONE	300			
01-02-55017	A 387 262 10 93	SPRING	300			
01-02-55018	A 011 981 13 05	TAPERED ROLLER BEARING	300			
01-02-55019	A 387 262 86 73	LOCK	300			
01-02-55020	A 013 997 00 48	SEAL RING	300			
01-02-55021	A 945 990 00 50	NUT	300			
01-02-55022	A 389 262 23 51	SPACER RING	300			
01-02-55023	A 389 262 33 52	SPACER WASHER	300			
01-02-55024	A 389 262 30 52	SPACER WASHER	300			
01-02-55025	A 389 262 22 55	SPACER WASHER	300			
01-02-55026	A 389 262 18 55	SPACER WASHER	300			
01-02-55027	A 389 262 14 55	SPACER WASHER	300			
01-02-55028	A 389 262 36 54	SPACER WASHER	300			
01-02-55029	A 389 262 28 54	SPACER WASHER	300			
01-02-55030	A 945 262 05 10	GEAR	300			
01-02-55031	A 015 981 20 05	TAPERED ROLLER BEARING	300			
01-02-55032	A 014 981 16 05	TAPERED ROLLER BEARING	300			
01-02-55033	A 389 262 50 34	SYNCHRONIZER RING	300			
01-02-55034	A 387 262 20 73	LOCK	300			
01-02-55035	A 389 262 47 35	SYNCHRONIZER BODY	300			
01-02-55036	A 945 262 02 13	GEAR	300			
01-02-55037	A 010 981 53 10	NEEDLE BEARING	300			
01-02-55038	A 389 262 07 37	SYNCHRONIZER CONE	300			
01-02-55039	A 387 262 08 93	SPRING	300			
01-02-55040	A 389 262 25 12	GEAR	300			
01-02-55041	A 389 262 00 34	SYNCHRONIZER RING	300			
01-02-55042	A 389 262 25 35	SYNCHRONIZER BODY	300			
01-02-55043	A 387 262 21 73	LOCK	300			
01-02-55044	A 387 262 23 73	LOCK	300			
01-02-55045	A 387 262 80 73	LOCK	300			
01-02-55046	A 387 262 20 11	GEAR	300			
01-02-55047	A 008 981 83 10	NEEDLE BEARING	300			
01-02-55048	A 389 262 01 35	SYNCHRONIZER BODY	300			
01-02-55049	A 389 262 17 23	SLIDING COLLAR	300			
01-02-55050	A 389 262 20 33	DOG CLUTCH GEAR	300			
01-02-55051	A 389 262 00 50	BUSHING	300			
01-02-55052	A 389 262 37 54	SPACER WASHER	300			

01-02-55053	A 389 262 08 09	SUN GEAR	300			
01-02-55054	A 007 994 18 41	LOCK	300			
01-02-55055	A 945 260 46 61	PLANETARY CARRIER	300			
01-02-55056	A 389 269 47 34	OIL LINE	300			
01-02-55057	N000472 060000	LOCK RING	300			
01-02-55058	A 655 260 01 97	GEAR SET	300			
01-02-55059	A 945 262 02 08	ANNULUS	300			
01-02-55060	A 389 262 14 25	DISC SUPPORT	300			
01-02-55061	A 389 262 07 73	LOCK	300			
01-02-55062	N000472 130000	LOCK RING	300			
01-02-55063	A 389 260 20 36	FOLLOWER RING	300			
01-02-55064	A 389 262 05 37	SYNCHRONIZER CONE	300			
01-02-55065	A 389 262 02 93	SPRING	300			
01-02-55066	A 389 262 20 35	SYNCHRONIZER BODY	300			
01-02-55067	N000471 120000	LOCK RING	300			
01-02-55068	A 389 262 02 51	SPACER RING	300			
01-02-55069	A 389 262 92 34	SYNCHRONIZER RING	300			
01-02-55070	A 945 262 00 45	FLANGE	300			
01-02-55071	A 389 262 03 62	THRUST WASHER	300			
01-02-55072	A 945 263 06 02	COUNTERSHAFT	300			
01-02-55073	A 389 994 00 41	LOCK	300			
01-02-55074	A 945 263 08 10	GEAR	300			
01-02-55075	A 389 262 20 11	GEAR	300			
01-02-55076	A 976 263 00 30	REVERSE IDLER SHAFT	300			
01-02-55077	A 389 263 10 31	REVERSE IDLER GEAR	300			
01-02-55078	A 389 263 08 50	BUSHING	300			
01-02-55079	A 012 981 89 10	NEEDLE BEARING	300			
01-02-55080	A 945 263 00 41	BRACKET	300			
01-02-55081	A 389 269 03 10	OIL PUMP SHAFT	300			
01-02-55082	A 389 260 06 90	OIL PUMP	300			
01-02-55083	A 389 262 51 54	SPACER WASHER	300			
01-02-55084	A 389 262 56 54	SPACER WASHER	300			
01-02-55085	A 389 262 62 54	SPACER WASHER	300			
01-02-55086	A 945 269 00 67	PIPE	300			
01-02-55087	A 945 269 00 34	OIL LINE	300			
01-02-55088	A 126 994 05 35	SNAP RING	300			
01-02-55089	A 655 260 01 57	REPAIR KIT	300			
01-02-55090	A 389 261 00 50	BUSHING	300			
01-02-55091	A 389 993 21 01	SPRING	300			
01-02-55092	A 389 997 01 32	SCREW PLUG	300			
01-02-55093	N007603 038105	SEAL RING	300			
01-02-55094	A 389 997 15 72	FITTING	300			
01-02-55095	N007346 011013	CLAMPING SLEEVE	300			
01-02-55096	A 389 265 27 49	SLIDE	300			
01-02-55097	A 945 265 01 49	SLIDE	300			
01-02-55098	A 389 265 27 74	PIN	300			
01-02-55099	A 009 981 05 10	NEEDLE BEARING	300			
01-02-55100	A 945 267 08 19	SHIFTING CYLINDER	300			
01-02-55101	A 000 267 01 97	BOOT	300			
01-02-55102	A 387 267 06 50	BUSHING	300			
01-02-55103	A 945 267 02 17	ROD	300			
01-02-55104	A 389 268 09 50	BUSHING	300			
01-02-55105	A 387 263 28 52	SPACER WASHER	300			
01-02-55106	A 387 263 30 52	SPACER WASHER	300			
01-02-55107	A 945 267 02 18	PISTON	300			
01-02-55108	A 945 265 00 01	SHIFTING FORK	300			
01-02-55109	A 389 262 25 55	SPACER WASHER	300			
01-02-55110	A 389 262 20 52	SPACER WASHER	300			
01-02-55111	A 389 262 32 52	SPACER WASHER	300			
01-02-55112	A 006 994 42 41	LOCK	300			
01-02-55113	A 389 267 11 74	PIN	300			

01-02-55114	A 387 993 44 01	SPRING	300			
01-02-55115	A 387 993 45 01	SPRING	300			
01-02-55116	A 389 267 23 50	BUSHING	300			
01-02-55117	A 389 267 73 17	ROD	300			
01-02-55118	A 389 267 10 18	PISTON	300			
01-02-55119	A 389 267 09 74	PIN	300			
01-02-55120	A 389 993 06 01	SPRING	300			
01-02-55121	A 945 268 00 56	SCREW PLUG	300			
01-02-55122	A 389 265 24 49	SLIDE	300			
01-02-55123	A 389 265 09 74	PIN	300			
01-02-55124	A 003 990 29 40	WASHER	300			
01-02-55125	A 945 267 13 19	SHIFTING CYLINDER	300			
01-02-55126	A 389 990 09 01	SCREW	300			
01-02-55127	A 945 268 02 74	PIN	300			
01-02-55128	A 945 993 04 01	SPRING	300			
01-02-55129	N000472 019000	SNAP RING	300			
01-02-55130	N005401 312000	BALL	300			
01-02-55131	A 945 268 02 33	SHIFTING FINGER	300			
01-02-55132	N001481 012020	CLAMPING SLEEVE	300			
01-02-55133	A 945 268 01 46	SHIFTING SEGMENT	300			
01-02-55134	A 389 997 03 19	THREADED PIN	300			
01-02-55135	N000471 038002	LOCK RING	300			
01-02-55136	A 945 268 00 13	SHIFTING SEGMENT	300			
01-02-55137	A 389 997 04 19	THREADED PIN	300			
01-02-55138	A 945 268 04 74	PIN	300			
01-02-55139	A 387 993 21 01	SPRING	300			
01-02-55140	A 387 268 10 76	WASHER	300			
01-02-55141	A 945 993 06 01	SPRING	300			
01-02-55142	N912009 028200	SNAP RING	300			
01-02-55143	A 976 268 00 76	WASHER	300			
01-02-55144	A 945 268 09 29	SHIFTING ROD	300			
01-02-55145	A 945 268 19 50	BUSHING	300			
01-02-55146	A 945 268 22 50	BUSHING	300			
01-02-55147	A 945 260 02 47	SHIFTING TUBE	300			
01-02-55148	A 976 261 13 33	COVER	300			
01-02-55149	A 945 260 15 13	TRANSMISSION CASE COVER	300			
01-02-55150	A 945 268 20 50	BUSHING	300			
01-02-55151	A 945 260 04 37	LEVER	300			
01-02-55152	N000007 004123	CILINDRICAL PIN	300			
01-02-55153	A 945 268 03 33	SHIFTING FINGER	300			
01-02-55154	N006888 005012	WOODRUFF KEY	300			
01-02-55155	A 387 268 00 52	SPACER WASHER	300			
01-02-55156	A 387 268 01 52	SPACER WASHER	300			
01-02-55157	N080705 016003	NUT	300			
01-02-55158	A 945 261 05 33	COVER	300			
01-02-55159	A 001 990 42 04	SCREW	300			
01-02-55160	N910105 008043	SCREW	300			
01-02-55161	A 945 268 02 25	SHIFTING ROD	300			
01-02-55162	N007993 012200	SNAP RING	300			
01-02-55163	A 389 268 00 51	SPACER RING	300			
01-02-55164	A 389 268 06 74	PIN	300			
01-02-55165	N000988 006019	FITTED WASHER	300			
01-02-55166	A 389 261 17 33	COVER	300			
01-02-55167	N000137 008204	SPRING WASHER	300			
01-02-55168	A 124 281 00 82	BREATHING CAP	300			
01-02-55169	A 945 268 01 74	PIN	300			
01-02-55170	N001481 004006	DOWEL PIN	300			
01-02-55171	A 945 268 02 50	BUSHING	300			
01-02-55172	A 945 268 02 46	SHIFTING SEGMENT	300			
01-02-55173	A 023 997 77 48	SEAL RING	300			
01-02-55174	A 016 981 28 10	NEEDLE BEARING	300			

01-02-55175	A 945 268 38 34	BEARING COVER	300			
01-02-55176	A 000 997 36 34	SCREW	300			
01-02-55177	A 012 981 33 10	NEEDLE BEARING	300			
01-02-55178	A 012 997 82 47	SEAL RING	300			
01-02-55179	A 000 990 46 77	SCREW	300			
01-02-55180	A 001 545 17 09	SWITCH	300			
01-02-55181	A 013 542 57 17	SENDER UNIT	300			
01-02-55182	A 942 540 00 13	CABLE HARNESS	300			
01-02-55183	A 009 981 43 05	TAPERED ROLLER BEARING	300			
01-02-55184	A 004 981 09 05	TAPERED ROLLER BEARING	300			
01-02-55185	A 673 997 02 45	REPAIR KIT	300			
01-02-55186	A 003 981 29 05	BALL BEARING	300			
01-02-55187	A 387 350 00 40	REPAIR KIT	300			
01-02-55188	A 346 350 36 39	RING GEAR AND PINION	300			
01-02-55189	A 346 353 08 55	CYLINDER	300			
01-02-55190	A 346 353 00 90	PROTECTIVE CAP	300			
01-02-55191	A 017 997 31 47	SEAL RING	300			
01-02-55192	A 019 997 05 47	SEAL RING	300			
01-02-55193	A 389 262 31 55	SPACER WASHER	300			
01-02-55194	A 389 263 59 52	SPACER WASHER	300			
01-02-55195	A 389 263 69 52	SPACER WASHER	300			
01-02-55196	A 945 262 03 23	SLIDING COLLAR	300			
01-02-55197	A 945 262 16 10	GEAR	300			
01-02-55198	A 016 981 00 10	NEEDLE BEARING	300			
01-02-55199	A 013 981 11 05	TAPERED ROLLER BEARING	300			
01-02-55200	A 945 262 04 23	SLIDING COLLAR	300			
01-02-55201	A 009 981 15 10	NEEDLE BEARING(1.0X4.0)	300			
01-02-55202	A 012 981 93 05	TAPERED ROLLER BEARING	300			
01-02-55203	A 004 981 88 25	BEARING	300			
01-02-55204	A 945 262 08 23	SLIDING COLLAR	300			
01-02-55205	A 007 981 40 25	BALL BEARING	300			
01-02-55206	A 014 997 51 48	SEAL RING	300			
01-02-55207	A 014 981 14 05	TAPERED ROLLERBEARING	300			
01-02-55208	A 945 263 05 13	GEAR	300			
01-02-55209	A 004 981 92 25	BALL BEARING	300			
01-02-55210	A 015 997 36 48	SEAL RING	300			
01-02-55211	A 015 997 60 48	SEAL RING	300			
01-02-55212	A 389 269 03 21	STRAINER	300			
01-02-55213	A 006 997 64 47	SEAL RING	300			
01-02-55214	N007603 016105	SEAL RING,VLRUB	300			
01-02-55215	A 014 997 36 47	SEAL RING	300			
01-02-55216	A 389 265 28 74	PIN	300			
01-02-55217	A 015 997 40 48	SEAL RING	300			
01-02-55218	A 021 997 77 48	SEAL RING	300			
01-02-55219	A 013 997 75 48	SEAL RING	300			
01-02-55220	A 387 268 11 50	BUSHING	300			
01-02-55221	A 945 268 36 34	BEARING COVER	300			
01-02-55222	A 945 262 19 05	MAIN SHAFT	300			
01-02-55223 to 01-02-56195		Spare parts for Scania	various			
01-02-56196 to 01-02-58624		Spare parts for Renault	various			