

<b>SPARE PARTS FOR MINI BUSES NASER IVECO</b>		
---	--	--

<b>CODE</b>	<b>PART NO.</b>	<b>DESCRIPTION</b>
01-02-09158	1722120	DISC KEY
01-02-09159	1904678	RING SET (1CYL.)
01-02-09160	4570798	ADJ COLLAR
01-02-09161	5470799	ADJ COLLAR
01-02-09162	4600189	NUT HEX RANK SHAFT
01-02-09163	4600190	SAFETY PLATE CRANK SHAFT
01-02-09164	4601295	ROCKER BRKT
01-02-09165	4601296	COMP SPRING
01-02-09166	4603450	CAMSHAFT BUSH
01-02-09167	4603451	CAMSHAFT BUSH
01-02-09168	4770255	GEAR OF DRIVE
01-02-09169	4782877	FAN ASSY
01-02-09170	4783226	CON ROD BUSH
01-02-09171	4784890	VALVE EXH
01-02-09172	4796457	HEAD CAMPING SCREW
01-02-09173	4804320	TEMP ADJ COVER
01-02-09174	4818545	GEAR CRANK SHAFT
01-02-09175	4818557	GEAR FUEL PUMP
01-02-09176	4819460	INTAKE MANY FOLD
01-02-09177	4833010	BALL
01-02-09178	4842403	ROCKER SHAFT
01-02-09179	4845136	UPPER COVER SEAL
01-02-09180	4848199	PISTON SET
01-02-09181	4848298	CYL.BLOCK ASSY
01-02-09182	4848307	SUMP
01-02-09183	4848377	WASHER
01-02-09184	4848378	CIRCLIP
01-02-09185	4848476	PIPE COMP LETE
01-02-09186	4848550	OIL COOLER ASSY
01-02-09187	4848643	ALT BELT TENSIONER
01-02-09188	4848973	ROCKER ARM
01-02-09189	14196670	VALVE CONE
01-02-09190	14328301	CUP PLUG
01-02-09191	97188160	INJECTOR ASSY
01-02-09192	97188215	SPRING
01-02-09193	97188244	NOZZEL CAP BOLT
01-02-09194	97188472	V BELT FENNER
01-02-09195	98413884	SHOULDER PLATE
01-02-09196	98418420	GEAR CAM SHFT
01-02-09197	98418851	COVER
01-02-09198	98419016	PULLEY ON PUMP
01-02-09199	98419181	BELT TENSIONER
01-02-09200	98419182	DRIVING PULLEY
01-02-09201	98424277	COMP OIL DRAIN PIPE
01-02-09202	98428257	FUEL PUMP
01-02-09203	98428286	CRANK SHAFT
01-02-09204	98428924	BUSH IDLER GEAR
01-02-09205	98435622	VALVE INLET
01-02-09206	98436428	V BELT
01-02-09207	98439855	HEX HEAD SCREW
01-02-09208	98447726	DAMPER COMPLETE
01-02-09209	98456215	CYL HEAD GASKET
01-02-09210	98471524	CUP FOR TAPPET
01-02-09211	04232606W	OIL FILTER CAP
01-02-09212	04603449W	CAMSHAFT BUSH
01-02-09213	04780108W	ENGINE VALVE SPRING (04780108)
01-02-09214	04780558W	VALVE CAP

01-02-09215	04802126W	VALVE GUIDE	
01-02-09216	04803030W	CYLINDER LINER(0480303W)	
01-02-09217	0481691W	OIL PUMP ENGINE	
01-02-09218	04848325W	CYL.HEAD ASSY	
01-02-09219	04849996W	FLAT ENGINE GASKET(0484994W)	
01-02-09220	04851921W	GASKET INLET.	
01-02-09221	10260060W	WASHER	
01-02-09222	11066676W	RING SPLIT FOR SHAFT	
01-02-09223	14457581W	O RING(1445781)	
01-02-09224	14458281W	TOROISAL GASKET(1448281)	
01-02-09225	98408472W	GASKET	
01-02-09226	98413884W	SCREW	
01-02-09227	98414013W	SPINDLE	
01-02-09228	98415831W	WATER PUMP	
01-02-09229	98418703W	STG PUMP	
01-02-09230	98420268W	SET OF V.BELT(97188472)	
01-02-09231	98428396W	FLAT ENGINE GASKET(98428396)	
01-02-09232	98428397W	GASKET EXHANSE	
01-02-09233	98432310W	THERMOSTAT (9846716)	
01-02-09234	98432651W	OIL FILTER ELEMENT	
01-02-09235	98438756W	INJECTOR PIPE (98438756)	
01-02-09236	98438757W	INJECTOR PIPE(98438757)	
01-02-09237	98438758W	INJ PIPE	
01-02-09238	98438759W	INJECTOR PIPE(98438759)	
01-02-09239	98455718W	GASKET-SUMPSEAL RUBBER	
01-02-09240	98457859W	SUMP SEAL RUBBER	
01-02-09241	98457860W	SUMP GASKET	
01-02-09242	98458149W	STUD	
01-02-09243	98495493W	VALVE SEAT	
01-02-09244	A1507700	GEAR BOX ASSY ZF	
01-02-09245	A7707000	CON ROD ASSY	
01-02-09246	A8298300	ENG ASSY	
01-02-09247	B1516601	S/A OF SELECTOR FRONT	
01-02-09248	B1516602	S/A OF SELECTOR FRONT	
01-02-09249	B1516609	SYNCRON N 130 R 2/3	
01-02-09250	B1516613	GEAR GH CLAMP	
01-02-09251	B1516614	S/A OF SELECTOR FRONT	
01-02-09252	B1656411	SYNCRON NISER HUB	
01-02-09253	B1704601	S/A GEAR LEVER	
01-02-09254	B1719104	G.S. ROD LOWER	
01-02-09255	B1796712	S/A OF CSO TUBE	
01-02-09256	B4368701	S/A NY LNVE HOSE 1450	
01-02-09257	B4368702	S/A OF NYL HOSE 370	
01-02-09258	B4368712	S/A NYL PIPE 650	
01-02-09259	B4368713	S/A NY HOSE 290	
01-02-09260	B4369501	S/A NYL PIPE 3250	
01-02-09261	B4369502	S/A NYL PIPE 1710	
01-02-09262	B4369503	S/A OF NYL HOSE 3980	
01-02-09263	B4369505	S/A NYL PIPE 4520	
01-02-09264	B4371401	S/A NYL PIPE 850	
01-02-09265	B4371402	S/A NYL PIPE 670	
01-02-09266	B4376673	S/A OF NYL HOSE 1310	
01-02-09267	B4376687	S/A NYL PIPE 4200	
01-02-09268	B4378707	S/A NYL PIPE 650	
01-02-09269	B4379504	S/A NYL PIPE 4320	
01-02-09270	B4384706	S/A OF NYL HOSE 70	
01-02-09271	B4388613	S/A NYL HOSE 820	
01-02-09272	B4407401	S/A NYL PIPE 2500	
01-02-09273	B4431105	S/A NYL PIPE 1875	
01-02-09274	B4476674	S/A OF NYL HOSE 2020	

01-02-09275	B4599801M	EXH PIPE	
01-02-09276	B4599802M	EXH PIPE	
01-02-09277	B5018802	STRAP 115	
01-02-09278	B5094402	FUEL TANK	
01-02-09279	B6600208	S/A OF FELEX ARM	
01-02-09280	B7713701	S/A NYL PIPE 1720	
01-02-09281	B7713702	S/A NYL PIPE 3800	
01-02-09282	B7875101	WIRING REVERSE	
01-02-09283	B1313202	CLUTCH DISC-C	
01-02-09284	B1719117	SPHERICAL BRG ASSY	
01-02-09285	B2034307	BALL JOINT	
01-02-09286	B2394101	DRAG LINK	
01-02-09287	B2525103	TIE ROD KIT	
01-02-09288	B2525104	STUB AXLE	
01-02-09289	B2525106	FRT HUB	
01-02-09290	B3041702	RR HUB	
01-02-09291	B4377201	S/A NHOSE ULU-WT	
01-02-09292	B4431105	TUBE PUMP	
01-02-09293	B4498005	TUBE FILTER	
01-02-09294	B4498007	TUBE ASSY	
01-02-09295	B5412222	SEWITCH ASSY IGN	
01-02-09296	B6105408	PARKING BR HOSE	
01-02-09297	B6600208	HOSE	
01-02-09298	B7083004	INJ LEAK OFF-C	
01-02-09299	B7083004	LEAK OFF LINE	
01-02-09300	B7713701	PIPE ASSY-C	
01-02-09301	B7764402	FLY WHEEL STARTER RING	
01-02-09302	B7771201	DIP STICK S/A	
01-02-09303	B7771202	DIPSTICK GUIDE	
01-02-09304	B7790001	PIPE COPM	
01-02-09305	F0242010	TAPPER ROLLER BRG	
01-02-09306	F0242210	TAPPER ROLLER BRG	
01-02-09307	B7713702	PIPE ASSY -C	
01-02-09308	F0242410	ROLLER BRG REAR	
01-02-09309	F0242510	SPIGOT BRG	
01-02-09310	F0242610	ROLLER BEARING	
01-02-09311	F0242710	NEDDLE ROLLER BRG	
01-02-09312	F0242810	N.R.BEARING RG	
01-02-09313	F0242910	N.R.BEARING	
01-02-09314	F0243010	N.R.BEARING	
01-02-09315	F0243011	NEDDLE ROLLER BRG	
01-02-09316	F0243110	N.R. BEARING	
01-02-09317	F0243210	NEDDLE ROLLER BRG	
01-02-09318	F0243310	NEDDLE ROLLER BRG	
01-02-09319	F0248510	ROLLER BEARING L/S	
01-02-09320	F0248610	T.R. BEARING	
01-02-09321	F04766077W	PILOT BRG	
01-02-09322	F0530550	RUBBER BUSH	
01-02-09323	F0611100	WIRING ENGINELV II	
01-02-09324	F0731410	CIR CLIP	
01-02-09325	F0736710	SANP RING	
01-02-09326	F0736810	CIR CLIP	
01-02-09327	F0737210	CIR CLIP	
01-02-09328	F0737310	CIR CLIP	
01-02-09329	F0737410	CIR CLIP	
01-02-09330	F0737710	CIR CLIP	
01-02-09331	F0737910	CIR CLIP	
01-02-09332	F0738210	CIR CLIP	
01-02-09333	F0738310	CIR CLIP	
01-02-09334	F0739410	SPLIT RING (F0739510)	

01-02-09335	F0739710	SPLIT RING	
01-02-09336	F0741110	SPACER	
01-02-09337	F0741510	SPACER	
01-02-09338	F0845414	JUBLIEE CLIP	
01-02-09339	F0900113	NUT RR SPRING U B	
01-02-09340	F0927415	BALL PIN	
01-02-09341	F0927815	BALL PIN	
01-02-09342	F0928415	REY IDLER PIN	
01-02-09343	F0928415	REV IDER P/N	
01-02-09344	F1138613	DUST CAP	
01-02-09345	F1437311S	OUT PUT FLANGE	
01-02-09346	F1600116	SYNCRO NISER RING	
01-02-09347	F1600216	SYNCRO RING	
01-02-09348	F1624715	GEAR SPEED	
01-02-09349	F1647111	GEAR CS 3&D	
01-02-09350	F1647211	GEAR C/S	
01-02-09351	F1647311	GEAR M/S 4TH	
01-02-09352	F1647411	3RD GEAR ON M/SHAFT	
01-02-09353	F1647511	2RD GEAR ON M/SHAFT	
01-02-09354	F1647711	GEAR M/S REV	
01-02-09355	F1650211	FIXED DOG CL REV	
01-02-09356	F1650811	SYNCRO RING (P1802607)	
01-02-09357	F1646911	GEAR CS 4TH	
01-02-09358	F1650911	REY IDLER GEAR	
01-02-09359	F1651011	SLIDING DOG CLUTCH	
01-02-09360	F1651111	SYNCRO CANE 4TH &5TH	
01-02-09361	F1651511	GEAR C/S SH 8.9	
01-02-09362	F1651711	SLIDING DOG CLUTCH	
01-02-09363	F1652011	SPEED METER	
01-02-09364	F1652111	SYNCRO HUB	
01-02-09365	F1652311	GEAR M/S	
01-02-09366	F1652411	SYNCRO HUB (P7805316)	
01-02-09367	F1652811	SYNCRO CONE	
01-02-09368	F1651911	SLIDING DOG CLUTCH	
01-02-09369	F1758000	GASKIT	
01-02-09370	F1758200	GASKIT	
01-02-09371	F1758300	GASKIT	
01-02-09372	F1758400	GASKIT	
01-02-09373	F1758500	GASKIT	
01-02-09374	F1758600	GASKIT	
01-02-09375	F1758700	GASKIT	
01-02-09376	F1758800	GASKIT	
01-02-09377	F1758900	JOINT	
01-02-09378	F1769400	GASKIT ELBOW	
01-02-09379	F1770800	ANT SEAL FOR STRAP	
01-02-09380	F1833042	MAIN GEAR BOX CASE ZF	
01-02-09381	F1834342	GEAR CASE FRONT	
01-02-09382	F2430622	SELECTOR FORK	
01-02-09383	F2430722	SELECTOR FORK	
01-02-09384	F2452711	SELECTOR LEVER	
01-02-09385	F2460911C	OUTER LEVER	
01-02-09386	F2746900	OIL SEAL	
01-02-09387	F2747000	OIL SEAL	
01-02-09388	F2747200	OIL SEAL	
01-02-09389	F2747400	O RING ZF	
01-02-09390	F2747411	O RING	
01-02-09391	F3142615	PIVOT SCREW	
01-02-09392	F3142715	PIVOT SCREW 1ST &REV	
01-02-09393	F3142915	PLUG	
01-02-09394	F3143115	SCREW PLUG	

01-02-09395	F3342011	LAY SHAFT	
01-02-09396	F3344111	REVERSE SELECTION	
01-02-09397	F3541410	NUT FR.U BOLT	
01-02-09398	F3543310	NUT STG WHEEL	
01-02-09399	F3550410	HELICRL INSERT	
01-02-09400	F3551911	NUT PROP SHAFT	
01-02-09401	F3555010	U BOLT FS RR	
01-02-09402	F3587811	BOLT PROP SHAFT	
01-02-09403	F3637410	HELICAL SPRING	
01-02-09404	F3637510	HELICAL SPRING	
01-02-09405	F3637510	HELICAL SPRING	
01-02-09406	F3637910	SPRING	
01-02-09407	F3347511	MAIN SHAFT	
01-02-09408	F3643310	SPRING	
01-02-09409	F4232015	DETEND PLUNGER	
01-02-09410	F4554510M	LEAF SPRING ASSY FR	
01-02-09411	F4831060	KNOB GEAR SHAFT LEVER	
01-02-09412	F4931013	LOCKING WASHER	
01-02-09413	F4940910	SPACER RING	
01-02-09414	F4941100	SPACER (F4940910)	
01-02-09415	F4941810	WASHER (P7800111)	
01-02-09416	F4942810	WHSHER	
01-02-09417	F4944110	SEALING RING	
01-02-09418	F4944210	WASHER	
01-02-09419	F4944310	WAVY WASHER	
01-02-09420	F4944510	WASHER	
01-02-09421	F4950513	LOCKING RING	
01-02-09422	F7401250	PAD BRAKE & CLPODEL	
01-02-09423	F7467600	BALL JOINT	
01-02-09424	F7600715	PUSH ROD ASSY BR	
01-02-09425	F7858800	EXHAUST BRAKE UNT	
01-02-09426	F7859500	STG COL ASSY	
01-02-09427	F8007900	S/A HOSE CLUTCH	
01-02-09428	F8018700	REV	
01-02-09429	F8030300	A/R TANK 1515	
01-02-09430	F8030400	A/R TANK 10	
01-02-09431	F8056300	R.P. METER	
01-02-09432	F0200200	BRG THRUST 909	
01-02-09433	F0200500	FR WHEEL BRG OUTER	
01-02-09434	F0200600	FR WHEEL BRG INNER	
01-02-09435	F0247610	FLY WHEEL BRG	
01-02-09436	F0248910	NEEDLE ROLLER BEARING G BOX	
01-02-09437	F0249110	SPHERICAL SPG 909	
01-02-09438	F0537830	BUSH SPINDLE 909	
01-02-09439	F0711815	FLY WHEEL STARTER RING	
01-02-09440	F0846111	CLAMP	
01-02-09441	F0847314	RET.CLIP	
01-02-09442	F0932211	REBOUND PIN	
01-02-09443	F0960715	BALL PIN	
01-02-09444	F1030300	UPPER HEAD TANK	
01-02-09445	F1292515	SPACER	
01-02-09446	F1757700	GASKET -909	
01-02-09447	F1767400	GASKET -C	
01-02-09448	F1769400	GASKET -C	
01-02-09449	F1837842	FRT CASING	
01-02-09450	F1863922	DRUM	
01-02-09451	F1953415	TUBE	
01-02-09452	F1956850	HOSE- RADIATOR 909	
01-02-09453	F1957950	HOSE- RADIATOR 909	
01-02-09454	F1958150	HOSE-C	

01-02-09455	F1958350	HOSE-C	
01-02-09456	F1959150	HOSE OVERFLOW	
01-02-09457	F0245910	RR WHEEL BRG OUTER	
01-02-09458	F2560610	LUBRICATION-C	
01-02-09459	F2600214	WEAR PAD RH	
01-02-09460	F2600314	WEAR PAD LH	
01-02-09461	F2631814	SIDE WEAR PAD	
01-02-09462	F2631914	DSIDE WEAR PAD	
01-02-09463	F2636700	MOUNTING INS-C	
01-02-09464	F2637400	INSULATOR- C	
01-02-09465	F2637500	INSULATOR	
01-02-09466	F2637700	BUNPER-RAXLE-C	
01-02-09467	F2637800	INSULATOR-C	
01-02-09468	F2638100	INSULATOR	
01-02-09469	F2638300	SPG.EYE BUSH-C	
01-02-09470	F2701950	O RING	
01-02-09471	F2749100	C/SHAFT OIL SEAL FRT(97188107)	
01-02-09472	F2753100	GREASE SEAL 909	
01-02-09473	F2753300	OIL SEAL	
01-02-09474	F3141415	PLUG	
01-02-09475	F3244311	ARM STG SPINDLE	
01-02-09476	F3244611	ARM STG LOWER RH	
01-02-09477	F3244711	ARM STG LOWER LH	
01-02-09478	F3279715	PUSH ROD	
01-02-09479	F3284015	LINK ROD	
01-02-09480	F3349511	CAM SHAFT	
01-02-09481	F3436722	CL W/D SLEEVE	
01-02-09482	F3538410	RH THREAD NUT	
01-02-09483	F3544410	LOCK SPRING (F3644410)	
01-02-09484	F3554410	I BOLT	
01-02-09485	F3558410	NUT	
01-02-09486	F3561410	NUT	
01-02-09487	F3561510	WELD NUT	
01-02-09488	F3566811	THIN NUT	
01-02-09489	F3585411	BOLT 10X19	
01-02-09490	F3587811	BOLT	
01-02-09491	F3593711	U BOLT-MUPFFLER	
01-02-09492	F3595215	WHEEL BOLT -R/909	
01-02-09493	F3596115	WHL NUT LH RS909	
01-02-09494	F3596415	BOLT	
01-02-09495	B1313201	CLUTCH COVER ASSEMBLY	
01-02-09496	F3647610	RETAINER SPRING	
01-02-09497	F3778415	EHEEL BOLT FR	
01-02-09498	F4130211	U K KIT	
01-02-09499	F4457210	SHIM 2.7MM-909	
01-02-09500	F4457410	SHIM 2.9MM-909	
01-02-09501	F4458510	SHIM 4.0MM-909	
01-02-09502	F7100922	FORK ALT	
01-02-09503	F7101013	BRKT SH ABSORBER	
01-02-09504	F7106810	LINK AIR BAR	
01-02-09505	F7107522	NRKT-EN.RH-C	
01-02-09506	F7108022	BRACKET SPRG FRT	
01-02-09507	F3551911	NUT	
01-02-09508	F7108122	BRKT SPRG FR	
01-02-09509	F7108322	FR BRKT	
01-02-09510	F7113122	ALT SUPPORT	
01-02-09511	F7113822	BRKT SPG RR RH	
01-02-09512	F7113922	BRKT SPG RR LH	
01-02-09513	F7125000	AIR GAUGE-C	
01-02-09514	F7403300	LF WARNING SWITCH SL SWIT	

01-02-09515	F7423800	SELF STARTER ASSY	
01-02-09516	F7424600	FLASHER UNIT	
01-02-09517	F7426100	FUEL GAUGE	
01-02-09518	F7445100	AIR COMP ASSY	
01-02-09519	F7447400	STARTER BUTTON	
01-02-09520	F7606860	SHROUD LOWER	
01-02-09521	F7608560	SHROUD UPPER LH	
01-02-09522	F7608660	SHROUD UPPER RH	
01-02-09523	F7610760	STG COL GAITER (F7400050)	
01-02-09524	F7614360	STG WHEEL	
01-02-09525	F7812300	RELAY STARTER	
01-02-09526	F7830800	FOOT CONT VALVE	
01-02-09527	F7851900	SHOCK ABSRB. FR.C	
01-02-09528	F7852200	SHO . ABSORB . NRR909	
01-02-09529	F7856800	WATER SEPERATOR	
01-02-09530	F7858700	BEEPER ALARM ASSY	
01-02-09531	F7863100	FOOT CONT VALVE	
01-02-09532	F7869800	INSULATOR ASSY	
01-02-09533	F7870970	BOOT CLLEVER-C	
01-02-09534	F7871810	CLIP BALL RET	
01-02-09535	F7872510	RADIATOR	
01-02-09536	F7873530	MASTER CYL	
01-02-09537	F7874000	BRKT SL CYL	
01-02-09538	F7874830	WATER HOSE (F78740-912)	
01-02-09539	F7882400	BALL JOINT	
01-02-09540	F7882500	BALL JOINT	
01-02-09541	F7888400	SENSOR WAT. TEMP	
01-02-09542	F7888600	PRESS TRANSOUCCER	
01-02-09543	F7895000	DIESEL TANK CAP	
01-02-09544	F8006500	SPEEDO METER 1:1(F8006500)	
01-02-09545	F8007900	S/A OF HOSE	
01-02-09546	F8008700	UNLOADER VALVE	
01-02-09547	F8008800	FILTER	
01-02-09548	F8010800	PR REDUCING VALVE	
01-02-09549	F8031200	OIL PRESS GAUGE	
01-02-09550	F8034300	TEMP. GAUGE	
01-02-09551	F8038600	WIPWER MOTOR 24V	
01-02-09552	F8040700	HORN HIGH TONE	
01-02-09553	F8040800	HORN LOW TONE	
01-02-09554	F8041400	AMMETER	
01-02-09555	F8052200	ALTERNATOR ASSY	
01-02-09556	F8055600	TANK UNIT FLOAT	
01-02-09557	F7855600	AIR CLEARER C/PTE	
01-02-09558	F8100100	CABLE ASSY -909	
01-02-09559	H2637900	INSULATOR -C	
01-02-09560	H4100800	KOLOK WASHER	
01-02-09561	K0202910	RR WHEEL BRG INNER	
01-02-09562	L3011218	NUT	
01-02-09563	L3811418	NUT 1414/PT	
01-02-09564	L3811618	NUT	
01-02-09565	P1301312	DISANCE PIECE	
01-02-09566	P1304218	INJ PUMP HEAD	
01-02-09567	P1308144	NOZZLE SHIM 1.04	
01-02-09568	P2402251	MAJ REPKIT COMP	
01-02-09569	P2404751	MAJ REPKIT D/C	
01-02-09570	P2605651	KIT OVER HAUL GASKIT	
01-02-09571	P3162445	LEAFT SPRING FR MAIN	
01-02-09572	P3162545	LEAF SPR FR 2ND	
01-02-09573	P3162645	LEAF SPR FR 3RD	
01-02-09574	P3208445	LEAF SPR RR 1S1	

01-02-09575	P3208545	LEAF SPR RR SND	
01-02-09576	P3208645	LEAF SPR RR 3RD	
01-02-09577	P4500114	SLIDING SLEEVE	
01-02-09578	P4500135	SHAFT NUT	
01-02-09579	P4500332	YOKE SEPARATOR	
01-02-09580	P4501339	SLIPYOKE ASSY	
01-02-09581	P7800107	SPLIT RING	
01-02-09582	P7800127	WASHER	
01-02-09583	P7800311	DUST CAP	
01-02-09584	P7800336	SPRING	
01-02-09585	P3800424	SELECTOR LEVER	
01-02-09586	P7800434	STOP TUBE	
01-02-09587	P7800524	CONNECTING ROD	
01-02-09588	P7800534	SELEEVE	
01-02-09589	P7800541C	BALL JOINT	
01-02-09590	P7800631	PLUG	
01-02-09591	P7800641C	BALL JOINT	
01-02-09592	P7800727X	OIL SEAL	
01-02-09593	P7800741C	BALL JOINT	
01-02-09594	P7800909	ROLL PIN	
01-02-09595	P7800935C	BOLT	
01-02-09596	P7801009	ROLL PIN	
01-02-09597	P7801235	DETENT PLUNGER	
01-02-09598	P7801535C	NUT	
01-02-09599	P7801835	LOCK NUT	
01-02-09600	P7804049C	WASHER	
01-02-09601	P7804707	CAP SCRAPPER	
01-02-09602	P7804807	CIR CLIP	
01-02-09603	P0921951	KIT-CL BRAKE PO	
01-02-09604	P0922051	KIT -ACCL LINKAGE	
01-02-09605	P0927651	WP REP KIT - MINOR	
01-02-09606	P4500126	RUBBER CBRG	
01-02-09607	P0931951	CYL HEAD KIT	
01-02-09608	P1004151	REPAIR KIT	
01-02-09609	P1008351	REPAIR KIT -C	
01-02-09610	P1011951	FOOT V.REEP KIT-C	
01-02-09611	P1012151	REP.KIT REL VALVE	
01-02-09612	P1012351	O S P VALVE	
01-02-09613	P1012451	REPIR KIT	
01-02-09614	P1012551	HAND CONT VALVE	
01-02-09615	P1013051	REP . KIT - BR CHAMBER	
01-02-09616	P1013351	REP KIT OF PBV	
01-02-09617	P1014051	REP AIR KIT A/F	
01-02-09618	P1300125	REDUCING NIPPLE	
01-02-09619	P1300620	PULLING ELECTRO MAG	
01-02-09620	P1301340	FILTER INSERT	
01-02-09621	P1301607	SEALING-6D	
01-02-09622	P1301618	FILTER HOUSING	
01-02-09623	P1303056	NOZZLE	
01-02-09624	P1312939	HAND PRIMING PUMP	
01-02-09625	P1542700	INSULATOR909	
01-02-09626	P1602536	SHOE SPRING 909	
01-02-09627	P1602851	SLAVE CYLINDER	
01-02-09628	P1602951	REP.KIT MAST . CYL.	
01-02-09629	P1603051	SHOE HLD. SWN KIT	
01-02-09630	P1604251	KIT TOQUE PLATE ASSY FR	
01-02-09631	P1604351	KIT TOQUE PLATE ASSY FR	
01-02-09632	P1604451	KIT TOQUE PLATE ASSY RR	
01-02-09633	P1604951	KIT SLAVE CYL	
01-02-09634	P1605954	LINED SHOE 909	



01-02-09635	P1606154	LINING KT . STD 909	
01-02-09636	P1611939	EXPANDER ASSY	
01-02-09637	P2400851	IN-SHAFT SEAL KIT	
01-02-09638	P2401427	O RING	
01-02-09639	P2401551	TH.BEARING KIT	
01-02-09640	P2402251	TIE ROD KIT	
01-02-09641	P2403027	COVER SEAL	
01-02-09642	P2403151	SEAL KIT	
01-02-09643	P2403751	VALVE KIT /POPPET	
01-02-09644	P2403851	SEALKIT - PISTON	
01-02-09645	P2403951	SEAL KIT	
01-02-09646	P2404051	S/S ADJ SCREW KIT	
01-02-09647	P2404151	MAJOR SEAL KIT	
01-02-09648	P2404251	SEARVICE KIT	
01-02-09649	P2404951	DRAG LINK KIT	
01-02-09650	P2406535	WING NUT	
01-02-09651	P2407239	STRAINERASSY	
01-02-09652	P2601402	CON ROD BRG	
01-02-09653	P2601502	CON ROD BRG S1	
01-02-09654	P2601602	CON ROD BRG S2	
01-02-09655	P2602102	MAIN BEARING	
01-02-09656	P1602436	SHOE PRING 909	
01-02-09657	P2602202	MAIN BEARING	
01-02-09658	P2602302	MAIN BEARING	
01-02-09659	P2605651	KIT OVER HAUL GASKIT	
01-02-09660	P2606151	THRUST WASHER (1901385)	
01-02-09661	P3103207	AIR CLEAER ORING	
01-02-09662	P3103307	AIR CLEAER ORING	
01-02-09663	P3600551	CL.REP KIT	
01-02-09664	P3700715	ALT PULLEY	
01-02-09665	P4300249	TH.WAHER RS.120	
01-02-09666	P4300402	DIFF . BRG.RS.120	
01-02-09667	P4300914	COMP/PLANG RS .120	
01-02-09668	P4301033	AXLE SHAFT -RS .120	
01-02-09669	P4301427	OIL SEAL RS 120	
01-02-09670	P4301902	BRG .PIN . OT RS.120	
01-02-09671	P4302002	BRG .PIN . OT RS.120	
01-02-09672	P4302102	DIFF. BRG	
01-02-09673	P4305949	TH.WAHSER RS.120	
01-02-09674	P4307635	CAP.SCREW RS.120	
01-02-09675	P4307839	CROWN WHEEL PINION	
01-02-09676	P4308539	DRIVER HEAD ASSY	
01-02-09677	P4500114	COMPANION FLANGE	
01-02-09678	P4500135	SHAFT NUT	
01-02-09679	P4500351	C BEARING ASSY	
01-02-09680	P8101527	OIL SEAL RR CR SHAFT (98461686)	
01-02-09681	X1006700	TANK RADIATAR	
01-02-09682	X1130850	RUBBER COVER	
01-02-09683	X1903750	FLEXIBLE HOSE CAMP	
01-02-09684	X1908950	HOST DAT PAD	
01-02-09685	X1958815M	EXH PIPE	
01-02-09686	X2102111	KNUCKLE	
01-02-09687	X3205611	DROP ARM	
01-02-09688	X3503910	U BOLT RS FR	
01-02-09689	X3504210	U BOLT RS RR	
01-02-09690	X3506710	U BOLT FS FR	
01-02-09691	X3972900	RES	
01-02-09692	X3973700	FLOW CONTROL VALVE	
01-02-09693	X3979200	SILENCER	
01-02-09694	X4504710M	LEAF SPRING ASSY FR	

01-02-09695	X4507810M	LEAF SPRING ASSY RR	
01-02-09696	X4507910M	LEAF SPRING ASSY RR	
01-02-09697	X7800310	CAP HEADER TANK	
01-02-09698	X8000600	COMBINATION SWITCH	
01-02-09699	X0204110	CLRELEASE BRK.	
01-02-09700	X0404122	BRACKET SPRG FRT	
01-02-09701	X0700300	RAD COWL	
01-02-09702	X2702150	OIL SEAL-RR HUB	
01-02-09703	X2702250	OIL SEAL-RR HUB	
01-02-09704	X3505010	EYE BOLT	
01-02-09705	X3538511	SCREW	
01-02-09706	P4302202	DIF . BRG.RH.RS.120	
01-02-09707	X3598515	NUT	
01-02-09708	X3602810	SPERING	
01-02-09709	X3710215	PIN	
01-02-09710	X3972800	STG ASSY	
01-02-09711	X3981700	RELAY VALVE	
01-02-09712	X4409110	SHIM 8.0MM	
01-02-09713	X4409710	SHIM 3.10MM	
01-02-09714	X4411110	SHIM 4.0MM	
01-02-09715	X4923110	F7964715	
01-02-09716	X7100222	BRACKET LH	
01-02-09717	X7424400	HOSE ASSY	
01-02-09718	X7426100	TURBO CHARGER (97188461)	
01-02-09719	X7432300	PROP SHAFT RR	
01-02-09720	X7434200	PROP SHAFT ASSY	
01-02-09721	X7436400	SPEEDO CABLE	
01-02-09722	X7436800	ACCL-CABLE LHD	
01-02-09723	X8000600	SWITCH ASSY	
01-02-09724	X8003700	HEAD LAMP RELAY	
01-02-09725	X8003800	RELAY	
01-02-09726	4815585	OIL DELAY PIPE	
01-02-09727	4816108	OIL SUPPLY TUBE	
01-02-09728	10296260	RS GASKET	
01-02-09729	4848545	OIL SUCTION LINE	
01-02-09730	4818560	SHAFT AND GEAR ASSY	
01-02-09731	97181034	PIPE- UPER TANK	
01-02-09732	F7855300	CAP FILLER	
01-02-09733	F7855410	CAP PRESSURE	
01-02-09734	X3972800	POWER STEERING BOX	
01-02-09735	T6500001	FRONT W/S GLASS LAMINATED	
01-02-09736	T6500002	REAR W/S GLASS	
01-02-09737	T6500003	DR DOOR GLASS	
01-02-09738	T6500004	1ST,2ND,3RD BAY FIXED GLASS LH	
01-02-09739	T6500005	1ST,2ND,3RD BAY SLIDING GLASS LH	
01-02-09740	T6500006	FLOCK CHANNEL FOR SLIDING GLASS	
01-02-09741	T6500007	SLIDING GLASS LOCK LH	
01-02-09742	T6500008	1ST,2ND,3RD BAY FIXED GLASS RH	
01-02-09743	T6500009	1ST,2ND,3RD BAY SLIDING GLASS RH	
01-02-09744	T6500010	FLOCK CHANNEL FOR SLIDING GLASS	
01-02-09745	T6500011	SLIDING GLASS LOCK RH	
01-02-09746	T7500012	REAR VIEW MIRROR LH	
01-02-09747	T7500013	REAR VIEW MIRROR RH	
01-02-09748	T7500014	REAR VIEW MIRROR BRACKET LH	
01-02-09749	T8500015	FRONT DIRECTION INDICATOR LH	
01-02-09750	T8500016	FRONT DIRECTION INDICATOR RH	
01-02-09751	T9500001	REAR VIEW MIRROR BRACKET RH	
01-02-09752	T8500017	HEAD LAMP RH	
01-02-09753	T8500018	HEAD LAMP LH	
01-02-09754	T8500019	REAR LAMP LH	

01-02-09755	T8500020	REAR LAMP RH	
01-02-09756	T8500021	NUMBER PLATE LIGHT	
01-02-09757	T5500001	WHEEL CAP FRONT	
01-02-09758	T5500002	WHEEL CAP REAR	
01-02-09759	T4500001	FRONT BUMPER	
01-02-09760	T4500002	REAR BUMPER	
01-02-09761	T4500003	EMBLISHER LH	
01-02-09762	T4500004	EMBLISHER RH	
01-02-09763	T4500005	BOTTOM GRILL	
01-02-09764	T4500006	TOP GRILL SHOW BEADING FRONT	
01-02-09765	T4500007	FRONT FACIA	
01-02-09766	T8500022	MARKER LAMP FRONT	
01-02-09767	T8500023	MARKER LAMP REAR	
01-02-09768	T4500008	PASS DOOR SOLONOID VALVE	
01-02-09769	T4500009	PASS DOOR CYLINDER	
01-02-09770	T4500010	LIGHT SWITCH	
01-02-09771	T450011	FUEL TANK FLAP DOOR	
01-02-09772	98414013	SPINDLE	
01-02-09773	4848237	FRONT COVER COMPLETE	
01-02-09774	98424045	COVER	
01-02-09775	4766126	TIMING GEAR BOX-COMPL.	
01-02-09776	98424046	T.GEAR BOX GASKET	
01-02-09777	4849994	REAR COVER SEAL	
01-02-09778	4781935	COVER SEAL	
01-02-09779	98461686	OIL SEAL ENG.REAR	
01-02-09780	4655844	DISC KEY	
01-02-09781	14328101	CAP PLUG	
01-02-09782	4655847	HUB/CRANKSHAFT	
01-02-09783	4770452	RING SPLIT	
01-02-09784	4835569	PIN FOR PISTON	
01-02-09785	78475474	NOZZLE FOR COOLING PISTON	
01-02-09786	4763440	SAFETY PLATE	
01-02-09787	98475228	UNION FOR NOZZLE	
01-02-09788	97188106	OIL SEAL	
01-02-09789	4848315	THREADED DOUBLESOUK BOLT	
01-02-09790	4848314	THREADED DOUBLESOUK BOLT	
01-02-09791	98428397	GASKET	
01-02-09792	97188474	EXHAUST MANIFOLD	
01-02-09793	P 3700715	PULLY	
01-02-09794	P3700622	DISC KEY	
01-02-09795	P3702352	ROTOR ASS.	
01-02-09796	P3703002	BALL BEARING	
01-02-09797	P3707539	RECTIFIERS ASS	
01-02-09798	P3701204	SRE BRACKET	
01-02-09799	P3707639	REGULATOR&BRUSH BOX ASS	
01-02-09800	P3702902	BALL BEARING	
01-02-09801	P3701104	BRACKET	
01-02-09802	P3702452	STATER	
01-02-09803	8190403	STATER ARMATUR	
01-02-09804	79080372	STARTER SUPPORT	
01-02-09805	8190402	BRUSH HOLDER	
01-02-09806	8190404	STATER WINDING	
01-02-09807	8190401	STATER SUPPORT	
01-02-09808	79081046	KIT STARTER	
01-02-09809	79081045	KIT STARTER	
01-02-09810	P160024	PROPELLER SHAFT COMP	
<b>SPARE PARTS FOR</b>			
<b>CODE</b>	<b>Part No.</b>	<b>ParT Name</b>	
01-02-09811	47730-36030	CYLINDER ASSY, FRONT DISC BRAKE, RH	
01-02-09812	47750-36030	CYLINDER ASSY, FRONT DISC BRAKE, LH	

01-02-09813	04491-36070	PAD KIT, DISC BRAKE, FRONT	
01-02-09814	04479-36020	CYLINDER KIT, DISC BRAKE, FRONT	
01-02-09815	81554-36260	GASKET, REAR COMBINATION LAMP BODY, RH	
01-02-09816	81554-36260	GASKET, REAR COMBINATION LAMP BODY, LH	
01-02-09817	81551-36330	LENS, REAR COMBINATION LAMP, RH	
01-02-09818	84561-36200	LENS, REAR COMBINATION LAMP, LH	
01-02-09819	41110-36590	CARRIER ASSY, DIFFERENTIAL , REAR	
01-02-09820	42610-36420	WHEEL, DISC (FOR REAR)	
01-02-09821	42613-36080	RING, DISC WHEEL SIDE	
01-02-09822	90942-01093	NUT, HUB (FOR AXLE)	
01-02-09823	42610-36480	WHEEL, DISC (FOR SPARE)	
01-02-09824	90311-75003	SEAL, OIL (FOR REAR AXLE HUB RH)	
01-02-09825	42420-39015	HUB (OR SHAFT) & BRAKE DRUM REAR AXLE, RH	
01-02-09826	90311-75003	SEAL, OIL (FOR REAR AXLE DRUM REAR AXLE, LH)	
01-02-09827	90366-60012	BEARING (FOR REAR AXLE HUB INNER RH)	
01-02-09828	90366-60012	BEARING (FOR REAR AXLE HUB INNER LH)	
01-02-09829	42431-36150	DRUM SUB-ASSY, REAR BRAKE	
01-02-09830	90942-02071	BOLT, HUB (FOR REAR AXLE RH)	
01-02-09831	90937-01122	PIECE, BALANCE (FOR REAR BRAKE DRUM)	
01-02-09832	90942-02072	BOLT, HUB (FOR REAR AXLE LH)	
01-02-09833	42321-55031	BOLT, DOUBLE WHEEL STOP, RH	
01-02-09834	42321-36050	GASKET, REAR AXLE SHAFT, RH	
01-02-09835	42321-36050	GASKET, REAR AXLE SHAFT, LH	
01-02-09836	42311-36190	SHAFT, REAR AXLE, RH	
01-02-09837	90916-02330	BELT, V (FOR FAN AND ALTERNATOR)	
01-02-09838	90916-02387	BELT, V (COOLER COMPRESSOR TO CRANKSHAFT PULLEY)	
01-02-09839	90916-02419	BELT, V (COOLER COMPRESSOR TO CRANKSHAFT PULLEY)	
01-02-09840	90916-03089	THERMOSTAT	
01-02-09841	16573-17020	HOSE, RADIATOR, NO. 3	
01-02-09842	16551-17020	HOSE, SUB RADIATOR, NO. 1	
01-02-09843	16346-66020	GASKET, THERMOSTAT	
01-02-09844	16554-17020	HOSE, SUB RADIATOR, NO. 4	
01-02-09845	16572-17100	HOSE, RADIATOR, OUTLET	
01-02-09846	16552-17010	HOSE, SUB RADIATOR, NO. 2	
01-02-09847	16401-72090	CAP SUB-ASSY, WATER FILLER	
01-02-09848	16361-17040	FAN	
01-02-09849	16400-17200	RADIATOR ASSY	
01-02-09850	16711-17070	SHROUD SUB-ASSY, FAN	
01-02-09851	16100-19235	PUMP ASSY, WATER	
01-02-09852	16271-17010	GASKET, WATER PUMP	
01-02-09853	90116-08112	BOLT, STUD (FOR WATER PUMP COUPLING)	
01-02-09854	16371-17010	PULLEY, FAN	
01-02-09855	16210-17030	COUPLING ASSY, FLUID	
01-02-09856	12261-17010	HOSE, VENTILATION	
01-02-09857	90467-22010	CLIP OR CLAMP (FOR VENTILATION HOSE)	
01-02-09858	11400-17120	BLOCK ASSY , SHORT	
01-02-09859	19000-17820	ENGINE ASSY, PARTIAL	
01-02-09860	81274-95700	GASKET, LICENSE PLATE LAMP BODY	
01-02-09861	81274-95700	GASKET, LICENSE PLATE LAMP BODY	
01-02-09862	81276-36100	COVER, LICENSE PLATE LAMP	
01-02-09863	28100-17030	STARTER ASSY	
01-02-09864	28139-54250	WIRE, LEAD, NO. 1 (FOR STARTER)	
01-02-09865	28150-17030	SWITCH ASSY, MAGNET STARTER	
01-02-09866	90099-10107	BEARING, STARTER ARMATURE	
01-02-09867	90099-10119	BEARING, STARTER ARMATURE	
01-02-09868	28160-77090	ARMATURE ASSY, STARTER	
01-02-09869	28120-56071	YOKE ASSY, STARTER	
01-02-09870	28140-77090	HOLDER ASSY, STARTER BRUSH	
01-02-09871	28130-17030	FRAME ASSY, STARTER COMMUTATOR END	
01-02-09872	23761-17010	PIPE ASSY, NOZZLE LEAKAGE	

01-02-09873	23600-69055	HOLDER AND NOZZLE SET, NOZZLE
01-02-09874	11177-64010	GASKET, INJECTION NOZZLE SEAT
01-02-09875	11165-54030	SHIM (FOR COMBUSTION CHAMBER)
01-02-09876	11106-17021	CHAMBER SUB-ASSY , COMBUSTION
01-02-09877	23620-69045	NOZZLE ASSY
01-02-09878	17410-17110	PIPE ASSY, EXHAUST, FRONT
01-02-09879	17402-17050	PIPE SUB-ASSY, EXHAUST, FRONT NO.2
01-02-09880	17403-17150	PIPE ASSY, EXHAUST, CENTER
01-02-09881	17567-58010	CUSHION, TAIL PIPE (FOR CENTER)
01-02-09882	17567-17010	CUSHION, TAIL PIPE (FOR REAR)
01-02-09883		
01-02-09884	12281-17020	HANGER, ENGINE, NO. 1
01-02-09885	90311-32017	SEAL, OIL (FOR OIL SEAL RETAINER, NO.2)
01-02-09886	91511-60820	STD PART
01-02-09887	91621-61020	STD PART
01-02-09888	90253-11021	PIN, RING (FORR OIL SEAL FETRAINER, NO.2)
01-02-09889	90253-11021	STD PART
01-02-09890	90468-05034	COVER, TIMING BELT NO. 1
01-02-09891	11321-17010	RETAINER, CAMSHAFT OIL SEAL
01-02-09892	11301-17021	CASE SUB-ASSY, TIMING GEAR
01-02-09893	90210-08019	STD PART
01-02-09894	90109-06046	STD PART
01-02-09895	11328-17010	GASKET, TIMING GEAR (OR CHAIN) COVER
01-02-09896	90344-51005	STD PART
01-02-09897	91511-60850	STD PART
01-02-09898		
01-02-09899	13204-17011	BEARING SET, CONNECTING ROD0.25
01-02-09900	13205-17011	BEARING SET, CONNECTING ROD0.50
01-02-09901	13011-17030	RING SET, PISTON
01-02-09902	13013-17030	RING SET , 0.5
01-02-09903	13041-17010-04	BEARING, CONNECTING ROD STD
01-02-09904	13101-17010-01	PISTON SUB-ASSY, W/PIN
01-02-09905	90521-32004	RING, HOLE SNAP (FOR PISTON PIN)
01-02-09906	11701-17010-02	BEARING, CRANKSHAFT STD
01-02-09907	90999-73126	BUSH (FOR CONNECTING ROD SMALL END)
01-02-09908	11705-17010	BEARING SET, CRANKSHAFT 0.50
01-02-09909	13265-17010	BOLT, CONNECTING ROD
01-02-09910	13408-17010	PULLEY, CRANKSHAFT
01-02-09911	13201-17010	ROD SUB-ASSY, CONNECTING
01-02-09912	11011-17001	WASHER SET, CRANKSHAFT THRUST
01-02-09913	90105-24001	BOLT (FOR CRANKSHAFT PULLEY SET)
01-02-09914	95161-30516	KEY (FOR CRANKSHAFT TIMING GEAR)
01-02-09915	90201-27001	WASHER, PLATE (FOR CRANKSHAFT PULLEY SET)
01-02-09916	13411-17010	CRANKSHAFT
01-02-09917	13522-17010	GEAR, PUMP DRIVE SHAFT
01-02-09918	13581-17010	SHAFT, IDLE GEAR, NO. 1
01-02-09919	13581-17011	SHAFT, IDLE GEAR, NO. 1
01-02-09920	13521-17010	GEAR OR SPROCKET, CRANKSHAFT TIMING
01-02-09921	90105-10347	STD PART
01-02-09922	90250-05121	PIN, STRAINHT (FOR FLYWHEEL)
01-02-09923	13525-17010	GEAR, IDLE, NO. 1
01-02-09924	13572-17010	PLATE, IDLE GEAR THRUST
01-02-09925	13572-17020	PLATE, IDLE GEAR THRUST
01-02-09926	13451-17020	FLYWHEEL SUB-ASSY
01-02-09927	88451-36100	PULLEY, CRANKSHAFT, NO. 2
01-02-09928	13407-17020	DAMPER SUB-ASSY, CRANKSHAFT
01-02-09929		
01-02-09930	88320-36530	COMPRESSOR ASSY, COOLER
01-02-09931	88410-36510	CLUTCH ASSY, MAGNET
01-02-09932	88412-36130	ROTOR SUB-ASSY, MAGNET CLUTCH

01-02-09933	88403-36040	HUB SUB-ASSY, MAGNET CLUTCH	
01-02-09934	88411-36240	STARTOR SUB-ASSY, MAGNET CLUTCH	
01-02-09935	88335-12050	WASHER (FOR MAGENT CLUTCH)	
01-02-09936	90099-07132	STD PART	
01-02-09937	88431-36610	BRACKET, COMPRESSOR MOUNTING , NO. 1	
01-02-09938	91511-61030	STD PART	
01-02-09939	91512-61025	STD PART	
01-02-09940	16604-76010	PULLEY ASSY, IDLE	
01-02-09941	88444-36150	BRACKET, IDLE PULLEY	
01-02-09942	90105-08099	BOLT, IDLE PULLEY	
01-02-09943	90091-20608	STD PART	
01-02-09944	90119-10360	STD PART	
01-02-09945	12261-17010	HOSE VENTOLATION	
01-02-09946	90467-22010	CLIP OR CLAMP (FOR VENTILATION HOSE)	
01-02-09947	22505-54010	PUMP SUB-ASSY , FUEL FEED	
01-02-09948	93315-14012	STD PART	
01-02-09949	90201-12109	WASHER, AIR BLEEDER NIPPLE	
01-02-09950	22632-54010	COUPLING, INJECTION PUMP	
01-02-09951	22178-17520	BRACKET (FOR INJECTION PUMP ASSY)	
01-02-09952	22169-54180	JOINT, RUBBER	
01-02-09953	22161-54010	WASHER, DRIVE SHAFT	
01-02-09954	90099-13018	KEY (FOR DRIVE GEAR)	
01-02-09955	22108-17010	RING SUB-ASSY, ROLLER	
01-02-09956	90099-00723	SCREW, CROSSRECESS COUNTERSUNK	
01-02-09957	90099-04946	STD PART	
01-02-09958	22511-58650	COVER, FEED PUMP	
01-02-09959	22149-56200	STD PART	
01-02-09960	22193-54770	RING , O (FOR GOVERNOR ADJUSTING SHAFT)	
01-02-09961	88625-36140	THERMOSTOR, COOLER, NO. 1	
01-02-09962	87105-36070	FAN, COOLER BLOWER, NO. 2	
01-02-09963	88550-36020	MOTOR ASSY, BLOWER	
01-02-09964	88501-36080	EVAPORATOR SUB-ASSY , COOLER , NO. 1	
01-02-09965	88605-36121	HARNESS SUB-ASSY, COOLER WIRING, NO. 1	
01-02-09966	88510-36132	UNIT ASSY, COOLER	
01-02-09967	27060-17240	ALTERNATOR ASSY	
01-02-09968	90099-00197	STD PART	
01-02-09969	27310-17240	FRAME ASSY, DRIVE END, ALTERNATOR	
01-02-09970	90099-10192	BEARING (FOR ALTERNATOR DRIVE END FRAME)	
01-02-09971	90099-00195	STD PART	
01-02-09972	90099-04966	STD PART	
01-02-09973	27312-42010	PLATE, RETAINER	
01-02-09974	27411-17030	PULLEY, ALTERNATOR	
01-02-09975	27389-42010	INSULATOR, TERMINAL	
01-02-09976	27330-17240	ROTOR ASSY, ALTERNATOR	
01-02-09977	27443-63020	COVER, ALTERNATOR BEARING	
01-02-09978	90099-10140	BEARING (FOR ALTERNATOR ROTOR)	
01-02-09979	27384-50030	WASHER	
01-02-09980	27387-42021	INSULATOR , TERMINAL	
01-02-09981	27064-42010	SEAL, ALTERNATOR PLATE	
01-02-09982	27388-42010	COVER, ALTERNATOR BRUSH	
01-02-09983	27370-75060	HOLDER ASSY, ALTERNATOR BRUSH	
01-02-09984	27039-50090	COVER, ALTERNATOR REAR END	
01-02-09985	27700-58060	REGULATOR ASSY, GNERATOR	
01-02-09986	27365-55080	PLATE, TERMINAL	
01-02-09987	93319-14025	STD PART	
01-02-09988	48531-80581	ABSORBER ASSY, SHOCK, REAR RH	
01-02-09989	48531-80581	ABSORBER ASSY, SHOCK, REAR LH	
01-02-09990	90948-03011	WASHER, REAR SHOCK ABSORBER CUSHION, NO. 1 LH	
01-02-09991	90948-03011	WASHER, REAR SHOCK ABSORBER CUSHION, NO. 1 RH	
01-02-09992	48416-36300	BRACKET, SPRING, NO. 4 RH	

01-02-09993	48417-36170	BRACKET, SPRING, NO. 4 LH	
01-02-09994	48414-36320	BRACKER, SPRING, NO. 3, RH	
01-02-09995	48415-36100	BRACKET, SPRING, NO. 3, LH	
01-02-09996	48422-36030	SUPPORT, REAR SPRING PIN, RH	
01-02-09997	48422-36030	SUPPORT, REAR SPRING PIN, LH	
01-02-09998	90901-05006	BOLT WASHER BA	
01-02-09999	91651-60814	BOLT WL WASHER	
01-02-10000	04483-36120	SHACKLE , REAR SPRING , RH	
01-02-10001	04483-36120	SHACKLE , REAR SPRING , LH	
01-02-10002	90117-16042	BOLT, U (FOR REAR SPRING RH)	
01-02-10003	90117-16042	BOLT, U (FOR REAR SPRING LH)	
01-02-10004	90948-01004	CUSHION, FRONT SHOCK ABSORBER , NO. 1 RH	
01-02-10005	48511-80041	ABSORBER ASSY, SHOCK , FRONT RH	
01-02-10006	48511-80041	ABSORBER ASSY, SHOCK , FRONT LH	
01-02-10007	90948-01004	CUSHION, FRONT SHOCK ABSORBER , NO. 1 LH	
01-02-10008	90948-02054	RETAINER, FRONT SHOCK ABSORBER CUSHION, NO. 2 RH	
01-02-10009	90948-02054	RETAINER, FRONT SHOCK ABSORBER CUSHION, NO. 2 LH	
01-02-10010	48107-36030	ARM SUB-ASSY, ANCHOR, RH	
01-02-10011	48108-36030	ARM SUB-ASSY, ANCHOR, LH	
01-02-10012	90179-12016	NUT	
01-02-10013	48162-36100	SPRING , TORSION BAR, LH	
01-02-10014	48161-36100	SPRING , TORSION BAR, RH	
01-02-10015	48174-36010	COVER, TORSION BAR DUST, LH	
01-02-10016	48174-36010	COVER, TORSION BAR DUST, RH	
01-02-10017	48514-36050	BRACKET, FRONT SHOCK ABSORBER, LOWER RH	
01-02-10018	48514-36050	BRACKET, FRONT SHOCK ABSORBER, LOWER LH	
01-02-10019	REAR WIPER		
01-02-10020	85224-60070-	PLAT,REAR WIPER RUBBER BAKINK ,NO.1	
01-02-10021	85214-20340-	RUBBER, REAR , WEPER	
01-02-10022	85244-36010	CAP , REAR WIPER	
01-02-10023	85242-36010	BLADE ASSY , REAR WIPER	
01-02-10024	82130-36020	MOTOR ASSY , RER WIPER	
01-02-10025	85241-36010	ARM ASSY , REAR WIPER	
01-02-10026	85292-36010	COVER , REAR WIPER ARM	
01-02-10027	LAMPS		
01-02-10028	81515-36270-	PLUQ ASSY , FRONT TURN SINGAL LMP	
01-02-10029	90981-12015-	BULB ( FOR FRONT TURN SINGAL LAMP )	
01-02-10030	81511-36280-	LENS, FRONT TURN SINGL LAMP , RH	
01-02-10031	81521-36220	LENS, FRONT TURN SINGL LAMP , RH	
01-02-10032	MNIFOLD		
01-02-10033	91621-B0812	**STD PART	
01-02-10034	17167-17030-	INSULTOR , EXHAUST MANIFOLD HEAT , NO. 1	
01-02-10035	17151-17010-	RING , EXHAUST MANIFOLD	
01-02-10036	17142-17010-	CASE , EXHAUST MANIFORD , NO. 2	
01-02-10037	96732-24042-	**STD PART	
01-02-10038	17141-17010-	MANIFOLD , EXHAUST	
01-02-10039	90179-10037-	** STD PART	
01-02-10040	90126-10006-	BOLT , STUD ( FOR MNIFOLD TO EXHAUST PIPE )	
01-02-10041	17115-17010-	GASKET , INTAKE MNIFOLD HOLE COVER	
01-02-10042	17113-17030-	PIPE , INTAKE	
01-02-10043	90116-10171-	BOLT , STUT ( FOR MANIFOLD TO CYLINDER HEAD )	
01-02-10044	CAMSHAFT		
01-02-10045	13501-17010-	CAMSHAFT	
01-02-10046	13711-17010-	VALVE ,INTAKE	
01-02-10047	13715-54040-	VALVE , EXHUST	
01-02-10048	90913-02094-	SEAL OR RING ,O ( FOR VALVE STEAM OIL )	
01-02-10049	90201-23003-	WASHER , PLATE ( FOR VALVE SPRING SEAT )	
01-02-10050	11801-17010-	BEARING SET , CAMSHAFT	
01-02-10051	13571-17010-	PLATE, CASHAFT THRUST	
01-02-10052	13568-19195-	BELT , TIMING	

01-02-10053	13741-57020-	RETAINER , VALVE SPRING	
01-02-10054	90913-03014-	LOCK , VALVE SPRING RETAINER	
01-02-10055	13751-54010-	LIFTER , VALVE	
01-02-10056	90280-05004-	KEY , WOODRUFF ( FOR TIMING GEAR)	
01-02-10057	13753-17040-	SHIM , VALVE ADJUSTING	
01-02-10058	WINDSHIELD		
01-02-10059	85212-36010-	BLADE , FR WIPER , RH	
01-02-10060	85224-36040-	PLTE , WIPER RUBBER BCKING , NO. 1	
01-02-10061	85214-33060-	RUBBER , WIPER ,RH	
01-02-10062	85224-36030-	PLATE , WIPER RUBER BCKING , NO. 2	
01-02-10063	85211-36010-	ARM , FR WIPER ,RH	
01-02-10064	85222-36020-	BLA DE , FR WIPER , LH	
01-02-10065	85221-36020	ARM,FR WIDER ,LH	
01-02-10066	CYLINDER		
01-02-10067	90105-06138	** STD PART	
01-02-10068	90179-06199-	** STD PART	
01-02-10069	92122-60635	**STD PART	
01-02-10070	12180-55010-	CAP SUB - ASSY , OIL FILLTER	
01-02-10071	90430-37004-	GASKET ( FOR OIL FILTER CAP )	
01-02-10072	11213-17010-	GASKET, CYLINDER HEAT CVOVER	
01-02-10073	11201-17020-	COVER SUB -ASSY , CYLINDER HEAT	
01-02-10074	90910-02096-	BOLT ( FOR CYLIDER HEAT SET )	
01-02-10075	11183-54011-	PLUG , SEMICIRCULAR	
01-02-10076	90201-11032-	WASHER , PLATE ( FOR CYLINDER HEAT SET )	
01-02-10077	11101-17050-	HEAT SUB - ASSY , CYLINDER	
01-02-10078	11122-17020-	BUSH , EXHUST VALVE GUIDE	
01-02-10079	FRONT		
01-02-10080	43512-36170-	DISC , FRONT	
01-02-10081	90368-28001-	BEARING ( FOR FRONT AXEL HUB OUTER RH )	
01-02-10082	90942-02071-	BOLT , HUB ( FOR FRONT AXEL RH )	
01-02-10083	90368-42545-	BEARING ( FOR FRONT AXEL HUB INTER RH )	
01-02-10084	90942-02072-	BOLT , HUB ( FOR FRONT AXEL LH )	
01-02-10085	90368-42045-	BEARING ( FOR FRONT AXEL HUB INTER RH )	
01-02-10086	90311-68001-	SEAL , OIL ( FOR FRONT AXEL HUB RH )	
01-02-10087	90311-68001-	SEAL , OIL ( FOR FRONT AXEL HUB LH )	
01-02-10088	center door		
01-02-10089	67874-36010-	WEATHERSTRIP , CENTER DOOR , UPPER NO . 2	
01-02-10090	67868-30040-	RETAINER , DOOR WEATHERSTAR , RH	
01-02-10091	67873-36010-	WEATHERSTRIP , REAR DOOR CLASS , FRONT RH	
01-02-10092	68709-90B00-	CASE SUB -ASSY , CENTER DOOR UPPER BERING	
01-02-10093	75742-90B01-	MOUDLING , CENTER DOOR , REAR	
01-02-10094	67027-36010-	COVER SUB - ASSY , CENTER DOOR , OUTER	
01-02-10095	AIR CLEANER		
01-02-10096	53207-36090-	DUCT SUB -ASSY , COOL AIR INTAKE	
01-02-10097	69111-10780-	CLAMP ( FOR AIR CLEANERR HOSE , NO. 2)	
01-02-10098	69111-10900	CLAMP ( FOR AIR CLEANERR HOSE , NO. 2)	
01-02-10099	17882-17021-	HOSE , AIR CLEANERR, NO. 2	
01-02-10100	69111-10800-	CLAMP ( FOR AIR CLEANERR HOSE , NO. 1)	
01-02-10101	17881-17050	HOSE , AIR CLEANERR, NO. 1	
01-02-10102	17801-61030-	ELEMENT SUB-ASSY , AIR CLEANERRFILTER	
01-02-10103	SIDE		
01-02-10104	61277-36010-	JOINT ,ROOF DRIP CHANNEL	
01-02-10105	61357-36010-	CHANNEL ,ROOF DRIP SIDE , CENTER NO. 1	
01-02-10106	61357-36010-	CHANNEL ,ROOF DRIP SIDE , CENTER NO. 1	
01-02-10107	61211-36010-	PILLAR NO. 1 OUTER, UPPER RH	
01-02-10108	61211-36020-	PILLAR NO. 1 OUTER, UPPER RH	
01-02-10109	61356-36010	CHANNEL ,ROOF DRIP SIDE , FRONT RH	
01-02-10110	61112-36050	PANEL , NO. 2 SIDE , RH	
01-02-10111	65415-36060-	PANEL , REAR BODY . FRONT RH	
01-02-10112	65417-36010	PANEL , REAR BODY . REAR RH	



01-02-10113	61274-36020-	PILLAR NO. 10 INNER, RH	
01-02-10114	61274-36020-	PILLAR NO. 10 INNER, RH	
01-02-10115	61274-36010-	PILLAR NO. 10 INNER, RH	
01-02-10116	61631-36010-	PANEL , REAR WHEEL HOUSE , OUTER RH	
01-02-10117	61633-36010-	PANEL , WHEEL HOUSE	
01-02-10118		OIL PUMP	
01-02-10119	15133-17010-	PLUG , OIL PUMP RELIFE VALVE	
01-02-10120	15134-67020-	GASKET , OIL PUMP REFLIEF VALVE	
01-02-10121	15132-17010-	SPRING ,OIL PUMP RELIEF VALVE	
01-02-10122	15131-17010-	VALVE .OIL PUMP RELIEF	
01-02-10123	15193-17010-	GASKET OIL PUMP	
01-02-10124	15149-17010-	GASKET,OIL STRINER FLANGE	
01-02-10125	15163-17010-	GEAR,OIL PUMP DRIVE SHAFT	
01-02-10126	90179-06222-	**STD PART	
01-02-10127	90119-06600-	**STD PART	
01-02-10128	15104-17030-	STRAINER SUB- ASSY ,OIL	
01-02-10129		OIL FILTER	
01-02-10130	90430-12221-	**STD PART	
01-02-10131	90341-12025-	**STD PART	
01-02-10132	90915-30002-	FILTER SUB -ASSY ,OIL	
01-02-10133	15721--17010-	COVER ,OIL COOLER	
01-02-10134	15725-17010-	GASKET .OIL FILTER	
01-02-10135		FRONT BUMPER	
01-02-10136	52141-36040-	STAY ,FRONT BUMPER .RH	
01-02-10137	52142-36040	STAY ,FRONT BUMPER .LH	
01-02-10138	52018-36901-	BUMPER ASSY ,FRONT	
01-02-10139		RADIATOR	
01-02-10140	53131-36010-	DOOR ,HEADLMP ,RH	
01-02-10141	58219-36010	BRACKET ,FRONT FLOOR TO GRILLE	
01-02-10142	53111-36010-	GRILIE , RADIATOR	
01-02-10143	53132-36010-	DOOR ,HEADLMP ,LH	
01-02-10144		LOCK	
01-02-10145	69005-36291-	CYLINDER SET ,LOCK	
01-02-10146		MOUNTING	
01-02-10147	12361-17031-	INSULTOR ,ENGINE MOUNTING ,FRONT	
01-02-10148	12381-17020-	STABILIZER ,ENGINE MOUNTING	
01-02-10149	12371-17040-	INSULTOR ,ENGINE MOUNTING ,REAR NO.1	
01-02-10150		FRONT PANEL	
01-02-10151	56121-36010-	WEATHERSTRIP ,WINDSHIELD	
01-02-10152	56111-36040-	GLASS ,WINDSHIELD	
01-02-10153		SUSPENSION	
01-02-10154	51003-3B671-	FRAME SUB-ASSY	
01-02-10155		ENGINE	
01-02-10156	04111-17010-	GSKET KIT ,ENGINE OVERHAUL	
01-02-10157	04112-17010-	GSKET KIT ,ENGINE VALVE GRIND	
01-02-10158			
01-02-10159		RER AXEL	
01-02-10160	41110-36590-	CARRIER ASSY ,DEFFERENTIAL ,REAR	
01-02-10161		CYLINDER BLOCK	
01-02-10162	11448-17010-	ORIFICE ,CYLINDER BLOCK OIL	
01-02-10163	96411-42500	PLUG ,TIGHT .NO.3 (FOR CYLINDER BLOCK )	
01-02-10164	90250-06068-	PIN ,STRAIGHT ( FOR ENGINE REAR OIL SEAL )	
01-02-10165	96411-43500-	PLUG ,TIGHT .NO.6 (FOR CYLINDER BLOCK )	
01-02-10166	90250-08120	PIN ,STRAIGHT ( FOR TIMING GER SET )	
01-02-10167	90331-35002-	PLUG ,TIGHT .NO.1 (FOR CYLINDER BLOCK )	
01-02-10168		TRANSMISSION ASSY	
01-02-10169	33110-3J471-	TRANSMISSIN ASSY MANUAL	
01-02-10170		TRANSMISSION GEAR	
01-02-10171	33301-36170-	SHAFT , INPUT	
01-02-10172	33369-36010	RING, SYNCHRONIZSER, NO3	

01-02-10173	90363-45010-	BEARING FOR INPUT SHAFT FRONT	
01-02-10174	33034-36100-	GEAR , 3RD	
01-02-10175	33323-36010-	SPACER, SYNCHRONIZER RING	
01-02-10176	33366-36040-	KEY, SYNCHROMESH SHIFTING NO2	
01-02-10177	33371-36030-	SPRING , SYNCHROMESH SHIFTING KEY NO2	
01-02-10178	90520-28054-	RING SHAFT SNAP FOR TRANSMISSION CLUCH	
01-02-10179	33392-36010-	SPRING , SYNCHROMESH SHIFTING KEY NO3	
01-02-10180	90364-37012	BEARING NIDEL ROLER , 5TH GEAR	
01-02-10181	33335-37050-	GEAR,1ST	
01-02-10182	33367-36050-	RING, SYNCHRONIZER , NO1	
01-02-10183	33365-36030-	KEY, SYNCHROMESH SHIFTING NO1	
01-02-10184	90521-22003-	RING, SNAP, COUNTER GEAR REAR BEARING	
01-02-10185	90365-37006-	BERING OR ROLLER ( FOR COUNTER GEAR)	
01-02-10186	33482-39445-	GEAR SUB-ASSY SPEED METER DRIVEN	
01-02-10187	GEAR SHAFT		
01-02-10188	33244-37020-	SHAFT, GEAR SHIFT FORK, NO.3	
01-02-10189	33243-37020-	SHAFT, GEAR SHIFT FORK, NO.2	
01-02-10190	33205-37030-	SHAFT SUB-ASSY, GEAR SHIFT FORK NO.1	
01-02-10191	33213-36050-	FORK, GEAR SHIFT NO.2	
01-02-10192	33212-36031	FORK, GEAR SHIFT NO.1	
01-02-10193	33214-36060	FORK, GEAR SHIFT NO.3	
01-02-10194	TRANSMISSION CABLE		
01-02-10195	33822-36031-	CABLE TRANSMISION CONTROL SELECT	
01-02-10196	33821-36041-	CABLE TRANSMISION CONTROL SHIFT	
01-02-10197	33790-36560-	ROD, GEAR SELECTING NO.2	
01-02-10198	33850-36310-	ROD ASSY GEAR SELECT NO.3	
01-02-10199	33840-36440	ROD ASSY GEAR SHIFTING	
01-02-10200	CLUTCH & RELEAS FORK		
01-02-10201	31230-36200-	BEARING ASSY CLUTCH RELEASE	
01-02-10202	31210-36220-	COVER ASSY, CLUTCH	
01-02-10203	31250-36502-	DISK ASSY CLUTCH	
01-02-10204	31204-36142-	FORK ASSY, CLUTCH RELEASE	
01-02-10205	51202-36170-	CROSSMEMBER SUB ASSY FRONT SUSPENSION	
01-02-10206	PROPELLER SHAFT		
01-02-10207	04371-36030-	SPID KIT UNIVERSAL JIONT	
01-02-10208	04371-36050-	SPID KIT UNIVERSAL JIONT	
01-02-10209	37304-36030	FLANGE SUB-ASSY, UNIVERSAL JIONT	
01-02-10210	37230-36130-	BEARING ASSY, CENTER SUPPORT, NO.2	
01-02-10211	37100-36740-	SHAFT ASSY , PROPELLER W/CENTER BEARING	
01-02-10212	37110-36740-	SHAFT ASSY, PROPELLER, REAR	
01-02-10213	GLASSES		
01-02-10214	62109-36050-	CLASS,SIDE LOWER WINDOW	
01-02-10215	62111-36050	GLASS, FRONT SIDE WINDOW FRONT RH	
01-02-10216	62221-36070	GLASS, SIDE WINDOW, REAR RH	
01-02-10217	68141-36030-	RUN, SIDE FRONT WINDOW, RH	
01-02-10218	93540-24010-	SCREW TAPPING	
01-02-10219	93540-23010	SCREW TAPPING	
01-02-10220	POWER STEERING		
01-02-10221	44107-36360-	HOSING SUB-ASSY, POWER STEERING GEAR	
01-02-10222	44110-36360	GEAR ASSY POWER STEERING	
01-02-10223	90204-30040-	WASHER FOR PITMAN ARM	
01-02-10224	45312-36250-	BRACKET, STERING GEAR HOSING	
01-02-10225	90170-30001-	NUT, CASTEL ( FOR PITMAN ARM )	
01-02-10226	90099-10140	BEARING ALTERNATOR	
01-02-10227	82111-36214	WIRE , ENGINE ROOM MAIN	
01-02-10228	82214-60010	WIRE , LAMP	
01-02-10229	82219-36050	WIR , SEN SOR	
01-02-10230	04494-36240	SHOE KIT , REAR BRAKE	
01-02-10231	04474-36020	CYLINDER , KIT , REAR WHEEL	
01-02-10232	11115-17040	GASKET - CYLINDER HEAD	

01-02-10233	11704-17010	BEARING SET 0.25	
01-02-10234	13103-17100	PISTON 0.50	
01-02-10235	13753-17090	SHIM	
01-02-10236	13753-17100	SHIM	
01-02-10237	13753-54010	SHIM	
01-02-10238	13753-54060	SHIM	
01-02-10239	13753-54160	SHIM	
01-02-10240	13753-54260	SHIM	
01-02-10241	45046-39275	END SUB ASSY TIE ROD RH	
01-02-10242	45046-39275	END SUB ASSY TIE ROD LH	
01-02-10243	45466-55020	CLAMP , TIE ROD END	
01-02-10244	45466-36020	CLAMP , TIE ROD END	
01-02-10245	13505-17020	IDELER SUB -ASSY	
<b>SPARE PARTS FOR</b>			
<b>PROTON WIRA</b>			
<b>1.5MT</b>			
<b>CODE</b>			
01-02-10246	PC110118	ENGINE ASSY	
01-02-10247	MD329820	ENGINE ASSY,SHORT	
01-02-10248	MD997672	GASKET KIT,ENG OVERHAUL	
01-02-10249	MD997671	GASKET KIT,ENG OVERHAUL,UPR	
01-02-10250	MD970389	LIQUID GASKET,ENG	
01-02-10251	MD167991	COVER,ROCKER	
01-02-10252	MD143995	GASKET,ROCKER COVER	
01-02-10253	MD106809	HOSE,ROCKER COVER BREATHER	
01-02-10254	MD012947	VALVE,PCV	
01-02-10255	MD363392	CAP ASSY,ENG OIL FILLER	
01-02-10256	MD311638	GASKET,ENG OIL FILLER CAP	
01-02-10257	MD323491	HEAD ASSY,ENG CYLINDER	
01-02-10258	MF665541	CAP,CYLINDER HEAD	
01-02-10259	MD355550	BOLT,CYLINDER HEAD	
01-02-10260	MD153103	OIL SEAL,CAMSHAFT	
01-02-10261	MD142923	SEAT,EXHAUST VALVE	
01-02-10262	MD323473	GASKET , CYLINDER HEAD	
01-02-10263	MD148418	SEAT,INLET VALVE	
01-02-10264	MD356013	GUIDE,INLET VALVE	
01-02-10265	MD343941	GUIDE,EXHAUST VALVE	
01-02-10266	MD323312	BLOCK ASSY,CYLINDER	
01-02-10267	MF472403	PIN,CYLINDER BLOCK	
01-02-10268	MF665541	CAP,CYLINDER BLOCK	
01-02-10269	MS471109	BUSHING,CYLINDER BLOCK	
01-02-10270	MD183242	GASKET,RR OIL SEAL CASE	
01-02-10271	MD332492	BEARING,CRANKSHAFT	
01-02-10272	MD332719	BEARING,CRANKSHAFT,CTR	
01-02-10273	MD372250	OIL SEAL,CRANKSHAFT,RR	
01-02-10274	MD194710	GAUGE,ENG OIL LEVEL	
01-02-10275	MD309537	OIL PAN,ENG	
01-02-10276	MD050316	PLUG,ENG OIL PAN.	
01-02-10277	MD050317	GASKET,ENG OIL PAN DRAIN PLU	
01-02-10278	MD160683	COVER,TIMING BELT	
01-02-10279	MD160681	COVER,TIMING BELT	
01-02-10280	MD136816	GASKET , TIMING BELT COVER	
01-02-10281	MD191945	GASKET , TIMING BELT COVER	
01-02-10282	MD191946	GASKET , TIMING BELT COVER	
01-02-10283	MD189493	GASKET , TIMING BELT COVER	
01-02-10284	MD160685	GASKET , TIMING BELT COVER	
01-02-10285	MD191948	GASKET , TIMING BELT COVER	
01-02-10286	MD191947	GASKET , TIMING BELT COVER	
01-02-10287	PW502900	STRAINER,ENG OIL PAN	
01-02-10288	MD183238	GASKET,OIL STRAINER	

01-02-10289	MD327703	CRANKSHAFT	
01-02-10290	MD117083	BOLT,CONNROD	
01-02-10291	MD312667	CONNECTING ROD ASSY	
01-02-10292	MD143090	BEARING,CONNROD	
01-02-10293	PC112108	PISTON & PIN ASSY	
01-02-10294	PC112110	PISTON & PIN ASSY	
01-02-10295	PC112109	PISTON & PIN ASSY	
01-02-10296	PC112106	PISTON & PIN ASSY	
01-02-10297	MD030628	FLYWHEEL	
01-02-10298	MD195747	NUT,CONNROD	
01-02-10299	MD154779	PULLEY,CRANKSHAFT	
01-02-10300	MD143090	BEARING SET,CONNROD	
01-02-10301	MD145529	PULLEY,CRANKSHAFT DAMPER	
01-02-10302	MD158551	RING SET,PISTON	
01-02-10303	MD158552	RING SET,PISTON	
01-02-10304	MD158549	RING SET,PISTON	
01-02-10305	MD158553	RING SET,PISTON	
01-02-10306	MD149625	SPROCKET,CRANKSHAFT CAMSHAFT	
01-02-10307	MD180084	CAMSHAFT	
01-02-10308	MD145813	BELT,VALVE TIMING	
01-02-10309	MD160442	SPRING,VALVE TIMING BELT TEN	
01-02-10310	MD146186	TENSIONER,VALVE TIMING BELT	
01-02-10311	MD140050	ROCKER ARM,INLET & EXHAUST V	
01-02-10312	MD140049	ROCKER ARM,INLET & EXHAUST V	
01-02-10313	MD140048	ROCKER ARM,INLET VALVE	
01-02-10314	MD140047	ROCKER ARM,INLET VALVE	
01-02-10315	MD166811	SHAFT,INLET VALVE ROCKER ARM	
01-02-10316	MD166812	SHAFT,EXHAUST VALVE ROCKER A	
01-02-10317	MD019845	ADJUSTING SCREW,ROCKER ARM	
01-02-10318	MD000961	NUT,ROCKER ARM ADJUSTING SCR	
01-02-10319	MD016482	RETAINER,VALVE SPRING	
01-02-10320	MD082530	RETAINER,VALVE SPRING	
01-02-10321	MD128434	VALVE,INLET	
01-02-10322	MD128435	VALVE,INLET	
01-02-10323	MD016495	SEAT,VALVE SPRING	
01-02-10324	MD147965	SEAT,VALVE SPRING	
01-02-10325	MD139602	SPRING,INLET & EXHAUST VALVE	
01-02-10326	MD139603	SPRING,INLET & EXHAUST VALVE	
01-02-10327	MD149314	VALVE,EXHAUST	
01-02-10328	MD307343	SEAL,VALVE STEM	
01-02-10329	MD016483	LOCK,VALVE SPRING RETAINER	
01-02-10330	PW510276	SWITCH,ENG OIL PRESSURE	
01-02-10331	PW510829	BRACKET,ENG FR MOUNTING	
01-02-10332	MB176637	NUT,ENG SUPPORT ROD	
01-02-10333	MB288462	NUT,ENG MOUNTING	
01-02-10334	MD171177	CASE ASSY,CYLINDER BLOCK,FR	
01-02-10335	MD191423	GASKET,ENG FR CASE	
01-02-10336	MD372248	OIL SEAL,CRANKSHAFT,FR	
01-02-10337	MD136704	GEAR,ENG OIL PUMP DRIVE	
01-02-10338	MD136705	GEAR,ENG OIL PUMP DRIVEN	
01-02-10339	MD000312	GASKET,ENG OIL PUMP INR	
01-02-10340	PW510253	OIL FILTER	
01-02-10341	MB885661	FUEL TANK ASSY	
01-02-10342	MR271610	CAP,FUEL TANK	
01-02-10343	MB129895	FILTER,FUEL IN TANK	
01-02-10344	MB382513	GASKET,FUEL TANK GAUGE	
01-02-10345	MB890033	STRAINER,FUEL	
01-02-10346	MB857430	TUBE,BRAKE MAIN,LH	
01-02-10347	MB857431	TUBE,BRAKE MAIN,RH	
01-02-10348	MS660236	CLIP,FUEL LINE	

01-02-10349	MD176202	FUEL PUMP ASSY	
01-02-10350	MS642599	HOSE,FUEL PUMP BREATHER	
01-02-10351	MD302639	GASKET,FUEL PUMP	
01-02-10352	MD119633	INSULATOR,FUEL PUMP MOUNTING	
01-02-10353	MD006598	HOSE KIT,FUEL PUMP FUEL FEED	
01-02-10354	MD154368	TUBE,FUEL PUMP BREATHER	
01-02-10355	MF450405	WASHER,FUEL PUMP	
01-02-10356	MF430005	NUT,FUEL PUMP	
01-02-10357	MD109230	CLAMP,FUEL PUMP	
01-02-10358	MD184461	CARBURETOR ASSY	
01-02-10359	MD615066	BOOT,CARB ACCEL PUMP PLUNGER	
01-02-10360	MD615430	GASKET KIT,CARB	
01-02-10361	MD193668	GASKET,CARB	
01-02-10362	MD193667	GASKET,CARB	
01-02-10363	MD615338	FLOAT & PIN KIT,CARB	
01-02-10364	MD188448	INSULATOR,CARB HEAT	
01-02-10365	MD615336	PLUG KIT,CARB	
01-02-10366	MD615337	PLUG KIT,CARB	
01-02-10367	MD615332	PLUNGER KIT,CARB ACCEL PUMP	
01-02-10368	MD615331	ROD KIT,CARB ACCEL PUMP	
01-02-10369	MD615345	ADJUSTING SCREW KIT,FAST IDL	
01-02-10370	MD615339	ADJUSTING SCREW KIT,CARB MIX	
01-02-10371	MD615344	ADJUSTING SCREW KIT,CARB SPE	
01-02-10372	MD325073	STUD,CARB	
01-02-10373	MD615322	NEEDLE VALVE KIT,CARB FLOAT	
01-02-10374	MD615329	VALVE,CARB FUEL CUT-OFF SOLE	
01-02-10375	MD615365	BRACKET KIT,CARB ACCEL CABLE	
01-02-10376	MD615427	CHAMBER,CARB SUCTION	
01-02-10377	MD615482	COMPENSATOR KIT,CARB THROTTL	
01-02-10378	MD615368	SPRING SET,CARB THROTTLE COM	
01-02-10379	MD615367	GASKET,CARB THROTTLE COMPENS	
01-02-10380	MD615424	ADAPTER,CARB VACUUM HOSE	
01-02-10381	MD615431	GASKET,CARB VACUUM HOSE ADAP	
01-02-10382	MD615325	SPRING,CARB MAIN JET	
01-02-10383	MD615319	BOWL,CARB FLOAT	
01-02-10384	MD615363	GASKET,CARB FLOAT BOWL	
01-02-10385	MD615434	CAP,CARB INR	
01-02-10386	MD615327	SCREW,CARB INR	
01-02-10387	MD601663	SCREW,CARB INR	
01-02-10388	MD615323	SCREW,CARB INR	
01-02-10389	MD615326	SCREW,CARB INR	
01-02-10390	MD615324	SCREW,CARB INR	
01-02-10391	MD601460	SCREW,CARB INR	
01-02-10392	MD615343	SCREW,CARB INR	
01-02-10393	MD601959	SNAP RING,CARB INR	
01-02-10394	MF241262	BOLT,CARB	
01-02-10395	MF101226	BOLT,CARB	
01-02-10396	MD615397	HOSE,CARB INR	
01-02-10397	MB539798	ARM,ACCEL PEDAL	
01-02-10398	MB539799	BRACKET,ACCEL PEDAL ARM	
01-02-10399	MB539803	SPRING,ACCEL PEDAL ARM RETUR	
01-02-10400	MB844837	STOPPER,ACCEL PEDAL ARM	
01-02-10401	PW521033	CABLE,ACCEL	
01-02-10402	MB539804	SPACER,ACCEL CONTROL EQUIP	
01-02-10403	MF522405	SNAP RING,ACCEL CONTROL EQUI	
01-02-10404	MB539801	PIN,ACCEL CONTROL EQUIP	
01-02-10405	MS440503	NUT,ACCEL CONTROL EQUIP	
01-02-10406	MB539809	CLIP,ACCEL CONTROL EQUIP	
01-02-10407	MS240179	BOLT,ACCEL CONTROL EQUIP	
01-02-10408	MS240121	BOLT,ACCEL CONTROL EQUIP	

01-02-10409	PW521091	RADIATOR ASSY	
01-02-10410	MB660667	CAP,RADIATOR	
01-02-10411	PW501831	HOSE,RADIATOR CONDENSER TANK	
01-02-10412	MS612798	HOSE,RADIATOR CONDENSER TANK	
01-02-10413	MB660610V1	HOSE,RADIATOR,LWR	
01-02-10414	MB845944V1	HOSE,RADIATOR,UPR	
01-02-10415	MB660630	INSULATOR,RADIATOR SUPPORT,U	
01-02-10416	MB660637	INSULATOR,RADIATOR SUPPORT,L	
01-02-10417	PW530210	PLUG ASSY,RADIATOR	
01-02-10418	MB660663	SENSOR, RADIATOR WATER TEMPE	
01-02-10419	PW530222	SHROUD,COOLING FAN	
01-02-10420	MB845120	TANK ASSY,RADIATOR CONDENSER	
01-02-10421	PW521101	BOLT,RADIATOR	
01-02-10422	PW530225	BOLT,RADIATOR	
01-02-10423	PW530217	NUT,RADIATOR	
01-02-10424	PW530211	O-RING,RADIATOR	
01-02-10425	MS240125	BOLT,RADIATOR SUPPORT	
01-02-10426	PW530223	FAN,COOLING	
01-02-10427	PW530224	MOTOR,COOLING FAN	
01-02-10428	MS660205	CLIP,RADIATOR CONDENSER TANK	
01-02-10429	MS240398	BOLT,RADIATOR CONDENSER TANK	
01-02-10430	MS660027	CLIP,RADIATOR PIPING	
01-02-10431	MA609112	CLIP,RADIATOR PIPING	
01-02-10432	PC141106	WATER PUMP KIT	
01-02-10433	MD171757	GASKET,WATER PUMP	
01-02-10434	MD300872	PULLEY,WATER PUMP	
01-02-10435	PW510580	V-RIBBED BELT,WATER PUMP & A	
01-02-10436	MF140239	BOLT,WATER PUMP	
01-02-10437	MF140028	BOLT,WATER PUMP	
01-02-10438	MF241223	BOLT,COOLING FAN	
01-02-10439	MD182975	PIPE,WATER PUMP INLET	
01-02-10440	MS660256	CLIP,COOLING WATER LINE	
01-02-10441	MS660236	CLIP,COOLING WATER LINE	
01-02-10442	MF140021	BOLT,COOLING WATER LINE	
01-02-10443	MD030764	O-RING,COOLING WATER LINE	
01-02-10444	MD182986	HOSE,INLET MANIFOLD WATER BY	
01-02-10445	MD191456	HOSE,CARB WATER RETURN	
01-02-10446	MD155835	HOSE,CARB WATER FEED	
01-02-10447	MD091056	GAUGE UNIT,WATER TEMPERATURE	
01-02-10448	MD620518	BODY ASSY,AIR CLEANER	
01-02-10449	PW510200	ELEMENT,AIR CLEANER	
01-02-10450	MD147567	GASKET,AIR CLEANER TO CARB	
01-02-10451	MD167028	JET,AIR CLEANER VACUUM	
01-02-10452	MD620888	COVER,AIR CLEANER	
01-02-10453	MD300252	HEAT DUCT,AIR CLEANER	
01-02-10454	MD620848	GASKET,AIR CLEANER TEMPERATU	
01-02-10455	PW510207	GASKET,AIR CLEANER TEMPERATU	
01-02-10456	MD177976	DUCT,AIR CLEANER INTAKE	
01-02-10457	PW510203	INSULATOR,AIR CLEANER SUPPOR	
01-02-10458	MD620541	COMPENSATOR,AIR CLEANER IDLE	
01-02-10459	MD180104	PRE-CLEANER ASSY,AIR CLEANER	
01-02-10460	MD620814	SENSOR,AIR CLEANER AIR TEMPE	
01-02-10461	MD604726	PAN,PRE-CLEANER DUST	
01-02-10462	MD001865	TERMINAL,AIR CLEANER VACUUM	
01-02-10463	MD620241	GROMMET,AIR CLEANER	
01-02-10464	MF350024	SCREW,AIR CLEANER INR	
01-02-10465	MS632599	HOSE,AIR CLEANER INR	
01-02-10466	MS632599	HOSE,AIR CLEANER INR	
01-02-10467	MS632599	HOSE,AIR CLEANER INR	
01-02-10468	MS632599	HOSE,AIR CLEANER INR	

01-02-10469	MS610499	TUBE,AIR CLEANER	
01-02-10470	MF450154	WASHER,AIR CLEANER	
01-02-10471	MD620242	WASHER,AIR CLEANER	
01-02-10472	MF453033	SCREW,AIR CLEANER	
01-02-10473	MD154913	NUT,AIR CLEANER	
01-02-10474	MS440503	NUT,AIR CLEANER	
01-02-10475	PW510204	COLLAR,AIR CLEANER	
01-02-10476	MD021443	CLAMP,AIR CLEANER	
01-02-10477	MD137524	CLAMP,AIR CLEANER	
01-02-10478	MF240051	BOLT,AIR CLEANER	
01-02-10479	MD016967	ENGINE HANGER	
01-02-10480	MD137517	ENGINE HANGER	
01-02-10481	MD150880	FITTING,WATER OUTLET HOSE	
01-02-10482	MD158870	MANIFOLD,INLET	
01-02-10483	MD192249	GASKET,INLET MANIFOLD	
01-02-10484	MD076961	JOINT,INLET MANIFOLD	
01-02-10485	MD143990	STAY,INLET MANIFOLD	
01-02-10486	MF450405	WASHER,INLET MANIFOLD	
01-02-10487	MS661142	PLUG,INLET MANIFOLD	
01-02-10488	MF430005	NUT,INLET MANIFOLD	
01-02-10489	MD088093	NIPPLE,INLET MANIFOLD	
01-02-10490	MD008484	NIPPLE,INLET MANIFOLD	
01-02-10491	MD305458	NIPPLE,INLET MANIFOLD	
01-02-10492	MD026761	CAP,INLET MANIFOLD	
01-02-10493	MF241256	BOLT,INLET MANIFOLD	
01-02-10494	MF140056	BOLT,INLET MANIFOLD	
01-02-10495	MD160789	MANIFOLD,EXHAUST	
01-02-10496	MD179704	COVER,EXHAUST MANIFOLD	
01-02-10497	MD172613	COVER,EXHAUST MANIFOLD	
01-02-10498	MS450035	WASHER,EXHAUST MANIFOLD	
01-02-10499	MR258655	STUD,EXHAUST MANIFOLD	
01-02-10500	MF402585	STUD,EXHAUST MANIFOLD	
01-02-10501	MD000569	NUT,EXHAUST MANIFOLD	
01-02-10502	MD067956	BOLT,EXHAUST MANIFOLD	
01-02-10503	MF247862	BOLT,EXHAUST MANIFOLD	
01-02-10504	MF140221	BOLT,EXHAUST MANIFOLD	
01-02-10505	MB687021	GASKET,EXHAUST PIPE	
01-02-10506	MB687002	GASKET,EXHAUST PIPE	
01-02-10507	MB687012	GASKET,EXHAUST PIPE	
01-02-10508	MB514690	COLLAR,EXHAUST PIPE	
01-02-10509	MB059333	NUT,EXHAUST PIPE	
01-02-10510	MF244882	BOLT,EXHAUST PIPE	
01-02-10511	MS240116	BOLT,EXHAUST PIPE	
01-02-10512	MF241286	BOLT,EXHAUST PIPE	
01-02-10513	MF244859	BOLT,EXHAUST PIPE	
01-02-10514	PW530069	PIPE,EXHAUST,FR	
01-02-10515	MB857464	PIPE,EXHAUST,CTR	
01-02-10516	MR127640	HANGER,EXHAUST MUFFLER	
01-02-10517	MR127639	HANGER,EXHAUST MUFFLER	
01-02-10518	MR127638	HANGER,EXHAUST MUFFLER	
01-02-10519	PW530151	MUFFLER,EXHAUST MAIN	
01-02-10520	MR106133	PROTECTOR,UNDER FR FLOOR HEA	
01-02-10521	MF243623	BOLT,FLOOR HEAT PROTECTOR	
01-02-10522	MD153516	VALVE,PURGE CONTROL	
01-02-10523	MD136205	VALVE,EGR	
01-02-10524	MD119127	GASKET,EGR VALVE	
01-02-10525	MD041839	CHECK VALVE,EMISSION CONTROL	
01-02-10526	MD186355	THERMO-VALVE,EMISSION CONTRO	
01-02-10527	MD165547	THERMO-VALVE,EMISSION CONTRO	
01-02-10528	MB906358	HOSE & PIPE ASSY,EMISSION VA	

01-02-10529	MF140202	BOLT,EMISSION CONTROL EQUIP	
01-02-10530	MB249339	BAND,EMISSION CONTROL EQUIP	
01-02-10531	MF241263	BOLT,EGR EQUIP	
01-02-10532	PW501777	STARTER ASSY	
01-02-10533	MD618445	ARMATURE,STARTER	
01-02-10534	PC160101	BRACKET,STARTER,FR	
01-02-10535	MD607927	BRACKET,STARTER,RR	
01-02-10536	MD611372	CLUTCH,STARTER OVERRUNNING	
01-02-10537	MD607926	HOLDER ASSY,STARTER BRUSH	
01-02-10538	MD607921	LEVER KIT,STARTER PINION SHI	
01-02-10539	MD607887	SCREW SET,STARTER INR	
01-02-10540	PC160102	STOPPER KIT,STARTER PINION	
01-02-10541	MD618581	SWITCH KIT,STARTER MAGNETIC	
01-02-10542	MD607896	SWITCH SET,STARTER ARMATURE,	
01-02-10543	MD611366	YOKE,STARTER	
01-02-10544	MD607922	BOLT,STARTER INR	
01-02-10545	MF140269	BOLT,STARTER	
01-02-10546	MF140270	BOLT,STARTER	
01-02-10547	PW501783	STARTER ASSY	
01-02-10548	MD604518	ARMATURE,STARTER	
01-02-10549	MD604520	HOUSING ASSY STARTER	
01-02-10550	MD604521	FRAME ASSY,STARTER END	
01-02-10551	MD604522	HOLDER ASSY,STARTER BRUSH	
01-02-10552	MD604917	LEVER STARTER DRIVE	
01-02-10553	MD604524	SWITCH ASSY,STARTER MAGNETIC	
01-02-10554	MD604911	YOKE,STARTER	
01-02-10555	MF140269	BOLT,STARTER	
01-02-10556	PW536095	ALTERNATOR ASSY	
01-02-10557	MD618679	BEARING,ALTERNATOR ROTOR	
01-02-10558	MD611928	BEARING,ALTERNATOR ROTOR	
01-02-10559	PW510646	BRACE,ALTERNATOR ADJUSTING	
01-02-10560	PC161102	BRACKET ASSY,ALTERNATOR,FR	
01-02-10561	PC161104	BRACKET ASSY,ALTERNATOR,RR	
01-02-10562	PC161101	PULLEY,ALTERNATOR	
01-02-10563	MD611776	RECTIFIER,ALTERNATOR	
01-02-10564	MD618696	REGULATOR,ALTERNATOR	
01-02-10565	PC161103	ROTOR ASSY,ALTERNATOR	
01-02-10566	PC161105	SCREW SET,ALTERNATOR INR	
01-02-10567	MD618905	STATOR,ALTERNATOR	
01-02-10568	MF450005	WASHER,ALTERNATOR	
01-02-10569	MF450405	WASHER,ALTERNATOR	
01-02-10570	PW510649	NUT,ALTERNATOR	
01-02-10571	MF430005	NUT,ALTERNATOR	
01-02-10572	MD133180	BOLT,ALTERNATOR	
01-02-10573	MF140233	BOLT,ALTERNATOR	
01-02-10574	MD021662	BOLT,ALTERNATOR	
01-02-10575	MD159279	DISTRIBUTOR ASSY	
01-02-10576	MD618392	ADVANCER,DISTRIBUTOR VACUUM	
01-02-10577	MD618283	CAP ASSY,DISTRIBUTOR	
01-02-10578	MD618291	CABLE,DISTRIBUTOR LEAD	
01-02-10579	MD618823	COVER,DISTRIBUTOR BREAKER	
01-02-10580	MD618284	ROTOR,DISTRIBUTOR	
01-02-10581	MD618393	HOUSING ASSY,DISTRIBUTOR	
01-02-10582	MD618292	O-RING,DISTRIBUTOR	
01-02-10583	MD618290	PICKUP KIT,DISTRIBUTOR	
01-02-10584	MD618293	IGNITER KIT,DISTRIBUTOR	
01-02-10585	MD618287	SCREW SET,DISTRIBUTOR	
01-02-10586	MD129546	SUPPORT,DISTRIBUTOR SPARK PL	
01-02-10587	MD618315	CLAMP,DISTRIBUTOR INR	
01-02-10588	MD102178	WASHER,DISTRIBUTOR	



01-02-10589	MF434114	NUT,DISTRIBUTOR	
01-02-10590	MF140228	BOLT,DISTRIBUTOR	
01-02-10591	MD180171	CABLE SET,SPARK PLUG	
01-02-10592	MD180172	CABLE,SPARK PLUG,NO.1	
01-02-10593	MD180173	CABLE,SPARK PLUG,NO.2	
01-02-10594	MD180174	CABLE,SPARK PLUG,NO.3	
01-02-10595	MD180175	CABLE,SPARK PLUG,NO.4	
01-02-10596	MS851182LP	SPARK PLUG	
01-02-10597	MD120820	CLAMP,SPARK PLUG CABLE	
01-02-10598	MD113566	RELAY BATTERY	
01-02-10599	MD706185	CLIP,CLUTCH RELEASE BEARING	
01-02-10600	PW550013	BEARING,CLUTCH RELEASE	
01-02-10601	MD715179	SEAL,CLUTCH RELEASE FORK SHA	
01-02-10602	MD717936	SEAL,CLUTCH RELEASE FORK SHA	
01-02-10603	MD730293	SHAFT & FORK,CLUTCH RELEASE	
01-02-10604	MD715273	SPRING,CLUTCH RELEASE FORK R	
01-02-10605	PW550165	COVER ASSY,CLUTCH	
01-02-10606	PW550246	DISC,CLUTCH	
01-02-10607	MF472629	SPRING PIN,M/T CLUTCH CONTRO	
01-02-10608	MD741639	BRACKET,M/T CLUTCH CONTROL E	
01-02-10609	PW521070	CABLE ASSY,CLUTCH	
01-02-10610	MB012582	INSULATOR,CLUTCH OTR CABLE	
01-02-10611	MU510001	PIN,CLUTCH CONTROL EQUIP	
01-02-10612	MB249339	BAND,CLUTCH CONTROL EQUIP	
01-02-10613	MD971035	MANUAL TRANSAXLE ASSY	
01-02-10614	MD997740	LIQUID GASKET,M/T	
01-02-10615	MD701721	OIL SEAL,CLUTCH RELEASE FORK	
01-02-10616	MF241223	BOLT,T/M CONNECTING	
01-02-10617	MD706012	BOLT,T/M CONNECTING	
01-02-10618	MF140021	BOLT,T/M CONNECTING	
01-02-10619	MF241251	BOLT,T/M CONNECTING	
01-02-10620	MF140266	BOLT,T/M CONNECTING	
01-02-10621	MF140271	BOLT,T/M CONNECTING	
01-02-10622	MD740892	BOLT,T/M CONNECTING	
01-02-10623	MD744772	CASE,M/T	
01-02-10624	MD742208	BRACKET,M/T CASE MOUNTING	
01-02-10625	MD733296	BREATHER,M/T CASE	
01-02-10626	MD741751	COVER,M/T CASE BREATHER HOLE	
01-02-10627	MD732462	COVER,M/T CASE 5TH GEAR	
01-02-10628	MD725064	HOLDER,M/T CASE MAGNET	
01-02-10629	MD955485	MAGNET,M/T CASE	
01-02-10630	MD000312	GASKET,M/T CASE PLUG	
01-02-10631	MD701850	PLUG,M/T CASE	
01-02-10632	MD728088	PLUG,M/T CASE	
01-02-10633	MF472405	PIN,M/T CASE	
01-02-10634	MD741559	OIL GUIDE,M/T CASE	
01-02-10635	MD721067	OIL GUIDE,M/T CASE	
01-02-10636	MF660036	GASKET,M/T CASE	
01-02-10637	MF241253	BOLT,M/T CASE	
01-02-10638	MD736249	BOLT,M/T CASE	
01-02-10639	MD734702	BOLT,M/T CASE	
01-02-10640	MD736249	BOLT,M/T CASE	
01-02-10641	MF241288	BOLT,M/T CASE	
01-02-10642	MF241308	BOLT,M/T CASE	
01-02-10643	MD747079	HOUSING,CLUTCH	
01-02-10644	MD735926	RETAINER,CLUTCH HOUSING FR B	
01-02-10645	MF241308	BOLT,T/M MOUNTING	
01-02-10646	MD751609	BRACKET,T/M CASE ROLL STOPPE	
01-02-10647	MD742588	BRACKET,T/M CASE ROLL STOPPE	
01-02-10648	MD741818	OIL SEAL,M/T INPUT SHAFT	

01-02-10649	PW550023	BEARING,M/T GEARSHIFT SHAFT	
01-02-10650	MD718557	BOOT,M/T GEARSHIFT SHAFT	
01-02-10651	MD747660	OIL SEAL,M/T GEARSHIFT SHAFT	
01-02-10652	MD707184	OIL SEAL,T/M FR DIFF CASE	
01-02-10653	MD741834	GEAR,SPEEDOMETER DRIVEN	
01-02-10654	MD741325	O-RING,SPEEDOMETER DRIVEN GE	
01-02-10655	MD741303	OIL SEAL,SPEEDOMETER DRIVEN	
01-02-10656	MD741302	SLEEVE,SPEEDOMETER DRIVEN GE	
01-02-10657	MF140004	BOLT,SPEEDOMETER GEAR	
01-02-10658	MD722948	BEARING,M/T INPUT SHAFT	
01-02-10659	MD719136	BEARING,M/T INPUT SHAFT	
01-02-10660	MD719318	BEARING,M/T INPUT SHAFT	
01-02-10661	MD719137	BEARING,M/T INPUT SHAFT	
01-02-10662	PW550016	BEARING,M/T INPUT SHAFT	
01-02-10663	MD747734	SHAFT,M/T INPUT	
01-02-10664	MD748579	GEAR,M/T INPUT SHAFT 3RD SPE	
01-02-10665	MD743237	GEAR,M/T INPUT SHAFT 4TH SPE	
01-02-10666	MD742828	GEAR,M/T INPUT SHAFT 5TH SPE	
01-02-10667	MD719138	SLEEVE,M/T INPUT SHAFT 4TH G	
01-02-10668	MD732111	SLEEVE,M/T INPUT SHAFT 5TH G	
01-02-10669	MD719308	SPACER,M/T INPUT SHAFT	
01-02-10670	MD731428	SPACER,M/T INPUT SHAFT	
01-02-10671	MD730510	GEAR CLUSTER,M/T INTERMEDIAT	
01-02-10672	MD742764	GEAR,M/T INTERMEDIATE SHAFT	
01-02-10673	MD742764	GEAR,M/T INTERMEDIATE SHAFT	
01-02-10674	MD748575	GEAR,M/T INTERMEDIATE SHAFT	
01-02-10675	MD748575	GEAR,M/T INTERMEDIATE SHAFT	
01-02-10676	MD730505	GEAR,M/T INTERMEDIATE SHAFT	
01-02-10677	PW550018	BEARING,M/T INTERMEDIATE GEA	
01-02-10678	MD718033	BEARING,M/T INTERMEDIATE GEA	
01-02-10679	PW550020	BEARING,M/T INTERMEDIATE GEA	
01-02-10680	MD719302	SLEEVE,M/T INTERMEDIATE SHAF	
01-02-10681	MD736750	SPACER,M/T INTERMEDIATE SHAF	
01-02-10682	MD736751	SPACER,M/T INTERMEDIATE SHAF	
01-02-10683	MD718511	SPACER,M/T INTERMEDIATE SHAF	
01-02-10684	MD720969	SPACER,M/T INTERMEDIATE SHAF	
01-02-10685	MD720970	SPACER,M/T INTERMEDIATE SHAF	
01-02-10686	MD720971	SPACER,M/T INTERMEDIATE SHAF	
01-02-10687	MD720972	SPACER,M/T INTERMEDIATE SHAF	
01-02-10688	MD720973	SPACER,M/T INTERMEDIATE SHAF	
01-02-10689	MD720974	SPACER,M/T INTERMEDIATE SHAF	
01-02-10690	MD730415	SHAFT,M/T OUTPUT	
01-02-10691	MD707506	BEARING,M/T OUTPUT SHAFT	
01-02-10692	PW550022	BEARING,M/T OUTPUT SHAFT	
01-02-10693	MD747736	GEAR,M/T REV IDLER	
01-02-10694	MD744091	SHAFT,M/T REV IDLER GEAR	
01-02-10695	MD720947	SPACER,M/T OUTPUT SHAFT	
01-02-10696	MD720956	SPACER,M/T OUTPUT SHAFT	
01-02-10697	MD720957	SPACER,M/T OUTPUT SHAFT	
01-02-10698	MD720958	SPACER,M/T OUTPUT SHAFT	
01-02-10699	MD720959	SPACER,M/T OUTPUT SHAFT	
01-02-10700	MD720960	SPACER,M/T OUTPUT SHAFT	
01-02-10701	MD720961	SPACER,M/T OUTPUT SHAFT	
01-02-10702	MD720962	SPACER,M/T OUTPUT SHAFT	
01-02-10703	MD712346	SPACER,M/T OUTPUT SHAFT	
01-02-10704	MD712347	SPACER,M/T OUTPUT SHAFT	
01-02-10705	MD712348	SPACER,M/T OUTPUT SHAFT	
01-02-10706	MD712349	SPACER,M/T OUTPUT SHAFT	
01-02-10707	MD736756	SPACER,M/T OUTPUT SHAFT	
01-02-10708	MD720948	SPACER,M/T OUTPUT SHAFT	

01-02-10709	MD720949	SPACER,M/T OUTPUT SHAFT	
01-02-10710	MD720950	SPACER,M/T OUTPUT SHAFT	
01-02-10711	MD720951	SPACER,M/T OUTPUT SHAFT	
01-02-10712	MD720952	SPACER,M/T OUTPUT SHAFT	
01-02-10713	MD720953	SPACER,M/T OUTPUT SHAFT	
01-02-10714	MD720954	SPACER,M/T OUTPUT SHAFT	
01-02-10715	MD720955	SPACER,M/T OUTPUT SHAFT	
01-02-10716	MD749412	HUB & SLEEVE,M/T 1ST & 2ND S	
01-02-10717	MD749415	HUB & SLEEVE,M/T 3RD & 4TH S	
01-02-10718	MD747639	HUB & SLEEVE,M/T 5TH SYNCH	
01-02-10719	MD723919	PLATE,M/T 5TH SYNCH HUB STOP	
01-02-10720	MD742441	SPRING,M/T SYNCH KEY	
01-02-10721	MD742441	SPRING,M/T SYNCH KEY	
01-02-10722	MD739066	SPRING,M/T SYNCH KEY	
01-02-10723	MD745892	RING,M/T SYNCH	
01-02-10724	MD745890	RING,M/T SYNCH	
01-02-10725	MD745891	RING,M/T SYNCH	
01-02-10726	MD745893	RING,M/T SYNCH	
01-02-10727	MD745892	RING,M/T SYNCH	
01-02-10728	MD748663	KEY,M/T SYNCH	
01-02-10729	MD742776	KEY,M/T SYNCH	
01-02-10730	MD742778	KEY,M/T SYNCH	
01-02-10731	MD770987	CASE,M/T DIFF	
01-02-10732	MD716594	BEARING,M/T DIFF CASE	
01-02-10733	MD770492	GEAR,M/T DIFF DRIVE	
01-02-10734	MD722125	GEAR KIT,M/T DIFF	
01-02-10735	MB185340	SPACER SET,M/T DIFF SIDE GEA	
01-02-10736	MD707530	SHAFT,M/T DIFF PINION	
01-02-10737	MD727658	SPACER,M/T DIFF	
01-02-10738	MD710458	SPACER,M/T DIFF	
01-02-10739	MD727660	SPACER,M/T DIFF	
01-02-10740	MD727659	SPACER,M/T DIFF	
01-02-10741	MD720943	SPACER,M/T DIFF	
01-02-10742	MD710454	SPACER,M/T DIFF	
01-02-10743	MD710456	SPACER,M/T DIFF	
01-02-10744	MD710460	SPACER,M/T DIFF	
01-02-10745	MD720937	SPACER,M/T DIFF	
01-02-10746	MD720940	SPACER,M/T DIFF	
01-02-10747	MA111369	WASHER,M/T POWER TRAIN	
01-02-10748	MD706537	SNAP RING,M/T POWER TRAIN	
01-02-10749	MD706538	SNAP RING,M/T POWER TRAIN	
01-02-10750	MD706539	SNAP RING,M/T POWER TRAIN	
01-02-10751	MD703779	SNAP RING,M/T POWER TRAIN	
01-02-10752	MD703781	SNAP RING,M/T POWER TRAIN	
01-02-10753	MD703780	SNAP RING,M/T POWER TRAIN	
01-02-10754	MD730785	SNAP RING,M/T POWER TRAIN	
01-02-10755	MD730786	SNAP RING,M/T POWER TRAIN	
01-02-10756	MD730787	SNAP RING,M/T POWER TRAIN	
01-02-10757	MD730788	SNAP RING,M/T POWER TRAIN	
01-02-10758	MD730834	SNAP RING,M/T POWER TRAIN	
01-02-10759	MD730835	SNAP RING,M/T POWER TRAIN	
01-02-10760	MD706557	PIN,M/T POWER TRAIN	
01-02-10761	MD718035	NUT,M/T POWER TRAIN	
01-02-10762	MD720603	GASKET,M/T POWER TRAIN	
01-02-10763	MD749478	BOLT,M/T POWER TRAIN	
01-02-10764	MD040557	BOLT,M/T POWER TRAIN	
01-02-10765	PW550090	SWITCH,M/T GEARSHIFT BACKUP	
01-02-10766	MD734488	BALL UNIT,M/T GEARSHIFT EQUI	
01-02-10767	MD723339	COVER,M/T SELECT SHAFT	
01-02-10768	MD713757	COVER,M/T SELECT SHAFT	

01-02-10769	MD735237	FORK,M/T GEARSHIFT 5TH	
01-02-10770	MD720082	FORK,M/T GEARSHIFT 1ST & 2ND	
01-02-10771	MD741558	FORK,M/T GEARSHIFT 3RD & 4TH	
01-02-10772	MD738513	LEVER,M/T GEARSHIFT REV	
01-02-10773	MD721253	LEVER,M/T SELECT SHAFT	
01-02-10774	MD736074	LUG,M/T GEARSHIFT REV RAIL	
01-02-10775	MD747314	PLATE,M/T GEARSHIFT SHAFT ST	
01-02-10776	MD749481	RAIL,M/T GEARSHIFT 1ST & 2ND	
01-02-10777	MD741568	RAIL,M/T GEARSHIFT 3RD & 4TH	
01-02-10778	MD749955	RAIL,M/T GEARSHIFT 5TH & REV	
01-02-10779	MD740893	SHAFT KIT,M/T GEARSHIFT	
01-02-10780	MD719188	SHAFT,M/T SELECT LEVER	
01-02-10781	MD735927	SHOE,M/T REV SHIFT LEVER	
01-02-10782	MD712919	SHOE,M/T SELECT LEVER	
01-02-10783	MD720248	STOPPER KIT,M/T GEARSHIFT SH	
01-02-10784	MD742416	BRACKET,M/T GEARSHIFT CABLE	
01-02-10785	MD740179	PLATE,M/T GEARSHIFT INTERLOC	
01-02-10786	MD720908	PLUNGER,M/T GEARSHIFT RAIL I	
01-02-10787	MD749757	SPRING,M/T GEARSHIFT ADJUSTI	
01-02-10788	MD718370	SPRING,M/T GEARSHIFT NEUTRAL	
01-02-10789	MD717899	SPRING,M/T GEARSHIFT NEUTRAL	
01-02-10790	MF472572	SPRING PIN,M/T GEARSHIFT EQU	
01-02-10791	MF472535	SPRING PIN,M/T GEARSHIFT EQU	
01-02-10792	MD713416	WASHER,M/T GEARSHIFT EQUIP	
01-02-10793	MD723290	WASHER,M/T GEARSHIFT EQUIP	
01-02-10794	MF450154	WASHER,M/T GEARSHIFT EQUIP	
01-02-10795	MF450405	WASHER,M/T GEARSHIFT EQUIP	
01-02-10796	MD771797	SPRING,M/T GEARSHIFT EQUIP	
01-02-10797	MD701722	PIN,M/T GEARSHIFT EQUIP	
01-02-10798	MD705490	PIN,M/T GEARSHIFT EQUIP	
01-02-10799	MD746241	PIN,M/T GEARSHIFT EQUIP	
01-02-10800	MF430005	NUT,M/T GEARSHIFT EQUIP	
01-02-10801	MF660035	GASKET,M/T GEARSHIFT EQUIP	
01-02-10802	MD720602	GASKET,M/T GEARSHIFT EQUIP	
01-02-10803	MD719165	BUSHING,M/T GEARSHIFT EQUIP	
01-02-10804	MD717881	BRACKET,M/T GEARSHIFT EQUIP	
01-02-10805	MF241252	BOLT,M/T GEARSHIFT EQUIP	
01-02-10806	MD717876	BOLT,M/T GEARSHIFT EQUIP	
01-02-10807	MD717883	BOLT,M/T GEARSHIFT EQUIP	
01-02-10808	MF241255	BOLT,M/T GEARSHIFT EQUIP	
01-02-10809	MD723985	BOLT,M/T GEARSHIFT EQUIP	
01-02-10810	MF540011	BALL,M/T GEARSHIFT EQUIP	
01-02-10811	MB659934	LEVER,GEARSHIFT	
01-02-10812	MB970269	KNOB,GEARSHIFT LEVER	
01-02-10813	MB870574	PIECE,GEARSHIFT LEVER BRACKE	
01-02-10814	MB659954	PIPE,GEARSHIFT LEVER	
01-02-10815	MB367323	SEAT,GEARSHIFT LWR LEVER RET	
01-02-10816	MB659938	LEVER,GEARSHIFT LINK,LWR	
01-02-10817	MB659932	LEVER,GEARSHIFT LINK,UPR	
01-02-10818	MB871926	SPRING,GEARSHIFT LINK LEVER	
01-02-10819	MB871927	COLLAR,GEARSHIFT LINK	
01-02-10820	MF522004	SNAP RING,GEARSHIFT LINK	
01-02-10821	MF472038	PIN,GEARSHIFT LINK	
01-02-10822	MS440503	NUT,GEARSHIFT LINK	
01-02-10823	MF430726	NUT,GEARSHIFT LINK	
01-02-10824	MF430005	NUT,GEARSHIFT LINK	
01-02-10825	MF450154	WASHER,GEARSHIFT LINK	
01-02-10826	MF450406	WASHER,GEARSHIFT LINK	
01-02-10827	MB367720	WASHER,GEARSHIFT LINK	
01-02-10828	MF450405	WASHER,GEARSHIFT LINK	

01-02-10829	MF450154	WASHER,GEARSHIFT LINK	
01-02-10830	MB180001	WASHER,GEARSHIFT LINK	
01-02-10831	MB367526	CLIP,GEARSHIFT LINK	
01-02-10832	MB580253	BUSHING,GEARSHIFT LINK	
01-02-10833	MB307949	BUSHING,GEARSHIFT LINK	
01-02-10834	MB367320	BUSHING,GEARSHIFT LINK	
01-02-10835	MR103559	BUSHING,GEARSHIFT LINK	
01-02-10836	MB949743	BUSHING,GEARSHIFT LINK	
01-02-10837	MB949744	BUSHING,GEARSHIFT LINK	
01-02-10838	MD749843	BRACKET,GEARSHIFT LINK	
01-02-10839	MU240081	BOLT,GEARSHIFT LINK	
01-02-10840	MF103174	BOLT,GEARSHIFT LINK	
01-02-10841	MB249338	BAND,GEARSHIFT LINK	
01-02-10842	MB659931	CABLE,GEARSHIFT	
01-02-10843	PW550185	BOOT KIT,FR AXLE JOINT,LH/RH	
01-02-10844	PW550189	BOOT KIT,FR AXLE SHAFT,LH/RH	
01-02-10845	PW550191	DAMPER KIT,FR AXLE DYNAMIC,L	
01-02-10846	PW550190	DAMPER KIT,FR AXLE DYNAMIC,R	
01-02-10847	PW550187	JOINT & SHAFT KIT,FR AXLE,LH	
01-02-10848	PW550188	JOINT & SHAFT KIT,FR AXLE,RH	
01-02-10849	PW550186	JOINT KIT,FR AXLE SHAFT,LH/RH	
01-02-10850	PW550157	SHAFT ASSY,FR AXLE DRIVE,LH	
01-02-10851	PW550159	SHAFT ASSY,FR AXLE DRIVE,RH	
01-02-10852	MF472085	PIN,FR AXLE	
01-02-10853	MB109029	NUT,FR AXLE	
01-02-10854	MB109025	WASHER,FR AXLE	
01-02-10855	MB526340	CLIP,FR AXLE	
01-02-10856	MB526340	CLIP,FR AXLE	
01-02-10857	MB844465	KNUCKLE,LH	
01-02-10858	MB844466	KNUCKLE,RH	
01-02-10859	MB911495	BOLT,FR WHEEL HUB	
01-02-10860	MB518761	BOLT,FR WHEEL HUB	
01-02-10861	MB808442	BEARING,FR WHEEL HUB	
01-02-10862	MB948961	HUB ASSY,FR WHEEL	
01-02-10863	MB808443	OIL SEAL,FR WHEEL HUB,INR	
01-02-10864	MB808444	OIL SEAL,FR WHEEL HUB,OTR	
01-02-10865	MB808445	SNAP RING,FR WHEEL HUB	
01-02-10866	MB573720	NUT,FR WHEEL HUB	
01-02-10867	MR449769	DISC,FR BRAKE	
01-02-10868	MB857768	COVER,FR BRAKE DISC,LH	
01-02-10869	MB857769	COVER,FR BRAKE DISC,RH	
01-02-10870	MB911495	BOLT,RR WHEEL HUB	
01-02-10871	MB809360	CAP,RR WHEEL HUB	
01-02-10872	PC272502	HUB ASSY,RR WHEEL	
01-02-10873	MB584600	NUT,RR WHEEL HUB	
01-02-10874	MF200075	SCREW,RR WHEEL HUB	
01-02-10875	MB699290	DRUM,RR BRAKE	
01-02-10876	MB870009	CLAMP,SPARE TIRE CARRIER	
01-02-10877	MB871295	CAP,DISC WHEEL FULL	
01-02-10878	MB057636	NUT,WHEEL	
01-02-10879	MB871285	WHEEL,DISC	
01-02-10880	MR102687	DAMPER,FR AXLE CROSSMEMBER D	
01-02-10881	MR130413	MEMBER,FR AXLE,CTR	
01-02-10882	PW530618	CROSSMEMBER,FR AXLE,NO.1	
01-02-10883	MB176661	BOLT,FR AXLE CROSSMEMBER	
01-02-10884	MB176660	BOLT,FR AXLE CROSSMEMBER	
01-02-10885	MR102863	BOLT,FR AXLE CROSSMEMBER	
01-02-10886	MB673240	NUT,FR AXLE CROSSMEMBER	
01-02-10887	MB844447	COLLAR,FR AXLE CROSSMEMBER	
01-02-10888	MB844447	COLLAR,FR AXLE CROSSMEMBER	

01-02-10889	MB844445	BUSHING,FR AXLE CROSSMEMBER	
01-02-10890	MB844446	BUSHING,FR AXLE CROSSMEMBER	
01-02-10891	MB808264	BRACKET,FR SUSP LWR ARM,RR	
01-02-10892	MB176047	COVER,FR SUSP LWR ARM BALL J	
01-02-10893	MB892823	ARM ASSY,FR SUSP,LWR LH	
01-02-10894	MB892824	ARM ASSY,FR SUSP,LWR RH	
01-02-10895	MU431503	NUT,FR SUSP LWR ARM	
01-02-10896	MS440003	NUT,FR SUSP LWR ARM	
01-02-10897	MB518762	BOLT,FR SUSP LWR ARM	
01-02-10898	MR102860	BOLT,FR SUSP LWR ARM	
01-02-10899	MB808909	BUSHING,FR SUSP LWR ARM,LH	
01-02-10900	MB808910	BUSHING,FR SUSP LWR ARM,RH	
01-02-10901	MB518957	DAMPER,FR SUSP STRUT	
01-02-10902	MB109960	COVER,FR SUSP STRUT	
01-02-10903	MB303070	COVER,FR SUSP STRUT	
01-02-10904	MB808306	INSULATOR,FR SUSP STRUT	
01-02-10905	PW531333	STRUT,FR SUSP,LH	
01-02-10906	PW531334	STRUT,FR SUSP,RH	
01-02-10907	MU431503	NUT,FR SUSP STRUT	
01-02-10908	MF434105	NUT,FR SUSP STRUT	
01-02-10909	MB808305	SEAT,FR SUSP SPRING,UPR	
01-02-10910	PW531330	SPRING,FR SUSP COIL	
01-02-10911	PW531336	BAR,FR SUSP STABILIZER	
01-02-10912	MB844457	BRACKET,FR SUSP STABILIZER B	
01-02-10913	MB241974	LINK KIT,FR SUSP STABILIZER	
01-02-10914	MB142761	BOLT,FR SUSP STABILIZER	
01-02-10915	PW531338	BUSHING,FR SUSP STABILIZER	
01-02-10916	MB844817	CAP,RR SUSP STRUT HOSE	
01-02-10917	MB809285	DAMPER,RR SUSP STRUT	
01-02-10918	MB809280	PAD,RR SUSP SPRING,UPR	
01-02-10919	MB910873	SPRING,RR SUSP COIL	
01-02-10920	PW550293	ARM ASSY,RR SUSP,LWR LH	
01-02-10921	PW550294	ARM ASSY,RR SUSP,LWR RH	
01-02-10922	MB809335	BOLT,RR SUSP LWR ARM	
01-02-10923	MB809342	BOLT,RR SUSP LWR ARM	
01-02-10924	PW530954	ARM ASSY,RR SUSP,UPR LH	
01-02-10925	PW530955	ARM ASSY,RR SUSP,UPR RH	
01-02-10926	MB809338	PLATE,RR SUSP LWR ARM	
01-02-10927	MB809284	COVER,RR SUSP STRUT	
01-02-10928	PW550297	ARM ASSY,RR SUSP TRAILING,LH	
01-02-10929	PW550298	ARM ASSY,RR SUSP TRAILING,RH	
01-02-10930	MR102063	BUSHING,INDEPENDENT RR SUSP	
01-02-10931	MB809345	BOLT,INDEPENDENT RR SUSP ARM	
01-02-10932	MU431503	NUT,RR SUSP UPR ARM	
01-02-10933	MB809342	BOLT,RR SUSP UPR ARM	
01-02-10934	MF240082	BOLT,RR SUSP UPR ARM	
01-02-10935	MF430123	NUT,RR SUSP LWR ARM	
01-02-10936	MU431503	NUT,RR SUSP LWR ARM	
01-02-10937	MS450044	WASHER,RR SUSP LWR ARM	
01-02-10938	MR244851	BUSHING,RR SUSP LWR ARM	
01-02-10939	MR130231	BUSHING,RR SUSP COIL SPRING	
01-02-10940	MR130230	BUSHING,RR SUSP COIL SPRING	
01-02-10941	MB809281	CUP,RR SHOCK ABSORBER	
01-02-10942	MB809285	DAMPER,RR SHOCK ABSORBER	
01-02-10943	MB911185	SHOCK ABSORBER,RR SUSP	
01-02-10944	MB871321	SHOCK ABSORBER,RR SUSP	
01-02-10945	MB910847	INSULATOR,RR SUSP STRUT	
01-02-10946	MB910847	INSULATOR,RR SHOCK ABSORBER	
01-02-10947	MB809335	BOLT,RR SUSP ASSIST LINK	
01-02-10948	MF240081	BOLT,RR SUSP ASSIST LINK	

01-02-10949	MF430123	NUT,RR SUSP ASSIST LINK	
01-02-10950	MS450044	WASHER,RR SUSP ASSIST LINK	
01-02-10951	PW530952	LINK,RR SUSP ASSIST (LH)	
01-02-10952	PW530953	LINK,RR SUSP ASSIST(RH)	
01-02-10953	MB809338	PLATE,RR SUSP ASSIST LINK	
01-02-10954	MB871748	COLLAR,RR SUSP COIL SPRING	
01-02-10955	MB242360	WASHER,RR SUSP COIL SPRING	
01-02-10956	MF434105	NUT,RR SUSP COIL SPRING	
01-02-10957	MS440002	NUT,RR SUSP COIL SPRING	
01-02-10958	MU431503	NUT,RR SUSP COIL SPRING	
01-02-10959	MB809342	BOLT,RR SUSP COIL SPRING	
01-02-10960	MB806050	CABLE,PARKING BRAKE,RR LH	
01-02-10961	MB806051	CABLE,PARKING BRAKE,RR RH	
01-02-10962	MB520377	EQUALIZER,PARKING BRAKE CABL	
01-02-10963	MB806058	CLAMP,PARKING BRAKE CABLE	
01-02-10964	MB256401	CLAMP,PARKING BRAKE CABLE	
01-02-10965	MB806059	CLAMP,PARKING BRAKE CABLE	
01-02-10966	PW531238	LEVER ASSY,PARKING BRAKE (PH	
01-02-10967	MB895092	SWITCH,PARKING BRAKE	
01-02-10968	MF522406	SNAP RING,PARKING BRAKE CABL	
01-02-10969	MS440503	NUT,PARKING BRAKE CABLE	
01-02-10970	MB520917	GROMMET,PARKING BRAKE CABLE	
01-02-10971	MS240085	BOLT,PARKING BRAKE CABLE	
01-02-10972	MS240085	BOLT,PARKING BRAKE LEVER	
01-02-10973	MF240001	BOLT,PARKING BRAKE LEVER	
01-02-10974	MR205677	BLEEDER,FR BRAKE CALIPER	
01-02-10975	MB699472	SEAL KIT,FR BRAKE CALIPER PI	
01-02-10976	MB928424	CALIPER KIT,FR BRAKE,LH	
01-02-10977	MB928425	CALIPER KIT,FR BRAKE,RH	
01-02-10978	MA140440	CAP,FR BRAKE CALIPER BLEEDER	
01-02-10979	MB699475	PISTON,FR BRAKE CALIPER	
01-02-10980	PW530557	PAD SET,FR BRAKE	
01-02-10981	MR389605	CLIP KIT,FR BRAKE	
01-02-10982	MR389645	SHIM KIT,FR BRAKE	
01-02-10983	MF450407	WASHER,FR BRAKE	
01-02-10984	MB295548	PLUG,FR BRAKE	
01-02-10985	MB134808	PIN,FR BRAKE	
01-02-10986	MB193958	PIN,FR BRAKE	
01-02-10987	MR205902	BOLT,FR BRAKE	
01-02-10988	MB668488	LEVER,PARKING BRAKE OPERATIN	
01-02-10989	MB668489	LEVER,PARKING BRAKE OPERATIN	
01-02-10990	MB618298	BLEEDER,RR BRAKE WHEEL CYLIN	
01-02-10991	MB134975	CUP & BOOT KIT,RR BRAKE WHEE	
01-02-10992	MB618981	CYLINDER ASSY,RR BRAKE WHEEL	
01-02-10993	MB618981	CYLINDER ASSY,RR BRAKE WHEEL	
01-02-10994	MB668480	ADJUSTER,RR BRAKE SHOE SLACK	
01-02-10995	MB668481	ADJUSTER,RR BRAKE SHOE SLACK	
01-02-10996	MT100169	CUP,RR BRAKE SHOE HOLD-DOWN	
01-02-10997	MB668486	LEVER,RR BRAKE SHOE SLACK AD	
01-02-10998	MB668487	LEVER,RR BRAKE SHOE SLACK AD	
01-02-10999	PC351603	SHOE SET,RR BRAKE	
01-02-11000	MB618204	SPRING,RR BRAKE SHOE HOLD-DO	
01-02-11001	MB618201	SPRING,RR BRAKE SHOE RETAINE	
01-02-11002	MB668458	SPRING,RR BRAKE SHOE TO LEVE	
01-02-11003	MB668457	SPRING,RR BRAKE SHOE TO SHOE	
01-02-11004	MA151648	RETAINER,RR BRAKE CHAMBER	
01-02-11005	MB668738	PLATE,RR BRAKE BACKING,LH	
01-02-11006	MB668739	PLATE,RR BRAKE BACKING,RH	
01-02-11007	MA151645	PLUG,RR BRAKE	
01-02-11008	MB618205	PLUG,RR BRAKE	

01-02-11009	MS450043	WASHER,RR BRAKE	
01-02-11010	MA151647	WASHER,RR BRAKE	
01-02-11011	MT107344	PIN,RR BRAKE	
01-02-11012	MR205904	BOLT,RR BRAKE	
01-02-11013	MF241223	BOLT,RR BRAKE	
01-02-11014	MV026287	CAP,RR BRAKE	
01-02-11015	MB857402	BOOSTER ASSY,BRAKE	
01-02-11016	MA140192	FITTING,BRAKE BOOSTER VACUUM	
01-02-11017	MB857399	HOSE,BRAKE BOOSTER VACUUM	
01-02-11018	MB857405	HOSE,BRAKE BOOSTER VACUUM	
01-02-11019	MB238089	SEAL,BRAKE BOOSTER BODY	
01-02-11020	MB151106	WASHER,BRAKE BOOSTER	
01-02-11021	MF473492	PIN,BRAKE BOOSTER	
01-02-11022	MF472042	PIN,BRAKE BOOSTER	
01-02-11023	MS440503	NUT,BRAKE BOOSTER	
01-02-11024	MB058828	CLIP,BRAKE BOOSTER	
01-02-11025	PW530424	HOSE,RR BRAKE BODY SIDE	
01-02-11026	MB699322	TUBE,RR AXLE BRAKE,LH	
01-02-11027	MB699323	TUBE,RR AXLE BRAKE,RH	
01-02-11028	MA431825	CLIP,RR AXLE BRAKE TUBE	
01-02-11029	PW530423	HOSE,FR BRAKE	
01-02-11030	MS440503	NUT,BRAKE FLUID LINE	
01-02-11031	MB316561	GROMMET,BRAKE FLUID LINE	
01-02-11032	MA111832	GASKET,BRAKE FLUID LINE	
01-02-11033	MB618507	CLIP,BRAKE FLUID LINE	
01-02-11034	MB344587	CLIP,BRAKE FLUID LINE	
01-02-11035	MB082162	CLIP,BRAKE FLUID LINE	
01-02-11036	MB500569	CLIP,BRAKE FLUID LINE	
01-02-11037	MB668000	CLIP,BRAKE FLUID LINE	
01-02-11038	MB344587	CLIP,BRAKE FLUID LINE	
01-02-11039	MB344693	CLIP,BRAKE FLUID LINE	
01-02-11040	MB082326	EYEBOLT,BRAKE FLUID LINE	
01-02-11041	MS240121	BOLT,BRAKE FLUID LINE	
01-02-11042	MF240050	BOLT,BRAKE FLUID LINE	
01-02-11043	MS240121	BOLT,BRAKE FLUID LINE	
01-02-11044	PW510511	VALVE,BRAKE FLUID PROPORTION	
01-02-11045	MB857410	TUBE,BRAKE M/CYL PRIMARY	
01-02-11046	MB857411	TUBE,BRAKE M/CYL SECONDARY	
01-02-11047	MB857412	TUBE,FR BRAKE,LH	
01-02-11048	MB857413	TUBE,FR BRAKE,RH	
01-02-11049	MB807258	PEDAL,CLUTCH	
01-02-11050	PW502132	PAD,CLUTCH PEDAL	
01-02-11051	MB003682	BUSHING,CLUTCH PEDAL	
01-02-11052	PW502143	STOPPER,CLUTCH PEDAL	
01-02-11053	MF450008	WASHER,CLUTCH PEDAL	
01-02-11054	MF451107	WASHER,CLUTCH PEDAL	
01-02-11055	MF522005	SNAP RING,CLUTCH PEDAL	
01-02-11056	MS440503	NUT,CLUTCH PEDAL	
01-02-11057	MB500966	BUSHING,BRAKE PEDAL	
01-02-11058	MB003682	BUSHING,BRAKE PEDAL	
01-02-11059	MA126093	PAD,BRAKE PEDAL	
01-02-11060	MB807255	PEDAL,BRAKE	
01-02-11061	MB911101	SPRING,BRAKE PEDAL RETURN	
01-02-11062	MB500595	STOPPER,BRAKE PEDAL	
01-02-11063	MB807265	SPACER,BRAKE PEDAL	
01-02-11064	MF450406	WASHER,BRAKE PEDAL	
01-02-11065	MF430006	NUT,BRAKE PEDAL	
01-02-11066	MS240125	BOLT,BRAKE PEDAL	
01-02-11067	MB911455	BOLT,BRAKE PEDAL	
01-02-11068	MB911499	MEMBER,PEDAL SUPPORT	



01-02-11069	MB435457	SWITCH,STOP LAMP	
01-02-11070	MR128397	CYLINDER ASSY,BRAKE MASTER	
01-02-11071	MB534349	COLLAR,BRAKE M/CYL	
01-02-11072	MB928822	COLLAR,BRAKE M/CYL	
01-02-11073	PC356302	CYLINDER KIT,BRAKE MASTER	
01-02-11074	MB151326	FLOAT,BRAKE M/CYL FLUID RESE	
01-02-11075	PW510348	SEAL,BRAKE M/CYL TO FLUID RE	
01-02-11076	PW510341	STOPPER,BRAKE M/CYL SECONDAR	
01-02-11077	MF450405	WASHER,BRAKE M/CYL	
01-02-11078	MR129264	NUT,BRAKE M/CYL	
01-02-11079	MB058362	CLIP,BRAKE M/CYL	
01-02-11080	MB534289	BOLT,BRAKE M/CYL INR	
01-02-11081	MF243623	BOLT,BRAKE M/CYL	
01-02-11082	MF140021	BOLT,BRAKE M/CYL	
01-02-11083	MB857391	BRACKET,BRAKE FLUID RESERVOI	
01-02-11084	PW510508	CAP,BRAKE FLUID RESERVOIR TA	
01-02-11085	PW510509	DIAPHRAGM,BRAKE FLUID RESERV	
01-02-11086	MB534534	RESERVOIR ASSY,BRAKE FLUID	
01-02-11087	MB618382	SWITCH,BRAKE FLUID LEVEL IND	
01-02-11088	MB082024	HOSE,BRAKE M/CYL FLUID RESER	
01-02-11089	MB082024	HOSE,BRAKE M/CYL FLUID RESER	
01-02-11090	PC370104	PAD,STEERING WHEEL	
01-02-11091	MB970402DB	WHEEL ASSY,STEERING	
01-02-11092	MU431503	NUT,STEERING WHEEL	
01-02-11093	MS350125	SCREW,STEERING WHEEL	
01-02-11094	PC370101	MARK,STEERING PAD	
01-02-11095	PW521108	COLUMN ASSY,STEERING	
01-02-11096	MR102620	COVER,STEERING COLUMN DASH P	
01-02-11097	MB898850	COVER,STEERING COLUMN,LWR	
01-02-11098	MB898854	COVER,STEERING COLUMN,UPR	
01-02-11099	MB892528	BAND,STEERING COLUMN INR	
01-02-11100	MS240147	BOLT,STEERING COLUMN	
01-02-11101	MB532373	BOLT,STEERING COLUMN	
01-02-11102	MS240122	BOLT,STEERING COLUMN	
01-02-11103	MS240147	BOLT,STEERING COLUMN	
01-02-11104	MS450042	WASHER,STEERING COLUMN	
01-02-11105	MB891128	WASHER,STEERING COLUMN	
01-02-11106	PW530587	SPACER,STEERING COLUMN INR	
01-02-11107	MB242069	SCREW,STEERING COLUMN	
01-02-11108	PW530585	SNAP RING,STEERING COLUMN IN	
01-02-11109	MB409439	SCREW,STEERING COLUMN COVER	
01-02-11110	MB522123	GROMMET,STEERING COLUMN COVE	
01-02-11111	PW530588	BEARING,STEERING COLUMN SHAF	
01-02-11112	PW530586	STOPPER,STEERING SHAFT BEARI	
01-02-11113	PW530576	LEVER,STEERING COLUMN ADJUST	
01-02-11114	PW510879	BAND,STEERING GEAR	
01-02-11115	PW510878	BAND,STEERING GEAR	
01-02-11116	PW510881	BELLOWS,STEERING GEAR	
01-02-11117	MB266706	BRACKET,STEERING GEAR MOUNTI	
01-02-11118	MB315258	BRACKET,STEERING GEAR MOUNTI	
01-02-11119	PC370501	CUSHION,STEERING GEAR	
01-02-11120	MB864381	CUSHION,STEERING GEAR	
01-02-11121	MF472054	PIN,STEERING GEAR	
01-02-11122	PW530090	O-RING,STEERING GEAR,INR	
01-02-11123	MB122128	NUT,STEERING GEAR	
01-02-11124	MF430123	NUT,STEERING GEAR	
01-02-11125	MS240118	BOLT,STEERING GEAR	
01-02-11126	PW550279	GEAR & LINK ASSY,P/S	
01-02-11127	PW510185	END ASSY,TIE ROD	
01-02-11128	PW510190	COVER,TIE ROD END	

01-02-11129	PW550281	TIE ROD,STEERING	
01-02-11130	PW530085	TUBE,P/S CYLINDER OIL FEED	
01-02-11131	PW530086	TUBE,P/S CYLINDER OIL FEED	
01-02-11132	MB815091	BRACKET,P/S OIL PUMP	
01-02-11133	PW530569	OIL PUMP ASSY,P/S	
01-02-11134	MR272335	CAP,P/S OIL RESERVOIR	
01-02-11135	MB350950	FILTER,P/S OIL RESERVOIR	
01-02-11136	MB815094	RESERVOIR ASSY,P/S OIL	
01-02-11137	MF241251	BOLT,P/S OIL PUMP	
01-02-11138	MF244880	BOLT,P/S OIL PUMP	
01-02-11139	MF244882	BOLT,P/S OIL PUMP	
01-02-11140	MS240121	BOLT,P/S OIL PUMP	
01-02-11141	MB553549	LABEL,P/S OIL PUMP RESERVOIR	
01-02-11142	MB815123	HOSE,P/S OIL PUMP SUCTION	
01-02-11143	PW530421	HOSE,P/S OIL PRESSURE	
01-02-11144	MB864589	HOSE,P/S OIL RETURN	
01-02-11145	MR130053	HOLDER,P/S OIL HOSE	
01-02-11146	MB010721	HOSE,P/S OIL RETURN CONNECTI	
01-02-11147	MB010722	HOSE,P/S OIL RETURN CONNECTI	
01-02-11148	MB501603	TUBE,P/S OIL RETURN	
01-02-11149	MR198056	TUBE,P/S OIL RETURN	
01-02-11150	MR198054	TUBE,P/S OIL COOLER	
01-02-11151	MB864590	TUBE,P/S OIL PRESSURE	
01-02-11152	MF450407	WASHER,P/S OIL LINE	
01-02-11153	MF430727	NUT,P/S OIL LINE	
01-02-11154	MR198029	CLIP,P/S OIL LINE	
01-02-11155	MB407206	CLIP,P/S OIL LINE	
01-02-11156	MR223376	CLIP,P/S OIL LINE	
01-02-11157	MS660166	CLIP,P/S OIL LINE	
01-02-11158	MS660168	CLIP,P/S OIL LINE	
01-02-11159	MR198030	CLIP,P/S OIL LINE	
01-02-11160	MB636996	CLAMP,P/S OIL LINE	
01-02-11161	MB636997	CLAMP,P/S OIL LINE	
01-02-11162	MB815136	BRACKET,P/S OIL LINE	
01-02-11163	MS240095	BOLT,P/S OIL LINE	
01-02-11164	MS240085	BOLT,P/S OIL LINE	
01-02-11165	MB950259	O-RING,P/S OIL LINE	
01-02-11166	MB192717	O-RING,P/S OIL LINE	
01-02-11167	MB253964	CLIP,FR BUMPER	
01-02-11168	MB271999	CLIP,FR BUMPER	
01-02-11169	MB575451	PAD,FR BUMPER FACE	
01-02-11170	MR106097	FACE,FR BUMPER	
01-02-11171	PW532852	REINFORCEMENT,FR BUMPER	
01-02-11172	MB847340	BRACKET,FR LICENSE PLATE	
01-02-11173	MS452348	SCREW,FR BUMPER	
01-02-11174	MS440502	NUT,FR BUMPER	
01-02-11175	MB481588	GROMMET,FR BUMPER	
01-02-11176	MB131256	BOLT,FR BUMPER	
01-02-11177	MU140011	BOLT,FR BUMPER	
01-02-11178	PW532224	REINFORCEMENT,RR BUMPER	
01-02-11179	MB847463	BRACKET,RR BUMPER SIDE,UPR L	
01-02-11180	MB847464	BRACKET,RR BUMPER SIDE,UPR R	
01-02-11181	MB847587	BRACKET,RR BUMPER SIDE,LWR	
01-02-11182	MB253964	CLIP,RR BUMPER	
01-02-11183	MB547806	CLIP,RR BUMPER	
01-02-11184	MA156028	GASKET,RR BUMPER	
01-02-11185	MB847456	FACE,RR BUMPER	
01-02-11186	MF453030	SCREW,RR BUMPER	
01-02-11187	MS452348	SCREW,RR BUMPER	
01-02-11188	MS440503	NUT,RR BUMPER	

01-02-11189	MS240145	BOLT,RR BUMPER	
01-02-11190	MS240146	BOLT,RR BUMPER	
01-02-11191	MU140011	BOLT,RR BUMPER	
01-02-11192	MB481588	GROMMET,RR BUMPER	
01-02-11193	MB153825	CLIP,RADIATOR GRILLE	
01-02-11194	MB884516	GRILLE,RADIATOR	
01-02-11195	PC421201	HOOD	
01-02-11196	MB819740	CABLE,HOOD LOCK RELEASE	
01-02-11197	MB270408	DAMPER,HOOD	
01-02-11198	MB270607	DAMPER,HOOD	
01-02-11199	MB794164	HANDLE,HOOD LOCK RELEASE	
01-02-11200	PW533789	HANDLE,HOOD LOCK RELEASE (PH	
01-02-11201	MB866525	HINGE,HOOD,LH	
01-02-11202	MB866526	HINGE,HOOD,RH	
01-02-11203	PW532221	LATCH,HOOD	
01-02-11204	MB142761	BOLT,HOOD HINGE	
01-02-11205	MF243650	BOLT,HOOD HINGE	
01-02-11206	PW532121	ROD,HOOD SUPPORT	
01-02-11207	MB884643	WEATHERSTRIP,HOOD,FR LH	
01-02-11208	MB884644	WEATHERSTRIP,HOOD,FR RH	
01-02-11209	MR106454	WEATHERSTRIP,HOOD,RR	
01-02-11210	MF453033	SCREW,HOOD LOCKING	
01-02-11211	MS440503	NUT,HOOD HINGE	
01-02-11212	MU481139	CLIP,HOOD	
01-02-11213	MU481027	CLIP,HOOD	
01-02-11214	MB889048	GROMMET,HOOD LOCKING	
01-02-11215	MU240093	BOLT,HOOD LOCKING	
01-02-11216	MB011808	CLIP,HOOD LOCKING	
01-02-11217	MB889049	CLIP,HOOD LOCKING	
01-02-11218	MU481073	CLIP,HOOD LOCKING	
01-02-11219	MB945551	FENDER,FR LH	
01-02-11220	MB945552	FENDER,FR RH	
01-02-11221	MB945553	BRACKET,FR FENDER,LH	
01-02-11222	MB945554	BRACKET,FR FENDER,RH	
01-02-11223	MS440133	NUT,FR FENDER	
01-02-11224	MS100221	BOLT,FR FENDER	
01-02-11225	MB945556	PANEL,FR END COVER	
01-02-11226	MS240125	BOLT,BODY LOOSE PANEL	
01-02-11227	MB945419	FENDER SHIELD,FR LH	
01-02-11228	MB945420	FENDER SHIELD,FR RH	
01-02-11229	MB945427	FRAME,FR FENDER SHIELD,UPR L	
01-02-11230	MB945428	FRAME,FR FENDER SHIELD,UPR R	
01-02-11231	MB945429	FRAME,FR FENDER SHIELD,UPR O	
01-02-11232	MB945430	FRAME,FR FENDER SHIELD,UPR O	
01-02-11233	MB945431	PLATE,FR FENDER SHIELD,LH	
01-02-11234	MB945432	PLATE,FR FENDER SHIELD,RH	
01-02-11235	MB945425	FRAME,FR FENDER SHIELD,UPR I	
01-02-11236	MB945426	FRAME,FR FENDER SHIELD,UPR I	
01-02-11237	MB945435	GUSSET,FR END,INR LH	
01-02-11238	MB945436	GUSSET,FR END,INR RH	
01-02-11239	MB945437	GUSSET,FR END,OTR LH	
01-02-11240	MB835891	BRACE,FR SIDEMEMBER TO CROSS	
01-02-11241	MB835892	BRACE,FR SIDEMEMBER TO CROSS	
01-02-11242	MB945423	WHEELHOUSE,FR INR LH	
01-02-11243	MB945424	WHEELHOUSE,FR INR RH	
01-02-11244	MB945445	STAY,FR END STRUCTURE	
01-02-11245	MB945441	SUPPORT ASSY,HEADLAMP	
01-02-11246	MB945449	SUPPORT,HEADLAMP,LH	
01-02-11247	MB945450	SUPPORT,HEADLAMP,RH	
01-02-11248	MB945447	PANEL,HEADLAMP SUPPORT,UPR	

01-02-11249	MB945443	PANEL,HEADLAMP SUPPORT,LWR	
01-02-11250	MB945433	SIDE SILL,FR FLOOR,FR INR LH	
01-02-11251	MB945434	SIDE SILL,FR FLOOR,FR INR RH	
01-02-11252	MB945421	SIDEMEMBER ASSY,FR LH	
01-02-11253	MB945422	SIDEMEMBER ASSY,FR RH	
01-02-11254	MB945512	CROSSMEMBER,FR DECK	
01-02-11255	MB945509	EXTENSION,COWL TOP,LH	
01-02-11256	MB945510	EXTENSION,COWL TOP,RH	
01-02-11257	MB945508	PANEL,COWL TOP	
01-02-11258	MB945417	DASH PANEL	
01-02-11259	PW563122	GLASS,WINDSHIELD	
01-02-11260	MB814151	SPACER,WINDSHIELD	
01-02-11261	PC422303	DAM,WINDSHIELD	
01-02-11262	PW534232	MOULDING,WINDSHIELD,UPR	
01-02-11263	MB945513	PANEL,ROOF	
01-02-11264	MB945517	BOW,ROOF	
01-02-11265	MB945518	BOW,ROOF	
01-02-11266	MB945519	BOW,ROOF	
01-02-11267	MB945515	RAIL,ROOF,FR	
01-02-11268	MB945520	RAIL,ROOF,RR	
01-02-11269	MB291893	NUT,FR SIDE STRUCTURE	
01-02-11270	MB945459	PILLAR,CTR LWR INR,LH	
01-02-11271	MB945460	PILLAR,CTR LWR INR,RH	
01-02-11272	MB945457	PILLAR,CTR OTR,LH	
01-02-11273	MB945458	PILLAR,CTR OTR,RH	
01-02-11274	MB945453	PILLAR ASSY,FR LH	
01-02-11275	MB945454	PILLAR ASSY,FR RH	
01-02-11276	MB945475	PANEL,QTR,OTR LH	
01-02-11277	MB945476	PANEL,QTR,OTR RH	
01-02-11278	MB945479	EXTENSION,QTR PANEL,OTR LH	
01-02-11279	MB945480	EXTENSION,QTR PANEL,OTR RH	
01-02-11280	MB945495	PANEL,QTR,INR LH	
01-02-11281	MB945496	PANEL,QTR,INR RH	
01-02-11282	MB945481	EXTENSION,QTR PANEL,LWR OTR	
01-02-11283	MB945482	EXTENSION,QTR PANEL,LWR OTR	
01-02-11284	MB945485	EXTENSION,QTR PANEL,UPR OTR	
01-02-11285	MB945486	EXTENSION,QTR PANEL,UPR OTR	
01-02-11286	MB945489	PILLAR,RR INR LH	
01-02-11287	MB945490	PILLAR,RR INR RH	
01-02-11288	MB945503	PANEL,RR WHEELHOUSE,INR LH	
01-02-11289	MB945504	PANEL,RR WHEELHOUSE,INR RH	
01-02-11290	MB945473	SIDE SILL,FR FLOOR,OTR LH	
01-02-11291	MB945474	SIDE SILL,FR FLOOR,OTR RH	
01-02-11292	MB945567	BRACE,RR WHEELHOUSE INR PANE	
01-02-11293	MB945568	BRACE,RR WHEELHOUSE INR PANE	
01-02-11294	MB945527	PANEL,RR COMBINATION LAMP HO	
01-02-11295	MB945528	PANEL,RR COMBINATION LAMP HO	
01-02-11296	MB945493	BRACE,RR FLOOR SIDE,LH	
01-02-11297	MB945494	BRACE,RR FLOOR SIDE,RH	
01-02-11298	MB945565	BRACE,RR SHELF,LH	
01-02-11299	MB945566	BRACE,RR SHELF,RH	
01-02-11300	MB945563	BRACE,RR SEAT BACK,LH	
01-02-11301	MB945564	BRACE,RR SEAT BACK,RH	
01-02-11302	MB945569	HOOK,RR SEAT	
01-02-11303	MB945463	RAIL,ROOF SIDE,OTR,LH	
01-02-11304	MB945464	RAIL,ROOF SIDE,OTR,RH	
01-02-11305	MB945469	RAIL,ROOF SIDE,INR,LH	
01-02-11306	MB945470	RAIL,ROOF SIDE,INR,RH	
01-02-11307	MB945548	LID,FUEL FILLER	
01-02-11308	MB023335	HOOK,FUEL FILLER LID	

01-02-11309	MS240121	BOLT,FUEL FILLER LID PANEL	
01-02-11310	MB642442	CLIP,FUEL FILLER LID LOCKING	
01-02-11311	MB835845	BRACKET,FUEL TANK,RR LH	
01-02-11312	MB835846	BRACKET,FUEL TANK,RR RH	
01-02-11313	MB945069	HANGER,EXHAUST TAIL PIPE	
01-02-11314	MB945550	HANGER,EXHAUST TAIL PIPE	
01-02-11315	MB945526	BRACKET,SPARE TIRY	
01-02-11316	MB945405	SIDE SILL,FR FLOOR,INR LH	
01-02-11317	MB945404	SIDE SILL,FR FLOOR,INR RH	
01-02-11318	MB945401	CROSSMEMBER,FR FLOOR	
01-02-11319	MB945400	FLOOR,FR	
01-02-11320	MB945402	REINFORCEMENT,FR FLOOR BACKB	
01-02-11321	MB945027	SIDEMEMBER,FR FLOOR	
01-02-11322	MB945028	SIDEMEMBER,FR FLOOR	
01-02-11323	MB945415	BRACKET,RR FLOOR JACK SUPPOR	
01-02-11324	MB861679	CROSSMEMBER,RR FLOOR	
01-02-11325	MB945561	EXTENSION,RR FLOOR SIDEMEMBE	
01-02-11326	MB945562	EXTENSION,RR FLOOR SIDEMEMBE	
01-02-11327	MB945413	FLOOR,RR	
01-02-11328	MB945406	EXTENSION,RR FLOOR	
01-02-11329	MB945411	SIDEMEMBER,RR FLOOR,LH	
01-02-11330	MB945412	SIDEMEMBER,RR FLOOR,RH	
01-02-11331	MB945524	PANEL,RR END	
01-02-11332	MB945448	PANEL,RR SHELF	
01-02-11333	MB567659	SPACER,RR WINDOW	
01-02-11334	MB814156	SPACER,RR WINDOW	
01-02-11335	MB975900	GLASS,RR WINDOW	
01-02-11336	PC422303	DAM,RR WINDOW	
01-02-11337	MB696794	MOULDING,RR WINDOW,LWR	
01-02-11338	PW534234	MOULDING,RR WINDOW,UPR	
01-02-11339	MB814176	CLIP,RR WINDOW MOULDING	
01-02-11340	MB819948	CABLE,FUEL FILLER LID LOCK R	
01-02-11341	PW532153	CABLE,TRUNK LID LOCK RELEASE	
01-02-11342	MB945547	PANEL,TRUNK LID	
01-02-11343	MB926555	DAMPER,TRUNK LID	
01-02-11344	MB402060	DAMPER,TRUNK LID	
01-02-11345	MB960395	HANDLE,TRUNK LID LOCK RELEAS	
01-02-11346	MB945557	HINGE,TRUNK LID,LH	
01-02-11347	MB945558	HINGE,TRUNK LID,RH	
01-02-11348	MB883228	PLATE,TRUNK LID LOCK CYLINDE	
01-02-11349	MB847439	LATCH,TRUNK LID	
01-02-11350	MB197499	STRIKER,TRUNK LID LATCH	
01-02-11351	MB847444	WEATHERSTRIP,TRUNK LID	
01-02-11352	MR106395	TORSION BAR,TRUNK LID,LH	
01-02-11353	MR106396	TORSION BAR,TRUNK LID,RH	
01-02-11354	MS240202	BOLT,TRUNK LID HINGE	
01-02-11355	MS240303	BOLT,TRUNK LID HINGE	
01-02-11356	MU670031	PLUG,TRUNK LID	
01-02-11357	MF453045	SCREW,TRUNK LID LOCKING	
01-02-11358	MS440502	NUT,TRUNK LID LOCKING	
01-02-11359	MB270319	CLIP,TRUNK LID LOCKING	
01-02-11360	MU481073	CLIP,TRUNK LID LOCKING	
01-02-11361	MS240121	BOLT,TRUNK LID LOCKING	
01-02-11362	MS240021	BOLT,TRUNK LID LOCKING	
01-02-11363	MB305211	BAND,TRUNK LID LOCKING	
01-02-11364	MB885647	PANEL,AIR GUIDE	
01-02-11365	PW532117	PANEL,AIR GUIDE,LH	
01-02-11366	PW532118	PANEL,AIR GUIDE,RH	
01-02-11367	MB826679A	COVER,ENG ROOM UNDER,LH	
01-02-11368	MB826680A	COVER,ENG ROOM UNDER,RH	

01-02-11369	MB547806	CLIP,ENG ROOM COVER	
01-02-11370	MU670026	PLUG,ENG ROOM COVER	
01-02-11371	MS452348	SCREW,BODY LOOSE PANEL	
01-02-11372	MS480003	GROMMET,BODY LOOSE PANEL	
01-02-11373	MB344728	CLIP,BODY LOOSE PANEL	
01-02-11374	MB344728	CLIP,BODY LOOSE PANEL	
01-02-11375	MS240121	BOLT,BODY LOOSE PANEL	
01-02-11376	MS240605	BOLT,ENG ROOM COVER	
01-02-11377	MU670033	PLUG,BODY	
01-02-11378	PW532359	PLUG,BODY	
01-02-11379	MU670026	PLUG,BODY	
01-02-11380	MU670024	PLUG,BODY	
01-02-11381	MB406988	PLUG,BODY	
01-02-11382	MU670021	PLUG,BODY	
01-02-11383	MU670031	PLUG,BODY	
01-02-11384	MU670004	PLUG,BODY	
01-02-11385	MU670024	PLUG,BODY	
01-02-11386	MS452348	SCREW,SPLASH SHIELD	
01-02-11387	MB586869	PLUG,SPLASH SHIELD	
01-02-11388	MB138567	GROMMET,SPLASH SHIELD	
01-02-11389	MS480003	GROMMET,SPLASH SHIELD	
01-02-11390	MB344728	CLIP,SPLASH SHIELD	
01-02-11391	MS100242	BOLT,SPLASH SHIELD	
01-02-11392	MB575310	PLUG,FLOOR	
01-02-11393	MB015890	PLUG,FLOOR	
01-02-11394	MT406751	PLUG,FLOOR	
01-02-11395	MB103117	PLUG,FLOOR	
01-02-11396	MU670025	PLUG,FLOOR	
01-02-11397	MT134301	PLUG,FLOOR	
01-02-11398	MU670035	PLUG,FLOOR	
01-02-11399	MU670024	PLUG,FLOOR	
01-02-11400	MB847529	SHIELD,SPLASH,FR LH	
01-02-11401	MB847530	SHIELD,SPLASH,FR RH	
01-02-11402	MB572857	BOLT,STEERING LOCK	
01-02-11403	MB903647	BULB,STEERING LOCK	
01-02-11404	MS200124	SCREW,STEERING LOCK	
01-02-11405	MR182607	SCREW,STEERING LOCK	
01-02-11406	MB903644	SWITCH,ENG STARTING	
01-02-11407	MR142595	SWITCH ASSY,ENG STARTING	
01-02-11408	MB894780	SWITCH,ENG STARTING SWITCH A	
01-02-11409	MR169729	CYLINDER & KEY SET,LOCK	
01-02-11410	MR106403	CYLINDER,FR DOOR LOCK,LH	
01-02-11411	MR106404	CYLINDER,FR DOOR LOCK,RH	
01-02-11412	MR169734	CYLINDER,STEERING LOCK	
01-02-11413	MR106402	CYLINDER,TRUNK LID LOCK	
01-02-11414	MB921971	KEY,BLANK	
01-02-11415	MB885764	RETAINER,DOOR LOCK CYLINDER	
01-02-11416	PC427108	RUBBER WASHER,LOCK CYLINDER	
01-02-11417	PW510630	LABEL,FUEL UNLEADED	
01-02-11418	PW510633	LABEL,TIRE PRESSURE	
01-02-11419	MU240121	BOLT,FR DOOR HINGE	
01-02-11420	MB945531	PANEL ASSY,FR DOOR,LH	
01-02-11421	MB945532	PANEL ASSY,FR DOOR,RH	
01-02-11422	MR106083	SASH,FR DOOR WINDOW,RR LWR L	
01-02-11423	MR106084	SASH,FR DOOR WINDOW,RR LWR R	
01-02-11424	MB574273	HINGE,FR DOOR,LWR LH	
01-02-11425	MB574274	HINGE,FR DOOR,LWR RH	
01-02-11426	MB574274	HINGE,FR DOOR,UPR LH	
01-02-11427	MB574273	HINGE,FR DOOR,UPR RH	
01-02-11428	MF453076	SCREW,FR DOOR	

01-02-11429	MB105489	CLIP,FR DOOR	
01-02-11430	MB819521	CATCH,FR DOOR WINDOW GLASS	
01-02-11431	PW552367	GLASS,FR DOOR WINDOW,LH	
01-02-11432	PW552368	GLASS,FR DOOR WINDOW,RH	
01-02-11433	MB517810	HOLDER,FR DOOR WINDOW GLASS	
01-02-11434	MS240041	BOLT,FR DOOR WINDOW	
01-02-11435	MB365692	CUSHION,FR DOOR	
01-02-11436	MB819673	WEATHERSTRIP,FR DOOR OPENING	
01-02-11437	MB819674	WEATHERSTRIP,FR DOOR OPENING	
01-02-11438	PW532189	WEATHERSTRIP,FR DOOR OPENING	
01-02-11439	PW532190	WEATHERSTRIP,FR DOOR OPENING	
01-02-11440	MB574963	DAMPER,FR DOOR	
01-02-11441	MB819703	SEAL,FR DOOR DELTA,INR	
01-02-11442	MB819701	SEAL,FR DOOR DELTA,OTR	
01-02-11443	MB830079	SEAL,FR DOOR DELTA,OTR	
01-02-11444	PW532226	MOULDING,FR DOOR WINDOW BELT	
01-02-11445	PW532227	MOULDING,FR DOOR WINDOW BELT	
01-02-11446	PW502496	CLIP,FR DOOR WINDOW REGULATO	
01-02-11447	PC431321	MOTOR,FR DOOR POWER WINDOW R	
01-02-11448	PC431323	MOTOR,FR DOOR POWER WINDOW R	
01-02-11449	PC431320	REGULATOR,FR DOOR WINDOW,LH	
01-02-11450	PC431322	REGULATOR,FR DOOR WINDOW,RH	
01-02-11451	MF453048	SCREW,FR DOOR WINDOW REGULAT	
01-02-11452	MB258979	BOLT,FR DOOR WINDOW REGULATO	
01-02-11453	MB819505	CHECK,FR DOOR	
01-02-11454	PW533641	ACTUATOR,FR DOOR,LH	
01-02-11455	PW533642	ACTUATOR,FR DOOR,RH	
01-02-11456	MB960543	COVER,FR DOOR INSIDE HANDLE,	
01-02-11457	MB960544	COVER,FR DOOR INSIDE HANDLE,	
01-02-11458	MB819551	HANDLE,FR DOOR OUTSIDE,LH	
01-02-11459	MB819552	HANDLE,FR DOOR OUTSIDE,RH	
01-02-11460	MB717039	KNOB,FR DOOR INSIDE LOCK	
01-02-11461	MB774548	KNOB,FR DOOR INSIDE LOCK (PH	
01-02-11462	MB827589	ROD,FR DOOR INSIDE HANDLE,LH	
01-02-11463	MB827590	ROD,FR DOOR INSIDE HANDLE,RH	
01-02-11464	MB827593	ROD,FR DOOR INSIDE LOCK,LH	
01-02-11465	MB827594	ROD,FR DOOR INSIDE LOCK,RH	
01-02-11466	MB827587	ROD,FR DOOR OUTSIDE LOCK,LH	
01-02-11467	MB827588	ROD,FR DOOR OUTSIDE LOCK,RH	
01-02-11468	PC431453	ROD,FR DOOR LATCH,LH	
01-02-11469	PC431454	ROD,FR DOOR LATCH,RH	
01-02-11470	MB574974	SHIM,FR DOOR LATCH STRIKER	
01-02-11471	MB626247	STRIKER,FR DOOR LATCH	
01-02-11472	PC431445	LATCH,FR DOOR,LH	
01-02-11473	PC431446	LATCH,FR DOOR,RH	
01-02-11474	MB794018	HANDLE,FR DOOR INSIDE,LH	
01-02-11475	MB794020	HANDLE,FR DOOR INSIDE,RH	
01-02-11476	MB632510	SPRING PIN,FR DOOR LOCKING	
01-02-11477	MB134382	CUSHION,FR DOOR LOCK	
01-02-11478	MS480003	GROMMET,FR DOOR LOCKING	
01-02-11479	MU481193	CLIP,FR DOOR LOCKING	
01-02-11480	MU481194	CLIP,FR DOOR LOCKING	
01-02-11481	MB590537	CLIP,FR DOOR LOCKING	
01-02-11482	MS470433	CLIP ROD	
01-02-11483	MU200075	SCREW,FR DOOR LOCKING	
01-02-11484	MU340023	SCREW,FR DOOR LOCKING	
01-02-11485	MF453047	SCREW,FR DOOR LOCKING	
01-02-11486	MF457292	SCREW,FR DOOR LOCKING	
01-02-11487	MU240062	BOLT,FR DOOR LOCKING	
01-02-11488	MS240055	BOLT,FR DOOR LOCKING	

01-02-11489	MS240040	BOLT,FR DOOR LOCKING	
01-02-11490	MS470434	CLIP ROD	
01-02-11491	MB774547	COVER,FR DOOR INSIDE LOCK KN	
01-02-11492	MB869162	BOX,FR DOOR TRIM	
01-02-11493	PC431601DB	TRIM,FR DOOR,LH	
01-02-11494	PC431607DB	TRIM,FR DOOR,RH	
01-02-11495	MB819649	WEATHERSTRIP,FR DOOR BELT,IN	
01-02-11496	MB819650	WEATHERSTRIP,FR DOOR BELT,IN	
01-02-11497	MB774538	CAP,FR DOOR TRIM SCREW	
01-02-11498	MB774538	CAP,FR DOOR TRIM SCREW (PHAS	
01-02-11499	MB608249	SCREW,FR DOOR TRIM	
01-02-11500	MF453915	SCREW,FR DOOR TRIM	
01-02-11501	MF453093	SCREW,FR DOOR TRIM	
01-02-11502	MF453047	SCREW,FR DOOR TRIM	
01-02-11503	MB817100	GROMMET,FR DOOR TRIM	
01-02-11504	MB692947	GROMMET,FR DOOR TRIM	
01-02-11505	MS480002	GROMMET,FR DOOR TRIM	
01-02-11506	MB851006	CLIP,FR DOOR TRIM	
01-02-11507	PW534049	BRACKET,FR DOOR ARMREST	
01-02-11508	MB365691	CUSHION,RR DOOR	
01-02-11509	MB517810	HOLDER,RR DOOR WINDOW GLASS	
01-02-11510	MU240121	BOLT,RR DOOR HINGE	
01-02-11511	MB945535	PANEL ASSY,RR DOOR,LH	
01-02-11512	MB945536	PANEL ASSY,RR DOOR,RH	
01-02-11513	MB819519	RUNCHANNEL,RR DOOR WINDOW GL	
01-02-11514	MB819520	RUNCHANNEL,RR DOOR WINDOW GL	
01-02-11515	MB819361	HINGE,RR DOOR,LWR LH	
01-02-11516	MB819362	HINGE,RR DOOR,LWR RH	
01-02-11517	MB546471	HINGE,RR DOOR,UPR LH	
01-02-11518	MB546472	HINGE,RR DOOR,UPR RH	
01-02-11519	MF453076	SCREW,RR DOOR	
01-02-11520	MB105489	CLIP,RR DOOR	
01-02-11521	MU240087	BOLT,RR DOOR WINDOW	
01-02-11522	MF201546	SCREW,RR DOOR WINDOW	
01-02-11523	PW552375	GLASS,RR DOOR WINDOW,LH	
01-02-11524	PW552376	GLASS,RR DOOR WINDOW,RH	
01-02-11525	PW552383	GLASS,RR DOOR STATIONARY WIN	
01-02-11526	PW552384	GLASS,RR DOOR STATIONARY WIN	
01-02-11527	MB819639	WEATHERSTRIP,RR DOOR STATION	
01-02-11528	MB819640	WEATHERSTRIP,RR DOOR STATION	
01-02-11529	MB574963	DAMPER,RR DOOR	
01-02-11530	MB819527	SASH,RR DOOR WINDOW,CTR LH	
01-02-11531	MB819528	SASH,RR DOOR WINDOW,CTR RH	
01-02-11532	MB819677	WEATHERSTRIP,RR DOOR OPENING	
01-02-11533	MB819678	WEATHERSTRIP,RR DOOR OPENING	
01-02-11534	PW532115B	WEATHERSTRIP,RR DOOR OPENING	
01-02-11535	PW532116B	WEATHERSTRIP,RR DOOR OPENING	
01-02-11536	PW532228	MOULDING,RR DOOR WINDOW BELT	
01-02-11537	PW532229	MOULDING,RR DOOR WINDOW BELT	
01-02-11538	MR106427	ESCUTCHEON,RR DOOR WINDOW RE	
01-02-11539	MR106424	HANDLE ASSY,RR DOOR WINDOW R	
01-02-11540	PW532141	REGULATOR,RR DOOR WINDOW,LH	
01-02-11541	PW532142	REGULATOR,RR DOOR WINDOW,RH	
01-02-11542	MF453048	SCREW,RR DOOR WINDOW REGULAT	
01-02-11543	MA165425	CLIP,RR DOOR WINDOW REGULATO	
01-02-11544	MB258979	BOLT,RR DOOR WINDOW REGULATO	
01-02-11545	PW533733	ACTUATOR,RR DOOR LOCK	
01-02-11546	MB960543	COVER,RR DOOR INSIDE HANDLE,	
01-02-11547	MB960544	COVER,RR DOOR INSIDE HANDLE,	
01-02-11548	MB134382	CUSHION,RR DOOR INSIDE HANDL	



01-02-11549	MB794018	HANDLE,RR DOOR INSIDE,LH	
01-02-11550	MB794020	HANDLE,RR DOOR INSIDE,RH	
01-02-11551	MB819557	HANDLE,RR DOOR OUTSIDE,LH	
01-02-11552	MB819558	HANDLE,RR DOOR OUTSIDE,RH	
01-02-11553	MB717039	KNOB,RR DOOR INSIDE LOCK	
01-02-11554	MB830391	LATCH,RR DOOR,LH	
01-02-11555	MB830392	LATCH,RR DOOR,RH	
01-02-11556	MB843973	ROD,RR DOOR INSIDE HANDLE,LH	
01-02-11557	MB843974	ROD,RR DOOR INSIDE HANDLE,RH	
01-02-11558	MB830395	ROD,RR DOOR INSIDE LOCK,LH	
01-02-11559	MB830396	ROD,RR DOOR INSIDE LOCK,RH	
01-02-11560	MB843971	ROD,RR DOOR OUTSIDE HANDLE,L	
01-02-11561	MB843972	ROD,RR DOOR OUTSIDE HANDLE,R	
01-02-11562	MB574974	SHIM,RR DOOR LATCH STRIKER	
01-02-11563	MB626247	STRIKER,RR DOOR LATCH	
01-02-11564	MB632510	SPRING PIN,RR DOOR LOCKING	
01-02-11565	MU481090	SNAP,RR DOOR LOCKING	
01-02-11566	MU481091	SNAP,RR DOOR LOCKING	
01-02-11567	MU200075	SCREW,RR DOOR LOCKING	
01-02-11568	MU340028	SCREW,RR DOOR LOCKING	
01-02-11569	MF453047	SCREW,RR DOOR LOCKING	
01-02-11570	MF457292	SCREW,RR DOOR LOCKING	
01-02-11571	MS480003	GROMMET,RR DOOR LOCKING	
01-02-11572	MU481193	CLIP,RR DOOR LOCKING	
01-02-11573	MU481194	CLIP,RR DOOR LOCKING	
01-02-11574	MB590578	CLIP,RR DOOR LOCKING	
01-02-11575	MU481161	CLIP,RR DOOR LOCKING	
01-02-11576	MU240062	BOLT,RR DOOR LOCKING	
01-02-11577	MS240055	BOLT,RR DOOR LOCKING	
01-02-11578	MS240040	BOLT,RR DOOR LOCKING	
01-02-11579	MB517469	CHECK,RR DOOR	
01-02-11580	MB774547	COVER,RR DOOR INSIDE LOCK KN	
01-02-11581	MB774547	COVER,RR DOOR INSIDE LOCK KN	
01-02-11582	MB819653	WEATHERSTRIP,RR DOOR BELT,IN	
01-02-11583	MB819654	WEATHERSTRIP,RR DOOR BELT,IN	
01-02-11584	PC432601DB	TRIM,RR DOOR,LH	
01-02-11585	PC432607DB	TRIM,RR DOOR,RH	
01-02-11586	PW534049	BRACKET,RR DOOR ARMREST	
01-02-11587	MB082944	SCREW,RR DOOR TRIM	
01-02-11588	MF453093	SCREW,RR DOOR TRIM	
01-02-11589	MF453047	SCREW,RR DOOR TRIM	
01-02-11590	MB817100	GROMMET,RR DOOR TRIM	
01-02-11591	MS480002	GROMMET,RR DOOR TRIM	
01-02-11592	MB851006	CLIP,RR DOOR TRIM	
01-02-11593	MB869162	BOX,RR DOOR TRIM	
01-02-11594	PW534223	GARNISH,FR DECK	
01-02-11595	MB662743	CLIP,AIR INLET GRILLE	
01-02-11596	MS470075	CLIP,AIR INLET GRILLE	
01-02-11597	MB814166	CLIP,AIR INLET GRILLE	
01-02-11598	MB814167	CLIP,AIR INLET GRILLE	
01-02-11599	MB696753	MOULDING,FR DOOR PROTECT	
01-02-11600	MB696754	MOULDING,RR DOOR PROTECT	
01-02-11601	MB814170	SPACER,DRIP MOULDING	
01-02-11602	PW534221	MOULDING,DRIP,LH	
01-02-11603	PW534222	MOULDING,DRIP,RH	
01-02-11604	MB814153	CLIP,DRIP MOULDING	
01-02-11605	MB814157	CLIP,DRIP MOULDING	
01-02-11606	MB814152	CLIP,DRIP MOULDING	
01-02-11607	MB814154	CLIP,DRIP MOULDING	
01-02-11608	PW534930	GARNISH,RR END PANEL	

01-02-11609	MB476821	CLIP,RR END PANEL GARNISH	
01-02-11610	MF456097	SCREW,FR MARK	
01-02-11611	MB884244	MARK,PROTON	
01-02-11612	MB884514	MARK,TOP	
01-02-11613	PW555078	MARK,1.5GL	
01-02-11614	MR106617	MARK,WIRA	
01-02-11615	MR106239	MIRROR ASSY,DOOR,LH	
01-02-11616	MR106240	MIRROR ASSY,DOOR,RH	
01-02-11617	MB929659	CAP,RR VIEW MIRROR STAY	
01-02-11618	MB696855	MIRROR & HOLDER DOOR,LH	
01-02-11619	MB696854	MIRROR & HOLDER DOOR,RH	
01-02-11620	MB814101	COVER,DOOR MIRROR DELTA,INR	
01-02-11621	MB814102	COVER,DOOR MIRROR DELTA,INR	
01-02-11622	MB814169	CLIP,RR VIEW MIRROR	
01-02-11623	MS350129	SCREW,RR VIEW MIRROR	
01-02-11624	MB814121	MUD GUARD,FR LH	
01-02-11625	MB814122	MUD GUARD,FR RH	
01-02-11626	MB847559	MUD GUARD,RR LH	
01-02-11627	MB847560	MUD GUARD,RR RH	
01-02-11628	MU440009	NUT,RR MUD GUARD	
01-02-11629	MS240156	BOLT,RR MUD GUARD	
01-02-11630	MS452348	SCREW,RR MUD GUARD	
01-02-11631	PW559725	PANEL,INSTRUMENT	
01-02-11632	PW559739	PAD,INSTRUMENT PANEL	
01-02-11633	PW568121	PANEL,INSTRUMENT CORNER (PHA	
01-02-11634	PW568092	PANEL,INSTRUMENT,LWR	
01-02-11635	PW568042	POCKET,SUNGLASSES	
01-02-11636	MR702038	AIR OUTLET,INSTRUMENT PANEL	
01-02-11637	MR702035	AIR OUTLET,INSTRUMENT PANEL	
01-02-11638	MB975947	AIR OUTLET,INSTRUMENT PANEL,	
01-02-11639	MB972559	ASHTRAY,INSTRUMENT PANEL	
01-02-11640	PW564970	POCKET,INSTRUMENT PANEL	
01-02-11641	MR702123	PAD,INSTRUMENT PANEL,LWR CTR	
01-02-11642	MB869812	BRACKET,INSTRUMENT PANEL SID	
01-02-11643	MB869811	BRACKET,INSTRUMENT PANEL SID	
01-02-11644	MB847689	BRACKET,INSTRUMENT CTR PANEL	
01-02-11645	PW568100	COVER,INSTRUMENT PANEL,LWR L	
01-02-11646	PW568103	COVER,INSTRUMENT PANEL,LWR R	
01-02-11647	PW534199	BRACKET,INSTRUMENT PANEL SID	
01-02-11648	MB803536	BRACKET,INSTRUMENT PANEL SID	
01-02-11649	PW559822	PANEL,INSTRUMENT METER CLUST	
01-02-11650	MB847660	PROTECTOR,INSTRUMENT PANEL	
01-02-11651	MB847665	REINFORCEMENT,INSTRUMENT PAN	
01-02-11652	MB847664	REINFORCEMENT,INSTRUMENT PAN	
01-02-11653	MB847654	REINFORCEMENT,INSTRUMENT PAN	
01-02-11654	PW534889	REINFORCEMENT,INSTRUMENT PAN	
01-02-11655	MB869880	SPRING,INSTRUMENT PANEL SIDE	
01-02-11656	MB652510	SPRING,INSTRUMENT PANEL SIDE	
01-02-11657	PW559813	PANEL,INSTRUMENT,CTR	
01-02-11658	MB603995	GROMMET,INSTRUMENT PANEL	
01-02-11659	MU240027	BOLT,INSTRUMENT PANEL	
01-02-11660	MS240141	BOLT,INSTRUMENT PANEL	
01-02-11661	MB133273	BOLT,INSTRUMENT PANEL	
01-02-11662	MB409438	SCREW,INSTRUMENT PANEL	
01-02-11663	MF453033	SCREW,INSTRUMENT PANEL	
01-02-11664	MS350125	SCREW,INSTRUMENT PANEL	
01-02-11665	MB135995	NUT,INSTRUMENT PANEL	
01-02-11666	MB797966	COVER,GLOVEBOX	
01-02-11667	MB145348	CUSHION,GLOVEBOX	
01-02-11668	PW568130	GLOVEBOX ASSY	

01-02-11669	MB803588	FRAME,GLOVEBOX,LWR	
01-02-11670	MB794168	LOCK,GLOVEBOX	
01-02-11671	PW534255	STRIKER,GLOVEBOX	
01-02-11672	MF453685	SCREW,GLOVEBOX	
01-02-11673	MF453033	SCREW,GLOVEBOX	
01-02-11674	MS350125	SCREW,GLOVEBOX	
01-02-11675	MB135995	NUT,GLOVEBOX	
01-02-11676	MB385409	SPRING,PARCEL BOX	
01-02-11677	MB409438	SCREW,INSTRUMENT PANEL PAD	
01-02-11678	MF453033	SCREW,INSTRUMENT PANEL PAD	
01-02-11679	MF453093	SCREW,INSTRUMENT PANEL PAD	
01-02-11680	MB135995	NUT,INSTRUMENT PANEL PAD	
01-02-11681	MF453033	SCREW,METER BEZEL	
01-02-11682	MF453687	SCREW,METER BEZEL	
01-02-11683	MB135995	NUT,METER BEZEL	
01-02-11684	MB652510	CLIP,METER BEZEL	
01-02-11685	MF453031	SCREW,INSTRUMENT PANEL ASHTR	
01-02-11686	MB135995	NUT,INSTRUMENT PANEL ASHTRAY	
01-02-11687	MB918617	BULB,INSTRUMENT PANEL ASHTRA	
01-02-11688	MB409436	SCREW,INSTRUMENT PANEL AIR O	
01-02-11689	MF453688	SCREW,INSTRUMENT PANEL UNDER	
01-02-11690	MB135995	NUT,INSTRUMENT PANEL UNDER T	
01-02-11691	MB652510	CLIP,INSTRUMENT PANEL UNDER	
01-02-11692	MF453687	SCREW,INSTRUMENT PANEL SIDE	
01-02-11693	MB135995	NUT,INSTRUMENT PANEL SIDE TR	
01-02-11694	MF453685	SCREW,INSTRUMENT PANEL TRIM	
01-02-11695	MF453033	SCREW,INSTRUMENT PANEL TRIM	
01-02-11696	MB409436	SCREW,INSTRUMENT PANEL TRIM	
01-02-11697	MB970382	PLUG,INSTRUMENT PANEL TRIM P	
01-02-11698	PW568184	PLUG,INSTRUMENT PANEL TRIM P	
01-02-11699	MB135995	NUT,INSTRUMENT PANEL TRIM PL	
01-02-11700	MR713623	GRILLE,SIDE DEFROSTER	
01-02-11701	MR713620	GRILLE,SIDE DEFROSTER	
01-02-11702	PW535452	COVER,GEARSHIFT LEVER	
01-02-11703	PW568061	CONSOLE,FLOOR,FR	
01-02-11704	PW535448	LID,FLOOR CONSOLE	
01-02-11705	MB869843	PANEL,GEARSHIFT LEVER	
01-02-11706	MB803659	BRACKET,CONSOLE	
01-02-11707	PW568071	ASHTRAY,FLOOR CONSOLE	
01-02-11708	PW535468	CONSOLE,FLOOR,RR	
01-02-11709	PW535410	PLUG,FLOOR CONSOLE	
01-02-11710	MB847678	REINFORCEMENT,FLOOR CONSOLE,	
01-02-11711	MF453033	SCREW,FLOOR CONSOLE	
01-02-11712	MF453093	SCREW,FLOOR CONSOLE	
01-02-11713	MB409436	SCREW,FLOOR CONSOLE	
01-02-11714	MF453095	SCREW,FLOOR CONSOLE	
01-02-11715	MB135995	NUT,FLOOR CONSOLE	
01-02-11716	MS480012	GROMMET,FLOOR CONSOLE	
01-02-11717	MS240121	BOLT,FLOOR CONSOLE	
01-02-11718	MS350070	SCREW,ASSIST GRIP	
01-02-11719	MB217819	CLIP,ASSIST GRIP	
01-02-11720	MB718134	HOLDER,SUNVISOR	
01-02-11721	PW535216	MIRROR ASSY,ROOM	
01-02-11722	MB178921	SPRING,ROOM MIRROR PLATE	
01-02-11723	PW555434	SUNVISOR,LH	
01-02-11724	PW555023	SUNVISOR,RH	
01-02-11725	MF453929	SCREW,ROOM MIRROR	
01-02-11726	MF454048	SCREW,SUNVISOR	
01-02-11727	MB345647	CAP,ROOF SIDE ASSIST GRIP	
01-02-11728	MB345648	CAP,ROOF SIDE ASSIST GRIP	

01-02-11729	MB345646	GRIP,ROOF INSIDE ASSIST	
01-02-11730	PW555054	HEADLINING	
01-02-11731	MB643846	CLIP,HEADLINING	
01-02-11732	MB817060	CLIP,HEADLINING	
01-02-11733	PW559191	SCUFF PLATE,FR LH	
01-02-11734	PW559193	SCUFF PLATE,FR RH	
01-02-11735	PW559195	SCUFF PLATE,RR LH	
01-02-11736	PW559197	SCUFF PLATE,RR RH	
01-02-11737	MB918592	CLIP,SCUFF PLATE	
01-02-11738	PW559223	TRIM,CTR PILLAR,LWR LH (PHAS	
01-02-11739	PW559225	TRIM,CTR PILLAR,LWR RH (PHAS	
01-02-11740	MB793938	TRIM,CTR PILLAR,UPR LH	
01-02-11741	MB793939	TRIM,CTR PILLAR,UPR RH	
01-02-11742	MR713671	TRIM,FR PILLAR,LH	
01-02-11743	MR713673	TRIM,FR PILLAR,RH	
01-02-11744	MR106129	TRIM,RR PILLAR,LH	
01-02-11745	MR106131	TRIM,RR PILLAR,RH	
01-02-11746	MU470013	CLIP,RR PILLAR TRIM	
01-02-11747	MB619582	CLIP,RR PILLAR TRIM	
01-02-11748	MU470013	CLIP,CTR PILLAR TRIM	
01-02-11749	MU470013	CLIP,FR PILLAR TRIM	
01-02-11750	PW559179	TRIM,COWL SIDE,LH	
01-02-11751	PW559180	TRIM,COWL SIDE,RH	
01-02-11752	MB899664	CLIP,FLOOR TRIM	
01-02-11753	MB568890	CAP,RR SIDE TRIM	
01-02-11754	MN002839	HOOK,RR SIDE TRIM TONGUE	
01-02-11755	PW515812	TRIM,RR SHELF	
01-02-11756	MB128398	CLIP,RR SHELF TRIM	
01-02-11757	MB375995	CLIP,RR SHELF TRIM	
01-02-11758	MB779749	CLIP,RR SIDE TRIM	
01-02-11759	MB779749	CLIP,RR END TRIM	
01-02-11760	MB885008	BOARD,LUGGAGE ROOM PARTITION	
01-02-11761	PW559205	MAT,FLOOR	
01-02-11762	MR106075	PAD,FR FLOOR BACKBONE	
01-02-11763	PW534219	BOARD,CARGO FLOOR	
01-02-11764	MB768473	HOOK,FR FLOOR CARPET	
01-02-11765	MS450157	SCREW,FR FLOOR CARPET	
01-02-11766	MB147332	CLIP,FR FLOOR CARPET	
01-02-11767	MB344702	CLIP,FR FLOOR CARPET	
01-02-11768	PW534575V1	MAT,TRUNK ROOM	
01-02-11769	PC530101DGR	BACK ASSY,FR SEAT,LH	
01-02-11770	PC530103DGR	BACK ASSY,FR SEAT,RH	
01-02-11771	PC530105DGR	CUSHION ASSY,FR SEAT,LH (PHA	
01-02-11772	PC530107DGR	CUSHION ASSY,FR SEAT,RH (PHA	
01-02-11773	MU431010	NUT,FR SEAT	
01-02-11774	MS440504	NUT,FR SEAT	
01-02-11775	MB158706	BUSHING,FR SEAT	
01-02-11776	MF455497	SCREW,FR SEAT	
01-02-11777	MB410568	SCREW,FR SEAT	
01-02-11778	MB902325	SCREW,FR SEAT	
01-02-11779	MF350743	SCREW,FR SEAT	
01-02-11780	MB144649	BOLT,FR SEAT	
01-02-11781	MF240051	BOLT,FR SEAT	
01-02-11782	MB902324	BOLT,FR SEAT	
01-02-11783	MS240189	BOLT,FR SEAT	
01-02-11784	MF247223	BOLT,FR SEAT	
01-02-11785	MB778517	COVER,FR SEAT ANCHOR	
01-02-11786	PC530109DGR	COVER,FR SEAT BACK,LH	
01-02-11787	PC530111DGR	COVER,FR SEAT BACK,RH	
01-02-11788	PC530113DGR	COVER,FR SEAT CUSHION,LH (PH	

01-02-11789	PC530115DGR	COVER,FR SEAT CUSHION,RH (PH	
01-02-11790	MB969482	COVER,FR SEAT HINGE,LH	
01-02-11791	MB969486	COVER,FR SEAT HINGE,RH	
01-02-11792	MB975081	COVER,FR SEAT SIDE SHIELD,LH	
01-02-11793	MB969477	COVER,FR SEAT SIDE SHIELD,RH	
01-02-11794	MB789848	GUIDE,FR SEAT HEADREST (PHAS	
01-02-11795	MB789851	GUIDE,FR SEAT HEADREST (PHAS	
01-02-11796	PC530117DGR	HEADREST,FR SEAT	
01-02-11797	MB873969	COVER,FR SEAT ANCHOR,RR	
01-02-11798	MB874499	COVER,FR SEAT ANCHOR,RR LH	
01-02-11799	MB874500	COVER,FR SEAT ANCHOR,RR RH	
01-02-11800	MB874501	PROTECTOR,FR SEAT FREE HINGE	
01-02-11801	MB874502	WIRE,FR SEAT	
01-02-11802	MB874479	ADJUSTER,FR SEAT HEIGHT	
01-02-11803	MB592793	ADJUSTER,FR SEAT RECLINING,L	
01-02-11804	MB592749	ADJUSTER,FR SEAT RECLINING,R	
01-02-11805	MB874484	ADJUSTER,FR SEAT SLIDE	
01-02-11806	MB874482	ADJUSTER,FR SEAT SLIDE	
01-02-11807	MB975088	COVER,FR SEAT SLIDE RAIL BRA	
01-02-11808	MB797367	KNOB,FR SEAT RECLINING ADJUS	
01-02-11809	MB797369	KNOB,FR SEAT RECLINING ADJUS	
01-02-11810	MB797363	KNOB,FR SEAT SLIDE ADJUSTER,	
01-02-11811	MB797365	KNOB,FR SEAT SLIDE ADJUSTER,	
01-02-11812	MB792725	LEVER,FR SEAT HEIGHT ADJUSTE	
01-02-11813	PC531102DGR	BACK ASSY,RR SEAT	
01-02-11814	PC531113DGR	COVER,RR SEAT BACK	
01-02-11815	PC531124DGR	COVER,RR SEAT CUSHION	
01-02-11816	PC531128DGR	CUSHION ASSY,RR SEAT	
01-02-11817	MB873947	HOOK,RR SEAT	
01-02-11818	MS440522	NUT,RR SEAT	
01-02-11819	MB131256	BOLT,RR SEAT	
01-02-11820	PW534370	ADJUSTER,FR SEAT BELT	
01-02-11821	PW534371	ADJUSTER,FR SEAT BELT	
01-02-11822	PW534397	COVER,FR SEAT BELT SASH GUID	
01-02-11823	PW534398	COVER,FR SEAT BELT SASH GUID	
01-02-11824	PW534922	SEAT BELT,FR LH	
01-02-11825	PW534366	SEAT BELT,FR RH	
01-02-11826	PW534926	SEAT BELT,FR INR,LH	
01-02-11827	PW537550	SEAT BELT,FR INR,RH	
01-02-11828	MF453031	SCREW,FR SEAT BELT	
01-02-11829	PW534417	SEAT BELT,RR SEAT,LH	
01-02-11830	PW534420	SEAT BELT,RR SEAT,RH	
01-02-11831	PW534433	SEAT BELT,RR SEAT,CTR	
01-02-11832	MF453031	SCREW,RR SEAT BELT	
01-02-11833	MR106523	HEADLAMP,BODY,LH	
01-02-11834	MR106524	HEADLAMP,BODY,RH	
01-02-11835	MB883223	HEADLAMP ASSY,LH	
01-02-11836	MB883224	HEADLAMP ASSY,RH	
01-02-11837	PW501690	BULB,HEADLAMP	
01-02-11838	MS440133	NUT,HEADLAMP	
01-02-11839	MB970334	GARNISH,FR BUMPER SIDE,LH	
01-02-11840	MB970342	GARNISH,FR BUMPER SIDE,RH	
01-02-11841	PW536915	LAMP UNIT,FR TURN SIGNAL,LH	
01-02-11842	PW536916	LAMP UNIT,FR TURN SIGNAL,RH	
01-02-11843	MR175545	BULB,FR LAMP	
01-02-11844	MB847540	LAMP ASSY,TURN SIGNAL FR SID	
01-02-11845	PW536037	LAMP ASSY,TURN SIGNAL,FR LH	
01-02-11846	PW536038	LAMP ASSY,TURN SIGNAL,FR RH	
01-02-11847	PW536917	SPRING,FR COMBINATION LAMP,L	
01-02-11848	MR106498	SPRING,FR COMBINATION LAMP,R	

01-02-11849	MR106499	HOOK,CORNERING LAMP	
01-02-11850	PW516175	BULB,FR TURN SIGNAL LAMP	
01-02-11851	PW537461	LAMP ASSY,COMBINATION,RR LH	
01-02-11852	PW537462	LAMP ASSY,COMBINATION,RR RH	
01-02-11853	PW538029	GARNISH,RR COMBINATION LAMP,	
01-02-11854	PW538023	GARNISH,RR COMBINATION LAMP,	
01-02-11855	PW538030	GARNISH,RR COMBINATION LAMP,	
01-02-11856	PW538024	GARNISH,RR COMBINATION LAMP,	
01-02-11857	PW538035	GASKET,RR COMBINATION LAMP	
01-02-11858	PW538025	LAMP UNIT,RR COMBINATION,LH	
01-02-11859	PW538026	LAMP UNIT,RR COMBINATION,RH	
01-02-11860	MS440502	NUT,STOP LAMP	
01-02-11861	MB793919	CLIP,STOP LAMP	
01-02-11862	MS820079	BULB,STOP LAMP	
01-02-11863	MS440502	NUT,TAIL LAMP	
01-02-11864	MS820090	BULB,TAIL LAMP	
01-02-11865	MS820038	BULB,TAIL LAMP	
01-02-11866	MS820046	BULB,TAIL LAMP	
01-02-11867	PW536907	LAMP ASSY,RR LID,LH	
01-02-11868	PW536908	LAMP ASSY,RR LID,RH	
01-02-11869	PW538948	SCREW,RR LAMP	
01-02-11870	MS440502	NUT,RR LAMP	
01-02-11871	MS820046	BULB,BACKUP LAMP	
01-02-11872	PW537465	LAMP ASSY,BACKUP,LH	
01-02-11873	PW537466	LAMP ASSY,BACKUP,RH	
01-02-11874	MR106517	GASKET,BACK UP LAMP	
01-02-11875	MR106348	LAMP UNIT,LICENSE PLATE	
01-02-11876	MR106349	GASKET,LICENSE PLATE LAMP BA	
01-02-11877	MB847567	LAMP ASSY,LICENSE PLATE	
01-02-11878	MS820090	BULB,LICENSE PLATE LAMP	
01-02-11879	MR106518	GASKET,RR LID LAMP LENS	
01-02-11880	MR106350	SCREW,LICENSE PLATE LAMP	
01-02-11881	MS480001	GROMMET,LICENSE PLATE LAMP	
01-02-11882	PW501274	LAMP ASSY,ROOM	
01-02-11883	MB529091	LAMP ASSY,TRUNK ROOM	
01-02-11884	MB337964	LENS,ROOM LAMP	
01-02-11885	MF820512	BULB,ROOM LAMP	
01-02-11886	MS820071	BULB,TRUNK ROOM LAMP	
01-02-11887	MF453152	SCREW,ROOM LAMP	
01-02-11888	MR191139	ARM ASSY,WINDSHIELD WIPER	
01-02-11889	MR191140	ARM ASSY,WINDSHIELD WIPER	
01-02-11890	MR106265P	BLADE ASSY,WINDSHIELD WIPER	
01-02-11891	MR106285	COVER,WINDSHIELD WIPER ARM H	
01-02-11892	PW537036	LINK,WINDSHIELD WIPER	
01-02-11893	PW537037	MOTOR,WINDSHIELD WIPER	
01-02-11894	MS440074	NUT,WINDSHIELD WIPER	
01-02-11895	MS440502	NUT,WINDSHIELD WIPER	
01-02-11896	MB543148	CAP,WINDSHIELD WASHER TANK F	
01-02-11897	PW500075	MOTOR,WINDSHIELD WASHER	
01-02-11898	MB881365	NOZZLE,WINDSHIELD WASHER	
01-02-11899	MC845482	GASKET,WINDSHIELD WASHER TAN	
01-02-11900	MB929622	TANK,WINDSHIELD WASHER	
01-02-11901	MB084419	JOINT,WINDSHIELD WASHER	
01-02-11902	MS240145	BOLT,WINDSHIELD WASHER	
01-02-11903	MF453033	SCREW,INSTRUMENT PANEL METER	
01-02-11904	MR175545	BULB,INSTRUMENT PANEL METER	
01-02-11905	MR175547	BULB,INSTRUMENT PANEL METER	
01-02-11906	MR175577	SWITCH,SPEEDOMETER REED	
01-02-11907	MR175582	CABLE,SPEEDOMETER REED	
01-02-11908	MB803899	CABLE,SPEEDOMETER	

01-02-11909	PC543140	SPEEDOMETER	
01-02-11910	PC543142	TACHOMETER	
01-02-11911	PC543146	GAUGE,FUEL & WATER TEMPERATU	
01-02-11912	MB884739	CLOCK,DIGITAL	
01-02-11913	MB921445	CAP,DOOR LAMP SWITCH	
01-02-11914	MB628452	CAP,DOOR LAMP SWITCH	
01-02-11915	MB628452	CAP,DOOR LAMP SWITCH	
01-02-11916	MB953678	SWITCH,WINDSHIELD WIPER & WI	
01-02-11917	PC546113	SWITCH ASSY,FR DOOR POWER WI	
01-02-11918	MB863523	SWITCH,COLUMN	
01-02-11919	MR106121	SWITCH,HEADLAMP LEVELING	
01-02-11920	MB698713	SWITCH KIT,DOOR LAMP	
01-02-11921	PW536010	SWITCH KIT,DOOR LAMP	
01-02-11922	MB884737	SWITCH,HAZARD WARNING LAMP	
01-02-11923	MB884732	SWITCH,RR WINDOW DEFOGGER	
01-02-11924	PW536994	SWITCH,TRUNK ROOM LAMP	
01-02-11925	PW537075	RELAY,POWER WINDOW	
01-02-11926	PW538001	CIGAR LIGHTER,INSTRUMENT PAN	
01-02-11927	PW536042	HARNESS,RADIO EARTHING	
01-02-11928	PW546177	HARNESS,RADIO	
01-02-11929	PW546174	RADIO	
01-02-11930	PC545118	ESCUTCHEON (RADIO FRONT)	
01-02-11931	PC545107	OUTER,ESCUTCHEON RADIO	
01-02-11932	MB423642	PANEL,RADIO BLIND	
01-02-11933	MF453033	SCREW,AUDIO EQUIP	
01-02-11934	PC545307	GARNISH,RR SHELF SPEAKER,LH	
01-02-11935	PC545310	GARNISH,RR SHELF SPEAKER,RH	
01-02-11936	PW546079	SPEAKER RR	
01-02-11937	MF453033	SCREW,SPEAKER	
01-02-11938	PW536061	ANTENNA ASSY	
01-02-11939	MB852928	BUZZER,ELECTRIC	
01-02-11940	PW546184	HORN	
01-02-11941	PW546185	HORN	
01-02-11942	MF453030	SCREW,BUZZER	
01-02-11943	MB852268	CONTROL UNIT,DOOR	
01-02-11944	PW500081	FLASHER UNIT,HAZARD & TURN S	
01-02-11945	PW538984	TIMER,IGNITION KEY ILLUMINAT	
01-02-11946	PW537075	RELAY,POWER	
01-02-11947	PW537075	RELAY,SPECIAL LAMP	
01-02-11948	PW537075	RELAY	
01-02-11949	PW516427	RELAY	
01-02-11950	MB249339	BAND,BATTERY WIRING	
01-02-11951	MB907204	L-BOLT KIT,BATTERY	
01-02-11952	MB241874	L-BOLT KIT,BATTERY	
01-02-11953	MB826677	TRAY,BATTERY	
01-02-11954	MS240145	BOLT,BATTERY STAY	
01-02-11955	MB818630	BOX,RELAY	
01-02-11956	MB818621	BOX ASSY,RELAY	
01-02-11957	MB818623	COVER,RELAY BOX	
01-02-11958	PW536953	CABLE,DEFOGGER	
01-02-11959	PW538795	HARNESS,BODY MAIN	
01-02-11960	PW538797	HARNESS,CHASSIS,FR	
01-02-11961	PW537409	HARNESS,CONTROL	
01-02-11962	PW538703	HARNESS,FR DOOR	
01-02-11963	PW538707	HARNESS,FR DOOR	
01-02-11964	PW536754V1	HARNESS,FUEL GAUGE UNIT	
01-02-11965	PW536754V2	HARNESS,FUEL GAUGE UNIT	
01-02-11966	PW538682	HARNESS,INSTRUMENT PANEL	
01-02-11967	PW539820	HARNESS,RR DOOR	
01-02-11968	PW539822	HARNESS,RR DOOR	

01-02-11969	PW539684	HARNES,ROOM LAMP	
01-02-11970	MB249339	BAND,ENG WIRING	
01-02-11971	MS440502	NUT,ENG WIRING	
01-02-11972	MS810965	FUSE,CHASSIS WIRING	
01-02-11973	MS440502	NUT,WIRING	
01-02-11974	MS810965	FUSE,BODY WIRING	
01-02-11975	MS810966	FUSE,BODY WIRING	
01-02-11976	MS810967	FUSE,BODY WIRING	
01-02-11977	MU840021	FUSIBLE LINK	
01-02-11978	MU840016	FUSIBLE LINK	
01-02-11979	MU840015	FUSIBLE LINK	
01-02-11980	MB183865	RELAY	
01-02-11981	MB885659	HEATER ASSY	
01-02-11982	MR189117	BLOWER ASSY,HEATER	
01-02-11983	MB939999	CORE,HEATER	
01-02-11984	MR315838	RESISTOR,HEATER	
01-02-11985	MB869427	HOSE A,HEATER WATER	
01-02-11986	MB869428	HOSE B,HEATER WATER	
01-02-11987	MB476821	CLIP,HEATER	
01-02-11988	MU470040	CLAMP,HEATER PIPING	
01-02-11989	MB898398	SWITCH,HEATER BLOWER	
01-02-11990	PW539059	CONTROLLER ASSY,HEATER	
01-02-11991	MB917920	KNOB,HEATER CONTROL LEVER	
01-02-11992	MR146644	BULB,HEATER CONTROL EQUIP	
01-02-11993	MR146643	BULB,HEATER CONTROL EQUIP	
01-02-11994	MF453033	SCREW,HEATER CONTROL EQUIP	
01-02-11995	MB476821	CLIP,HEATER DUCT	
01-02-11996	MF453030	SCREW,CTR VENTILATOR DUCT	
01-02-11997	PW510685	TOOL SET,STD	
01-02-11998	PW510986	BAR,JACK HANDLE EXTENSION	
01-02-11999	PW530093	JACK SET	
01-02-12000	PW510984	WRENCH,WHEEL NUT SOCKET	
01-02-12001	PW536257	CASE SUB-ASSY	
01-02-12002	PW536258	CASE SUB-ASSY	
01-02-12003	PW536259	EVAPORATOR SUB ASSY	
01-02-12004	PW536260	VALVE,EXPANSION	
01-02-12005	PW536261	TUBE & ACCY ASSY	
01-02-12006	PW536235	O-RING	
01-02-12007	PW536236	O-RING	
01-02-12008	PW536208	THERMISTOR ASSY	
01-02-12009	PW536210	RESISTOR BLOWER	
01-02-12010	PW536215	BRACKET	
01-02-12011	PW536216	WIRE HARNES	
01-02-12012	PW536217	AMMPLIFIER ASSY	
01-02-12013	PW536263	PACKING	
01-02-12014	PW536155	THERMISOR ASSY	
01-02-12015	PW536156	TANK, LIGUID,DRYER	
01-02-12016	PW536158	RESISTOR BLOWER	
01-02-12017	PW536218	COMPRESSOR ASSY W/CLUTCH	
01-02-12018	PW538166	MAGNETIC CLUTCH	
01-02-12019	PW536225	WASHER PLATE	
01-02-12020	PW536226	WASHER PLATE	
01-02-12021	PW536227	WASHER PLATE	
01-02-12022	PW536152	BRACKET COMP ASSY	
01-02-12023	PW536159	DISCHARGE HOSE	
01-02-12024	PW536234	O-RING	
01-02-12025	PW536191	SUCTION HOSE	
01-02-12026	PW536235	O-RING	
01-02-12027	PW536114	TUBE LIQUID	
01-02-12028	[PW536236	O-RING	



01-02-12029	PW5361683	TUBE&ACCY ASSY	
01-02-12030	PW536237	PRESSURE PIPE	
01-02-12031	PW536236	O-RING	
01-02-12032	PW536252	BELT,COMPRESSOR	
01-02-12033	PW536116	PULLEY ASSY IDLE	
01-02-12034	PW536119	PACKING	
01-02-12035	PW536120	BRACKET,CLAMP	
01-02-12036	PW538168	FAN SHROUD	
01-02-12037	PW538169	FAN MOTOR ASSY	
01-02-12038	PW538170	FAN BLADE	
01-02-12039	PW536241	BOLT,WASHER HEAD	
01-02-12040	PW536122	CLAMP PIPING	
01-02-12041	PW536123	CLAMP PIPING	
01-02-12042	PW536124	CLAMP	
01-02-12043	PW536164	CLAMP	
01-02-12044	PW536127	RELAY & ACCY ASSY	
01-02-12045	PC554676	WIRE HARNESS SUB-ASSY	
01-02-12046	PC554678	RELAY & ACCY ASSY	
01-02-12047	PC554679	FUSE	
01-02-12048	PC554680	FUSE	
01-02-12049	PW536194	TUBE LIQUID	
01-02-12050	PW536236	O-RING	
01-02-12051	PW536188	HOSE DRAIN	
01-02-12052	PW536132	CLAMP	
01-02-12053	PW536186	BRACKET	
01-02-12054	PW536136	ACTUATOR SET	
01-02-12055	PW536135	W-CLIP	
01-02-12056	PW536129	A/C SWITCH ASSY	
01-02-12057	PW536169	BRACKET IDLER PULLEY	
01-02-12058	PW536142	CLAMP	
01-02-12059	PW536130	CACUUM SWITCHING VALVE	
01-02-12060	PW536133	HOSE VACUUM A	
01-02-12061	PW536134	HOSE VACUUM B	
01-02-12062	PW536180	CLAMP	
01-02-12063	PW536181	CLAMP	
01-02-12064	PW536150	BOLT W/WASHER	
01-02-12065	PW5361683	BOLT ADJUST	
01-02-12066	PW536255	AIR COND SET	
<b>SPARE PARTS</b>			
<b>CODE</b>	<b>NUMBER</b>	<b>DESCRIPTION</b>	
01-02-12067	A 003 159 66 03 26	SPARK PLUG	
01-02-12068	A 011 997 97 92	V-BELT	
01-02-12069	A 220 240 07 17	ENGINE MOUNTING/LEFT	
01-02-12070	A 220 240 07 18	ENGINE MOUNTING/RIGHT	
01-02-12071	A 220 240 02 18	ENGINE MOUNTING	
01-02-12072	A 112 094 00 04	FILTER ELEMENT	
01-02-12073	A 112 078 00 49	INJECTION NOZZEL	
01-02-12074	A 019 997 13 48	SEAL RING,VLRUB	
01-02-12075	A 112 180 00 09	FILTER ELEMENT	
01-02-12076	A 002 477 30 01	FUEL FITER	
01-02-12077	A 210 501 03 15	RADIATOR CAP	
01-02-12078	A 112 010 06 28	OIL PAN	
01-02-12079	A 000 470 78 94	AUCILIARY PUMP	
01-02-12080	A 220 500 00 03	RADIATOR	
01-02-12081	A220 500 00 93	BLOWER	
01-02-12082	A 112 200 05 01	WATER PUMP	
01-02-12083	A 112 150 01 18	IGNITION CABLE	
01-02-12084	A 220 880 03 83	RADIATOR GRILLE SHELL	
01-02-12085	A 003 420 18 20	BRAKE SHOE	
01-02-12086	A 003 420 19 20	BRAKE SHOE	

01-02-12087	A 220 330 07 25	FRONT WHEEL HUB	
01-02-12088	A220 980 00 16	REPAIR KIT	
01-02-12089	A 112 151 00 01	STARTING MOTOR	
01-02-12090	A 011 154 32 02	ALTERNATOR	
01-02-12091	A 220 338 10 15	TI ROD	
01-02-12092	A 220 338 10 16	TI ROD	
01-02-12093	B 66470543	WHEEL -ALUMINUM	
01-02-12094	A 220 826 01 90	LENS	
01-02-12095	A220 826 02 90	LENS	
01-02-12096	A 220 820 01 61	LIGHTING UNIT	
01-02-12097	A 220 820 02 61	LIGHTING UNIT	
01-02-12098	A 220 820 00 45	WIPER BLADE	
01-02-12099	A 220 810 11 16	OUTSIDE REARVIEW MIRROR	
01-02-12100	A 220 810 08 16	OUTSIDE REARVIEW MIRROR	
01-02-12101	A 220 880 03 40	PANELLING	
01-02-12102	A 220 880 01 40	PANELLING	
01-02-12103	A 024 545 66 32	COMPOTER /ENGINE CONTROL	
01-02-12104	A 220 500 00 54	A/C CONDENSER	
01-02-12105	A 220 670 17 01	WINDSHELD	
01-02-12106	A 220 690 01 62 9040	LEDGE	
01-02-12107	A 220 690 02 62 9040	LEDGE	
01-02-12108	A 220 690 05 62 9040	LEDGE	
01-02-12109	A 220 690 06 62 9040	LEDGE	
01-02-12110	A 220 690 13 62 9040	LEDGE	
01-02-12111	A 220 690 14 62 9040	LEDGE	
01-02-12112	A 200 690 03 62 9040	LEDGE	
01-02-12113	A 000 230 51 11	COMPRESSOR	
01-02-12114	A 140 400 05 70	CLAMPING SCREW	
01-02-12115	A 220 690 04 62 9040	LEDGE	
01-02-12116	A 220 320 51 13	HYDROPNEUMATIC SPARING LEG	
01-02-12117	A 220 320 50 13	HYDROPNEUMATIC SPARING LEG	
01-02-12118	A 220 320 03 14	RESERVOIR	
01-02-12119	A 220 327 01 15	AIR RESERVOITR	
01-02-12120	A 220 330 00 20	STEERING KNUCKLE	
01-02-12121	A 220 330 01 20	STEERING KNUCKLE	
01-02-12122	A 168 357 00 89	LOCKING CAP	
01-02-12123	A 220 330 14 07	TRANSVERSE CONTROL ARE	
01-02-12124	A 220 330 15 07	TRANSVERSE CONTROL ARE	
01-02-12125	A 020 997 63 47	SEAL RING	
01-02-12126	A 210 997 02 46	SEAL RING	
01-02-12127	A 220 350 12 10	REAR AXLE SHAFT	
01-02-12128	A 210 350 08 37	REPAIR KIT	
01-02-12129	A 220 350 05 75	RUBBER MOUNTING	
01-02-12130	A 220 352 00 27	JOINT	
01-02-12131	A 220 357 02 08	FLANGE	
01-02-12132	A 220 350 26 06	CONTROL ARM	
01-02-12133	A 220 350 04 53	TIE ROD	
01-02-12134	A 220 350 22 06	CONTROL ARM	
01-02-12135	A 220 350 24 06	CONTROL ARM	
01-02-12136	A 220 460 08 00	STEERING BOX ASSEMBLY	
01-02-12137	A 220 460 10 00	REPAIR KIT	
01-02-12138	A 220 466 01 81	HOSE	
01-02-12139	A 220 997 54 82	HOSE	
01-02-12140	A 220 466 12 81	HOSE	
01-02-12141	A 220 460 03 16	STEER COLUMN JACKET TUBE	
01-02-12142	A 220 524 29 30	PANELLING	
01-02-12143	A 220 524 13 30	PANELLING	
01-02-12144	A 220 524 03 01	PROTECTIVE PLATE	
01-02-12145	A 004 541 46 01	BATTERY	
01-02-12146	A 220 545 00 10	SWTCH	

01-02-12147	A 220 545 01 24	SEWITCH,AUTOMATIC	
01-02-12148	A 220 545 00 22	SWITCH	
01-02-12149	A 220 610 00 14	CROSS MEMBER	
01-02-12150	A 220 620 10 86	SUPPORT	
01-02-12151	A 220 620 03 72	STIFFENING	
01-02-12152	A 220 620 01 72	STIFFENING	
01-02-12153	A 220 620 02 72	STIFFENING	
01-02-12154	A 220 640 00 71	STIFFENING	
01-02-12155	A 220 670 01 80	REAR WINDOW PANE	
01-02-12156	A 220 720 01 05	DOOR SHELL	
01-02-12157	A 220 720 02 05	DOOR SHELL	
01-02-12158	A 220 720 03 46	WINDOW REGULATOR	
01-02-12159	A220 720 04 46	WINDOW REGULATOR	
01-02-12160	A 220 730 03 05	DOOR SHELL	
01-02-12161	A 220 730 04 05	DOOR SHELL	
01-02-12162	A 220 730 03 46	WINDOW REGULATOR	
01-02-12163	A 220 730 04 46	WINDOW REGULATOR	
01-02-12164	A 210 780 01 12	ANGLE	
01-02-12165	A 220 780 02 12	ANGLE	
01-02-12166	A 220 869 00 20	RESERVOIR	
01-02-12167	A 210 869 09 21	PUMP	
01-02-12168	A 220 880 01 57	ENGINE HOOD	
01-02-12169	A 220 750 01 75	REAR LID	
01-02-12170	A 220 820 01 64	TAIL LAMP	
01-02-12171	A 220 820 02 64	TAIL LAMP	
01-02-12172	A 210 830 10 58	EVAPORA TOR	
01-02-12173	A 220 820 31 42	ELECTRIC MOTOR	
01-02-12174	A 210 830 11 18	FILTER	
01-02-12175	A 220 500 00 49	TANK	
01-02-12176	A 220 330 33 11	STRUT	
01-02-12177	A 220 330 34 11	STRUT	
01-02-12178	A 200 330 24 07	SPRING CONTROL AREM	
01-02-12179	A 220 330 25 07	SPRING CONTROL AREM	
01-02-12180	A 220 333 01 27	JOINT	
01-02-12181	A 140 320 08 89	ROD	
01-02-12182	A 220 410 00 15	FLEXIBLE JOINT DISC	
01-02-12183	A 210 410 21 81	RUBBER BOOT BEARING	
01-02-12184	A 220 421 09 12	BRAKE DISC	
01-02-12185	A 220 423 01 12	BRAKE DISC	
01-02-12186	A 220 420 05 20	BRAKE SHOE	
01-02-12187	A 005 430 91 01	BRAKE MASTER CYLINDER	
01-02-12188	A 023 997 84 47	SEAL RING	
01-02-12189	A 112 016 03 20	CYLINDER HEAD GASKET	
01-02-12190	A 112 016 04 20	CYLINDER HEAD GASKET	
01-02-12191	A 112 016 02 21	GASKET	
01-02-12192	A 112 016 03 21	GASKET	
01-02-12193	A 111 018 03 02	CAP,OIL FILLER	
01-02-12194	A 112 141 09 80	GASKET	
01-02-12195	A 112 142 01 80	GASKET	
01-02-12196	A 000 158 78 03	IGNITION COIL	
01-02-12197	A 112 202 01 10	PULLEY	
01-02-12198	A 000 202 00 19	TIGHTENER PULLEY	
01-02-12199	A 112 200 03 70	BELT TIGHTENER	
01-02-12200	A 112 203 02 75	THERMOSTAT ELEMENT	
01-02-12201	A 220 880 03 18	FRONT FENDER	
01-02-12202	A 220 880 04 18	FRONT FENDER	
01-02-12203	A 140 270 01 97	OIL PUMP	
01-02-12204	A 140 277 00 95	OIL FILTER	
01-02-12205	A 140 271 00 80	GASKET	
01-02-12206	A 140 270 08 12	OIL PAN	

01-02-12207	A 019 997 85 82	HOSE, TRANS COOLER ,VLRUB	
01-02-12208	A 020 997 36 82	HOSE	
01-02-12209	A 140 270 65 00	GASKET KIT	
01-02-12210	A140 270 07 61	ELECTRIC KIT	
01-02-12211	A 140 270 04 06	VALVE GEAR	
01-02-12212	A 140 272 00 25	INNER DISC	
01-02-12213	A 210 272 00 25	INNER DISC	
01-02-12214	A 140 272 07 25	INNER DISC	
01-02-12215	A 140 272 04 25	INNER DISC	
01-02-12216	A 140 272 06 25	INNER DISC	
01-02-12217	A 220 630 03 21	REAR FENDER	
01-02-12218	A 220 630 04 21	REAR FENDER	
01-02-12219	A 001 152 28 10	SOLENOID SWITCH	
01-02-12220	A 001 151 21 13	PINION	
01-02-12221	A 220 830 03 84	VALVE	
01-02-12222	A 126 353 00 42	SPACER SLEEVE , AXLE	
01-02-12223	A 201 400 04 25	HUB CAP	
01-02-12224	A 220 338 07 15	TIE ROD	
01-02-12225	A 220 670 00 93	REPAIR KIT	
01-02-12226	A 220 824 01 27	WIPER RUBBER	
<b>SPARE PARTS</b>			
<b>CODE</b>	<b>NUMBER</b>	<b>DESCRIPTION</b>	
01-02-12227	A 003 159 66 03 26	SPARK PLUG	
01-02-12228	A 011 997 97 92	V-BELT	
01-02-12229	A 220 240 07 17	ENGINE MOUNTING/LEFT	
01-02-12230	A 220 240 07 18	ENGINE MOUNTING/RIGHT	
01-02-12231	A 220 240 02 18	ENGINE MOUNTING	
01-02-12232	A 112 094 00 04	FILTER ELEMENT	
01-02-12233	A 112 078 00 49	INJECTION NOZZEL	
01-02-12234	A 019 997 13 48	SEAL RING,VLRUB	
01-02-12235	A 112 180 00 09	FILTER ELEMENT	
01-02-12236	A 002 477 30 01	FUEL FITER	
01-02-12237	A 210 501 03 15	RADIATOR CAP	
01-02-12238	A 112 010 06 28	OIL PAN	
01-02-12239	A 000 470 78 94	AUCILIARY PUMP	
01-02-12240	A 220 500 00 03	RADIATOR	
01-02-12241	A220 500 00 93	BLOWER	
01-02-12242	A 112 200 05 01	WATER PUMP	
01-02-12243	A 112 150 01 18	IGNITION CABLE	
01-02-12244	A 220 880 03 83	RADIATOR GRILLE SHELL	
01-02-12245	A 003 420 18 20	BRAKE SHOE	
01-02-12246	A 003 420 19 20	BRAKE SHOE	
01-02-12247	A 220 330 07 25	FRONT WHEEL HUB	
01-02-12248	A220 980 00 16	REPAIR KIT	
01-02-12249	A 112 151 00 01	STARTING MOTOR	
01-02-12250	A 011 154 32 02	ALTERNATOR	
01-02-12251	A 220 338 10 15	TI ROD	
01-02-12252	A 220 338 10 16	TI ROD	
01-02-12253	B 66470543	WHEEL -ALUMINUM	
01-02-12254	A 220 826 01 90	LENS	
01-02-12255	A220 826 02 90	LENS	
01-02-12256	A 220 820 01 61	LIGHTING UNIT	
01-02-12257	A 220 820 02 61	LIGHTING UNIT	
01-02-12258	A 220 820 00 45	WIPER BLADE	
01-02-12259	A 220 810 11 16	OUTSIDE REARVIEW MIRROR	
01-02-12260	A 220 810 08 16	OUTSIDE REARVIEW MIRROR	
01-02-12261	A 220 880 03 40	PANELLING	
01-02-12262	A 220 880 01 40	PANELLING	
01-02-12263	A 024 545 66 32	COMPOTER /ENGINE CONTROL	
01-02-12264	A 220 500 00 54	A/C CONDENSER	

01-02-12265	A 220 670 17 01	WINDSHELD	
01-02-12266	A 220 690 01 62 9040	LEDGE	
01-02-12267	A 220 690 02 62 9040	LEDGE	
01-02-12268	A 220 690 05 62 9040	LEDGE	
01-02-12269	A 220 690 06 62 9040	LEDGE	
01-02-12270	A 220 690 13 62 9040	LEDGE	
01-02-12271	A 220 690 14 62 9040	LEDGE	
01-02-12272	A 200 690 03 62 9040	LEDGE	
01-02-12273	A 000 230 51 11	COMPRESSOR	
01-02-12274	A 140 400 05 70	CLAMPING SCREW	
01-02-12275	A 220 690 04 62 9040	LEDGE	
01-02-12276	A 220 320 51 13	HYDROPNEUMATIC SPARING LEG	
01-02-12277	A 220 320 50 13	HYDROPNEUMATIC SPARING LEG	
01-02-12278	A 220 320 03 14	RESERVOIR	
01-02-12279	A 220 327 01 15	AIR RESERVOITR	
01-02-12280	A 220 330 00 20	STEERING KNUCKLE	
01-02-12281	A 220 330 01 20	STEERING KNUCKLE	
01-02-12282	A 168 357 00 89	LOCKING CAP	
01-02-12283	A 220 330 14 07	TRANSVERSE CONTROL ARE	
01-02-12284	A 220 330 15 07	TRANSVERSE CONTROL ARE	
01-02-12285	A 020 997 63 47	SEAL RING	
01-02-12286	A 210 997 02 46	SEAL RING	
01-02-12287	A 220 350 12 10	REAR AXLE SHAFT	
01-02-12288	A 210 350 08 37	REPAIR KIT	
01-02-12289	A 220 350 05 75	RUBBER MOUNTING	
01-02-12290	A 220 352 00 27	JOINT	
01-02-12291	A 220 357 02 08	FLANGE	
01-02-12292	A 220 350 26 06	CONTROL ARM	
01-02-12293	A 220 350 04 53	TIE ROD	
01-02-12294	A 220 350 22 06	CONTROL ARM	
01-02-12295	A 220 350 24 06	CONTROL ARM	
01-02-12296	A 220 460 08 00	STEERING BOX ASSEMBLY	
01-02-12297	A 220 460 10 00	REPAIR KIT	
01-02-12298	A 220 466 01 81	HOSE	
01-02-12299	A 220 997 54 82	HOSE	
01-02-12300	A 220 466 12 81	HOSE	
01-02-12301	A 220 460 03 16	STEER COLUMN JACKET TUBE	
01-02-12302	A 220 524 29 30	PANELLING	
01-02-12303	A 220 524 13 30	PANELLING	
01-02-12304	A 220 524 03 01	PROTECTIVE PLATE	
01-02-12305	A 004 541 46 01	BATTERY	
01-02-12306	A 220 545 00 10	SWTCH	
01-02-12307	A 220 545 01 24	SEWITCH,AUTOMATIC	
01-02-12308	A 220 545 00 22	SWITCH	
01-02-12309	A 220 610 00 14	CROSS MEMBER	
01-02-12310	A 220 620 10 86	SUPPORT	
01-02-12311	A 220 620 03 72	STIFFENING	
01-02-12312	A 220 620 01 72	STIFFENING	
01-02-12313	A 220 620 02 72	STIFFENING	
01-02-12314	A 220 640 00 71	STIFFENING	
01-02-12315	A 220 670 01 80	REAR WINDOW PANE	
01-02-12316	A 220 720 01 05	DOOR SHELL	
01-02-12317	A 220 720 02 05	DOOR SHELL	
01-02-12318	A 220 720 03 46	WINDOW REGULATOR	
01-02-12319	A220 720 04 46	WINDOW REGULATOR	
01-02-12320	A 220 730 03 05	DOOR SHELL	
01-02-12321	A 220 730 04 05	DOOR SHELL	
01-02-12322	A 220 730 03 46	WINDOW REGULATOR	
01-02-12323	A 220 730 04 46	WINDOW REGULATOR	
01-02-12324	A 210 780 01 12	ANGLE	

01-02-12325	A 220 780 02 12	ANGLE	
01-02-12326	A 220 869 00 20	RESERVOIR	
01-02-12327	A 210 869 09 21	PUMP	
01-02-12328	A 220 880 01 57	ENGINE HOOD	
01-02-12329	A 220 750 01 75	REAR LID	
01-02-12330	A 220 820 01 64	TAIL LAMP	
01-02-12331	A 220 820 02 64	TAIL LAMP	
01-02-12332	A 210 830 10 58	EVAPORA TOR	
01-02-12333	A 220 820 31 42	ELECTRIC MOTOR	
01-02-12334	A 210 830 11 18	FILTER	
01-02-12335	A 220 500 00 49	TANK	
01-02-12336	A 220 330 33 11	STRUT	
01-02-12337	A 220 330 34 11	STRUT	
01-02-12338	A 200 330 24 07	SPRING CONTROL AREM	
01-02-12339	A 220 330 25 07	SPRING CONTROL AREM	
01-02-12340	A 220 333 01 27	JOINT	
01-02-12341	A 140 320 08 89	ROD	
01-02-12342	A 220 410 00 15	FLEXIBLE JOINT DISC	
01-02-12343	A 210 410 21 81	RUBBER BOOT BEARING	
01-02-12344	A 220 421 09 12	BRAKE DISC	
01-02-12345	A 220 423 01 12	BRAKE DISC	
01-02-12346	A 220 420 05 20	BRAKE SHOE	
01-02-12347	A 005 430 91 01	BRAKE MASTER CYLINDER	
01-02-12348	A 023 997 84 47	SEAL RING	
01-02-12349	A 112 016 03 20	CYLINDER HEAD GASKET	
01-02-12350	A 112 016 04 20	CYLINDER HEAD GASKET	
01-02-12351	A 112 016 02 21	GASKET	
01-02-12352	A 112 016 03 21	GASKET	
01-02-12353	A 111 018 03 02	CAP,OIL FILLER	
01-02-12354	A 112 141 09 80	GASKET	
01-02-12355	A 112 142 01 80	GASKET	
01-02-12356	A 000 158 78 03	IGNITION COIL	
01-02-12357	A 112 202 01 10	PULLEY	
01-02-12358	A 000 202 00 19	TIGHTENER PULLEY	
01-02-12359	A 112 200 03 70	BELT TIGHTENER	
01-02-12360	A 112 203 02 75	THERMOSTAT ELEMENT	
01-02-12361	A 220 880 03 18	FRONT FENDER	
01-02-12362	A 220 880 04 18	FRONT FENDER	
01-02-12363	A 140 270 01 97	OIL PUMP	
01-02-12364	A 140 277 00 95	OIL FILTER	
01-02-12365	A 140 271 00 80	GASKET	
01-02-12366	A 140 270 08 12	OIL PAN	
01-02-12367	A 019 997 85 82	HOSE, TRANS COOLER ,VLRUB	
01-02-12368	A 020 997 36 82	HOSE	
01-02-12369	A 140 270 65 00	GASKET KIT	
01-02-12370	A140 270 07 61	ELECTRIC KIT	
01-02-12371	A 140 270 04 06	VALVE GEAR	
01-02-12372	A 140 272 00 25	INNER DISC	
01-02-12373	A 210 272 00 25	INNER DISC	
01-02-12374	A 140 272 07 25	INNER DISC	
01-02-12375	A 140 272 04 25	INNER DISC	
01-02-12376	A 140 272 06 25	INNER DISC	
01-02-12377	A 220 630 03 21	REAR FENDER	
01-02-12378	A 220 630 04 21	REAR FENDER	
01-02-12379	A 001 152 28 10	SOLENOID SWITCH	
01-02-12380	A 001 151 21 13	PINION	
01-02-12381	A 220 830 03 84	VALVE	
01-02-12382	A 126 353 00 42	SPACER SLEEVE , AXLE	
01-02-12383	A 201 400 04 25	HUB CAP	
01-02-12384	A 220 338 07 15	TIE ROD	

01-02-12385	A 220 670 00 93	REPAIR KIT	
01-02-12386	A 220 824 01 27	WIPER RUBBER	
<b>SPARE PARTS</b>			
<b>CODE</b>	<b>PART NO.</b>	<b>PART NAME</b>	
01-02-12387		ENGINE COMPLETE	
01-02-12388	MD330757	ENGINE ASSY/SHORT	
01-02-12389	MD972933	GASKET KIT ENG. OVERH	
01-02-12390	MD972932	GSKT KIT ,ENG OVERHAU	
01-02-12391	MD970389	LIQUID GASKET,ENG	
01-02-12392	MD997740	LIQUID GASKETM/T	
01-02-12393	MD331055	COVER,ROCKER	
01-02-12394	MD188435	GASKET ROCKER COVER	
01-02-12395	MD315208	HOSE,ROCKER COVER BR	
01-02-12396	MD179909	GASKET,PCV VALVE	
01-02-12397	MD183547	VALVE,PCV	
01-02-12398	MD363392	CAP ASSY,ENG OIL FIL	
01-02-12399	MD311638	GASKET,ENG OIL FILLE	
01-02-12400	MD305479	HEAD ASSY,ENG CYLIND	
01-02-12401	MD346924	GASKET,CYLINDER HEAD	
01-02-12402	MD198128	SEAL,C/HEAD SPK PLUG	
01-02-12403	MF520405	O-RING,ENG BREATHER	
01-02-12404	MD191470	BOLT,CYLINDER HEAD	
01-02-12405	MD153103	OIL SEAL/CAMSHAFT	
01-02-12406	MD188579	SEAT, EXHAUST VALVE	
01-02-12407	MD188580	SEAT, EXHAUST VALVE	
01-02-12408	MD191384	SEAT, INLE-T VALVE	
01-02-12409	MD191385	SEAT, INLET VALVE	
01-02-12410	MD318940	GUIDE,INLET VALVE	
01-02-12411	MD364870	GUIDE, INLET VALVE	
01-02-12412	MD364871	GUIDE, INLET VALVE	
01-02-12413	MD318689	GUIDE,EXHAUST VALVE	
01-02-12414	MD364740	GUIDE,EXHAUST VALVE.	
01-02-12415	MD364741	GUIDE,EXHAUST VALVE.	
01-02-12416	MD350888	BLOCK ASSY,CYLINDER	
01-02-12417	MF665541	CAP,CYLINDER HEAD	
01-02-12418	MF665542	CAP, CYLINDER BLOCK	
01-02-12419	MF665543	CAP/CYLINDER HEAD	
01-02-12420	MD327493	BEARING/CRANKSHAFT	
01-02-12421	MD327494	BEARING/CRANKSHAFT	
01-02-12422	MD327495	BEARING/CRANKSHAFT	
01-02-12423	MD327496	BEARING/CRANKSHAFT	
01-02-12424	MD327497	BEARING,CRANKSHAFT	
01-02-12425	MD351820	THRUST BRG SET CRANK	
01-02-12426	MD327493	BEARING CRANKSHAFT	
01-02-12427	MD327494	BEARING CRANKSHAFT	
01-02-12428	MD327495	BEARING CRANKSHAFT	
01-02-12429	MD327496	BEARING,CRANKSHAFT	
01-02-12430	MD351826	BEARING,CRANKSHAFT	
01-02-12431	MD359158	OIL SEAL,CRANKSHAFT	
01-02-12432	MD373891	GAUGE,ENG OIL LEVEL	
01-02-12433	MD317147	GUIDE,ENG OIL LEVEL	
01-02-12434	MD075834	O-RING/ENG, Oil FILLE	
01-02-12435	MD317089	O-RING/ENG, Oil FILLE	
01-02-12436	MD187511	OIL PAN,ENG	
01-02-12437	MD050316	PIUG,ENG OIL PAN	
01-02-12438	MD050317	GASKET,ENG O/PAN DRAIN	
01-02-12439	MD310415	COVER/TIMING BELT	
01-02-12440	MD366717	COVER,TIMING BELT	
01-02-12441	MD315539	COVER,TIMING BELT UN	
01-02-12442	MD191997	GASKET,TIMING BELT C	

01-02-12443	MD310589	GASKET,TIMING BELT C	
01-02-12444	MD304419	GASKET,TIMINGI BELT C	
01-02-12445	MD310590	GASKET,TIMINGI BELT C	
01-02-12446	MD188123	GASKET,TIMINGI BELT C	
01-02-12447	MD040344	STRAINER ENG OIL PAN	
01-02-12448	MD183240	GASKET, OIL STRAINER	
01-02-12449	MD346022	CRANKSHAFT	
01-02-12450	MD193027	CONNECTING ROD ASSY	
01-02-12451	MD327503	BEARING , CONNROD	
01-02-12452	MD327504	BEARIMG,CONROD	
01-02-12453	MD327505	BEARIMG,CONROD	
01-02-12454	MD188097	PISTON & PIN ASSY	
01-02-12455	MD194357	PISTON & PIN ASSY	
01-02-12456	MD194359	PISTON & PIN ASSY	
01-02-12457	MD188295	FLVWHEEL	
01-02-12458	MD335444	BRG,FLYWHEEL DRIVE P	
01-02-12459	MD306158	PULLEY,CRANKSHAFT DA	
01-02-12460	MD040556	RINC GEAR,.FLYWHEEL	
01-02-12461	MD313405	RING SET, PISTON	
01-02-12462	MD313406	RING SET, PISTON	
01-02-12463	MD313407	RING SET,PISTON	
01-02-12464	MD008959	KEY,CRANKSHAFT	
01-02-12465	MD326852	SPROCKET, CRANK CAM D	
01-02-12466	MD193040	CAMSHAFT	
01-02-12467	MD182293	BELT,VALVE TIMING	
01-02-12468	MD156604	PULLEY,VALVE TIMING	
01-02-12469	MD182537	PULLEY,TIMING BELT T	
01-02-12470	MD168059	Oil SEAL,BALNCER Sf	
01-02-12471	MD310812	SPROCKET,CAMSMRAFT	
01-02-12472	MD308587	ADJUSTER,TIMING BELT	
01-02-12473	MD339767	ADJUSTER,ROCKER ARM	
01-02-12474	MD178782	ROCKER ARM,EXHAUST V	
01-02-12475	MD167980	ROCKER ARM , INLET VAL	
01-02-12476	MD167981	ROCKER ARM INLET VAL	
01-02-12477	MD187818	SHAFT,INL VALVE ROCK	
01-02-12478	MD187819	SHAFT,.EXH VALVE ROCK	
01-02-12479	MD159209	RETAINER,VALVE SPRIN	
01-02-12480	MD159502	VALVE,.INLET	
01-02-12481	MD151527	SEAT,VALVE SPRING	
01-02-12482	MD314078	SPRING,INLET & EXH V	
01-02-12483	MD199193	VALVE,EXHAUST	
01-02-12484	MD151369	LOCK,VALVE SPRING RE	
01-02-12485	MD184303	SEAL,VALVE STEM	
01-02-12486	MD184303	SEAL,VALVE STEM	
01-02-12487	MD135005	SPROCKET,ENG OIL PUM	
01-02-12488	MD138993	SWITCH,ENG OIL PRESS	
01-02-12489	MR151348	CUSHION,C/ MBR ENG MO	
01-02-12490	MR133060	CUSHION,ENG RR MOUNT	
01-02-12491	MR234111	CROSS MEMBER,T/ M MOUN	
01-02-12492	MD314329	CASE ASSY,CYL BLOCK	
01-02-12493	MD187905	GASKET,ENG FR CASE	
01-02-12494	MD125376	PLUG,ENG FR CASE	
01-02-12495	MD041021	O--R1NG-ENG FR CASE	
01-02-12496	MD343563	OIL SEAL,CRANKSHAFT/	
01-02-12497	MD174581	GEAR OIL PUMP DRIVE	
01-02-12498	MD174582	GEAR OIL PUMP DRIVEN	
01-02-12499	MD365697	OIL SEAL,O/PUMP DRV	
01-02-12500	MD1898885	BRACKET ASSY-OIL FIL	
01-02-12501	MD185528	GASKET,OIL FILTER BR	
01-02-12502	MD360935	OIL FILTER ,CARTRIDG	



01-02-12503	MB504238	GASKET/FUEL FILLER N	
01-02-12504	MR134054	HOSE/FUEL FILLER	
01-02-12505	MB503574	NECK,FUEL FILLER	
01-02-12506	MR134030	FUEL TANK	
01-02-12507	MR342330	CAP.,FUEL TANK	
01-02-12508	MR122790	GAUGE UNIT,FUEL TANK	
01-02-12509	MB925886	VALVE F,TANK VAPOR 2	
01-02-12510	MR526922	VALVE FUEL TANK SAPET	
01-02-12511	MR252677	GASKET-FUEL TANK GAU	
01-02-12512	MB400461	GASKET,FUEL TANK, PUM	
01-02-12513	MS642596	HOSE-FUEL TANK	
01-02-12514	MS605158	HOSE-FUEL TANK	
01-02-12515	MS642896	HOSE/FUEL TANK	
01-02-12516	MB595451	HOSE,FUEL TANK	
01-02-12517	MB329078	GASKET-FUEL TANK,	
01-02-12518	MR376341	FUEL PUMP ASSY	
01-02-12519	MB503392	FILTER ,FUEL PUMP	
01-02-12520	MB433774	STRAINER/FUEL	
01-02-12521	MR188912	HOSE,FUEL RETURN LINE	
01-02-12522	MD196880	HOSE KIT,F/ PUMP FUEL	
01-02-12523	MD312831	HOSE KIT,F/PUMP PUEL	
01-02-12524	MD310247	TANK/FUEL VAPOR SEPA	
01-02-12525	MD315929	CARBUBETOR ASSY	
01-02-12526	MD626196	BREAKER KIT ,CARB CHO	
01-02-12527	MD626200	GASKET KIT,CARB	
01-02-12528	MD612419	CHKVAL KIT,CARB ACCE	
01-02-12529	MD626160	CHKVAL KIT,CARB PUMP	
01-02-12530	MD617511	GSKT,CARB FLOAT CHMB	
01-02-12531	MD626278	FLOAT « NEEDLE VALVE	
01-02-12532	MD626275	FLOAT PIN KIT CARB	
01-02-12533	MD612863	NEEDLE VALVE K CARB	
01-02-12534	MD626070	VALVE KIT CARB SOLEN	
01-02-12535	MR133129	CABLE , ACCEL	
01-02-12536	MR481784	RADIATOR ASSY	
01-02-12537	MR258647	CAP- RADIATOR	
01-02-12538	MR204323	HOSE , RADAITOR COMD T	
01-02-12539	MB660749	HOSE,RADIATOR COMD T	
01-02-12540	MR127437	HOSE RADATOR ,LWR	
01-02-12541	MR127436	HOSE/ RADIATOR ,UPR	
01-02-12542	MR241700	PLUG ASSY, RADIATOR	
01-02-12543	MR127441	TANK ASSY -RADIATOR C	
01-02-12544	MR404538	CLIPRADIATOR PIPING	
01-02-12545	MD972934	WATER PUMP KIT	
01-02-12546	MD186124	BELT,ALTERNATOR* OTH	
01-02-12547	MD312172	PULLEY,WATER PUMP	
01-02-12548	MD317680	FAN COOLING	
01-02-12549	MD317679	CLUTCH-COOLING FAN	
01-02-12550	MD312815	PIPEWATER PUMP INLE	
01-02-12551	MD312813	CASE/THERMOSTAT	
01-02-12552	MDI70031 .	THERMOSTAT KIT	
01-02-12553	MD313687	FITTING WATER INLET	
01-02-12554	MS660240	CLIP ROCKER COVER	
01-02-12555	MD030764	O-RING WATER PUMP IN	
01-02-12556	MD030763	O -RING COOLING WATER	
01-02-12557	MD304446	HOSE THROT BODY MATE	
01-02-12558	MD128002	HOSE COOLING WATER L	
01-02-12559	MD091056	GAUQE UNIT WATER TEM	
01-02-12560	MD620791	BODY ASSY,AIR CLEANE	
01-02-12561	MD620721	ELEMENT A IR CLEANER	
01-02-12562	MD025181	CASKET,A1R CLEANER T	

01-02-12563	MD620789	COVER,AIR CLEANER	
01-02-12564	MD320074	HEAT DUCT/AIR CLEANER	
01-02-12565	MD327555	DUCT,A/CLNR INTAKE	
01-02-12566	MD620814	SENSOR/CLNR AIR TE	
01-02-12567	MS632592	HOSEVACUM (2M)	
01-02-12568	MD154913	NUT-AIR CLEANER	
01-02-12569	MD313993	FITTING-WATER OUTLET	
01-02-12570	MD310051	MANIFOLD INLET	
01-02-12571	MD193224	GASKET ,INLET MANIFOLD	
01-02-12572	MR188194	MANIFOLD , EXHAUST	
01-02-12573	MD181032	GASKETEXHAUST MANIFOLD	
01-02-12574	MB687001	GASKET--EXHAUST PIPE	
01-02-12575	MR239074	PIPE EXHUST PIPE PR	
01-02-12576	MR239070	P1PE/EXHAUST-.CTR	
01-02-12577	MB548707	HANGER/EXHAUST MUFFL	
01-02-12578	MB431175	HANGER EXHAUST MUFL	
01-02-12579	MB845683	HANGER EXHAUST MUFL	
01-02-12580	MB612304	HANGER EXHAUST MUFL	
01-02-12581	MR239492	MUFLER-EXHAUST MAIN	
01-02-12582	MD310593	VALVE EMISSION VACUM	
01-02-12583	MD162837	STARTER ASSY	
01-02-12584	MD618445	ARMEATYURE ,STARTER	
01-02-12585	MD607892	BRG STARTER ARMEATURE	
01-02-12586	MD607903	BRG STARTER ARMEATURE	
01-02-12587	MD607554	BRUSH ,STARTER	
01-02-12588	MD607556	BRUSH,STARTER	
01-02-12589	MD611372	CLUTCH,STARTER OVER R	
01-02-12590	MD607926	HOLDER ASSY STARTER	
01-02-12591	MD607921	LEVER KEY START PINION	
01-02-12592	MD618581	SWITCH KIT, STARTER,M	
01-02-12593	MD354801	ALTERNATOR ASSY	
01-02-12594	MD618679	BEARING,ALTERNATOR R	
01-02-12595	MD611928	BEARING ALTERNATOR R	
01-02-12596	MD618689	BRUSH ALTERNATOR	
01-02-12597	MD618753	PULLY ALTERNATOR	
01-02-12598	MD619504	RECTIFIER ,ALTERNATOR	
01-02-12599	MD619542	REGULATOR ,ALTERNATOR	
01-02-12600	MD619027	ROTOR KIT,ALTERNATOR	
01-02-12601	MD619028	STARTER ,ALTERNATOR	
01-02-12602	MD314947	DISTRIBUTOR ASSEMBLY	
01-02-12603	MD618989	ADVANCER ,DISTRIBUTOR	
01-02-12604	MD618980	CAB ASSY DISTRIBUTOR	
01-02-12605	MD618284	ROTOR,DISTR IBUTOR	
01-02-12606	MD618524	PICKUP KIT,DISTRIBUT	
01-02-12607	MD618987	IGNITER KIT,DISTRIBU	
01-02-12608	MD618988	CONNECTOR KIT,ISTRI	
01-02-12609	MD309455	CCIL, ICNITION	
01-02-12610	MS851351	SPARK PLUG	
01-02-12611	MD975309	CABLE SET,SPK PLUS	
01-02-12612	MD113566	RELAY , ALTERNATOR SAF	
01-02-12613	MD703270	BEARING , CLUTCH RELEA	
01-02-12614	MD331291	COVER ASSY,CLUTCH	
01-02-12615	MR276980	DISC,CLUTCH	
01-02-12616	MR344789	CABLE ASSY,CLUTCH	
01-02-12617	MR273392	MANUAL TRANSMISSION	
01-02-12618	MR179714	GASKET KIT,M/T OVERH	
01-02-12619	MD701721	OIL SEAL,CLUTCH RLSE	
01-02-12620	MD703743	O/SEAL,M/T CASE EXT	
01-02-12621	MD23202	O/SEAL,M/T MAIN DRIV	
01-02-12622	MD705469	GEAR , SPEEDMETER DRI	

01-02-12623	MD701788	O-RINC, SPOOM DRIVEN	
01-02-12624	MF520403	O-RING,ENG OIL PUMP	
01-02-12625	MD705450	SLEEVE, SPEEDOMEETER D	
01-02-12626	MD705429	SLEEVE AS,SPOON DRVN	
01-02-12627	MF472536	SPRING PIN,SPEEDOMET	
01-02-12628	MR367565	PINION,M/T MAIN DRIV	
01-02-12629	MD736823	BRG, M/T NAIM DRIVE P	
01-02-12630	MD723140	SHAFT,M/T MAIN	
01-02-12631	MD703856	BRC,M/T INTERMEDIATE	
01-02-12632	MR357332	BEARING,M/T MIN SHA	
01-02-12633	MD703760	BEARING,M/T 1ST SPEE	
01-02-12634	MD723087	BEARING M/T O/D GEAR	
01-02-12635	MR581775	BEARING , M/T REV GEAR	
01-02-12636	MD701760	BEARING M/T O/D GEAR	
01-02-12637	MD737052	GEAR, M/T MAIN SHAFT	
01-02-12638	MR110049	GEAR,M/T MAIN SHAFT	
01-02-12639	MR305375	GEAR/M,M/T MAIN SHAFT	
01-02-12640	MR305379	GEAR/M,M/T MAIN SHAFT	
01-02-12641	MR232002	GEAR/M,M/T MAIN SHAFT	
01-02-12642	MD731433	BRG,M/T MAIN SHAFT P	
01-02-12643	MD717013	SLEEVE,M/T MAIN SFT	
01-02-12644	MD703768	SLEEVE,M/T MAIN SFT	
01-02-12645	MD703798	BRG, M/T CO/SHAFT EXT	
01-02-12646	MD716038	BEARING ,M/T COUNTERS	
01-02-12647	MD703794	BRG,M/T COUNTERSHA FT	
01-02-12648	MR305381	GEAR CLUSTER-M/T CO	
01-02-12649	MR232003	BRG,M/T COUNTERSHA FT	
01-02-12650	MD715769	BRG,M/T COUNTERSHA FT	
01-02-12651	MD712965	BEARING M/T REV IDLE	
01-02-12652	MD715770	GEARE M/T REV IDLE	
01-02-12653	MD714821	SHAFT,M/T BEV IDLER	
01-02-12654	MR276157	HUB & SLEEVE,M/T 1-2	
01-02-12655	MR276159	HUB & SLEEVE,M/T 3-4	
01-02-12656	MR276160	HUB 2 SLEEVE/N/T 5TH	
01-02-12657	MD701897	SPttINQ-M/T 1-2 SYNCH	
01-02-12658	MD725223	SPttINQ-M/T 1-2 SYNCH	
01-02-12659	MR111956	RING ,M/T SYNCH	
01-02-12660	MR196830	RING ,M/T SYNCH	
01-02-12661	MR196829	RING ,M/T SYNCH	
01-02-12662	MD701766	KEY,M/T STH & REV SY	
01-02-12663	MD728904	KEY,M/T SYNCH	
01-02-12664	MD723085	KEY,M/T 5TH & REV SY	
01-02-12665	MB937338	GASKET, T/F G/SHF HSG	
01-02-12666	MD703755	GSKT M/T G/SHF LEVER	
01-02-12667	MR196148	SWITCH ,M/T G/SHF B/U	
01-02-12668	MR145491	COVER,M/T G/SHF LVR	
01-02-12669	MR195478	FORK,M/T G/SHF O/D 2	
01-02-12670	MR195475	FORK,M/T G/SHF 1ST 2	
01-02-12671	MR195501	FORK,M/T G/SHF 3RD	
01-02-12672	MR263721	RAIL,M/T G/SMF 1ST	
01-02-12673	MR196578	RAIL,M/T G/SMF 3RD	
01-02-12674	MD725081	SHAFT KIT M/T GEAR SH	
01-02-12675	MD703613	SPR M/T SHF MEUTRA	
01-02-12676	MD701577	BSHG M/T G/SHF CONT	
01-02-12677	MR222699	SHAFT ASSY PROPELLER	
01-02-12678	MB154199	CTR BRG PROPELLER	
01-02-12679	MR196838	SPIDER KIT RR PROP U	
01-02-12680	MB301509	BOLT FR WHEEL HUB	
01-02-12681	MT141127	CAP FR WHEEL HUB	
01-02-12682	MB633086	BEARING FR WHEEL HUB	

01-02-12683	MB633087	BEARING FR WHEEL HUB	
01-02-12684	MT141132	OIL SEAL FR WHEEL HUB	
01-02-12685	MB950958	DISC FR BRAKE	
01-02-12686	MR241022	HOUSING ASSY RR AXLE	
01-02-12687	MB664447	BEARING RR AXLE SHAFT	
01-02-12688	MB092440	O-RING RR AXLE SHAFT	
01-02-12689	MB837719	OIL SEAL RR AXLE SHAFT	
01-02-12690	MB092437	OIL SEAL RR AXLE SHAFT	
01-02-12691	MR246794	SHAFT ASSY RR AXLE	
01-02-12692	MB584750	BOLT RR WHEEL HUB	
01-02-12693	MR470683	BEARING FR DIFF SIDE	
01-02-12694	MB393471	BRG FR DIFF DRY PIMI	
01-02-12695	MB393470	BRG RR DIFF DRY PIMI	
01-02-12696	MR263195	CARRIER ASSY RR DIFF	
01-02-12697	MR208659	GEAR KIT RR DIFF FIN	
01-02-12698	MR162752	GEAR KIT RR DIFF FIN	
01-02-12699	MB160949	OIL SEAL RR DIFF DRI	
01-02-12700	MB241967	SHAFT KIT RR DIFF PI	
01-02-12701	MB569391	SHIM SET DIFF DRV	
01-02-12702	MR179440	SHIM SET R DIFF DRV	
01-02-12703	MB950951	DRUM RR BRAKE	
01-02-12704	MR151423	CAP DISC WHEEL CTR	
01-02-12705	MB057636	NUT WHEEL	
01-02-12706	MR132234	WHEEL DISC	
01-02-12707	MR113884	KNUCKLE LM	
01-02-12708	MR113885	KNUCKLE RH	
01-02-12709	MR241023	ARM ASSY FR SUSP UPR	
01-02-12710	MR241024	ARM ASSY FR SUSP UPR	
01-02-12711	MR241027	B/JNT KIT FR SUSP LW	
01-02-12712	MR151459	COVER F SUSP LWR ARM	
01-02-12713	MR296027	ARM ASSY FR SUSP LWR	
01-02-12714	MR296028	ARM ASSY,FR SUSP LWR	
01-02-12715	MT362562	COVER F/SUSP WPR ARM	
01-02-12716	MB185995	STOPPER KIT FR LWR	
01-02-12717	MB185996	STOPPER KIT FR LWR A	
01-02-12718	MR241028	STOPPER KIT FR UPR A	
01-02-12719	MR132040	BOLT FR SUSP LWR ARM	
01-02-12720	MR132039	BUSHING FR SUSP LWR	
01-02-12721	MR234415	BAR FR SUSP STRUT LH	
01-02-12722	MR234416	BAR,FR SUSP STRUT RH	
01-02-12723	MR234247	BSHG KIT ,FR SUSP STR	
01-02-12724	MR150812	SPRING ,FR SUSP COIL	
01-02-12725	MR267700	SHOCK ABSORBER,FR SU	
01-02-12726	MW024526	BUSHING FR SHOCK ABS	
01-02-12727	MB110496	PLATE R SUS SPRING S	
01-02-12728	MB110494	SHACKLE,RR SUSP SPRI	
01-02-12729	MR353452	SPRING ASSY ,RR SUSP	
01-02-12730	MR151231	SHOCK ABSORBER,RR SU	
01-02-12731	MR151934	BOLT,RR SUSP SPRING	
01-02-12732	MB584531	BUSHING ,RR SUSP SPRING]	
01-02-12733	MB584530	BUSHING ,RR SUSP SPRING]	
01-02-12734	MR128382	CABLE,PARKING BRAKE	
01-02-12735	MR128197	CABLE,PARKING BRAKE	
01-02-12736	MR128198	CABLE ,PARKING BRAKE	
01-02-12737	MB520948	SWITCH ,PARKING BRAKE	
01-02-12738	MR527979	SEAL KIT,FR BRK	
01-02-12739	MR527975	CALIPERKIT ,FR BRAKE	
01-02-12740	MR527976	CALIPERKIT ,FR BRAKE	
01-02-12741	MR527545	PISTON FR BRAKE CALI	
01-02-12742	MR527550	PAD SET,FR BRAKE	

01-02-12743	MR527551	CLIP KIT,FR BRAKE	
01-02-12744	MR527552	SHIM KIT,FR BRAKE	
01-02-12745	MR527703	CUP & BOOT KIT,RR BR	
01-02-12746	MR493392	CYLINDER ASSY,RR BRA	
01-02-12747	MR493393	CYLINDER ASSY,RR BRA	
01-02-12748	MR496334	SHOE SET,RR BRAKE	
01-02-12749	MR493381	SPRING ,R/BRK SHOE HD	
01-02-12750	MR493380	SPRING,RR B/SHOE RET	
01-02-12751	MR493386	SPRING ,RR B/SHOE TO	
01-02-12752	MR493387	SPRING,RR B/SHOE RET	
01-02-12753	MR449473	BOOSTER ASSY,BRAKE	
01-02-12754	MR128205	HOSE ,BRAKE BOOSTER V	
01-02-12755	MB928711	SEAL,BRAKE BOOSTER B	
01-02-12756	MR449931	HOSE,RR AXLE BRAKE T	
01-02-12757	MR449929	HOSE,FR BRAKE BODYS	
01-02-12758	MR129778	HOSE,FR BRAKE BODY S	
01-02-12759	MB618320	VALVE ASSY,LOAD SEMS	
01-02-12760	MR128572	TUBE,FR BRAKE WHEEL	
01-02-12761	MR128573	TUB,FR BRAKE WHEEL	
01-02-12762	MA126093	PAD ,BRAKE PEDAL	
01-02-12763	MR329967	SWITCH,STOP LAMP	
01-02-12764	MR449476	CYLINDER ASSY,BRAKE	
01-02-12765	MR449522	CYLINDER KIT,BRAKE M	
01-02-12766	MR128726	SEAL ,BRAKE M/CYL TO	
01-02-12767	MR449507	CAP ,BRAKE FLUID RSVR	
01-02-12768	MR449503	SWITCH ,BRK FLUID LEV	
01-02-12769	MR151400	COLUMN ASSY,STEERING	
01-02-12770	MB166565	BRG,STEERING GEAR	
01-02-12771	MR210002	GEAR ASSY,STEERING	
01-02-12772	MB166582	O/SEAL STRG GEAR SCR	
01-02-12773	MB166508	O/SEAL STRG GR SECTOR	
01-02-12774	MR234879	BALL SCREW ASSY,STRO	
01-02-12775	MR241029	ARM KIT,PITMAN	
01-02-12776	MR296271	ARM KIT,STEERING IDL	
01-02-12777	MR241032	END ASSY,TIE ROD ,OTR	
01-02-12778	MR241031	END ASSY,TIE ROD ,INR	
01-02-12779	MR133550	RELAY ROD,STEERING L	
01-02-12780	MR125903	CROSS EMEMBER,CHAS FRM	
01-02-12781	MR125902	CROSS MEMBER,CHAS FRM	
01-02-12782	MR241037	BUMPER KIT,FR CTR	
01-02-12783	MR241045	BUMPER KIT FR CORNER	
01-02-12784	MR241046	BUMBPER KIT,FR CORNER	
01-02-12785	MR144810	PLATE ,FR BUMPER ,LWR	
01-02-12786	MR144811	REINFORCEMENT,FR BUM	
01-02-12787	MR144793	REINFORCEMENT,FR BUM	
01-02-12788	MR144794	REINFORCEMENT,FR BUM	
01-02-12789	MR144821	REING,FR BUMPER SIDE	
01-02-12790	MR144903	REINF,FR BUMPER SIDE	
01-02-12791	MR144825	STAY,FR BUMPER LH	
01-02-12792	MR144826	STAY,FR BUMPER ,RH	
01-02-12793	MR144801	SUPPORT,FR BUMPER,LH	
01-02-12794	MR144802	SUPPORT,FR BUMPER ,RH	
01-02-12795	MR144795	REINF,F/BMPR SIDE ,LW	
01-02-12796	MR144796	REINF,F/BMPR SIDE ,LW	
01-02-12797	MR241063	GGRILLE,RADIATOR	
01-02-12798	MR178081	HOOD	
01-02-12799	MR313755	CABLE,HOOD LOCK RELE	
01-02-12800	MB908639	DAMPER ,HOOD	
01-02-12801	MB513055	DAMPER,HOOD	
01-02-12802	MB270607	DAMPER,HOOD	

01-02-12803	MR144488	LATCH , HOOD	
01-02-12804	MR144494	ROD,HOOD SUPPORT	
01-02-12805	MR180831	WEATHER STRIP,HOOD,RR	
01-02-12806	MR144702	WEATHER STRIP,HOOD SI	
01-02-12807	MR180829	WEATHER STRIP ,HOOD,FR	
01-02-12808	MR144701	WEATHER STRIP ,HOOD,RR	
01-02-12809	MA155254	CLIP,HOOD LOCKING	
01-02-12810	MU481053	CLIP ,CHOCK CABLE	
01-02-12811	MR178083	FENDER ,FR LH	
01-02-12812	MR178084	FENDER ,FR RH	
01-02-12813	MR178013	FNDER SHIELD,FR LH	
01-02-12814	MR178015	FENDER SHIELD ,FR LH	
01-02-12815	MR439038	SUPPORT ASSY,HEADLAMP	
01-02-12816	MR439047	SUPPORT,HEADLAMP ,LH	
01-02-12817	MR178020	SUPPORT,HEADLAMP,RH	
01-02-12818	MR376136	PANEL,HEAD LAMP SUPPORT	
01-02-12819	MR178021	PANEL,HEAD LAMP SUPPORT	
01-02-12820	MR109221	GLASS,WINDSHIELD	
01-02-12821	MB344738	FASTENER,BACK DOOR	
01-02-12822	MR109930	SPACER,WINDSHIELD	
01-02-12823	MB419223	SPACER,WINDSHIELD	
01-02-12824	MR401336	MOULDING ,WIND SHIELD	
01-02-12825	MB929675	PROTECTOR,WINDSHIELD	
01-02-12826	MR178052	PANEL-ROOF	
01-02-12827	MR178055	BOW,ROOF	
01-02-12828	MR178042	RAIL,ROOF ,FR	
01-02-12829	MR178054	RAIL,ROOF,RR	
01-02-12830	MR178047	PILLAR,CTR LWR INR ,L	
01-02-12831	MR178048	PILLAR,CTR LWR INR R	
01-02-12832	MR178043	PILLAR,CTR UPR INR L	
01-02-12833	MR178044	PILLAR,CTR UPR INR R	
01-02-12834	MR178027	PILLAR ASSY ,FR LH	
01-02-12835	MR178026	PILLAR ASSY,FR RH	
01-02-12836	MR178041	PANEL,RR SIDE,OTR LH	
01-02-12837	MR178040	PANEL ,RR SIDE ,OTR RH	
01-02-12838	MR178049	PILLAR,RR INR LH	
01-02-12839	MR178050	PILLAR,RR INR RH	
01-02-12840	MR178029	SIDE SILL,FR FLOOR,O	
01-02-12841	MR178030	SIDE SILL,FR FLOOR ,O	
01-02-12842	MR178022	RAIL ,ROOF SIDE,INR	
01-02-12843	MR178114	LID ,FUEL FILLER	
01-02-12844	MB615440	HOOK,FUEL FILLER LID	
01-02-12845	MR109511	GLASS,RR WINDOW	
01-02-12846	MR191540	WEATHER STRIP ,RR WIND	
01-02-12847	MR144393	SUPPORT,HOOD LATCH	
01-02-12848	MR296229	SHIELD KIT,SPLASH ,RR	
01-02-12849	MR296230	SHIELD KIT ,SPLASH,RR	
01-02-12850	MR241033	SHIELD KIT,SPLASH,FR	
01-02-12851	MR586244	SHIELD KIT,SPLASH ,FR	
01-02-12852	MR123396	SWITCH ,ENG START SW	
01-02-12853	MR141180	SWITCH ASSY,ENG STAR	
01-02-12854	MR259337	CYLINDER &KEY SET,L	
01-02-12855	MR259317	CYLINDER ,FR DOOR LOC	
01-02-12856	MR259316	CYLINDER,FR DOOR LOC	
01-02-12857	MR259312	CYL,FUEL FILLER LID	
01-02-12858	MR259341	CYLINDER,GLOVE BOX LI	
01-02-12859	MR137973	CYLINDER,STEERING LO	
01-02-12860	MB543052	KEY,BLANK	
01-02-12861	MR178063	PANEL ASSY,FR DOOR ML	
01-02-12862	MR178064	PANEL ASSY ,FR DOOR,R	

01-02-12863	MR178071	PANEL ,FR DOOR ,OTR LH	
01-02-12864	MR178072	PANEL,FR DOOR ,OTR RH	
01-02-12865	MB574273	HINGE ,FR DOOR ,UPR LH	
01-02-12866	MB574274	HINGE,FR DOOR,LWR LH	
01-02-12867	MR144655	GLASS ,FR DOOR WINDOW	
01-02-12868	MR144656	GLASS FR DOOR WINDOW	
01-02-12869	MR365127	RUNCH ANNEL ,F,DR WDD	
01-02-12870	MR365128	RUNCHANNEL ,F,DR WDD	
01-02-12871	MR313366	W,STRIP,FR DOOR BELT	
01-02-12872	MR732302	W,STRIP,FR DOOR OPMG	
01-02-12873	MR732303	W,STRIP ,FR DOOR OPMG	
01-02-12874	MR144739	W,STRIP .FR DR OPMG ,O	
01-02-12875	MR144740	W,STRIP ,FR DR OPNG ,O	
01-02-12876	MR144745	FILM ,FR DOOR WATERPR	
01-02-12877	MR313792	FILM FR DOOR WATERPR	
01-02-12878	MR144685	MLDG ,F,DR WDO BELT L	
01-02-12879	MR144686	MLDG ,F,DR WDO BELT L	
01-02-12880	MR732133	HANDLE ASSY ,F,DR WDO	
01-02-12881	MR144523	REGULATOR ,FR DOOR WD	
01-02-12882	MR144524	REGULATOR ,FR DOOR WD	
01-02-12883	MR144539	HANDLE ,FR DOOR OUTSI	
01-02-12884	MR144540	HANDLE ,FR DOOR OUTSI	
01-02-12885	MR419097	ROD ,F,DR INSIDE HAND	
01-02-12886	MR419098	ROD ,F DR INSIDE HAND	
01-02-12887	MR419099	ROD ,FR DOOR INSIDE L	
01-02-12888	MR419100	ROD FR DOOR INSIDE L	
01-02-12889	MR432137	LATCH ,FR DOOR ,LH	
01-02-12890	MR432138	LATCH ,FR DOOR ,RH	
01-02-12891	MR432755	HANDLE ,RR DOOR INSID	
01-02-12892	MR432756	HANDLE ,RR DOOR INSID	
01-02-12893	MR178073	PANEL ASSY ,RR DOOR ,L	
01-02-12894	MR178074	PANEL ASSY ,RR DOOR ,R	
01-02-12895	MR178079	PANEL RR DOOR .OTR LH	
01-02-12896	MR178080	PANEL ,RR DOOR ,OTR RH	
01-02-12897	MR181761	RUNCHAN, R/ DR WDOGLA	
01-02-12898	MR181762	RUNCHAN, R/ DR WDOGLA	
01-02-12899	MB546472	HINGE,RRDOOR,UPRRH	
01-02-12900	MB546471	HINGE,RRDOOR,UPR LH	
01-02-12901	MR144651	GLASS,RRDOOR WINDOW	
01-02-12902	MR226041	GLASS,RRDOOR WINDOW	
01-02-12903	MR144695	M/STRIP,RR,DOOR BELT	
01-02-12904	MR144696	M/STRIP,RR,DOOR BELT	
01-02-12905	MR144753	M/STRIP,RR,DOOR BELT	
01-02-12906	MR144754	FILM, RRDOORWATER PA	
01-02-12907	MR732305	FILM, RRDOORWATER PA	
01-02-12908	MR144743	W/STRIP,R/DR OPENING	
01-02-12909	MR144744	W/STRIP,R/DR OPENG/OT	
01-02-12910	MR144697	MLDG,R/DR WOOBELT L	
01-02-12911	MR144696	MLDG,R/DR WOOBELT L	
01-02-12912	MR732133	HANDLE ASSY,F /DR WDO	
01-02-12913	MR144531	REGULATOR, R/ DR WINDOW	
01-02-12914	MR144532	REGULATOR, R/ DR WINDOW	
01-02-12915	MR432755	HANDLE,RR DOOR INSID	
01-02-12916	MR432756	HANDLE,RR DOOR INSID	
01-02-12917	MR144549	HANDLE,RR DOOR OUT SI	
01-02-12918	MR144550	HANDLE,RR DOOR OUT SI	
01-02-12919	MR462225	LATCH ,RR DOOR,LH	
01-02-12920	MR462226	LATCH ,RR DOOR,RH	
01-02-12921	MR419107	ROD,R/DR INSIDE HAND	
01-02-12922	MR419108	ROD,R/DR INSIDE HAND	

01-02-12923	MR419103	ROD,R/DR INSIDE L	
01-02-12924	MR419104	ROD,R/DR INSIDE L	
01-02-12925	MR419101	ROD,R/DR OUT SIDE HAN	
01-02-12926	MR419102	ROD,R/DR OUT SIDE HAN	
01-02-12927	MR 10226	GARNISH ,FR DECK	
01-02-12928	MB 567499	CLIP ,RR VIEW MIRROR	
01-02-12929	MB696120	CLIP, AIR INLET GRILL	
01-02-12930	MB 375995	CLIP BODY LOOSE PANE	
01-02-12931	MR 109 239	MOULDING, DRIP,LH	
01-02-12932	MR 109240	MOULDING, DRIP, RH	
01-02-12933	MB619578	MARK,THREE-DIA	
01-02-12934	MR 109253	MIRROR ASSY,DOOR,LH	
01-02-12935	MR 109254	MIRROR ASSY,DOOR,RH	
01-02-12936	MR 109287	MUD GURD,RR,LH	
01-02-12937	MR 109288	MUD GURD,RR,RH	
01-02-12938	MR133172	COVER GEARSHAFT LEV	
01-02-12939	MR 240542	MIRROR ASSY ROOM	
01-02-12940	MB140585	RING HEAD LAMPRETAIN	
01-02-12941	MS820176	SEALED BEAM UNIT	
01-02-12942	MB 185649	HEAD LAMP KIT,LH	
01-02-12943	MB 185650	HEAD LAMP KIT,RH	
01-02-12944	MS 820087	BULB ,LAMP(12V/ SW)	
01-02-12945	MR 191445	LAMP ASSY T/ SIG FR S	
01-02-12946	MR 241069	LAMPKIT,COMBINATION	
01-02-12947	MR241070	LAMPKIT,COMBINATION	
01-02-12948	MR245379	LAMP UNIT ,FR COMBINA	
01-02-12949	MR245380	LAMP UNIT ,FR COMBINA	
01-02-12950	MS 820046	BULB ,FR LAMP	
01-02-12951	MS820090	BULB ,HEAD LAMP	
01-02-12952	MR 241071	LAMP KIT COMBINATION	
01-02-12953	MR241072	LAMP KIT COMBINATION	
01-02-12954	MS 820038	BULB ,LAMP(12V 21/5W)	
01-02-12955	MS 820044	BULB(12V21W)	
01-02-12956	MR 191460	LAMPASSY,LICENSE PL	
01-02-12957	MS820090	BULB HEAD LAMP ,	
01-02-12958	MR 201683	LAMP ASSY , ROOM,CTR	
01-02-12959	MR 250667	LENSE,CTR ROOM LAMP	
01-02-12960	MFB 20513	BULB ROOM LAMP	
01-02-12961	MR192097	ARM ASSY,WINDO SHIELD	
01-02-12962	MR192110	ARM ASSY,WINDO SHIELD	
01-02-12963	MB 622853	BLADE WINDOW SHIELD WIP	
01-02-12964	MR 192098	BLADE WINDOW SHIELD	
01-02-12965	MR192109	BLADE WINDOW SHIELD	
01-02-12966	MB 881494	COVER WINDOSHIELDWIP	
01-02-12967	MR 109453	LINK, WINDOSHIELDWIP	
01-02-12968	MR109449	MOTOR,WINDOSHIELD WIP	
01-02-12969	MF 430005	NUT, ROCKER COVER	
01-02-12970	MB 848901	MOTOR, WINDOSHIELD WAS	
01-02-12971	MR 549524	NOZZLE ,WINDOSHIELD WA	
01-02-12972	MR109457	NOZZLE ,WINDOSHIELD WA	
01-02-12973	MR 245373	TANK ,WINDO SHIELD WASH	
01-02-12974	MS 820083	BULB GEARSHIFT LINK	
01-02-12975	MR 506286	BULB ,INSTRUMENT PANE	
01-02-12976	MB938363	BULB, INST PANEL METE	
01-02-12977	MR117592	CABLE SPEEDOMETER	
01-02-12978	MR250655	SPEEDOMETER	
01-02-12979	MR 201941	GAUGE,FUEL	
01-02-12980	MR 298862	GAUGE WATER,TEMPERAT	
01-02-12981	MR 329662	SWITCH, STEERING COLU	
01-02-12982	MR 439196	SWITCH KIT DOORLAMP	



<b>01-02-12983</b>	MR117573	SWITCH HAZARD WARNIN	
<b>01-02-12984</b>	MR141343	ANTENNA ASSY	
<b>01-02-12985</b>	MB818650	ROD ANTENNA	
<b>01-02-12986</b>	MB 881526	HORN	
<b>01-02-12987</b>	MR 383445	FLASHER UNIT, HAZARD	
<b>01-02-12988</b>	MR588567	RELAY ,HORN	
<b>01-02-12989</b>	MS820083	BULB GEARSHIFT LINK	
<b>01-02-12990</b>	MS 810965	FUSE ,SWITCH	
<b>01-02-12991</b>	MS 810965	FUSE ,SWITCH	
<b>01-02-12992</b>	MS 810967	FUSE RELAY	
<b>01-02-12993</b>	MS810876	FUSE, BODY WIRING	
<b>01-02-12994</b>	MS 810 877	FUSE, SWITCH	
<b>01-02-12995</b>	MU840021	FUSIBLE LINK	
<b>01-02-12996</b>	MU 840014	FUSIBLE LINK	
<b>01-02-12997</b>	MU 840015	FUSIBLE LINK	
<b>01-02-12998</b>	MU 840016	FUSIBLE LINK	
<b>01-02-12999</b>	MR 344790	HOSKIT, HEATER WATER	
<b>01-02-13000</b>	MR 151751	TOOLSET,STD	
<b>01-02-13001</b>	MR 210105	JACK OIL	